

Supplier & Grade:

New Arrival~ Lot 1 14days (Final VER)

Viewing time : 11am

Deadline: 4pm

Delivery time: 5pm

Please make sure you have already read our terms and conditions, including grading definition as well as the return policy. We would have assume you accepted all the mentioned terms, conditions and return policy when you place the bid.

***Simfree-it only means no sim lock, not include any other locks.**

Summary:

First, There are 269559 units of 14-Day Mobile Phones for bidding on the bid date on Mon, 27 Jan 2025, including 63100 units of Apple Iphone and 20198 units of high-end Samsung mobile phones.

Second, The Models details are : Apple I-phone 13/14/15 Series: 16633 Units, I-phone 11/12 Series: 11335 Units, I-phone XS/XS Max Series: 1272 Units, iPhone X/XR Series: 5052 Units, iPhone 8/7 Series: 7658 Units, iPhone 6s/6s Plus/ 6/ 6 plus Series: 12956 Units, I-pad Series: 2679 Units.

Huawei .

Third, Below are the Important Model List

Brand	Model	Qty	Grade
Lot 7	Mobiphone 3G Total	1000	Summary
Lot 1	Apple Watch Total	25	Summary
Lot 6	XT2095 Total	107	Summary
Oneplus SP-Bid -	Oneplus SP Bid.-Total	160	Summary
New xiaomi SP-Bid -	New xiaomi SP Bid.-Total	554	Summary
US Spec SP-Bid -	US SP SP Bid.- Total	611	Summary
Samsung SP-Bid -	Samsung SP Bid.- Total(Mostly Dual-Sim)	5885	Summary
Demo SP-Bid -	Demo SP Bid.- Total	23	Summary
Apple	iPhone 16 Pro Max Total(Mostly Dual-Sim)	11	Summary
Apple	iPhone 16 Pro Total(Mostly Dual-Sim)	7	Summary
Apple	iPhone 16 Plus Total(Mostly Dual-Sim)	1	Summary
Apple	iPhone 16 Total(Mostly Dual-Sim)	2	Summary
Apple	iPhone 15 Pro Max Total(Mostly Dual-Sim)	253	Summary
Apple	iPhone 15 Pro Total(Mostly Dual-Sim)	120	Summary
Apple	iPhone 15 Plus Total(Mostly Dual-Sim)	96	Summary
Apple	iPhone 15 Total(Mostly Dual-Sim)	144	Summary
Apple	iPhone 14 Pro Max Total(Mostly Dual-Sim)	816	Summary
Apple	iPhone 14 Pro Total(Mostly Dual-Sim)	524	Summary
Apple	iPhone 14 Plus Total(Mostly Dual-Sim)	199	Summary
Apple	iPhone 14 Total(Mostly Dual-Sim)	555	Summary
Apple	iPhone 13 Pro Max Total	9268	Summary
Apple	iPhone 13 Pro Total	702	Summary
Apple	iPhone 13 Total	2549	Summary
Apple	iPhone 13 Mini Total	509	Summary
Apple	iPhone 12 Pro Max Total	1562	Summary
Apple	iPhone 12 Pro Total	1862	Summary
Apple	iPhone 12 Total	1743	Summary
Apple	iPhone 12 Mini Total	2044	Summary
Apple	iPhone 11 Pro Max Total	973	Summary
Apple	iPhone 11 Pro Total	846	Summary
Apple	iPhone 11 Total	1259	Summary
Apple	iPhone Xs Max Total	580	Summary
Apple	iPhone Xs Total	343	Summary
Apple	iPhone Xr Total	493	Summary
Apple	iPhone X Total	418	Summary
Apple	iPhone 8 Plus Total	301	Summary
Apple	iPhone 8 Total	246	Summary
Apple	iPhone 7 Plus Total	469	Summary
Apple	iPhone 7 Total	3775	Summary
Apple	iPhone 6s Plus Total	675	Summary
Apple	iPhone 6s Total	1493	Summary
Apple	iPhone 6 Plus Total	697	Summary
Apple	iPhone 6 Total	3858	Summary
Apple	iPhone Se3 Total	232	Summary
Apple	iPhone Se2 Total	117	Summary
Apple	iPhone SE Total	84	Summary
Apple	iPhone 5s Total	2996	Summary
Apple	iPhone 5c Total	1582	Summary
Apple	iPhone 5 Total	1407	Summary
Apple	iPhone 4s Total	276	Summary
Apple	iPhone 4 Total	266	Summary
Apple	iCloud Lock Total	14087	Summary
Apple	iPad Total	1229	Summary

Plenty supply of EU version

Brand	Model	Qty	Grade	Line
Lot 7	Mobiphone 3G Total	1000	Summary	3
Other	Mobiphone 3G(SIM Free)	1000	Lot 7New	4
Lot 1	Apple Watch Total	25	Summary	5
Watch	Apple Watch Series 6 44mm	25	Lot 1New	6
Lot 6	XT2095 Total	107	Summary	7
Motorola	XT2095	107	Lot 6New	8
Oneplus SP-Bid -	Oneplus SP Bid.-Total	160	Summary	9
Other	One Plus Open	160	Oneplus SP-Bid -Nearly New	10
New xiaomi SP-Bid -	New xiaomi SP Bid.-Total	554	Summary	11
Other	Xiaomi Mi 12 5G(SIM Free)	22	New xiaomi SP-Bid -New	12
Other	Xiaomi Mi 13 5G(SIM Free)	7	New xiaomi SP-Bid -New	13
Other	Xiaomi Mi 13T 5G(SIM Free)	145	New xiaomi SP-Bid -New	14
Other	Xiaomi Mi 13T Pro 5G(SIM Free)	96	New xiaomi SP-Bid -New	15
Other	Xiaomi Redmi 12C(SIM Free)	58	New xiaomi SP-Bid -New	16
Other	Xiaomi Redmi 13C(SIM Free)	159	New xiaomi SP-Bid -New	17
Other	Xiaomi Redmi Note 10(SIM Free)	17	New xiaomi SP-Bid -New	18
Other	Xiaomi Redmi Note 11 Pro 5G(SIM Free)	50	New xiaomi SP-Bid -New	19
US Spec SP-Bid -	US SP SP Bid.- Total	611	Summary	20
Apple	iPhone 15 Pro Max (256GB)SIM Free	2	US Ver SP-Bid -AHandset (Good 1)(Broken Back Glass)(Full Fuction)	21
Apple	iPhone 15 Pro Max (1Tb)SIM Free	1	US Ver SP-Bid -AHandset (unknow part message)	22
Apple	iPhone 15 Pro Max (256GB)SIM Free	3	US Ver SP-Bid -AHandset (unknow part message)	23
Apple	iPhone 15 Pro Max (512GB)SIM Free	1	US Ver SP-Bid -AHandset (unknow part message)	24
Apple	iPhone 15 Pro Max (256GB)SIM Free	2	US Ver SP-Bid -BHandset (Power Up, Good LCD)	25
Apple	iPhone 15 Pro Max (1Tb)SIM Free	5	US Ver SP-Bid -BHandset (Power Up, Bad LCD)	26
Apple	iPhone 15 Pro Max (256GB)SIM Free	45	US Ver SP-Bid -BHandset (Power Up, Bad LCD)	27
Apple	iPhone 15 Pro Max (256GB)SIM Free	2	US Ver SP-Bid -SP Bid-No Power On-Change Battery(Reference Only)	28
Apple	iPhone 15 Pro Max (256GB)	1	US Ver SP-Bid -BHandset (Power Up, Bad LCD)	29
Apple	iPhone 15 Pro Max (256GB)	1	US Ver SP-Bid -BHandset (only electricity)	30
Apple	iPhone 15 Pro Max (256GB) (Problematic)	1	US Ver SP-Bid -BHandset (Power Up, Bad LCD)	31
Apple	iPhone 15 Pro (128GB)SIM Free	1	US Ver SP-Bid -AHandset (Broken Back Glass)	32
Apple	iPhone 15 Pro (128GB)	1	US Ver SP-Bid -BHandset (Power Up, Good LCD)	33
Apple	iPhone 15 Plus (128GB)SIM Free	1	US Ver SP-Bid -AHandset (Good)(Full Fuction)	34
Apple	iPhone 15 Plus (128GB)SIM Free	1	US Ver SP-Bid -AHandset (Broken Back Glass)(Full Fuction)	35
Apple	iPhone 15 Plus (128GB)SIM Free	1	US Ver SP-Bid -BHandset (Power Up, Good LCD)(Full Fuction)	36
Apple	iPhone 15 Plus (128GB)SIM Free	2	US Ver SP-Bid -BHandset (Power Up, Bad LCD)(FidWorking)	37
Apple	iPhone 15 Plus (128GB)SIM Free	4	US Ver SP-Bid -BHandset (Power Up, Bad LCD)	38
Apple	iPhone 15 Plus (256GB)SIM Free	3	US Ver SP-Bid -BHandset (Power Up, Bad LCD)	39
Apple	iPhone 15 Plus (128GB)SIM Free	1	US Ver SP-Bid -BHandset (only electricity)	40
Apple	iPhone 15 (128GB)SIM Free	1	US Ver SP-Bid -AHandset (Good 1)(Full Fuction)(unknow part message)	41
Apple	iPhone 15 (128GB) (Problematic)	1	US Ver SP-Bid -BHandset (Power Up, Bad LCD)	42
Apple	iPhone 14 Pro Max (256GB)SIM Free	1	US Ver SP-Bid -AHandset (Good 1)(Full Fuction)	43
Apple	iPhone 14 Pro Max (128GB)SIM Free	1	US Ver SP-Bid -AHandset (Good 1)(Broken Back Glass)(Full Fuction)	44
Apple	iPhone 14 Pro Max (128GB)SIM Free	4	US Ver SP-Bid -AHandset (Good 1)(Broken Back Glass)	45
Apple	iPhone 14 Pro Max (128GB)SIM Free	2	US Ver SP-Bid -AHandset (Good 1)(Full Fuction)(unknow part message)	46
Apple	iPhone 14 Pro Max (128GB)SIM Free	9	US Ver SP-Bid -AHandset (Good 1)(Broken Back Glass)(Full Fuction)(unknow part message)	47
Apple	iPhone 14 Pro Max (128GB)SIM Free	1	US Ver SP-Bid -AHandset (Full Fuction)	48
Apple	iPhone 14 Pro Max (128GB)SIM Free	2	US Ver SP-Bid -AHandset (Broken Back Glass)(Full Fuction)	49
Apple	iPhone 14 Pro Max (128GB)SIM Free	1	US Ver SP-Bid -AHandset	50
Apple	iPhone 14 Pro Max (128GB)SIM Free	3	US Ver SP-Bid -AHandset (Broken Back Glass)	51
Apple	iPhone 14 Pro Max (128GB)SIM Free	3	US Ver SP-Bid -AHandset (Full Fuction)(unknow part message)	52
Apple	iPhone 14 Pro Max (128GB)SIM Free	15	US Ver SP-Bid -AHandset (Broken Back Glass)(Full Fuction)(unknow part message)	53
Apple	iPhone 14 Pro Max (128GB)SIM Free	4	US Ver SP-Bid -AHandset (unknow part message)	54
Apple	iPhone 14 Pro Max (1Tb)SIM Free	2	US Ver SP-Bid -AHandset (Broken Back Glass)(unknow part message)	55
Apple	iPhone 14 Pro Max (128GB)SIM Free	1	US Ver SP-Bid -BHandset (Power Up, Good LCD)(Full Fuction)	56
Apple	iPhone 14 Pro Max (256GB)SIM Free	2	US Ver SP-Bid -BHandset (Power Up, Good LCD)(Full Fuction)	57
Apple	iPhone 14 Pro Max (256GB)SIM Free	2	S Ver SP-Bid -BHandset (Power Up, Good LCD)(Full Fuction)(unknow part message)	58
Apple	iPhone 14 Pro Max (256GB)SIM Free	2	S Ver SP-Bid -BHandset (Power Up, Good LCD)(Full Fuction)(unknow part message)	59
Apple	iPhone 14 Pro Max (128GB)SIM Free	18	US Ver SP-Bid -BHandset (Power Up, Bad LCD)(Full Fuction)	60
Apple	iPhone 14 Pro Max (256GB)SIM Free	6	US Ver SP-Bid -BHandset (Power Up, Bad LCD)(Full Fuction)	61
Apple	iPhone 14 Pro Max (128GB)SIM Free	2	US Ver SP-Bid -BHandset (Power Up, Bad LCD)(FidWorking)	62
Apple	iPhone 14 Pro Max (512GB)SIM Free	1	US Ver SP-Bid -BHandset (Power Up, Bad LCD)(FidWorking)	63
Apple	iPhone 14 Pro Max (128GB)SIM Free	5	US Ver SP-Bid -BHandset (Power Up, Bad LCD)	64
Apple	iPhone 14 Pro Max (1Tb)SIM Free	8	US Ver SP-Bid -BHandset (Power Up, Bad LCD)	65
Apple	iPhone 14 Pro Max (256GB)SIM Free	14	US Ver SP-Bid -BHandset (Power Up, Bad LCD)	66
Apple	iPhone 14 Pro Max (512GB)SIM Free	1	US Ver SP-Bid -BHandset (Power Up, Bad LCD)	67
Apple	iPhone 14 Pro Max (256GB) (SIM Freefid)	1	US Ver SP-Bid -BHandset (Power Up, Good LCD)(unknow part message)	68
Apple	iPhone 14 Pro Max (128GB)	10	US Ver SP-Bid -BHandset (Power Up, Bad LCD)	69
Apple	iPhone 14 Pro Max (256GB)	1	US Ver SP-Bid -BHandset (Power Up, Bad LCD)	70
Apple	iPhone 14 Pro Max (256GB)	2	US Ver SP-Bid -BHandset (only electricity)	71
Apple	iPhone 14 Pro Max (128GB) (Problematic)	1	US Ver SP-Bid -BHandset (Power Up, Bad LCD)	72
Apple	iPhone 14 Pro Max (256GB) (Problematic)	2	US Ver SP-Bid -BHandset (Power Up, Bad LCD)	73
Apple	iPhone 14 Pro Max (512GB) (Problematic)	1	US Ver SP-Bid -BHandset (Power Up, Bad LCD)	74
Apple	iPhone 14 Pro (128GB)SIM Free	1	US Ver SP-Bid -AHandset (Good)(Broken Back Glass)(Full Fuction)	75
Apple	iPhone 14 Pro (128GB)SIM Free	3	US Ver SP-Bid -AHandset (Good 1)(Full Fuction)	76
Apple	iPhone 14 Pro (128GB)SIM Free	2	US Ver SP-Bid -AHandset (Good 1)(Broken Back Glass)(Full Fuction)	77
Apple	iPhone 14 Pro (256GB)SIM Free	1	US Ver SP-Bid -AHandset (Good 1)(Broken Back Glass)(Full Fuction)	78
Apple	iPhone 14 Pro (128GB)SIM Free	1	US Ver SP-Bid -AHandset (Good 1)(Full Fuction)(unknow part message)	79
Apple	iPhone 14 Pro (128GB)SIM Free	1	US Ver SP-Bid -AHandset (Full Fuction)	80
Apple	iPhone 14 Pro (128GB)SIM Free	2	US Ver SP-Bid -AHandset (Broken Back Glass)(Full Fuction)	81
Apple	iPhone 14 Pro (256GB)SIM Free	2	US Ver SP-Bid -AHandset (Broken Back Glass)(Full Fuction)	82
Apple	iPhone 14 Pro (128GB)SIM Free	1	US Ver SP-Bid -AHandset (Broken Back Glass)(Full Fuction)(unknow part message)	83
Apple	iPhone 14 Pro (256GB)SIM Free	1	US Ver SP-Bid -AHandset (Broken Back Glass)(Full Fuction)(unknow part message)	84

Apple	iPhone 14 Pro (256GB)SIM Free	7	US Ver SP-Bid -AHandset (Broken Back Glass)(unknow part message)	85
Apple	iPhone 14 Pro (128GB)SIM Free	13	US Ver SP-Bid -BHandset (Power Up, Good LCD)(Full Fuction)	86
Apple	iPhone 14 Pro (256GB)SIM Free	4	US Ver SP-Bid -BHandset (Power Up, Good LCD)(Full Fuction)	87
Apple	iPhone 14 Pro (128GB)SIM Free	4	S Ver SP-Bid -BHandset (Power Up, Good LCD)(Full Fuction)(unknow part message)	88
Apple	iPhone 14 Pro (256GB)SIM Free	3	S Ver SP-Bid -BHandset (Power Up, Good LCD)(Full Fuction)(unknow part message)	89
Apple	iPhone 14 Pro (128GB)SIM Free	1	US Ver SP-Bid -BHandset (Power Up, Good LCD)(unknow part message)	90
Apple	iPhone 14 Pro (256GB)SIM Free	2	US Ver SP-Bid -BHandset (Power Up, Good LCD)(unknow part message)	91
Apple	iPhone 14 Pro (128GB)SIM Free	22	US Ver SP-Bid -BHandset (Power Up, Bad LCD)(Full Fuction)	92
Apple	iPhone 14 Pro (256GB)SIM Free	7	US Ver SP-Bid -BHandset (Power Up, Bad LCD)(Full Fuction)	93
Apple	iPhone 14 Pro (128GB)SIM Free	4	US Ver SP-Bid -BHandset (Power Up, Bad LCD)(FidWorking)	94
Apple	iPhone 14 Pro (256GB)SIM Free	4	US Ver SP-Bid -BHandset (Power Up, Bad LCD)(FidWorking)	95
Apple	iPhone 14 Pro (128GB)SIM Free	30	US Ver SP-Bid -BHandset (Power Up, Bad LCD)	96
Apple	iPhone 14 Pro (256GB)SIM Free	8	US Ver SP-Bid -BHandset (Power Up, Bad LCD)	97
Apple	iPhone 14 Pro (512GB)SIM Free	1	US Ver SP-Bid -BHandset (Power Up, Bad LCD)	98
Apple	iPhone 14 Pro (128GB)SIM Free	1	US Ver SP-Bid -BHandset (only electricity)	99
Apple	iPhone 14 Pro (128GB)SIM Free	2	US Ver SP-Bid -SP Bid-No Power On-Change Battery(Reference Only)	100
Apple	iPhone 14 Pro (128GB)	3	US Ver SP-Bid -BHandset (Power Up, Bad LCD)	101
Apple	iPhone 14 Pro (256GB) (Problematic)	1	US Ver SP-Bid -AHandset	102
Apple	iPhone 14 Pro (128GB) (Problematic)	1	US Ver SP-Bid -BHandset (Power Up, Good LCD)	103
Apple	iPhone 14 Plus (128GB)SIM Free	3	US Ver SP-Bid -AHandset (Good 1)(Full Fuction)	104
Apple	iPhone 14 Plus (128GB)SIM Free	1	US Ver SP-Bid -AHandset (Good 1)(Broken Back Glass)(Full Fuction)	105
Apple	iPhone 14 Plus (128GB)SIM Free	3	US Ver SP-Bid -AHandset (Good 1)(Full Fuction)(unknow part message)	106
Apple	iPhone 14 Plus (128GB)SIM Free	4	Ver SP-Bid -AHandset (Good 1)(Broken Back Glass)(Full Fuction)(unknow part message)	107
Apple	iPhone 14 Plus (128GB)SIM Free	2	US Ver SP-Bid -AHandset (Broken Back Glass)(Full Fuction)	108
Apple	iPhone 14 Plus (128GB)SIM Free	1	US Ver SP-Bid -AHandset (Full Fuction)(unknow part message)	109
Apple	iPhone 14 Plus (128GB)SIM Free	2	US Ver SP-Bid -AHandset (Broken Back Glass)(Full Fuction)(unknow part message)	110
Apple	iPhone 14 Plus (128GB)SIM Free	2	US Ver SP-Bid -BHandset (Power Up, Good LCD)(Full Fuction)	111
Apple	iPhone 14 Plus (128GB)SIM Free	3	S Ver SP-Bid -BHandset (Power Up, Good LCD)(Full Fuction)(unknow part message)	112
Apple	iPhone 14 Plus (128GB)SIM Free	1	US Ver SP-Bid -BHandset (Power Up, Bad LCD)(Full Fuction)	113
Apple	iPhone 14 Plus (128GB)SIM Free	9	US Ver SP-Bid -BHandset (Power Up, Bad LCD)(FidWorking)	114
Apple	iPhone 14 Plus (256GB)SIM Free	2	US Ver SP-Bid -BHandset (Power Up, Bad LCD)(FidWorking)	115
Apple	iPhone 14 Plus (128GB)SIM Free	14	US Ver SP-Bid -BHandset (Power Up, Bad LCD)	116
Apple	iPhone 14 Plus (256GB)SIM Free	6	US Ver SP-Bid -BHandset (Power Up, Bad LCD)	117
Apple	iPhone 14 Plus (128GB)	1	US Ver SP-Bid -AHandset	118
Apple	iPhone 14 Plus (128GB)	6	US Ver SP-Bid -BHandset (Power Up, Bad LCD)	119
Apple	iPhone 14 Plus (128GB) (Problematic)	4	US Ver SP-Bid -BHandset (Power Up, Bad LCD)	120
Apple	iPhone 14 (128GB)SIM Free	1	US Ver SP-Bid -AHandset (Good)(Full Fuction)	121
Apple	iPhone 14 (128GB)SIM Free	1	Ver SP-Bid -AHandset (Good)(Broken Back Glass)(Full Fuction)(unknow part message)	122
Apple	iPhone 14 (128GB)SIM Free	6	US Ver SP-Bid -AHandset (Good 1)(Full Fuction)	123
Apple	iPhone 14 (128GB)SIM Free	19	US Ver SP-Bid -AHandset (Good 1)(Broken Back Glass)(Full Fuction)	124
Apple	iPhone 14 (128GB)SIM Free	3	Ver SP-Bid -AHandset (Good 1)(Broken Back Glass)(Full Fuction)(unknow part message)	125
Apple	iPhone 14 (128GB)SIM Free	4	US Ver SP-Bid -AHandset (Full Fuction)	126
Apple	iPhone 14 (128GB)SIM Free	3	US Ver SP-Bid -AHandset (Broken Back Glass)(Full Fuction)	127
Apple	iPhone 14 (128GB)SIM Free	14	US Ver SP-Bid -AHandset (Full Fuction)(unknow part message)	128
Apple	iPhone 14 (128GB)SIM Free	32	US Ver SP-Bid -AHandset (Broken Back Glass)(Full Fuction)(unknow part message)	129
Apple	iPhone 14 (256GB)SIM Free	2	US Ver SP-Bid -AHandset (Broken Back Glass)(Full Fuction)(unknow part message)	130
Apple	iPhone 14 (128GB)SIM Free	4	US Ver SP-Bid -BHandset (Power Up, Good LCD)(Full Fuction)	131
Apple	iPhone 14 (128GB)SIM Free	28	S Ver SP-Bid -BHandset (Power Up, Good LCD)(Full Fuction)(unknow part message)	132
Apple	iPhone 14 (128GB)SIM Free	6	US Ver SP-Bid -BHandset (Power Up, Bad LCD)(Full Fuction)	133
Apple	iPhone 14 (128GB)SIM Free	7	US Ver SP-Bid -BHandset (Power Up, Bad LCD)(FidWorking)	134
Apple	iPhone 14 (128GB)SIM Free	58	US Ver SP-Bid -BHandset (Power Up, Bad LCD)	135
Apple	iPhone 14 (512GB)SIM Free	1	US Ver SP-Bid -BHandset (Power Up, Bad LCD)	136
Apple	iPhone 14 (128GB)	1	US Ver SP-Bid -BHandset (Power Up, Good LCD)	137
Apple	iPhone 14 (128GB)	5	US Ver SP-Bid -BHandset (Power Up, Bad LCD)	138
Apple	iPhone 14 (128GB) (Problematic)	2	US Ver SP-Bid -AHandset	139
Apple	iPhone 14 (128GB) (Problematic)	1	US Ver SP-Bid -BHandset (Power Up, Good LCD)	140
Apple	iPhone 14 (128GB) (Problematic)	2	US Ver SP-Bid -BHandset (Power Up, Bad LCD)	141
Samsung SP-Bid -	Samsung SP Bid.- Total(Mostly Dual-Sim)	5885	Summary	142
Samsung	S5310	1	Samsung SP-Bid -New	143
Samsung	A055F	3	Samsung SP-Bid -Nearly New	144
Samsung	A057	1	Samsung SP-Bid -Nearly New	145
Samsung	A065F	1	Samsung SP-Bid -Nearly New	146
Samsung	A256B	1	Samsung SP-Bid -Nearly New	147
Samsung	A536B	1	Samsung SP-Bid -Nearly New	148
Samsung	F707B(SIM Free)	1	Samsung SP-Bid -Nearly New	149
Samsung	F711B(SIM Free)	1	Samsung SP-Bid -Nearly New	150
Samsung	F721B(SIM Free)	1	Samsung SP-Bid -Nearly New	151
Samsung	F731B(SIM Free)	1	Samsung SP-Bid -Nearly New	152
Samsung	F926B(SIM Free)	1	Samsung SP-Bid -Nearly New	153
Samsung	G556B	1	Samsung SP-Bid -Nearly New	154
Samsung	S901B(SIM Free)	1	Samsung SP-Bid -Nearly New	155
Samsung	S926B(SIM Free)	1	Samsung SP-Bid -Nearly New	156
Samsung	X306B	1	Samsung SP-Bid -Nearly New	157
Samsung	X916B	1	Samsung SP-Bid -Nearly New	158
Samsung	F946B(SIM Free)	1	Samsung SP-Bid -14A(Good)	159
Samsung	X816B	1	Samsung SP-Bid -14A(Good)	160
Samsung	X906B	1	Samsung SP-Bid -14A(Good)	161
Samsung	A042F	1	Samsung SP-Bid -AHandset (Good)	162
Samsung	A045	1	Samsung SP-Bid -AHandset (Good)	163
Samsung	A055F	1	Samsung SP-Bid -AHandset (Good)	164
Samsung	A135F	2	Samsung SP-Bid -AHandset (Good)	165
Samsung	A146	4	Samsung SP-Bid -AHandset (Good)	166
Samsung	A205	4	Samsung SP-Bid -AHandset (Good)	167
Samsung	A226B	7	Samsung SP-Bid -AHandset (Good)	168
Samsung	A326B	2	Samsung SP-Bid -AHandset (Good)	169
Samsung	A346	5	Samsung SP-Bid -AHandset (Good)	170

Samsung	A405F	1	Samsung SP-Bid -AHandset (Good)	171
Samsung	A500F	59	Samsung SP-Bid -AHandset (Good)	172
Samsung	A520F	1	Samsung SP-Bid -AHandset (Good)	173
Samsung	A526(SIM Free)	1	Samsung SP-Bid -AHandset (Good)	174
Samsung	A536B	1	Samsung SP-Bid -AHandset (Good)	175
Samsung	A556	1	Samsung SP-Bid -AHandset (Good)	176
Samsung	F711B(SIM Free)	2	Samsung SP-Bid -AHandset (Good)	177
Samsung	F721B(SIM Free)	2	Samsung SP-Bid -AHandset (Good)	178
Samsung	F731B(SIM Free)	3	Samsung SP-Bid -AHandset (Good)	179
Samsung	F936B(SIM Free)	1	Samsung SP-Bid -AHandset (Good)	180
Samsung	G355	1	Samsung SP-Bid -AHandset (Good)	181
Samsung	G780F (SIM Free)	6	Samsung SP-Bid -AHandset (Good)	182
Samsung	G781B(SIM Free)	1	Samsung SP-Bid -AHandset (Good)	183
Samsung	G935F (SIM Free)	1	Samsung SP-Bid -AHandset (Good)	184
Samsung	G960F (SIM Free)	2	Samsung SP-Bid -AHandset (Good)	185
Samsung	G973F (SIM Free)	6	Samsung SP-Bid -AHandset (Good)	186
Samsung	G975F (SIM Free)	1	Samsung SP-Bid -AHandset (Good)	187
Samsung	G988B(SIM Free)	3	Samsung SP-Bid -AHandset (Good)	188
Samsung	G990(SIM Free)	10	Samsung SP-Bid -AHandset (Good)	189
Samsung	G990B(SIM Free)	1	Samsung SP-Bid -AHandset (Good)	190
Samsung	G991B(SIM Free)	27	Samsung SP-Bid -AHandset (Good)	191
Samsung	i9305	1	Samsung SP-Bid -AHandset (Good)	192
Samsung	N950F (SIM Free)	1	Samsung SP-Bid -AHandset (Good)	193
Samsung	P615(SIM Free)	1	Samsung SP-Bid -AHandset (Good)	194
Samsung	S711B(SIM Free)	1	Samsung SP-Bid -AHandset (Good)	195
Samsung	S911B	1	Samsung SP-Bid -AHandset (Good)	196
Samsung	S916B(SIM Free)	2	Samsung SP-Bid -AHandset (Good)	197
Samsung	T505	1	Samsung SP-Bid -AHandset (Good)	198
Samsung	A035F (IMEI Cut)	13	Samsung SP-Bid -14A	199
Samsung	A045F (IMEI Cut)	19	Samsung SP-Bid -14A	200
Samsung	A047F (IMEI Cut)	15	Samsung SP-Bid -14A	201
Samsung	A057	1	Samsung SP-Bid -14A	202
Samsung	A057F (IMEI Cut)	57	Samsung SP-Bid -14A	203
Samsung	A145F (IMEI Cut)	2	Samsung SP-Bid -14A	204
Samsung	A245F (IMEI Cut)	103	Samsung SP-Bid -14A	205
Samsung	A256(IMEI Cut)	60	Samsung SP-Bid -14A	206
Samsung	A346(IMEI Cut)	85	Samsung SP-Bid -14A	207
Samsung	E1190	3	Samsung SP-Bid -14A	208
Samsung	S5830	1	Samsung SP-Bid -14A	209
Samsung	X115	1	Samsung SP-Bid -14A	210
Samsung	X210(IMEI Cut)	74	Samsung SP-Bid -14A	211
Samsung	A015	1	Samsung SP-Bid -AHandset	212
Samsung	A037F	1	Samsung SP-Bid -AHandset	213
Samsung	A042F (IMEI Cut)	4	Samsung SP-Bid -AHandset	214
Samsung	A045F (IMEI Cut)	30	Samsung SP-Bid -AHandset	215
Samsung	A047F (IMEI Cut)	1	Samsung SP-Bid -AHandset	216
Samsung	A057	1	Samsung SP-Bid -AHandset	217
Samsung	A105F	1	Samsung SP-Bid -AHandset	218
Samsung	A137F	1	Samsung SP-Bid -AHandset	219
Samsung	A145	1	Samsung SP-Bid -AHandset	220
Samsung	A155F	3	Samsung SP-Bid -AHandset	221
Samsung	A156	1	Samsung SP-Bid -AHandset	222
Samsung	A202F	1	Samsung SP-Bid -AHandset	223
Samsung	A205	1	Samsung SP-Bid -AHandset	224
Samsung	A217	1	Samsung SP-Bid -AHandset	225
Samsung	A235F (IMEI Cut)	1	Samsung SP-Bid -AHandset	226
Samsung	A236B	1	Samsung SP-Bid -AHandset	227
Samsung	A256(IMEI Cut)	7	Samsung SP-Bid -AHandset	228
Samsung	A325F (IMEI Cut)	7	Samsung SP-Bid -AHandset	229
Samsung	A336	2	Samsung SP-Bid -AHandset	230
Samsung	A336B	1	Samsung SP-Bid -AHandset	231
Samsung	A346(IMEI Cut)	3	Samsung SP-Bid -AHandset	232
Samsung	A346B	1	Samsung SP-Bid -AHandset	233
Samsung	A510F	24	Samsung SP-Bid -AHandset	234
Samsung	A520F	1	Samsung SP-Bid -AHandset	235
Samsung	A525F (IMEI Cut)	1	Samsung SP-Bid -AHandset	236
Samsung	A546(IMEI Cut)	8	Samsung SP-Bid -AHandset	237
Samsung	A546B	1	Samsung SP-Bid -AHandset	238
Samsung	A736B(SIM Free)	1	Samsung SP-Bid -AHandset	239
Samsung	A736B(IMEI Cut) (SIM Free)	2	Samsung SP-Bid -AHandset	240
Samsung	F711B(SIM Free)	1	Samsung SP-Bid -AHandset	241
Samsung	F721B(SIM Free)	2	Samsung SP-Bid -AHandset	242
Samsung	F731B(SIM Free)	1	Samsung SP-Bid -AHandset	243
Samsung	F936B(SIM Free)	11	Samsung SP-Bid -AHandset	244
Samsung	F946B(SIM Free)	4	Samsung SP-Bid -AHandset	245
Samsung	F956B(SIM Free)	1	Samsung SP-Bid -AHandset	246
Samsung	G130	1	Samsung SP-Bid -AHandset	247
Samsung	G310	1	Samsung SP-Bid -AHandset	248
Samsung	G350	112	Samsung SP-Bid -AHandset	249
Samsung	G357F	1	Samsung SP-Bid -AHandset	250
Samsung	G525F	1	Samsung SP-Bid -AHandset	251
Samsung	G531F	19	Samsung SP-Bid -AHandset	252
Samsung	G925F	2	Samsung SP-Bid -AHandset	253
Samsung	G973F (SIM Free)	3	Samsung SP-Bid -AHandset	254
Samsung	G981B(SIM Free)	2	Samsung SP-Bid -AHandset	255
Samsung	G988B(SIM Free)	2	Samsung SP-Bid -AHandset	256

Samsung	G991B(SIM Free)	2	Samsung SP-Bid -AHandset	257
Samsung	i705	1	Samsung SP-Bid -AHandset	258
Samsung	i8160	97	Samsung SP-Bid -AHandset	259
Samsung	i8700	2	Samsung SP-Bid -AHandset	260
Samsung	i8750	2	Samsung SP-Bid -AHandset	261
Samsung	i9001	1	Samsung SP-Bid -AHandset	262
Samsung	i9003	5	Samsung SP-Bid -AHandset	263
Samsung	i9070	49	Samsung SP-Bid -AHandset	264
Samsung	i9082	1	Samsung SP-Bid -AHandset	265
Samsung	i9100	43	Samsung SP-Bid -AHandset	266
Samsung	i9103	1	Samsung SP-Bid -AHandset	267
Samsung	i9105	12	Samsung SP-Bid -AHandset	268
Samsung	i925	1	Samsung SP-Bid -AHandset	269
Samsung	i9305	1	Samsung SP-Bid -AHandset	270
Samsung	J100	75	Samsung SP-Bid -AHandset	271
Samsung	J105	3	Samsung SP-Bid -AHandset	272
Samsung	J106	2	Samsung SP-Bid -AHandset	273
Samsung	M135F (IMEI Cut)	1	Samsung SP-Bid -AHandset	274
Samsung	M346B(IMEI Cut)	17	Samsung SP-Bid -AHandset	275
Samsung	N7000	2	Samsung SP-Bid -AHandset	276
Samsung	N7100	1	Samsung SP-Bid -AHandset	277
Samsung	N9005	1	Samsung SP-Bid -AHandset	278
Samsung	N910 (Demo)	1	Samsung SP-Bid -AHandset	279
Samsung	N986B(SIM Free)	3	Samsung SP-Bid -AHandset	280
Samsung	P617(IMEI Cut) (SIM Free)	1	Samsung SP-Bid -AHandset	281
Samsung	S134	1	Samsung SP-Bid -AHandset	282
Samsung	S5830	143	Samsung SP-Bid -AHandset	283
Samsung	S6310	2	Samsung SP-Bid -AHandset	284
Samsung	S7275	5	Samsung SP-Bid -AHandset	285
Samsung	S7500	1	Samsung SP-Bid -AHandset	286
Samsung	S767	1	Samsung SP-Bid -AHandset	287
Samsung	S901B(SIM Free)	2	Samsung SP-Bid -AHandset	288
Samsung	S908B(SIM Free)	6	Samsung SP-Bid -AHandset	289
Samsung	S911B(SIM Free)	1	Samsung SP-Bid -AHandset	290
Samsung	T225	1	Samsung SP-Bid -AHandset	291
Samsung	T510	1	Samsung SP-Bid -AHandset	292
Samsung	T638B(IMEI Cut)	1	Samsung SP-Bid -AHandset	293
Samsung	T720	1	Samsung SP-Bid -AHandset	294
Samsung	X210(IMEI Cut)	3	Samsung SP-Bid -AHandset	295
Samsung	A013	27	Samsung SP-Bid -BHandset (Power Up, Good LCD)	296
Samsung	A013-1	1	Samsung SP-Bid -BHandset (Power Up, Good LCD)	297
Samsung	A013F	4	Samsung SP-Bid -BHandset (Power Up, Good LCD)	298
Samsung	A015-1	2	Samsung SP-Bid -BHandset (Power Up, Good LCD)	299
Samsung	A015F	1	Samsung SP-Bid -BHandset (Power Up, Good LCD)	300
Samsung	A022	2	Samsung SP-Bid -BHandset (Power Up, Good LCD)	301
Samsung	A022F	1	Samsung SP-Bid -BHandset (Power Up, Good LCD)	302
Samsung	A042-1	1	Samsung SP-Bid -BHandset (Power Up, Good LCD)	303
Samsung	A042F-1	2	Samsung SP-Bid -BHandset (Power Up, Good LCD)	304
Samsung	A045(SIM Free) -1	1	Samsung SP-Bid -BHandset (Power Up, Good LCD)	305
Samsung	A045-1	1	Samsung SP-Bid -BHandset (Power Up, Good LCD)	306
Samsung	A045F	1	Samsung SP-Bid -BHandset (Power Up, Good LCD)	307
Samsung	A045F (IMEI Cut) -1	1	Samsung SP-Bid -BHandset (Power Up, Good LCD)	308
Samsung	A045F-1	1	Samsung SP-Bid -BHandset (Power Up, Good LCD)	309
Samsung	A055(SIM Free) -1	2	Samsung SP-Bid -BHandset (Power Up, Good LCD)	310
Samsung	A057	1	Samsung SP-Bid -BHandset (Power Up, Good LCD)	311
Samsung	A057F-1	2	Samsung SP-Bid -BHandset (Power Up, Good LCD)	312
Samsung	A105-1	4	Samsung SP-Bid -BHandset (Power Up, Good LCD)	313
Samsung	A107-1	1	Samsung SP-Bid -BHandset (Power Up, Good LCD)	314
Samsung	A107F	1	Samsung SP-Bid -BHandset (Power Up, Good LCD)	315
Samsung	A125F	1	Samsung SP-Bid -BHandset (Power Up, Good LCD)	316
Samsung	A135	2	Samsung SP-Bid -BHandset (Power Up, Good LCD)	317
Samsung	A136B-1	2	Samsung SP-Bid -BHandset (Power Up, Good LCD)	318
Samsung	A137F	1	Samsung SP-Bid -BHandset (Power Up, Good LCD)	319
Samsung	A145	1	Samsung SP-Bid -BHandset (Power Up, Good LCD)	320
Samsung	A145F (IMEI Cut) -1	1	Samsung SP-Bid -BHandset (Power Up, Good LCD)	321
Samsung	A145F-1	1	Samsung SP-Bid -BHandset (Power Up, Good LCD)	322
Samsung	A155F	1	Samsung SP-Bid -BHandset (Power Up, Good LCD)	323
Samsung	A155F (IMEI Cut) -1	3	Samsung SP-Bid -BHandset (Power Up, Good LCD)	324
Samsung	A155F-1	1	Samsung SP-Bid -BHandset (Power Up, Good LCD)	325
Samsung	A156-1	1	Samsung SP-Bid -BHandset (Power Up, Good LCD)	326
Samsung	A205	2	Samsung SP-Bid -BHandset (Power Up, Good LCD)	327
Samsung	A205-1	2	Samsung SP-Bid -BHandset (Power Up, Good LCD)	328
Samsung	A207F	1	Samsung SP-Bid -BHandset (Power Up, Good LCD)	329
Samsung	A225-1	1	Samsung SP-Bid -BHandset (Power Up, Good LCD)	330
Samsung	A226B-1	1	Samsung SP-Bid -BHandset (Power Up, Good LCD)	331
Samsung	A236B-1	1	Samsung SP-Bid -BHandset (Power Up, Good LCD)	332
Samsung	A245F (IMEI Cut) -1	2	Samsung SP-Bid -BHandset (Power Up, Good LCD)	333
Samsung	A256B-1	1	Samsung SP-Bid -BHandset (Power Up, Good LCD)	334
Samsung	A260	3	Samsung SP-Bid -BHandset (Power Up, Good LCD)	335
Samsung	A260F	1	Samsung SP-Bid -BHandset (Power Up, Good LCD)	336
Samsung	A260F-1	1	Samsung SP-Bid -BHandset (Power Up, Good LCD)	337
Samsung	A305	1	Samsung SP-Bid -BHandset (Power Up, Good LCD)	338
Samsung	A315	2	Samsung SP-Bid -BHandset (Power Up, Good LCD)	339
Samsung	A346B-1	1	Samsung SP-Bid -BHandset (Power Up, Good LCD)	340
Samsung	A500-1	4	Samsung SP-Bid -BHandset (Power Up, Good LCD)	341
Samsung	A500F	8	Samsung SP-Bid -BHandset (Power Up, Good LCD)	342

Samsung	A500F-1	5	Samsung SP-Bid -BHandset (Power Up, Good LCD)	343
Samsung	A505-1	1	Samsung SP-Bid -BHandset (Power Up, Good LCD)	344
Samsung	A505F	3	Samsung SP-Bid -BHandset (Power Up, Good LCD)	345
Samsung	A505F-1	3	Samsung SP-Bid -BHandset (Power Up, Good LCD)	346
Samsung	A510-1	1	Samsung SP-Bid -BHandset (Power Up, Good LCD)	347
Samsung	A510F	242	Samsung SP-Bid -BHandset (Power Up, Good LCD)	348
Samsung	A510F-1	12	Samsung SP-Bid -BHandset (Power Up, Good LCD)	349
Samsung	A515F	2	Samsung SP-Bid -BHandset (Power Up, Good LCD)	350
Samsung	A515F-1	2	Samsung SP-Bid -BHandset (Power Up, Good LCD)	351
Samsung	A520F-1	1	Samsung SP-Bid -BHandset (Power Up, Good LCD)	352
Samsung	A528B	1	Samsung SP-Bid -BHandset (Power Up, Good LCD)	353
Samsung	A530F	2	Samsung SP-Bid -BHandset (Power Up, Good LCD)	354
Samsung	A546(SIM Free) -1	2	Samsung SP-Bid -BHandset (Power Up, Good LCD)	355
Samsung	A600F	1	Samsung SP-Bid -BHandset (Power Up, Good LCD)	356
Samsung	A700F	2	Samsung SP-Bid -BHandset (Power Up, Good LCD)	357
Samsung	A705F	1	Samsung SP-Bid -BHandset (Power Up, Good LCD)	358
Samsung	A710F	1	Samsung SP-Bid -BHandset (Power Up, Good LCD)	359
Samsung	A710F-1	2	Samsung SP-Bid -BHandset (Power Up, Good LCD)	360
Samsung	A715F-1	1	Samsung SP-Bid -BHandset (Power Up, Good LCD)	361
Samsung	A720F	1	Samsung SP-Bid -BHandset (Power Up, Good LCD)	362
Samsung	B350	1	Samsung SP-Bid -BHandset (Power Up, Good LCD)	363
Samsung	E1205	1	Samsung SP-Bid -BHandset (Power Up, Good LCD)	364
Samsung	E1272	1	Samsung SP-Bid -BHandset (Power Up, Good LCD)	365
Samsung	F711B-1	1	Samsung SP-Bid -BHandset (Power Up, Good LCD)	366
Samsung	F721B-1	7	Samsung SP-Bid -BHandset (Power Up, Good LCD)	367
Samsung	F731B(SIM Free)	1	Samsung SP-Bid -BHandset (Power Up, Good LCD)	368
Samsung	F731B-1	2	Samsung SP-Bid -BHandset (Power Up, Good LCD)	369
Samsung	F926B(SIM Free)	1	Samsung SP-Bid -BHandset (Power Up, Good LCD)	370
Samsung	F946B(SIM Free)	1	Samsung SP-Bid -BHandset (Power Up, Good LCD)	371
Samsung	G130	1	Samsung SP-Bid -BHandset (Power Up, Good LCD)	372
Samsung	G386F	2	Samsung SP-Bid -BHandset (Power Up, Good LCD)	373
Samsung	G556B(SIM Free)	1	Samsung SP-Bid -BHandset (Power Up, Good LCD)	374
Samsung	G715F	2	Samsung SP-Bid -BHandset (Power Up, Good LCD)	375
Samsung	G780-1	1	Samsung SP-Bid -BHandset (Power Up, Good LCD)	376
Samsung	G780F-1	1	Samsung SP-Bid -BHandset (Power Up, Good LCD)	377
Samsung	G781B(SIM Free)	1	Samsung SP-Bid -BHandset (Power Up, Good LCD)	378
Samsung	G850F	1	Samsung SP-Bid -BHandset (Power Up, Good LCD)	379
Samsung	G925F	10	Samsung SP-Bid -BHandset (Power Up, Good LCD)	380
Samsung	G925F-1	8	Samsung SP-Bid -BHandset (Power Up, Good LCD)	381
Samsung	G928-1	3	Samsung SP-Bid -BHandset (Power Up, Good LCD)	382
Samsung	G928F-1	2	Samsung SP-Bid -BHandset (Power Up, Good LCD)	383
Samsung	G930F	3	Samsung SP-Bid -BHandset (Power Up, Good LCD)	384
Samsung	G930F-1	1	Samsung SP-Bid -BHandset (Power Up, Good LCD)	385
Samsung	G935F	1	Samsung SP-Bid -BHandset (Power Up, Good LCD)	386
Samsung	G935F (SIM Free)	1	Samsung SP-Bid -BHandset (Power Up, Good LCD)	387
Samsung	G935F-1	5	Samsung SP-Bid -BHandset (Power Up, Good LCD)	388
Samsung	G950F	4	Samsung SP-Bid -BHandset (Power Up, Good LCD)	389
Samsung	G950F (SIM Free)	2	Samsung SP-Bid -BHandset (Power Up, Good LCD)	390
Samsung	G950F-1	4	Samsung SP-Bid -BHandset (Power Up, Good LCD)	391
Samsung	G960F	2	Samsung SP-Bid -BHandset (Power Up, Good LCD)	392
Samsung	G960F (SIM Free)	4	Samsung SP-Bid -BHandset (Power Up, Good LCD)	393
Samsung	G960F-1	1	Samsung SP-Bid -BHandset (Power Up, Good LCD)	394
Samsung	G965 (Demo) -1	1	Samsung SP-Bid -BHandset (Power Up, Good LCD)	395
Samsung	G965F (IMEI Cut) (SIM Free) -1	1	Samsung SP-Bid -BHandset (Power Up, Good LCD)	396
Samsung	G970F (SIM Free)	1	Samsung SP-Bid -BHandset (Power Up, Good LCD)	397
Samsung	G970F-1	1	Samsung SP-Bid -BHandset (Power Up, Good LCD)	398
Samsung	G973F	1	Samsung SP-Bid -BHandset (Power Up, Good LCD)	399
Samsung	G973F (SIM Free)	5	Samsung SP-Bid -BHandset (Power Up, Good LCD)	400
Samsung	G973F (IMEI Cut) (SIM Free) -1	1	Samsung SP-Bid -BHandset (Power Up, Good LCD)	401
Samsung	G975F-1	3	Samsung SP-Bid -BHandset (Power Up, Good LCD)	402
Samsung	G985F-1	2	Samsung SP-Bid -BHandset (Power Up, Good LCD)	403
Samsung	G990(SIM Free)	3	Samsung SP-Bid -BHandset (Power Up, Good LCD)	404
Samsung	G990(IMEI Cut) (SIM Free) -1	1	Samsung SP-Bid -BHandset (Power Up, Good LCD)	405
Samsung	G990B(SIM Free)	1	Samsung SP-Bid -BHandset (Power Up, Good LCD)	406
Samsung	G991B(SIM Free)	1	Samsung SP-Bid -BHandset (Power Up, Good LCD)	407
Samsung	i8160	1	Samsung SP-Bid -BHandset (Power Up, Good LCD)	408
Samsung	i9000	1	Samsung SP-Bid -BHandset (Power Up, Good LCD)	409
Samsung	I100	1	Samsung SP-Bid -BHandset (Power Up, Good LCD)	410
Samsung	M205F	1	Samsung SP-Bid -BHandset (Power Up, Good LCD)	411
Samsung	M515F (IMEI Cut) (SIM Free) -1	1	Samsung SP-Bid -BHandset (Power Up, Good LCD)	412
Samsung	N930 (Demo) -1	1	Samsung SP-Bid -BHandset (Power Up, Good LCD)	413
Samsung	N930F-1	1	Samsung SP-Bid -BHandset (Power Up, Good LCD)	414
Samsung	N960F (SIM Free) -1	1	Samsung SP-Bid -BHandset (Power Up, Good LCD)	415
Samsung	N980F (IMEI Cut) (SIM Free) -1	1	Samsung SP-Bid -BHandset (Power Up, Good LCD)	416
Samsung	N981B(SIM Free)	1	Samsung SP-Bid -BHandset (Power Up, Good LCD)	417
Samsung	P615	1	Samsung SP-Bid -BHandset (Power Up, Good LCD)	418
Samsung	S5570	2	Samsung SP-Bid -BHandset (Power Up, Good LCD)	419
Samsung	S901(IMEI Cut) (SIM Free) -1	2	Samsung SP-Bid -BHandset (Power Up, Good LCD)	420
Samsung	S901B(SIM Free)	2	Samsung SP-Bid -BHandset (Power Up, Good LCD)	421
Samsung	S901B-1	5	Samsung SP-Bid -BHandset (Power Up, Good LCD)	422
Samsung	S906(SIM Free)	5	Samsung SP-Bid -BHandset (Power Up, Good LCD)	423
Samsung	S908-1	1	Samsung SP-Bid -BHandset (Power Up, Good LCD)	424
Samsung	S908B(SIM Free)	1	Samsung SP-Bid -BHandset (Power Up, Good LCD)	425
Samsung	S908B-1	9	Samsung SP-Bid -BHandset (Power Up, Good LCD)	426
Samsung	S911B(SIM Free)	5	Samsung SP-Bid -BHandset (Power Up, Good LCD)	427
Samsung	S916B(SIM Free)	1	Samsung SP-Bid -BHandset (Power Up, Good LCD)	428

Samsung	S926B(SIM Free) -1	5	Samsung SP-Bid -BHandset (Power Up, Good LCD)	429
Samsung	S928B-1	1	Samsung SP-Bid -BHandset (Power Up, Good LCD)	430
Samsung	T307	21	Samsung SP-Bid -BHandset (Power Up, Good LCD)	431
Samsung	T500	1	Samsung SP-Bid -BHandset (Power Up, Good LCD)	432
Samsung	T505	1	Samsung SP-Bid -BHandset (Power Up, Good LCD)	433
Samsung	T590	1	Samsung SP-Bid -BHandset (Power Up, Good LCD)	434
Samsung	T813	1	Samsung SP-Bid -BHandset (Power Up, Good LCD)	435
Samsung	T875	1	Samsung SP-Bid -BHandset (Power Up, Good LCD)	436
Samsung	X110(IMEI Cut)	2	Samsung SP-Bid -BHandset (Power Up, Good LCD)	437
Samsung	X716B	1	Samsung SP-Bid -BHandset (Power Up, Good LCD)	438
Samsung	A346	1	Samsung SP-Bid -AHandset (LCD 1)	439
Samsung	A520F	1	Samsung SP-Bid -AHandset (LCD 1)	440
Samsung	A528B	1	Samsung SP-Bid -AHandset (LCD 1)	441
Samsung	A536B	1	Samsung SP-Bid -AHandset (LCD 1)	442
Samsung	A736B(SIM Free)	1	Samsung SP-Bid -AHandset (LCD 1)	443
Samsung	A908B(SIM Free)	1	Samsung SP-Bid -AHandset (LCD 1)	444
Samsung	G781B(SIM Free)	3	Samsung SP-Bid -AHandset (LCD 1)	445
Samsung	G925F	2	Samsung SP-Bid -AHandset (LCD 1)	446
Samsung	G950F (SIM Free)	14	Samsung SP-Bid -AHandset (LCD 1)	447
Samsung	G955F (SIM Free)	2	Samsung SP-Bid -AHandset (LCD 1)	448
Samsung	G965F (SIM Free)	5	Samsung SP-Bid -AHandset (LCD 1)	449
Samsung	G973F (SIM Free)	5	Samsung SP-Bid -AHandset (LCD 1)	450
Samsung	G973F (IMEI Cut) (SIM Free)	5	Samsung SP-Bid -AHandset (LCD 1)	451
Samsung	G975F (SIM Free)	6	Samsung SP-Bid -AHandset (LCD 1)	452
Samsung	G980F (SIM Free)	3	Samsung SP-Bid -AHandset (LCD 1)	453
Samsung	G981B(SIM Free)	5	Samsung SP-Bid -AHandset (LCD 1)	454
Samsung	G986B(SIM Free)	4	Samsung SP-Bid -AHandset (LCD 1)	455
Samsung	G991B(SIM Free)	6	Samsung SP-Bid -AHandset (LCD 1)	456
Samsung	G996B(SIM Free)	3	Samsung SP-Bid -AHandset (LCD 1)	457
Samsung	G998B(SIM Free)	1	Samsung SP-Bid -AHandset (LCD 1)	458
Samsung	M315F (IMEI Cut) (SIM Free)	1	Samsung SP-Bid -AHandset (LCD 1)	459
Samsung	N950F (SIM Free)	1	Samsung SP-Bid -AHandset (LCD 1)	460
Samsung	N960F (SIM Free)	5	Samsung SP-Bid -AHandset (LCD 1)	461
Samsung	N975F (SIM Free)	4	Samsung SP-Bid -AHandset (LCD 1)	462
Samsung	N986B(SIM Free)	2	Samsung SP-Bid -AHandset (LCD 1)	463
Samsung	S908B(SIM Free)	1	Samsung SP-Bid -AHandset (LCD 1)	464
Samsung	A107	1	Samsung SP-Bid -BHandset (Power Up, Good LCD) (LCD 1)	465
Samsung	A107F	1	Samsung SP-Bid -BHandset (Power Up, Good LCD) (LCD 1)	466
Samsung	A207F	1	Samsung SP-Bid -BHandset (Power Up, Good LCD) (LCD 1)	467
Samsung	A305F	2	Samsung SP-Bid -BHandset (Power Up, Good LCD) (LCD 1)	468
Samsung	A405F	3	Samsung SP-Bid -BHandset (Power Up, Good LCD) (LCD 1)	469
Samsung	A500	1	Samsung SP-Bid -BHandset (Power Up, Good LCD) (LCD 1)	470
Samsung	A500F	1	Samsung SP-Bid -BHandset (Power Up, Good LCD) (LCD 1)	471
Samsung	A505	1	Samsung SP-Bid -BHandset (Power Up, Good LCD) (LCD 1)	472
Samsung	A510	1	Samsung SP-Bid -BHandset (Power Up, Good LCD) (LCD 1)	473
Samsung	A510F	5	Samsung SP-Bid -BHandset (Power Up, Good LCD) (LCD 1)	474
Samsung	A520F	2	Samsung SP-Bid -BHandset (Power Up, Good LCD) (LCD 1)	475
Samsung	A715F	1	Samsung SP-Bid -BHandset (Power Up, Good LCD) (LCD 1)	476
Samsung	A715F (SIM Free)	1	Samsung SP-Bid -BHandset (Power Up, Good LCD) (LCD 1)	477
Samsung	A800F	1	Samsung SP-Bid -BHandset (Power Up, Good LCD) (LCD 1)	478
Samsung	G781B	3	Samsung SP-Bid -BHandset (Power Up, Good LCD) (LCD 1)	479
Samsung	G925F	5	Samsung SP-Bid -BHandset (Power Up, Good LCD) (LCD 1)	480
Samsung	G928	1	Samsung SP-Bid -BHandset (Power Up, Good LCD) (LCD 1)	481
Samsung	G930F	13	Samsung SP-Bid -BHandset (Power Up, Good LCD) (LCD 1)	482
Samsung	G935F	12	Samsung SP-Bid -BHandset (Power Up, Good LCD) (LCD 1)	483
Samsung	G950F	6	Samsung SP-Bid -BHandset (Power Up, Good LCD) (LCD 1)	484
Samsung	G950F (SIM Free)	5	Samsung SP-Bid -BHandset (Power Up, Good LCD) (LCD 1)	485
Samsung	G955F	1	Samsung SP-Bid -BHandset (Power Up, Good LCD) (LCD 1)	486
Samsung	G955F (SIM Free)	1	Samsung SP-Bid -BHandset (Power Up, Good LCD) (LCD 1)	487
Samsung	G960F (SIM Free)	5	Samsung SP-Bid -BHandset (Power Up, Good LCD) (LCD 1)	488
Samsung	G965F	1	Samsung SP-Bid -BHandset (Power Up, Good LCD) (LCD 1)	489
Samsung	G965F (SIM Free)	1	Samsung SP-Bid -BHandset (Power Up, Good LCD) (LCD 1)	490
Samsung	G973F (SIM Free)	1	Samsung SP-Bid -BHandset (Power Up, Good LCD) (LCD 1)	491
Samsung	G980F (SIM Free)	1	Samsung SP-Bid -BHandset (Power Up, Good LCD) (LCD 1)	492
Samsung	G986B(SIM Free)	2	Samsung SP-Bid -BHandset (Power Up, Good LCD) (LCD 1)	493
Samsung	G988B(SIM Free)	1	Samsung SP-Bid -BHandset (Power Up, Good LCD) (LCD 1)	494
Samsung	G990(SIM Free)	1	Samsung SP-Bid -BHandset (Power Up, Good LCD) (LCD 1)	495
Samsung	N950F	1	Samsung SP-Bid -BHandset (Power Up, Good LCD) (LCD 1)	496
Samsung	N950F (SIM Free)	1	Samsung SP-Bid -BHandset (Power Up, Good LCD) (LCD 1)	497
Samsung	N975F	1	Samsung SP-Bid -BHandset (Power Up, Good LCD) (LCD 1)	498
Samsung	A013	27	Samsung SP-Bid -BHandset (Power Up, Bad LCD)	499
Samsung	A013F	1	Samsung SP-Bid -BHandset (Power Up, Bad LCD)	500
Samsung	A015	35	Samsung SP-Bid -BHandset (Power Up, Bad LCD)	501
Samsung	A015F	22	Samsung SP-Bid -BHandset (Power Up, Bad LCD)	502
Samsung	A022	1	Samsung SP-Bid -BHandset (Power Up, Bad LCD)	503
Samsung	A032	4	Samsung SP-Bid -BHandset (Power Up, Bad LCD)	504
Samsung	A032F	1	Samsung SP-Bid -BHandset (Power Up, Bad LCD)	505
Samsung	A035	5	Samsung SP-Bid -BHandset (Power Up, Bad LCD)	506
Samsung	A042	2	Samsung SP-Bid -BHandset (Power Up, Bad LCD)	507
Samsung	A045(SIM Free)	1	Samsung SP-Bid -BHandset (Power Up, Bad LCD)	508
Samsung	A047F	6	Samsung SP-Bid -BHandset (Power Up, Bad LCD)	509
Samsung	A055(SIM Free)	14	Samsung SP-Bid -BHandset (Power Up, Bad LCD)	510
Samsung	A057	7	Samsung SP-Bid -BHandset (Power Up, Bad LCD)	511
Samsung	A057(SIM Free)	23	Samsung SP-Bid -BHandset (Power Up, Bad LCD)	512
Samsung	A105	2	Samsung SP-Bid -BHandset (Power Up, Bad LCD)	513
Samsung	A105F	5	Samsung SP-Bid -BHandset (Power Up, Bad LCD)	514

Samsung	A107	2	Samsung SP-Bid -BHandset (Power Up, Bad LCD)	515
Samsung	A107F	2	Samsung SP-Bid -BHandset (Power Up, Bad LCD)	516
Samsung	A125F	7	Samsung SP-Bid -BHandset (Power Up, Bad LCD)	517
Samsung	A127F	4	Samsung SP-Bid -BHandset (Power Up, Bad LCD)	518
Samsung	A135	12	Samsung SP-Bid -BHandset (Power Up, Bad LCD)	519
Samsung	A135F	1	Samsung SP-Bid -BHandset (Power Up, Bad LCD)	520
Samsung	A137F	5	Samsung SP-Bid -BHandset (Power Up, Bad LCD)	521
Samsung	A145	11	Samsung SP-Bid -BHandset (Power Up, Bad LCD)	522
Samsung	A145F	2	Samsung SP-Bid -BHandset (Power Up, Bad LCD)	523
Samsung	A146	3	Samsung SP-Bid -BHandset (Power Up, Bad LCD)	524
Samsung	A155F	5	Samsung SP-Bid -BHandset (Power Up, Bad LCD)	525
Samsung	A156B	3	Samsung SP-Bid -BHandset (Power Up, Bad LCD)	526
Samsung	A202F	9	Samsung SP-Bid -BHandset (Power Up, Bad LCD)	527
Samsung	A205	1	Samsung SP-Bid -BHandset (Power Up, Bad LCD)	528
Samsung	A207	1	Samsung SP-Bid -BHandset (Power Up, Bad LCD)	529
Samsung	A207F	7	Samsung SP-Bid -BHandset (Power Up, Bad LCD)	530
Samsung	A215	1	Samsung SP-Bid -BHandset (Power Up, Bad LCD)	531
Samsung	A217	2	Samsung SP-Bid -BHandset (Power Up, Bad LCD)	532
Samsung	A217F	1	Samsung SP-Bid -BHandset (Power Up, Bad LCD)	533
Samsung	A226B	2	Samsung SP-Bid -BHandset (Power Up, Bad LCD)	534
Samsung	A236	17	Samsung SP-Bid -BHandset (Power Up, Bad LCD)	535
Samsung	A236B	5	Samsung SP-Bid -BHandset (Power Up, Bad LCD)	536
Samsung	A245F (IMEI Cut)	18	Samsung SP-Bid -BHandset (Power Up, Bad LCD)	537
Samsung	A256B	2	Samsung SP-Bid -BHandset (Power Up, Bad LCD)	538
Samsung	A260	3	Samsung SP-Bid -BHandset (Power Up, Bad LCD)	539
Samsung	A260F	12	Samsung SP-Bid -BHandset (Power Up, Bad LCD)	540
Samsung	A315	1	Samsung SP-Bid -BHandset (Power Up, Bad LCD)	541
Samsung	A320F	1	Samsung SP-Bid -BHandset (Power Up, Bad LCD)	542
Samsung	A326B	2	Samsung SP-Bid -BHandset (Power Up, Bad LCD)	543
Samsung	A336B	1	Samsung SP-Bid -BHandset (Power Up, Bad LCD)	544
Samsung	A346B	2	Samsung SP-Bid -BHandset (Power Up, Bad LCD)	545
Samsung	A405F	162	Samsung SP-Bid -BHandset (Power Up, Bad LCD)	546
Samsung	A415	1	Samsung SP-Bid -BHandset (Power Up, Bad LCD)	547
Samsung	A415F	4	Samsung SP-Bid -BHandset (Power Up, Bad LCD)	548
Samsung	A500	6	Samsung SP-Bid -BHandset (Power Up, Bad LCD)	549
Samsung	A500F	133	Samsung SP-Bid -BHandset (Power Up, Bad LCD)	550
Samsung	A510	30	Samsung SP-Bid -BHandset (Power Up, Bad LCD)	551
Samsung	A510 (Demo)	4	Samsung SP-Bid -BHandset (Power Up, Bad LCD)	552
Samsung	A510F	225	Samsung SP-Bid -BHandset (Power Up, Bad LCD)	553
Samsung	A515F	1	Samsung SP-Bid -BHandset (Power Up, Bad LCD)	554
Samsung	A520	1	Samsung SP-Bid -BHandset (Power Up, Bad LCD)	555
Samsung	A528B	3	Samsung SP-Bid -BHandset (Power Up, Bad LCD)	556
Samsung	A530	2	Samsung SP-Bid -BHandset (Power Up, Bad LCD)	557
Samsung	A530F	328	Samsung SP-Bid -BHandset (Power Up, Bad LCD)	558
Samsung	A536	11	Samsung SP-Bid -BHandset (Power Up, Bad LCD)	559
Samsung	A536B	31	Samsung SP-Bid -BHandset (Power Up, Bad LCD)	560
Samsung	A546B	3	Samsung SP-Bid -BHandset (Power Up, Bad LCD)	561
Samsung	A700	1	Samsung SP-Bid -BHandset (Power Up, Bad LCD)	562
Samsung	A700F	20	Samsung SP-Bid -BHandset (Power Up, Bad LCD)	563
Samsung	A705F	16	Samsung SP-Bid -BHandset (Power Up, Bad LCD)	564
Samsung	A710	24	Samsung SP-Bid -BHandset (Power Up, Bad LCD)	565
Samsung	A710F	4	Samsung SP-Bid -BHandset (Power Up, Bad LCD)	566
Samsung	A715F	1	Samsung SP-Bid -BHandset (Power Up, Bad LCD)	567
Samsung	A720F	46	Samsung SP-Bid -BHandset (Power Up, Bad LCD)	568
Samsung	A750	10	Samsung SP-Bid -BHandset (Power Up, Bad LCD)	569
Samsung	A750F	105	Samsung SP-Bid -BHandset (Power Up, Bad LCD)	570
Samsung	A908B	1	Samsung SP-Bid -BHandset (Power Up, Bad LCD)	571
Samsung	A920F	13	Samsung SP-Bid -BHandset (Power Up, Bad LCD)	572
Samsung	F700F	8	Samsung SP-Bid -BHandset (Power Up, Bad LCD)	573
Samsung	F711B	8	Samsung SP-Bid -BHandset (Power Up, Bad LCD)	574
Samsung	F711B(SIM Free)	3	Samsung SP-Bid -BHandset (Power Up, Bad LCD)	575
Samsung	F721B	19	Samsung SP-Bid -BHandset (Power Up, Bad LCD)	576
Samsung	F721B(SIM Free)	16	Samsung SP-Bid -BHandset (Power Up, Bad LCD)	577
Samsung	F731B	8	Samsung SP-Bid -BHandset (Power Up, Bad LCD)	578
Samsung	F731B(SIM Free)	30	Samsung SP-Bid -BHandset (Power Up, Bad LCD)	579
Samsung	F741B	4	Samsung SP-Bid -BHandset (Power Up, Bad LCD)	580
Samsung	F741B(SIM Free)	6	Samsung SP-Bid -BHandset (Power Up, Bad LCD)	581
Samsung	F900F	3	Samsung SP-Bid -BHandset (Power Up, Bad LCD)	582
Samsung	F907B	4	Samsung SP-Bid -BHandset (Power Up, Bad LCD)	583
Samsung	F916B	3	Samsung SP-Bid -BHandset (Power Up, Bad LCD)	584
Samsung	F926(SIM Free)	343	Samsung SP-Bid -BHandset (Power Up, Bad LCD)	585
Samsung	F926B	42	Samsung SP-Bid -BHandset (Power Up, Bad LCD)	586
Samsung	F926B(SIM Free)	2	Samsung SP-Bid -BHandset (Power Up, Bad LCD)	587
Samsung	F936B	17	Samsung SP-Bid -BHandset (Power Up, Bad LCD)	588
Samsung	F936B(SIM Free)	28	Samsung SP-Bid -BHandset (Power Up, Bad LCD)	589
Samsung	F946B	8	Samsung SP-Bid -BHandset (Power Up, Bad LCD)	590
Samsung	F946B(SIM Free)	22	Samsung SP-Bid -BHandset (Power Up, Bad LCD)	591
Samsung	F956B	7	Samsung SP-Bid -BHandset (Power Up, Bad LCD)	592
Samsung	F956B(SIM Free)	8	Samsung SP-Bid -BHandset (Power Up, Bad LCD)	593
Samsung	G390	1	Samsung SP-Bid -BHandset (Power Up, Bad LCD)	594
Samsung	G715	1	Samsung SP-Bid -BHandset (Power Up, Bad LCD)	595
Samsung	G715F	6	Samsung SP-Bid -BHandset (Power Up, Bad LCD)	596
Samsung	G736B	1	Samsung SP-Bid -BHandset (Power Up, Bad LCD)	597
Samsung	G736B(SIM Free)	1	Samsung SP-Bid -BHandset (Power Up, Bad LCD)	598
Samsung	G780F	2	Samsung SP-Bid -BHandset (Power Up, Bad LCD)	599
Samsung	G781B	18	Samsung SP-Bid -BHandset (Power Up, Bad LCD)	600

Samsung	G781B(SIM Free)	1	Samsung SP-Bid -BHandset (Power Up, Bad LCD)	601
Samsung	G920	1	Samsung SP-Bid -BHandset (Power Up, Bad LCD)	602
Samsung	G925F	102	Samsung SP-Bid -BHandset (Power Up, Bad LCD)	603
Samsung	G928	1	Samsung SP-Bid -BHandset (Power Up, Bad LCD)	604
Samsung	G928F	56	Samsung SP-Bid -BHandset (Power Up, Bad LCD)	605
Samsung	G930	1	Samsung SP-Bid -BHandset (Power Up, Bad LCD)	606
Samsung	G930F	9	Samsung SP-Bid -BHandset (Power Up, Bad LCD)	607
Samsung	G935	4	Samsung SP-Bid -BHandset (Power Up, Bad LCD)	608
Samsung	G935F	5	Samsung SP-Bid -BHandset (Power Up, Bad LCD)	609
Samsung	G950F	15	Samsung SP-Bid -BHandset (Power Up, Bad LCD)	610
Samsung	G955	1	Samsung SP-Bid -BHandset (Power Up, Bad LCD)	611
Samsung	G955F	9	Samsung SP-Bid -BHandset (Power Up, Bad LCD)	612
Samsung	G960F	12	Samsung SP-Bid -BHandset (Power Up, Bad LCD)	613
Samsung	G965	4	Samsung SP-Bid -BHandset (Power Up, Bad LCD)	614
Samsung	G965 (Demo)	1	Samsung SP-Bid -BHandset (Power Up, Bad LCD)	615
Samsung	G965F	3	Samsung SP-Bid -BHandset (Power Up, Bad LCD)	616
Samsung	G970F	1	Samsung SP-Bid -BHandset (Power Up, Bad LCD)	617
Samsung	G973	1	Samsung SP-Bid -BHandset (Power Up, Bad LCD)	618
Samsung	G973F	11	Samsung SP-Bid -BHandset (Power Up, Bad LCD)	619
Samsung	G975F	8	Samsung SP-Bid -BHandset (Power Up, Bad LCD)	620
Samsung	G977B	4	Samsung SP-Bid -BHandset (Power Up, Bad LCD)	621
Samsung	G980F	24	Samsung SP-Bid -BHandset (Power Up, Bad LCD)	622
Samsung	G981	4	Samsung SP-Bid -BHandset (Power Up, Bad LCD)	623
Samsung	G981B	3	Samsung SP-Bid -BHandset (Power Up, Bad LCD)	624
Samsung	G985F	3	Samsung SP-Bid -BHandset (Power Up, Bad LCD)	625
Samsung	G986B	3	Samsung SP-Bid -BHandset (Power Up, Bad LCD)	626
Samsung	G988B	3	Samsung SP-Bid -BHandset (Power Up, Bad LCD)	627
Samsung	G990	3	Samsung SP-Bid -BHandset (Power Up, Bad LCD)	628
Samsung	G990B	2	Samsung SP-Bid -BHandset (Power Up, Bad LCD)	629
Samsung	G991B	7	Samsung SP-Bid -BHandset (Power Up, Bad LCD)	630
Samsung	G991B(SIM Free)	3	Samsung SP-Bid -BHandset (Power Up, Bad LCD)	631
Samsung	G996B	13	Samsung SP-Bid -BHandset (Power Up, Bad LCD)	632
Samsung	G998B	18	Samsung SP-Bid -BHandset (Power Up, Bad LCD)	633
Samsung	G998B(SIM Free)	1	Samsung SP-Bid -BHandset (Power Up, Bad LCD)	634
Samsung	J106	3	Samsung SP-Bid -BHandset (Power Up, Bad LCD)	635
Samsung	J810	1	Samsung SP-Bid -BHandset (Power Up, Bad LCD)	636
Samsung	M025F	1	Samsung SP-Bid -BHandset (Power Up, Bad LCD)	637
Samsung	M115F	5	Samsung SP-Bid -BHandset (Power Up, Bad LCD)	638
Samsung	M205F	4	Samsung SP-Bid -BHandset (Power Up, Bad LCD)	639
Samsung	M215F	13	Samsung SP-Bid -BHandset (Power Up, Bad LCD)	640
Samsung	M225F (IMEI Cut)	1	Samsung SP-Bid -BHandset (Power Up, Bad LCD)	641
Samsung	M236B	1	Samsung SP-Bid -BHandset (Power Up, Bad LCD)	642
Samsung	M515F	1	Samsung SP-Bid -BHandset (Power Up, Bad LCD)	643
Samsung	N920F	2	Samsung SP-Bid -BHandset (Power Up, Bad LCD)	644
Samsung	N950F	107	Samsung SP-Bid -BHandset (Power Up, Bad LCD)	645
Samsung	N960F	43	Samsung SP-Bid -BHandset (Power Up, Bad LCD)	646
Samsung	N975F	3	Samsung SP-Bid -BHandset (Power Up, Bad LCD)	647
Samsung	N986B	10	Samsung SP-Bid -BHandset (Power Up, Bad LCD)	648
Samsung	P580	1	Samsung SP-Bid -BHandset (Power Up, Bad LCD)	649
Samsung	P615	1	Samsung SP-Bid -BHandset (Power Up, Bad LCD)	650
Samsung	P617	3	Samsung SP-Bid -BHandset (Power Up, Bad LCD)	651
Samsung	S711B	2	Samsung SP-Bid -BHandset (Power Up, Bad LCD)	652
Samsung	S721B	1	Samsung SP-Bid -BHandset (Power Up, Bad LCD)	653
Samsung	S767	1	Samsung SP-Bid -BHandset (Power Up, Bad LCD)	654
Samsung	S901	9	Samsung SP-Bid -BHandset (Power Up, Bad LCD)	655
Samsung	S901(SIM Free)	4	Samsung SP-Bid -BHandset (Power Up, Bad LCD)	656
Samsung	S901B	34	Samsung SP-Bid -BHandset (Power Up, Bad LCD)	657
Samsung	S906	3	Samsung SP-Bid -BHandset (Power Up, Bad LCD)	658
Samsung	S906(SIM Free)	4	Samsung SP-Bid -BHandset (Power Up, Bad LCD)	659
Samsung	S906B	4	Samsung SP-Bid -BHandset (Power Up, Bad LCD)	660
Samsung	S908	16	Samsung SP-Bid -BHandset (Power Up, Bad LCD)	661
Samsung	S908(SIM Free)	9	Samsung SP-Bid -BHandset (Power Up, Bad LCD)	662
Samsung	S908B	49	Samsung SP-Bid -BHandset (Power Up, Bad LCD)	663
Samsung	S911B	4	Samsung SP-Bid -BHandset (Power Up, Bad LCD)	664
Samsung	S911B(SIM Free)	1	Samsung SP-Bid -BHandset (Power Up, Bad LCD)	665
Samsung	S916B	1	Samsung SP-Bid -BHandset (Power Up, Bad LCD)	666
Samsung	S918B	31	Samsung SP-Bid -BHandset (Power Up, Bad LCD)	667
Samsung	S918B(SIM Free)	16	Samsung SP-Bid -BHandset (Power Up, Bad LCD)	668
Samsung	S921B	5	Samsung SP-Bid -BHandset (Power Up, Bad LCD)	669
Samsung	S921B(SIM Free)	2	Samsung SP-Bid -BHandset (Power Up, Bad LCD)	670
Samsung	S926B(SIM Free)	1	Samsung SP-Bid -BHandset (Power Up, Bad LCD)	671
Samsung	S928B	7	Samsung SP-Bid -BHandset (Power Up, Bad LCD)	672
Samsung	S928B(SIM Free)	4	Samsung SP-Bid -BHandset (Power Up, Bad LCD)	673
Samsung	T220	5	Samsung SP-Bid -BHandset (Power Up, Bad LCD)	674
Samsung	T290	1	Samsung SP-Bid -BHandset (Power Up, Bad LCD)	675
Samsung	T297	1	Samsung SP-Bid -BHandset (Power Up, Bad LCD)	676
Samsung	T307	1	Samsung SP-Bid -BHandset (Power Up, Bad LCD)	677
Samsung	T395	1	Samsung SP-Bid -BHandset (Power Up, Bad LCD)	678
Samsung	T505	1	Samsung SP-Bid -BHandset (Power Up, Bad LCD)	679
Samsung	T510	5	Samsung SP-Bid -BHandset (Power Up, Bad LCD)	680
Samsung	T515	7	Samsung SP-Bid -BHandset (Power Up, Bad LCD)	681
Samsung	T560	3	Samsung SP-Bid -BHandset (Power Up, Bad LCD)	682
Samsung	T590	1	Samsung SP-Bid -BHandset (Power Up, Bad LCD)	683
Samsung	T597	1	Samsung SP-Bid -BHandset (Power Up, Bad LCD)	684
Samsung	T710	1	Samsung SP-Bid -BHandset (Power Up, Bad LCD)	685
Samsung	T715	1	Samsung SP-Bid -BHandset (Power Up, Bad LCD)	686

Samsung	T720	23	Samsung SP-Bid -BHandset (Power Up, Bad LCD)	687
Samsung	T725	7	Samsung SP-Bid -BHandset (Power Up, Bad LCD)	688
Samsung	T727	1	Samsung SP-Bid -BHandset (Power Up, Bad LCD)	689
Samsung	T810	3	Samsung SP-Bid -BHandset (Power Up, Bad LCD)	690
Samsung	T820	1	Samsung SP-Bid -BHandset (Power Up, Bad LCD)	691
Samsung	T825	27	Samsung SP-Bid -BHandset (Power Up, Bad LCD)	692
Samsung	T830	2	Samsung SP-Bid -BHandset (Power Up, Bad LCD)	693
Samsung	T835	5	Samsung SP-Bid -BHandset (Power Up, Bad LCD)	694
Samsung	T837	1	Samsung SP-Bid -BHandset (Power Up, Bad LCD)	695
Samsung	T860	2	Samsung SP-Bid -BHandset (Power Up, Bad LCD)	696
Samsung	T865	2	Samsung SP-Bid -BHandset (Power Up, Bad LCD)	697
Samsung	T867	2	Samsung SP-Bid -BHandset (Power Up, Bad LCD)	698
Samsung	T970	3	Samsung SP-Bid -BHandset (Power Up, Bad LCD)	699
Samsung	T976B	3	Samsung SP-Bid -BHandset (Power Up, Bad LCD)	700
Samsung	W700	1	Samsung SP-Bid -BHandset (Power Up, Bad LCD)	701
Samsung	X200	1	Samsung SP-Bid -BHandset (Power Up, Bad LCD)	702
Samsung	X205	2	Samsung SP-Bid -BHandset (Power Up, Bad LCD)	703
Samsung	X215	1	Samsung SP-Bid -BHandset (Power Up, Bad LCD)	704
Samsung	X216B	2	Samsung SP-Bid -BHandset (Power Up, Bad LCD)	705
Samsung	X218	1	Samsung SP-Bid -BHandset (Power Up, Bad LCD)	706
Samsung	X716B	1	Samsung SP-Bid -BHandset (Power Up, Bad LCD)	707
Samsung	X916B	1	Samsung SP-Bid -BHandset (Power Up, Bad LCD)	708
Samsung	A013	11	Samsung SP-Bid -BHandset (No Power)	709
Samsung	A013F	1	Samsung SP-Bid -BHandset (No Power)	710
Samsung	A015	4	Samsung SP-Bid -BHandset (No Power)	711
Samsung	A015F	5	Samsung SP-Bid -BHandset (No Power)	712
Samsung	A025	1	Samsung SP-Bid -BHandset (No Power)	713
Samsung	A025F	1	Samsung SP-Bid -BHandset (No Power)	714
Samsung	A032	1	Samsung SP-Bid -BHandset (No Power)	715
Samsung	A035	2	Samsung SP-Bid -BHandset (No Power)	716
Samsung	A037	1	Samsung SP-Bid -BHandset (No Power)	717
Samsung	A042	2	Samsung SP-Bid -BHandset (No Power)	718
Samsung	A045	8	Samsung SP-Bid -BHandset (No Power)	719
Samsung	A047F	1	Samsung SP-Bid -BHandset (No Power)	720
Samsung	A055	1	Samsung SP-Bid -BHandset (No Power)	721
Samsung	A057	3	Samsung SP-Bid -BHandset (No Power)	722
Samsung	A057F	3	Samsung SP-Bid -BHandset (No Power)	723
Samsung	A105F	14	Samsung SP-Bid -BHandset (No Power)	724
Samsung	A107F	6	Samsung SP-Bid -BHandset (No Power)	725
Samsung	A125F	5	Samsung SP-Bid -BHandset (No Power)	726
Samsung	A127F	4	Samsung SP-Bid -BHandset (No Power)	727
Samsung	A135	2	Samsung SP-Bid -BHandset (No Power)	728
Samsung	A135F	9	Samsung SP-Bid -BHandset (No Power)	729
Samsung	A136	2	Samsung SP-Bid -BHandset (No Power)	730
Samsung	A136B	7	Samsung SP-Bid -BHandset (No Power)	731
Samsung	A137F	1	Samsung SP-Bid -BHandset (No Power)	732
Samsung	A145	30	Samsung SP-Bid -BHandset (No Power)	733
Samsung	A145F	2	Samsung SP-Bid -BHandset (No Power)	734
Samsung	A146	3	Samsung SP-Bid -BHandset (No Power)	735
Samsung	A155	9	Samsung SP-Bid -BHandset (No Power)	736
Samsung	A155F	20	Samsung SP-Bid -BHandset (No Power)	737
Samsung	A156	3	Samsung SP-Bid -BHandset (No Power)	738
Samsung	A156B	1	Samsung SP-Bid -BHandset (No Power)	739
Samsung	A202F	3	Samsung SP-Bid -BHandset (No Power)	740
Samsung	A205F	2	Samsung SP-Bid -BHandset (No Power)	741
Samsung	A207F	2	Samsung SP-Bid -BHandset (No Power)	742
Samsung	A215	1	Samsung SP-Bid -BHandset (No Power)	743
Samsung	A217	3	Samsung SP-Bid -BHandset (No Power)	744
Samsung	A225	3	Samsung SP-Bid -BHandset (No Power)	745
Samsung	A236	7	Samsung SP-Bid -BHandset (No Power)	746
Samsung	A236B	2	Samsung SP-Bid -BHandset (No Power)	747
Samsung	A256	2	Samsung SP-Bid -BHandset (No Power)	748
Samsung	A260	2	Samsung SP-Bid -BHandset (No Power)	749
Samsung	A260F	17	Samsung SP-Bid -BHandset (No Power)	750
Samsung	A325F	1	Samsung SP-Bid -BHandset (No Power)	751
Samsung	A326B	7	Samsung SP-Bid -BHandset (No Power)	752
Samsung	A336	4	Samsung SP-Bid -BHandset (No Power)	753
Samsung	A336B	2	Samsung SP-Bid -BHandset (No Power)	754
Samsung	A346	3	Samsung SP-Bid -BHandset (No Power)	755
Samsung	A346B	3	Samsung SP-Bid -BHandset (No Power)	756
Samsung	A356	2	Samsung SP-Bid -BHandset (No Power)	757
Samsung	A356B	1	Samsung SP-Bid -BHandset (No Power)	758
Samsung	A405F	33	Samsung SP-Bid -BHandset (No Power)	759
Samsung	A500	3	Samsung SP-Bid -BHandset (No Power)	760
Samsung	A500F	15	Samsung SP-Bid -BHandset (No Power)	761
Samsung	A505F	1	Samsung SP-Bid -BHandset (No Power)	762
Samsung	A510F	11	Samsung SP-Bid -BHandset (No Power)	763
Samsung	A515F	1	Samsung SP-Bid -BHandset (No Power)	764
Samsung	A520F	6	Samsung SP-Bid -BHandset (No Power)	765
Samsung	A528B	1	Samsung SP-Bid -BHandset (No Power)	766
Samsung	A536	17	Samsung SP-Bid -BHandset (No Power)	767
Samsung	A536B	1	Samsung SP-Bid -BHandset (No Power)	768
Samsung	A546	6	Samsung SP-Bid -BHandset (No Power)	769
Samsung	A546B	8	Samsung SP-Bid -BHandset (No Power)	770
Samsung	A556	6	Samsung SP-Bid -BHandset (No Power)	771
Samsung	A556B	2	Samsung SP-Bid -BHandset (No Power)	772

Samsung	A605F	1	Samsung SP-Bid -BHandset (No Power)	773
Samsung	A7000	1	Samsung SP-Bid -BHandset (No Power)	774
Samsung	A700F	6	Samsung SP-Bid -BHandset (No Power)	775
Samsung	A705F	1	Samsung SP-Bid -BHandset (No Power)	776
Samsung	A710	7	Samsung SP-Bid -BHandset (No Power)	777
Samsung	A710F	2	Samsung SP-Bid -BHandset (No Power)	778
Samsung	A736B	2	Samsung SP-Bid -BHandset (No Power)	779
Samsung	A750	5	Samsung SP-Bid -BHandset (No Power)	780
Samsung	A750F	1	Samsung SP-Bid -BHandset (No Power)	781
Samsung	A800	1	Samsung SP-Bid -BHandset (No Power)	782
Samsung	A910F	1	Samsung SP-Bid -BHandset (No Power)	783
Samsung	F721	13	Samsung SP-Bid -BHandset (No Power)	784
Samsung	F926B	6	Samsung SP-Bid -BHandset (No Power)	785
Samsung	F936B	2	Samsung SP-Bid -BHandset (No Power)	786
Samsung	F946B	1	Samsung SP-Bid -BHandset (No Power)	787
Samsung	G715F	1	Samsung SP-Bid -BHandset (No Power)	788
Samsung	G750	1	Samsung SP-Bid -BHandset (No Power)	789
Samsung	G781B	2	Samsung SP-Bid -BHandset (No Power)	790
Samsung	G925 (Demo)	1	Samsung SP-Bid -BHandset (No Power)	791
Samsung	G925F	94	Samsung SP-Bid -BHandset (No Power)	792
Samsung	G928 (Demo)	1	Samsung SP-Bid -BHandset (No Power)	793
Samsung	G930F	25	Samsung SP-Bid -BHandset (No Power)	794
Samsung	G935F	20	Samsung SP-Bid -BHandset (No Power)	795
Samsung	G950F	16	Samsung SP-Bid -BHandset (No Power)	796
Samsung	G955F	4	Samsung SP-Bid -BHandset (No Power)	797
Samsung	G9600	1	Samsung SP-Bid -BHandset (No Power)	798
Samsung	G960F	11	Samsung SP-Bid -BHandset (No Power)	799
Samsung	G965F	18	Samsung SP-Bid -BHandset (No Power)	800
Samsung	G973F	16	Samsung SP-Bid -BHandset (No Power)	801
Samsung	G975F	9	Samsung SP-Bid -BHandset (No Power)	802
Samsung	G980F	6	Samsung SP-Bid -BHandset (No Power)	803
Samsung	G981	2	Samsung SP-Bid -BHandset (No Power)	804
Samsung	G986B	3	Samsung SP-Bid -BHandset (No Power)	805
Samsung	G990	2	Samsung SP-Bid -BHandset (No Power)	806
Samsung	G990B	2	Samsung SP-Bid -BHandset (No Power)	807
Samsung	G991B	14	Samsung SP-Bid -BHandset (No Power)	808
Samsung	G996B	1	Samsung SP-Bid -BHandset (No Power)	809
Samsung	G998B	23	Samsung SP-Bid -BHandset (No Power)	810
Samsung	M025F	1	Samsung SP-Bid -BHandset (No Power)	811
Samsung	M105	1	Samsung SP-Bid -BHandset (No Power)	812
Samsung	M115F	4	Samsung SP-Bid -BHandset (No Power)	813
Samsung	M205	1	Samsung SP-Bid -BHandset (No Power)	814
Samsung	M305	2	Samsung SP-Bid -BHandset (No Power)	815
Samsung	M317F	1	Samsung SP-Bid -BHandset (No Power)	816
Samsung	M556B	1	Samsung SP-Bid -BHandset (No Power)	817
Samsung	N920	1	Samsung SP-Bid -BHandset (No Power)	818
Samsung	N950F	5	Samsung SP-Bid -BHandset (No Power)	819
Samsung	N960F	10	Samsung SP-Bid -BHandset (No Power)	820
Samsung	N970F	1	Samsung SP-Bid -BHandset (No Power)	821
Samsung	N975F	5	Samsung SP-Bid -BHandset (No Power)	822
Samsung	N986	1	Samsung SP-Bid -BHandset (No Power)	823
Samsung	P613	1	Samsung SP-Bid -BHandset (No Power)	824
Samsung	S711B	2	Samsung SP-Bid -BHandset (No Power)	825
Samsung	S901	3	Samsung SP-Bid -BHandset (No Power)	826
Samsung	S908	11	Samsung SP-Bid -BHandset (No Power)	827
Samsung	S908B	1	Samsung SP-Bid -BHandset (No Power)	828
Samsung	S911B	4	Samsung SP-Bid -BHandset (No Power)	829
Samsung	S916B	2	Samsung SP-Bid -BHandset (No Power)	830
Samsung	S918B	48	Samsung SP-Bid -BHandset (No Power)	831
Samsung	S928	2	Samsung SP-Bid -BHandset (No Power)	832
Samsung	S928B	1	Samsung SP-Bid -BHandset (No Power)	833
Samsung	T220	2	Samsung SP-Bid -BHandset (No Power)	834
Samsung	T515	1	Samsung SP-Bid -BHandset (No Power)	835
Samsung	T719	2	Samsung SP-Bid -BHandset (No Power)	836
Samsung	T720	1	Samsung SP-Bid -BHandset (No Power)	837
Samsung	T725	1	Samsung SP-Bid -BHandset (No Power)	838
Samsung	T810	1	Samsung SP-Bid -BHandset (No Power)	839
Samsung	X115	4	Samsung SP-Bid -BHandset (No Power)	840
Samsung	X205	1	Samsung SP-Bid -BHandset (No Power)	841
Samsung	X210	1	Samsung SP-Bid -BHandset (No Power)	842
Samsung	X216B	1	Samsung SP-Bid -BHandset (No Power)	843
Demo SP-Bid -	Demo SP Bid.- Total	23	Summary	844
Samsung	F946B	1	Demo SP-Bid -14A(Good)	845
Samsung	A047F	2	Demo SP-Bid -AHandset	846
Samsung	A155F	1	Demo SP-Bid -AHandset	847
Samsung	A205	2	Demo SP-Bid -AHandset	848
Samsung	A217F	1	Demo SP-Bid -AHandset	849
Samsung	A256B	1	Demo SP-Bid -AHandset	850
Samsung	A556B	2	Demo SP-Bid -AHandset	851
Samsung	S711B	1	Demo SP-Bid -AHandset	852
Samsung	S911B	1	Demo SP-Bid -AHandset	853
Samsung	S916B	2	Demo SP-Bid -AHandset	854
Samsung	A035-1	1	Demo SP-Bid -BHandset (Power Up, Good LCD)	855
Samsung	A405F	1	Demo SP-Bid -BHandset (Power Up, Good LCD)	856
Samsung	A715F	5	Demo SP-Bid -BHandset (Power Up, Good LCD)	857
Samsung	G781B	2	Demo SP-Bid -AHandset (LCD 1)	858

Apple	iPhone 16 Pro Max Total(Mostly Dual-Sim)	11	Summary	859
Apple	iPhone 16 Pro Max (512GB)SIM Free	1	In Warranty-Nearly New(Full Fuction)	860
Apple	iPhone 16 Pro Max (256GB)SIM Free	2	In Warranty-AHandset (Good)(Full Fuction)	861
Apple	iPhone 16 Pro Max (256GB)SIM Free	1	In Warranty-AHandset (Good 1)(Full Fuction)	862
Apple	iPhone 16 Pro Max (256GB)SIM Free	1	In Warranty-AHandset (Good 1)(Broken Back Glass)(Full Fuction)	863
Apple	iPhone 16 Pro Max (256GB)SIM Free	3	In Warranty-BHandset (Power Up, Bad LCD)(FidWorking)	864
Apple	iPhone 16 Pro Max (512GB)SIM Free	1	In Warranty-BHandset (Power Up, Bad LCD)(FidWorking)	865
Apple	iPhone 16 Pro Max (256GB)SIM Free	1	In Warranty-BHandset (Power Up, Bad LCD)	866
Apple	iPhone 16 Pro Max (1Tb)SIM Free	1	BHandset (only electricity)	867
Apple	iPhone 16 Pro Total(Mostly Dual-Sim)	7	Summary	868
Apple	iPhone 16 Pro (256GB)SIM Free	1	In Warranty-AHandset (Good 1)(Broken Back Glass)(Full Fuction)	869
Apple	iPhone 16 Pro (256GB)SIM Free	1	In Warranty-BHandset (Power Up, Good LCD)(Full Fuction)	870
Apple	iPhone 16 Pro (128GB)SIM Free	2	In Warranty-BHandset (Power Up, Bad LCD)(FidWorking)	871
Apple	iPhone 16 Pro (128GB)SIM Free	2	In Warranty-BHandset (Power Up, Bad LCD)	872
Apple	iPhone 16 Pro (256GB)SIM Free	1	In Warranty-BHandset (Power Up, Bad LCD)	873
Apple	iPhone 16 Plus Total(Mostly Dual-Sim)	1	Summary	874
Apple	iPhone 16 Plus (128GB)SIM Free	1	In Warranty-BHandset (Power Up, Bad LCD)	875
Apple	iPhone 16 Total(Mostly Dual-Sim)	2	Summary	876
Apple	iPhone 16 (128GB)SIM Free	1	In Warranty-BHandset (Power Up, Bad LCD)	877
Apple	iPhone 16 (256GB) (SIM FreeProblematic)	1	Part 2 BHandset (Power Up, Good LCD)	878
Apple	iPhone 15 Pro Max Total(Mostly Dual-Sim)	253	Summary	879
Apple	iPhone 15 Pro Max (256GB)SIM Free	1	In Warranty-AHandset (Good)(Full Fuction)	880
Apple	iPhone 15 Pro Max (256GB)SIM Free	2	In Warranty-AHandset (Good)(Broken Back Glass)(Full Fuction)	881
Apple	iPhone 15 Pro Max (256GB)SIM Free	4	In Warranty-AHandset (Good 1)(Full Fuction)	882
Apple	iPhone 15 Pro Max (256GB)SIM Free	1	In Warranty-AHandset (Good 1)(Broken Back Glass)(Full Fuction)	883
Apple	iPhone 15 Pro Max (512GB)SIM Free	1	In Warranty-AHandset (Good 1)(Broken Back Glass)(Full Fuction)	884
Apple	iPhone 15 Pro Max (256GB)SIM Free	1	In Warranty-AHandset (Full Fuction)	885
Apple	iPhone 15 Pro Max (256GB)SIM Free	1	AHandset (Broken Back Glass)(Full Fuction)	886
Apple	iPhone 15 Pro Max (256GB)SIM Free	6	In Warranty-AHandset (Broken Back Glass)(Full Fuction)	887
Apple	iPhone 15 Pro Max (1Tb)SIM Free	1	In Warranty-BHandset (Power Up, Good LCD)(Full Fuction)	888
Apple	iPhone 15 Pro Max (256GB)SIM Free	8	In Warranty-BHandset (Power Up, Good LCD)(Full Fuction)	889
Apple	iPhone 15 Pro Max (256GB)SIM Free	2	BHandset (Power Up, Good LCD)(Full Fuction)	890
Apple	iPhone 15 Pro Max (512GB)SIM Free	1	BHandset (Power Up, Good LCD)(Full Fuction)	891
Apple	iPhone 15 Pro Max (256GB)SIM Free	1	In Warranty-BHandset (Power Up, Good LCD)(Full Fuction)(unknow part message)	892
Apple	iPhone 15 Pro Max (256GB)SIM Free	16	In Warranty-BHandset (Power Up, Bad LCD)(FidWorking)	893
Apple	iPhone 15 Pro Max (512GB)SIM Free	2	In Warranty-BHandset (Power Up, Bad LCD)(FidWorking)	894
Apple	iPhone 15 Pro Max (512GB)SIM Free	1	BHandset (Power Up, Bad LCD)(FidWorking)	895
Apple	iPhone 15 Pro Max (1Tb)SIM Free	2	In Warranty-BHandset (Power Up, Bad LCD)	896
Apple	iPhone 15 Pro Max (256GB)SIM Free	42	In Warranty-BHandset (Power Up, Bad LCD)	897
Apple	iPhone 15 Pro Max (512GB)SIM Free	4	In Warranty-BHandset (Power Up, Bad LCD)	898
Apple	iPhone 15 Pro Max (1Tb)SIM Free	3	BHandset (Power Up, Bad LCD)	899
Apple	iPhone 15 Pro Max (256GB)SIM Free	55	BHandset (Power Up, Bad LCD)	900
Apple	iPhone 15 Pro Max (512GB)SIM Free	12	BHandset (Power Up, Bad LCD)	901
Apple	iPhone 15 Pro Max (256GB)SIM Free	28	BHandset (only electricity)	902
Apple	iPhone 15 Pro Max (512GB)SIM Free	1	BHandset (only electricity)	903
Apple	iPhone 15 Pro Max (1Tb)	1	Part 2 BHandset (only electricity)	904
Apple	iPhone 15 Pro Max (256GB)SIM Free	8	SP Bid-No Power On-Change Battery(Reference Only)	905
Apple	iPhone 15 Pro Max (512GB)SIM Free	2	SP Bid-No Power On-Change Battery(Reference Only)	906
Apple	iPhone 15 Pro Max (256GB) (SIM FreeProblematic)	1	Part 2 AHandset	907
Apple	iPhone 15 Pro Max (512GB) (SIM FreeProblematic)	1	Part 2 AHandset	908
Apple	iPhone 15 Pro Max (512GB) (SIM FreeProblematic)	1	Part 2 BHandset (Power Up, Good LCD)	909
Apple	iPhone 15 Pro Max (256GB) (SIM FreeProblematic)	26	Part 2 BHandset (Power Up, Bad LCD)	910
Apple	iPhone 15 Pro Max (256GB) (SIM Freefid)	1	Part 2 AHandset	911
Apple	iPhone 15 Pro Max (256GB)	3	Part 2 AHandset	912
Apple	iPhone 15 Pro Max (512GB)	1	Part 2 AHandset	913
Apple	iPhone 15 Pro Max (256GB)	9	Part 2 BHandset (Power Up, Bad LCD)	914
Apple	iPhone 15 Pro Max (512GB)	1	Part 2 BHandset (Power Up, Bad LCD)	915
Apple	iPhone 15 Pro Max (256GB)	1	Part 2 BHandset (only electricity)	916
Apple	iPhone 15 Pro Max (256GB)	1	Mainboard	917
Apple	iPhone 15 Pro Total(Mostly Dual-Sim)	120	Summary	918
Apple	iPhone 15 Pro (128GB)SIM Free	3	In Warranty-AHandset (Good)(Broken Back Glass)(Full Fuction)	919
Apple	iPhone 15 Pro (128GB)SIM Free	1	In Warranty-AHandset (Good 1)(Full Fuction)	920
Apple	iPhone 15 Pro (256GB)SIM Free	1	AHandset (Good 1)(Full Fuction)	921
Apple	iPhone 15 Pro (512GB)SIM Free	1	AHandset (Good 1)(Full Fuction)	922
Apple	iPhone 15 Pro (128GB)SIM Free	1	In Warranty-AHandset (Good 1)(Broken Back Glass)(Full Fuction)	923
Apple	iPhone 15 Pro (128GB)SIM Free	1	In Warranty-AHandset (Broken Back Glass)(Full Fuction)	924
Apple	iPhone 15 Pro (256GB)SIM Free	1	In Warranty-AHandset (Broken Back Glass)(Full Fuction)	925
Apple	iPhone 15 Pro (512GB)SIM Free	1	In Warranty-AHandset (Broken Back Glass)(Full Fuction)	926
Apple	iPhone 15 Pro (128GB)SIM Free	1	AHandset (Broken Back Glass)	927
Apple	iPhone 15 Pro (128GB)SIM Free	1	In Warranty-BHandset (Power Up, Good LCD)(Full Fuction)	928
Apple	iPhone 15 Pro (512GB)SIM Free	2	In Warranty-BHandset (Power Up, Good LCD)(Full Fuction)	929
Apple	iPhone 15 Pro (128GB)SIM Free	1	BHandset (Power Up, Good LCD)(Full Fuction)	930
Apple	iPhone 15 Pro (256GB)SIM Free	1	In Warranty-BHandset (Power Up, Good LCD)	931
Apple	iPhone 15 Pro (128GB)SIM Free	1	BHandset (Power Up, Good LCD)	932
Apple	iPhone 15 Pro (128GB)SIM Free	1	In Warranty-BHandset (Power Up, Good LCD)(Full Fuction)(unknow part message)	933
Apple	iPhone 15 Pro (128GB)SIM Free	6	In Warranty-BHandset (Power Up, Bad LCD)(FidWorking)	934
Apple	iPhone 15 Pro (256GB)SIM Free	1	In Warranty-BHandset (Power Up, Bad LCD)(FidWorking)	935
Apple	iPhone 15 Pro (512GB)SIM Free	1	In Warranty-BHandset (Power Up, Bad LCD)(FidWorking)	936
Apple	iPhone 15 Pro (256GB)SIM Free	1	BHandset (Power Up, Bad LCD)(FidWorking)	937
Apple	iPhone 15 Pro (128GB)SIM Free	22	In Warranty-BHandset (Power Up, Bad LCD)	938
Apple	iPhone 15 Pro (256GB)SIM Free	6	In Warranty-BHandset (Power Up, Bad LCD)	939
Apple	iPhone 15 Pro (512GB)SIM Free	1	In Warranty-BHandset (Power Up, Bad LCD)	940
Apple	iPhone 15 Pro (128GB)SIM Free	6	BHandset (Power Up, Bad LCD)	941
Apple	iPhone 15 Pro (256GB)SIM Free	4	BHandset (Power Up, Bad LCD)	942
Apple	iPhone 15 Pro (512GB)SIM Free	1	BHandset (Power Up, Bad LCD)	943
Apple	iPhone 15 Pro (1Tb)	1	Part 2 BHandset (Power Up, Bad LCD)	944

Apple	iPhone 15 Pro (128GB)SIM Free	12	BHandset (only electricity)	945
Apple	iPhone 15 Pro (256GB)SIM Free	1	BHandset (only electricity)	946
Apple	iPhone 15 Pro (128GB)SIM Free	5	SP Bid-No Power On-Change Battery(Reference Only)	947
Apple	iPhone 15 Pro (256GB)SIM Free	2	SP Bid-No Power On-Change Battery(Reference Only)	948
Apple	iPhone 15 Pro (128GB) (SIM FreeProblematic)	1	Part 2 AHandset	949
Apple	iPhone 15 Pro (128GB) (SIM FreeProblematic)	14	Part 2 BHandset (Power Up, Bad LCD)	950
Apple	iPhone 15 Pro (256GB) (SIM FreeProblematic)	5	Part 2 BHandset (Power Up, Bad LCD)	951
Apple	iPhone 15 Pro (256GB) (SIM FreeProblematic)	1	Part 2 BHandset (only electricity)	952
Apple	iPhone 15 Pro (128GB)	1	Part 2 AHandset	953
Apple	iPhone 15 Pro (256GB)	1	Part 2 BHandset (Power Up, Good LCD)	954
Apple	iPhone 15 Pro (128GB)	5	Part 2 BHandset (Power Up, Bad LCD)	955
Apple	iPhone 15 Pro (256GB)	2	Part 2 BHandset (Power Up, Bad LCD)	956
Apple	iPhone 15 Pro (128GB) (Problematic)	2	Part 2 BHandset (Power Up, Good LCD)	957
Apple	iPhone 15 Plus Total(Mostly Dual-Sim)	96	Summary	958
Apple	iPhone 15 Plus (128GB)SIM Free	2	In Warranty-AHandset (Good 1)(Full Fuction)	959
Apple	iPhone 15 Plus (128GB)SIM Free	2	AHandset (Good 1)(Broken Back Glass)(Full Fuction)	960
Apple	iPhone 15 Plus (128GB)SIM Free	2	In Warranty-AHandset (Good 1)(Broken Back Glass)(Full Fuction)	961
Apple	iPhone 15 Plus (128GB)SIM Free	1	AHandset (Good 1)(Full Fuction)(unknow part message)	962
Apple	iPhone 15 Plus (128GB)SIM Free	1	In Warranty-AHandset (Full Fuction)	963
Apple	iPhone 15 Plus (128GB)SIM Free	1	In Warranty-AHandset (Broken Back Glass)(Full Fuction)	964
Apple	iPhone 15 Plus (128GB)SIM Free	1	AHandset	965
Apple	iPhone 15 Plus (128GB)SIM Free	1	AHandset (Bad Back Camera Glass)	966
Apple	iPhone 15 Plus (128GB)SIM Free	4	In Warranty-BHandset (Power Up, Good LCD)(Full Fuction)	967
Apple	iPhone 15 Plus (128GB)SIM Free	7	BHandset (Power Up, Good LCD)(Full Fuction)	968
Apple	iPhone 15 Plus (128GB)SIM Free	1	BHandset (Power Up, Good LCD)	969
Apple	iPhone 15 Plus (256GB)SIM Free	1	BHandset (Power Up, Good LCD)	970
Apple	iPhone 15 Plus (128GB)SIM Free	1	BHandset (Power Up, Good LCD)(Full Fuction)(unknow part message)	971
Apple	iPhone 15 Plus (128GB)SIM Free	2	In Warranty-BHandset (Power Up, Bad LCD)(FidWorking)	972
Apple	iPhone 15 Plus (256GB)SIM Free	1	BHandset (Power Up, Bad LCD)(FidWorking)	973
Apple	iPhone 15 Plus (128GB)SIM Free	2	In Warranty-BHandset (Power Up, Bad LCD)	974
Apple	iPhone 15 Plus (128GB)SIM Free	30	BHandset (Power Up, Bad LCD)	975
Apple	iPhone 15 Plus (256GB)SIM Free	4	BHandset (Power Up, Bad LCD)	976
Apple	iPhone 15 Plus (512GB)SIM Free	1	BHandset (Power Up, Bad LCD)	977
Apple	iPhone 15 Plus (128GB)SIM Free	10	BHandset (only electricity)	978
Apple	iPhone 15 Plus (256GB)SIM Free	1	BHandset (only electricity)	979
Apple	iPhone 15 Plus (128GB)SIM Free	1	SP Bid-No Power On-Change Battery(Reference Only)	980
Apple	iPhone 15 Plus (128GB) (SIM FreeProblematic)	1	Part 2 In Warranty-AHandset	981
Apple	iPhone 15 Plus (128GB) (SIM FreeProblematic)	1	Part 2 AHandset	982
Apple	iPhone 15 Plus (128GB) (SIM FreeProblematic)	1	Part 2 In Warranty-BHandset (Power Up, Good LCD)	983
Apple	iPhone 15 Plus (128GB) (SIM FreeProblematic)	1	Part 2 BHandset (Power Up, Good LCD)	984
Apple	iPhone 15 Plus (128GB) (SIM FreeProblematic)	12	Part 2 BHandset (Power Up, Bad LCD)	985
Apple	iPhone 15 Plus (128GB)	2	Part 2 BHandset (Power Up, Bad LCD)	986
Apple	iPhone 15 Plus (512GB)	1	Part 2 BHandset (Power Up, Bad LCD)	987
Apple	iPhone 15 Total(Mostly Dual-Sim)	144	Summary	988
Apple	iPhone 15 (128GB)SIM Free	1	In Warranty-AHandset (Good)(Broken Back Glass)(Full Fuction)	989
Apple	iPhone 15 (128GB)SIM Free	1	AHandset (Good)(Bad Back Camera Glass)	990
Apple	iPhone 15 (128GB)SIM Free	3	AHandset (Good 1)(Broken Back Glass)(Full Fuction)	991
Apple	iPhone 15 (128GB)SIM Free	1	In Warranty-AHandset (Good 1)(Broken Back Glass)(Full Fuction)	992
Apple	iPhone 15 (256GB)SIM Free	2	In Warranty-AHandset (Good 1)(Broken Back Glass)(Full Fuction)	993
Apple	iPhone 15 (128GB)SIM Free	1	AHandset (Good 1)(Full Fuction)(unknow part message)	994
Apple	iPhone 15 (128GB)SIM Free	1	In Warranty-14A(Good)(Full Fuction)	995
Apple	iPhone 15 (128GB)SIM Free	2	In Warranty-AHandset (Full Fuction)	996
Apple	iPhone 15 (256GB)SIM Free	1	In Warranty-AHandset (Full Fuction)	997
Apple	iPhone 15 (128GB)SIM Free	1	AHandset (Full Fuction)	998
Apple	iPhone 15 (128GB)SIM Free	1	AHandset (Broken Back Glass)(Full Fuction)	999
Apple	iPhone 15 (128GB)SIM Free	3	In Warranty-AHandset (Broken Back Glass)(Full Fuction)	1000
Apple	iPhone 15 (128GB)SIM Free	8	In Warranty-BHandset (Power Up, Good LCD)(Full Fuction)	1001
Apple	iPhone 15 (128GB)SIM Free	1	BHandset (Power Up, Good LCD)(Full Fuction)	1002
Apple	iPhone 15 (256GB)SIM Free	1	BHandset (Power Up, Good LCD)(Full Fuction)	1003
Apple	iPhone 15 (128GB)SIM Free	2	BHandset (Power Up, Good LCD)(Full Fuction)(unknow part message)	1004
Apple	iPhone 15 (128GB)SIM Free	1	BHandset (Power Up, Good LCD)(unknow part message)	1005
Apple	iPhone 15 (128GB)SIM Free	2	BHandset (Power Up, Bad LCD)(Full Fuction)	1006
Apple	iPhone 15 (128GB)SIM Free	6	In Warranty-BHandset (Power Up, Bad LCD)(FidWorking)	1007
Apple	iPhone 15 (256GB)SIM Free	1	In Warranty-BHandset (Power Up, Bad LCD)(FidWorking)	1008
Apple	iPhone 15 (128GB)SIM Free	2	BHandset (Power Up, Bad LCD)(FidWorking)	1009
Apple	iPhone 15 (128GB)SIM Free	17	In Warranty-BHandset (Power Up, Bad LCD)	1010
Apple	iPhone 15 (256GB)SIM Free	1	In Warranty-BHandset (Power Up, Bad LCD)	1011
Apple	iPhone 15 (128GB)SIM Free	6	BHandset (Power Up, Bad LCD)	1012
Apple	iPhone 15 (256GB)SIM Free	3	BHandset (Power Up, Bad LCD)	1013
Apple	iPhone 15 (128GB)SIM Free	26	BHandset (only electricity)	1014
Apple	iPhone 15 (256GB)SIM Free	1	BHandset (only electricity)	1015
Apple	iPhone 15 (128GB)SIM Free	14	SP Bid-No Power On-Change Battery(Reference Only)	1016
Apple	iPhone 15 (128GB) (SIM FreeProblematic)	1	Part 2 Non-Active-AHandset	1017
Apple	iPhone 15 (128GB) (SIM FreeProblematic)	2	Part 2 AHandset	1018
Apple	iPhone 15 (128GB) (SIM FreeProblematic)	6	Part 2 BHandset (Power Up, Good LCD)	1019
Apple	iPhone 15 (128GB) (SIM FreeProblematic)	17	Part 2 BHandset (Power Up, Bad LCD)	1020
Apple	iPhone 15 (256GB) (SIM FreeProblematic)	1	Part 2 BHandset (Power Up, Bad LCD)	1021
Apple	iPhone 15 (128GB) (SIM Freefid)	1	Part 2 In Warranty-AHandset	1022
Apple	iPhone 15 (128GB) (SIM Freefid)	1	Part 2 AHandset (unknow part message)	1023
Apple	iPhone 15 (128GB)	1	Part 2 AHandset	1024
Apple	iPhone 15 (128GB)	1	Part 2 BHandset (only electricity)	1025
Apple	iPhone 15 (128GB) (Problematic)	3	Part 2 BHandset (Power Up, Bad LCD)	1026
Apple	iPhone 14 Pro Max Total(Mostly Dual-Sim)	816	Summary	1027
Apple	iPhone 14 Pro Max (128GB)SIM Free	1	In Warranty-AHandset (Good)(Bad Back Camera Glass)(Full Fuction)	1028
Apple	iPhone 14 Pro Max (256GB)SIM Free	1	In Warranty-AHandset (Good)(Broken Back Glass)(Full Fuction)	1029
Apple	iPhone 14 Pro Max (128GB)SIM Free	1	AHandset (Good)(unknow part message)	1030

Apple	iPhone 14 Pro Max (128GB)SIM Free	1	In Warranty-AHandset (Good 1)(Full Fuction)	1031
Apple	iPhone 14 Pro Max (256GB)SIM Free	1	In Warranty-AHandset (Good 1)(Full Fuction)	1032
Apple	iPhone 14 Pro Max (128GB)SIM Free	2	AHandset (Good 1)(Full Fuction)	1033
Apple	iPhone 14 Pro Max (1Tb)SIM Free	1	AHandset (Good 1)(Full Fuction)	1034
Apple	iPhone 14 Pro Max (128GB)SIM Free	3	AHandset (Good 1)(Broken Back Glass)(Full Fuction)	1035
Apple	iPhone 14 Pro Max (256GB)SIM Free	1	In Warranty-AHandset (Good 1)(Bad Back Camera Glass)(Full Fuction)	1036
Apple	iPhone 14 Pro Max (128GB)SIM Free	8	In Warranty-AHandset (Good 1)(Broken Back Glass)(Full Fuction)	1037
Apple	iPhone 14 Pro Max (256GB)SIM Free	4	In Warranty-AHandset (Good 1)(Broken Back Glass)(Full Fuction)	1038
Apple	iPhone 14 Pro Max (512GB)SIM Free	1	In Warranty-AHandset (Good 1)(Broken Back Glass)(Full Fuction)	1039
Apple	iPhone 14 Pro Max (128GB)SIM Free	1	In Warranty-AHandset (Good 1)(Full Fuction)(unknow part message)	1040
Apple	iPhone 14 Pro Max (256GB)SIM Free	1	Warranty-AHandset (Good 1)(Broken Back Glass)(Full Fuction)(unknow part message)	1041
Apple	iPhone 14 Pro Max (128GB)SIM Free	1	In Warranty-AHandset (Full Fuction)	1042
Apple	iPhone 14 Pro Max (256GB)SIM Free	1	In Warranty-AHandset (Full Fuction)	1043
Apple	iPhone 14 Pro Max (128GB)SIM Free	6	AHandset (Broken Back Glass)(Full Fuction)	1044
Apple	iPhone 14 Pro Max (256GB)SIM Free	5	AHandset (Broken Back Glass)(Full Fuction)	1045
Apple	iPhone 14 Pro Max (128GB)SIM Free	16	In Warranty-AHandset (Broken Back Glass)(Full Fuction)	1046
Apple	iPhone 14 Pro Max (256GB)SIM Free	2	In Warranty-AHandset (Broken Back Glass)(Full Fuction)	1047
Apple	iPhone 14 Pro Max (128GB)SIM Free	4	AHandset (Broken Back Glass)	1048
Apple	iPhone 14 Pro Max (256GB)SIM Free	1	AHandset (Broken Back Glass)	1049
Apple	iPhone 14 Pro Max (128GB)SIM Free	1	AHandset (Full Fuction)(unknow part message)	1050
Apple	iPhone 14 Pro Max (128GB)SIM Free	1	In Warranty-AHandset (Broken Back Glass)(Full Fuction)(unknow part message)	1051
Apple	iPhone 14 Pro Max (256GB)SIM Free	14	AHandset (unknow part message)	1052
Apple	iPhone 14 Pro Max (512GB)SIM Free	1	AHandset (unknow part message)	1053
Apple	iPhone 14 Pro Max (128GB)SIM Free	10	AHandset (Broken Back Glass)(unknow part message)	1054
Apple	iPhone 14 Pro Max (1Tb)	2	Part 2 AHandset	1055
Apple	iPhone 14 Pro Max (128GB)SIM Free	13	In Warranty-BHandset (Power Up, Good LCD)(Full Fuction)	1056
Apple	iPhone 14 Pro Max (1Tb)SIM Free	1	In Warranty-BHandset (Power Up, Good LCD)(Full Fuction)	1057
Apple	iPhone 14 Pro Max (256GB)SIM Free	5	In Warranty-BHandset (Power Up, Good LCD)(Full Fuction)	1058
Apple	iPhone 14 Pro Max (512GB)SIM Free	1	In Warranty-BHandset (Power Up, Good LCD)(Full Fuction)	1059
Apple	iPhone 14 Pro Max (128GB)SIM Free	1	BHandset (Power Up, Good LCD)(Full Fuction)	1060
Apple	iPhone 14 Pro Max (128GB)SIM Free	6	BHandset (Power Up, Good LCD)	1061
Apple	iPhone 14 Pro Max (1Tb)SIM Free	1	BHandset (Power Up, Good LCD)	1062
Apple	iPhone 14 Pro Max (256GB)SIM Free	2	BHandset (Power Up, Good LCD)	1063
Apple	iPhone 14 Pro Max (512GB)SIM Free	1	BHandset (Power Up, Good LCD)	1064
Apple	iPhone 14 Pro Max (128GB)SIM Free	7	BHandset (Power Up, Good LCD)(Full Fuction)(unknow part message)	1065
Apple	iPhone 14 Pro Max (128GB)SIM Free	1	BHandset (Power Up, Good LCD)(unknow part message)	1066
Apple	iPhone 14 Pro Max (256GB)SIM Free	2	BHandset (Power Up, Good LCD)(unknow part message)	1067
Apple	iPhone 14 Pro Max (512GB)SIM Free	1	BHandset (Power Up, Good LCD)(unknow part message)	1068
Apple	iPhone 14 Pro Max (128GB)SIM Free	4	BHandset (Power Up, Bad LCD)(Full Fuction)	1069
Apple	iPhone 14 Pro Max (256GB)SIM Free	3	BHandset (Power Up, Bad LCD)(Full Fuction)	1070
Apple	iPhone 14 Pro Max (128GB)SIM Free	8	In Warranty-BHandset (Power Up, Bad LCD)(FidWorking)	1071
Apple	iPhone 14 Pro Max (256GB)SIM Free	4	In Warranty-BHandset (Power Up, Bad LCD)(FidWorking)	1072
Apple	iPhone 14 Pro Max (128GB)SIM Free	11	BHandset (Power Up, Bad LCD)(FidWorking)	1073
Apple	iPhone 14 Pro Max (256GB)SIM Free	4	BHandset (Power Up, Bad LCD)(FidWorking)	1074
Apple	iPhone 14 Pro Max (128GB)SIM Free	29	In Warranty-BHandset (Power Up, Bad LCD)	1075
Apple	iPhone 14 Pro Max (256GB)SIM Free	10	In Warranty-BHandset (Power Up, Bad LCD)	1076
Apple	iPhone 14 Pro Max (512GB)SIM Free	3	In Warranty-BHandset (Power Up, Bad LCD)	1077
Apple	iPhone 14 Pro Max (128GB)SIM Free	241	BHandset (Power Up, Bad LCD)	1078
Apple	iPhone 14 Pro Max (1Tb)SIM Free	7	BHandset (Power Up, Bad LCD)	1079
Apple	iPhone 14 Pro Max (256GB)SIM Free	28	BHandset (Power Up, Bad LCD)	1080
Apple	iPhone 14 Pro Max (512GB)SIM Free	18	BHandset (Power Up, Bad LCD)	1081
Apple	iPhone 14 Pro Max (1Tb)	2	Part 2 BHandset (Power Up, Bad LCD)	1082
Apple	iPhone 14 Pro Max (128GB)SIM Free	56	BHandset (only electricity)	1083
Apple	iPhone 14 Pro Max (256GB)SIM Free	10	BHandset (only electricity)	1084
Apple	iPhone 14 Pro Max (128GB)SIM Free	85	SP Bid-No Power On-Change Battery(Reference Only)	1085
Apple	iPhone 14 Pro Max (256GB)SIM Free	9	SP Bid-No Power On-Change Battery(Reference Only)	1086
Apple	iPhone 14 Pro Max (128GB) (SIM FreeProblematic)	1	Part 2 AHandset	1087
Apple	iPhone 14 Pro Max (128GB) (SIM FreeProblematic)	1	Part 2 BHandset (Power Up, Good LCD)	1088
Apple	iPhone 14 Pro Max (128GB) (SIM FreeProblematic)	1	Part 2 BHandset (Power Up, Good LCD)(unknow part message)	1089
Apple	iPhone 14 Pro Max (256GB) (SIM FreeProblematic)	1	Part 2 BHandset (Power Up, Good LCD)(unknow part message)	1090
Apple	iPhone 14 Pro Max (128GB) (SIM FreeProblematic)	70	Part 2 BHandset (Power Up, Bad LCD)	1091
Apple	iPhone 14 Pro Max (256GB) (SIM FreeProblematic)	2	Part 2 BHandset (Power Up, Bad LCD)	1092
Apple	iPhone 14 Pro Max (128GB) (SIM FreeProblematic)	1	Part 2 BHandset (only electricity)	1093
Apple	iPhone 14 Pro Max (128GB) (SIM Freefid)	2	Part 2 AHandset	1094
Apple	iPhone 14 Pro Max (256GB) (SIM Freefid)	2	Part 2 AHandset	1095
Apple	iPhone 14 Pro Max (128GB) (SIM Freefid)	1	Part 2 AHandset (unknow part message)	1096
Apple	iPhone 14 Pro Max (256GB) (SIM Freefid)	1	Part 2 AHandset (unknow part message)	1097
Apple	iPhone 14 Pro Max (128GB) (SIM Freefid)	1	Part 2 BHandset (Power Up, Good LCD)	1098
Apple	iPhone 14 Pro Max (128GB)	5	Part 2 AHandset	1099
Apple	iPhone 14 Pro Max (256GB)	4	Part 2 AHandset	1100
Apple	iPhone 14 Pro Max (512GB)	2	Part 2 AHandset	1101
Apple	iPhone 14 Pro Max (128GB)	2	Part 2 BHandset (Power Up, Good LCD)	1102
Apple	iPhone 14 Pro Max (256GB)	4	Part 2 BHandset (Power Up, Good LCD)	1103
Apple	iPhone 14 Pro Max (512GB)	2	Part 2 BHandset (Power Up, Good LCD)	1104
Apple	iPhone 14 Pro Max (128GB)	13	Part 2 BHandset (Power Up, Bad LCD)	1105
Apple	iPhone 14 Pro Max (256GB)	10	Part 2 BHandset (Power Up, Bad LCD)	1106
Apple	iPhone 14 Pro Max (512GB)	2	Part 2 BHandset (Power Up, Bad LCD)	1107
Apple	iPhone 14 Pro Max (128GB)	1	Part 2 BHandset (only electricity)	1108
Apple	iPhone 14 Pro Max (128GB)	4	Part 2 SP Bid-No Power On-Change Battery(Reference Only)	1109
Apple	iPhone 14 Pro Max (512GB)	2	Part 2 SP Bid-No Power On-Change Battery(Reference Only)	1110
Apple	iPhone 14 Pro Max (128GB)	7	Mainboard	1111
Apple	iPhone 14 Pro Max (256GB)	1	Mainboard	1112
Apple	iPhone 14 Pro Max (128GB) (Problematic)	2	Part 2 AHandset	1113
Apple	iPhone 14 Pro Max (128GB) (Problematic)	1	Part 2 BHandset (Power Up, Good LCD)	1114
Apple	iPhone 14 Pro Max (256GB) (Problematic)	2	Part 2 BHandset (Power Up, Good LCD)	1115
Apple	iPhone 14 Pro Max (128GB) (Problematic)	2	Part 2 BHandset (Power Up, Bad LCD)	1116

Apple	iPhone 14 Pro Total(Mostly Dual-Sim)	524	Summary	1117
Apple	iPhone 14 Pro (512GB)SIM Free	1	In Warranty-AHandset (Good 1)(Full Fuction)	1118
Apple	iPhone 14 Pro (256GB)SIM Free	2	AHandset (Good 1)(Full Fuction)	1119
Apple	iPhone 14 Pro (128GB)SIM Free	7	AHandset (Good 1)(Broken Back Glass)(Full Fuction)	1120
Apple	iPhone 14 Pro (256GB)SIM Free	2	AHandset (Good 1)(Broken Back Glass)(Full Fuction)	1121
Apple	iPhone 14 Pro (128GB)SIM Free	8	In Warranty-AHandset (Good 1)(Broken Back Glass)(Full Fuction)	1122
Apple	iPhone 14 Pro (256GB)SIM Free	2	In Warranty-AHandset (Good 1)(Broken Back Glass)(Full Fuction)	1123
Apple	iPhone 14 Pro (512GB)SIM Free	1	In Warranty-AHandset (Good 1)(Full Fuction)(unknow part message)	1124
Apple	iPhone 14 Pro (128GB)SIM Free	1	In Warranty-AHandset (Full Fuction)	1125
Apple	iPhone 14 Pro (512GB)SIM Free	1	In Warranty-AHandset (Full Fuction)	1126
Apple	iPhone 14 Pro (128GB)SIM Free	3	AHandset (Full Fuction)	1127
Apple	iPhone 14 Pro (256GB)SIM Free	1	AHandset (Full Fuction)	1128
Apple	iPhone 14 Pro (128GB)SIM Free	4	AHandset (Broken Back Glass)(Full Fuction)	1129
Apple	iPhone 14 Pro (256GB)SIM Free	3	AHandset (Broken Back Glass)(Full Fuction)	1130
Apple	iPhone 14 Pro (256GB)SIM Free	1	In Warranty-AHandset (Bad Back Camera Glass)(Full Fuction)	1131
Apple	iPhone 14 Pro (128GB)SIM Free	11	In Warranty-AHandset (Broken Back Glass)(Full Fuction)	1132
Apple	iPhone 14 Pro (256GB)SIM Free	2	In Warranty-AHandset (Broken Back Glass)(Full Fuction)	1133
Apple	iPhone 14 Pro (512GB)SIM Free	1	In Warranty-AHandset (Broken Back Glass)(Full Fuction)	1134
Apple	iPhone 14 Pro (256GB)SIM Free	2	AHandset	1135
Apple	iPhone 14 Pro (256GB)SIM Free	1	AHandset (Broken Back Glass)	1136
Apple	iPhone 14 Pro (256GB)SIM Free	2	AHandset (Full Fuction)(unknow part message)	1137
Apple	iPhone 14 Pro (128GB)SIM Free	1	AHandset (Broken Back Glass)(Full Fuction)(unknow part message)	1138
Apple	iPhone 14 Pro (256GB)SIM Free	3	AHandset (Broken Back Glass)(Full Fuction)(unknow part message)	1139
Apple	iPhone 14 Pro (512GB)SIM Free	1	AHandset (Broken Back Glass)(Full Fuction)(unknow part message)	1140
Apple	iPhone 14 Pro (128GB)SIM Free	10	AHandset (unknow part message)	1141
Apple	iPhone 14 Pro (256GB)SIM Free	7	AHandset (unknow part message)	1142
Apple	iPhone 14 Pro (128GB)SIM Free	2	AHandset (Broken Back Glass)(unknow part message)	1143
Apple	iPhone 14 Pro (256GB)SIM Free	1	AHandset (Broken Back Glass)(unknow part message)	1144
Apple	iPhone 14 Pro (512GB)SIM Free	1	AHandset (Broken Back Glass)(unknow part message)	1145
Apple	iPhone 14 Pro (128GB)SIM Free	7	In Warranty-BHandset (Power Up, Good LCD)(Full Fuction)	1146
Apple	iPhone 14 Pro (256GB)SIM Free	2	In Warranty-BHandset (Power Up, Good LCD)(Full Fuction)	1147
Apple	iPhone 14 Pro (128GB)SIM Free	10	BHandset (Power Up, Good LCD)(Full Fuction)	1148
Apple	iPhone 14 Pro (256GB)SIM Free	6	BHandset (Power Up, Good LCD)(Full Fuction)	1149
Apple	iPhone 14 Pro (128GB)SIM Free	1	BHandset (Power Up, Good LCD)(Full Fuction)(unknow part message)	1150
Apple	iPhone 14 Pro (256GB)SIM Free	2	BHandset (Power Up, Good LCD)(Full Fuction)(unknow part message)	1151
Apple	iPhone 14 Pro (128GB)SIM Free	2	BHandset (Power Up, Good LCD)(unknow part message)	1152
Apple	iPhone 14 Pro (512GB)SIM Free	1	BHandset (Power Up, Good LCD)(unknow part message)	1153
Apple	iPhone 14 Pro (128GB)SIM Free	6	BHandset (Power Up, Bad LCD)(Full Fuction)	1154
Apple	iPhone 14 Pro (256GB)SIM Free	1	BHandset (Power Up, Bad LCD)(Full Fuction)	1155
Apple	iPhone 14 Pro (128GB)SIM Free	3	In Warranty-BHandset (Power Up, Bad LCD)(FidWorking)	1156
Apple	iPhone 14 Pro (256GB)SIM Free	4	In Warranty-BHandset (Power Up, Bad LCD)(FidWorking)	1157
Apple	iPhone 14 Pro (512GB)SIM Free	1	In Warranty-BHandset (Power Up, Bad LCD)(FidWorking)	1158
Apple	iPhone 14 Pro (128GB)SIM Free	15	BHandset (Power Up, Bad LCD)(FidWorking)	1159
Apple	iPhone 14 Pro (256GB)SIM Free	8	BHandset (Power Up, Bad LCD)(FidWorking)	1160
Apple	iPhone 14 Pro (128GB)SIM Free	15	In Warranty-BHandset (Power Up, Bad LCD)	1161
Apple	iPhone 14 Pro (256GB)SIM Free	2	In Warranty-BHandset (Power Up, Bad LCD)	1162
Apple	iPhone 14 Pro (512GB)SIM Free	2	In Warranty-BHandset (Power Up, Bad LCD)	1163
Apple	iPhone 14 Pro (128GB)SIM Free	148	BHandset (Power Up, Bad LCD)	1164
Apple	iPhone 14 Pro (1Tb)SIM Free	2	BHandset (Power Up, Bad LCD)	1165
Apple	iPhone 14 Pro (256GB)SIM Free	38	BHandset (Power Up, Bad LCD)	1166
Apple	iPhone 14 Pro (512GB)SIM Free	11	BHandset (Power Up, Bad LCD)	1167
Apple	iPhone 14 Pro (128GB)SIM Free	1	BHandset (Power Up, Bad LCD)(unknow part message)	1168
Apple	iPhone 14 Pro (128GB)SIM Free	41	BHandset (only electricity)	1169
Apple	iPhone 14 Pro (256GB)SIM Free	9	BHandset (only electricity)	1170
Apple	iPhone 14 Pro (512GB)SIM Free	2	BHandset (only electricity)	1171
Apple	iPhone 14 Pro (128GB)SIM Free	33	SP Bid-No Power On-Change Battery(Reference Only)	1172
Apple	iPhone 14 Pro (256GB)SIM Free	3	SP Bid-No Power On-Change Battery(Reference Only)	1173
Apple	iPhone 14 Pro (128GB) (SIM FreeProblematic)	4	Part 2 AHandset	1174
Apple	iPhone 14 Pro (256GB) (SIM FreeProblematic)	3	Part 2 AHandset	1175
Apple	iPhone 14 Pro (128GB) (SIM FreeProblematic)	1	Part 2 BHandset (Power Up, Good LCD)	1176
Apple	iPhone 14 Pro (256GB) (SIM FreeProblematic)	2	Part 2 BHandset (Power Up, Good LCD)	1177
Apple	iPhone 14 Pro (128GB) (SIM FreeProblematic)	10	Part 2 BHandset (Power Up, Bad LCD)	1178
Apple	iPhone 14 Pro (256GB) (SIM FreeProblematic)	1	Part 2 BHandset (Power Up, Bad LCD)	1179
Apple	iPhone 14 Pro (128GB) (SIM FreeProblematic)	2	Part 2 BHandset (only electricity)	1180
Apple	iPhone 14 Pro (256GB) (SIM Freefid)	2	Part 2 AHandset	1181
Apple	iPhone 14 Pro (256GB) (SIM Freefid)	1	Part 2 BHandset (Power Up, Good LCD)	1182
Apple	iPhone 14 Pro (128GB)	4	Part 2 AHandset	1183
Apple	iPhone 14 Pro (256GB)	3	Part 2 AHandset	1184
Apple	iPhone 14 Pro (128GB)	6	Part 2 BHandset (Power Up, Good LCD)	1185
Apple	iPhone 14 Pro (128GB)	10	Part 2 BHandset (Power Up, Bad LCD)	1186
Apple	iPhone 14 Pro (256GB)	7	Part 2 BHandset (Power Up, Bad LCD)	1187
Apple	iPhone 14 Pro (512GB)	2	Part 2 BHandset (Power Up, Bad LCD)	1188
Apple	iPhone 14 Pro (256GB)	1	Part 2 BHandset (only electricity)	1189
Apple	iPhone 14 Pro (512GB)	1	Part 2 SP Bid-No Power On-Change Battery(Reference Only)	1190
Apple	iPhone 14 Pro (128GB)	4	Mainboard	1191
Apple	iPhone 14 Pro (256GB)	1	Mainboard	1192
Apple	iPhone 14 Pro (128GB) (Problematic)	1	Part 2 BHandset (Power Up, Bad LCD)	1193
Apple	iPhone 14 Plus Total(Mostly Dual-Sim)	199	Summary	1194
Apple	iPhone 14 Plus (128GB)SIM Free	1	AHandset (Good)(Bad Back Camera Glass)(Full Fuction)	1195
Apple	iPhone 14 Plus (128GB)SIM Free	1	AHandset (Good)(Broken Back Glass)(Full Fuction)	1196
Apple	iPhone 14 Plus (128GB)SIM Free	1	AHandset (Good)(unknow part message)	1197
Apple	iPhone 14 Plus (128GB)SIM Free	1	AHandset (Good 1)(Full Fuction)	1198
Apple	iPhone 14 Plus (512GB)SIM Free	1	AHandset (Good 1)(Full Fuction)	1199
Apple	iPhone 14 Plus (128GB)SIM Free	1	AHandset (Good 1)(Bad Back Camera Glass)(Full Fuction)	1200
Apple	iPhone 14 Plus (128GB)SIM Free	3	In Warranty-AHandset (Good 1)(Broken Back Glass)(Full Fuction)	1201
Apple	iPhone 14 Plus (128GB)SIM Free	2	AHandset (Good 1)(Full Fuction)(unknow part message)	1202

Apple	iPhone 14 Plus (128GB)SIM Free	1	AHandset (Full Fuction)	1203
Apple	iPhone 14 Plus (128GB)SIM Free	1	AHandset (Bad Back Camera Glass)(Full Fuction)	1204
Apple	iPhone 14 Plus (128GB)SIM Free	1	AHandset (Broken Back Glass)(Full Fuction)	1205
Apple	iPhone 14 Plus (128GB)SIM Free	1	In Warranty-AHandset (Broken Back Glass)(Full Fuction)	1206
Apple	iPhone 14 Plus (128GB)SIM Free	1	AHandset	1207
Apple	iPhone 14 Plus (128GB)SIM Free	2	AHandset (Bad Back Camera Glass)	1208
Apple	iPhone 14 Plus (128GB)SIM Free	1	AHandset (Broken Back Glass)	1209
Apple	iPhone 14 Plus (128GB)SIM Free	1	AHandset (Full Fuction)(unknow part message)	1210
Apple	iPhone 14 Plus (128GB)SIM Free	1	In Warranty-AHandset (Broken Back Glass)(Full Fuction)(unknow part message)	1211
Apple	iPhone 14 Plus (128GB)SIM Free	1	AHandset (Broken Back Glass)(Full Fuction)(unknow part message)	1212
Apple	iPhone 14 Plus (128GB)SIM Free	6	AHandset (unknow part message)	1213
Apple	iPhone 14 Plus (128GB)SIM Free	2	AHandset (Broken Back Glass)(unknow part message)	1214
Apple	iPhone 14 Plus (128GB)SIM Free	4	In Warranty-BHandset (Power Up, Good LCD)(Full Fuction)	1215
Apple	iPhone 14 Plus (256GB)SIM Free	2	BHandset (Power Up, Good LCD)(Full Fuction)	1216
Apple	iPhone 14 Plus (128GB)SIM Free	2	BHandset (Power Up, Good LCD)(Full Fuction)(unknow part message)	1217
Apple	iPhone 14 Plus (256GB)SIM Free	1	BHandset (Power Up, Good LCD)(Full Fuction)(unknow part message)	1218
Apple	iPhone 14 Plus (128GB)SIM Free	3	BHandset (Power Up, Good LCD)(unknow part message)	1219
Apple	iPhone 14 Plus (128GB)SIM Free	2	BHandset (Power Up, Bad LCD)(Full Fuction)	1220
Apple	iPhone 14 Plus (128GB)SIM Free	8	In Warranty-BHandset (Power Up, Bad LCD)(FidWorking)	1221
Apple	iPhone 14 Plus (256GB)SIM Free	1	In Warranty-BHandset (Power Up, Bad LCD)(FidWorking)	1222
Apple	iPhone 14 Plus (128GB)SIM Free	6	BHandset (Power Up, Bad LCD)(FidWorking)	1223
Apple	iPhone 14 Plus (256GB)SIM Free	1	BHandset (Power Up, Bad LCD)(FidWorking)	1224
Apple	iPhone 14 Plus (128GB)SIM Free	3	In Warranty-BHandset (Power Up, Bad LCD)	1225
Apple	iPhone 14 Plus (128GB)SIM Free	7	BHandset (Power Up, Bad LCD)	1226
Apple	iPhone 14 Plus (256GB)SIM Free	6	BHandset (Power Up, Bad LCD)	1227
Apple	iPhone 14 Plus (512GB)SIM Free	1	BHandset (Power Up, Bad LCD)	1228
Apple	iPhone 14 Plus (128GB)SIM Free	32	BHandset (only electricity)	1229
Apple	iPhone 14 Plus (256GB)SIM Free	1	BHandset (only electricity)	1230
Apple	iPhone 14 Plus (128GB)SIM Free	18	SP Bid-No Power On-Change Battery(Reference Only)	1231
Apple	iPhone 14 Plus (256GB)SIM Free	3	SP Bid-No Power On-Change Battery(Reference Only)	1232
Apple	iPhone 14 Plus (128GB) (SIM FreeProblematic)	7	Part 2 AHandset	1233
Apple	iPhone 14 Plus (128GB) (SIM FreeProblematic)	5	Part 2 BHandset (Power Up, Good LCD)	1234
Apple	iPhone 14 Plus (256GB) (SIM FreeProblematic)	1	Part 2 BHandset (Power Up, Good LCD)	1235
Apple	iPhone 14 Plus (128GB) (SIM FreeProblematic)	20	Part 2 BHandset (Power Up, Bad LCD)	1236
Apple	iPhone 14 Plus (256GB) (SIM FreeProblematic)	2	Part 2 BHandset (Power Up, Bad LCD)	1237
Apple	iPhone 14 Plus (128GB) (SIM Freefid)	1	Part 2 AHandset	1238
Apple	iPhone 14 Plus (128GB) (SIM Freefid)	2	Part 2 BHandset (Power Up, Good LCD)	1239
Apple	iPhone 14 Plus (128GB)	2	Part 2 AHandset	1240
Apple	iPhone 14 Plus (128GB)	4	Part 2 BHandset (Power Up, Good LCD)	1241
Apple	iPhone 14 Plus (256GB)	1	Part 2 BHandset (Power Up, Good LCD)	1242
Apple	iPhone 14 Plus (128GB)	13	Part 2 BHandset (Power Up, Bad LCD)	1243
Apple	iPhone 14 Plus (256GB)	1	Part 2 BHandset (Power Up, Bad LCD)	1244
Apple	iPhone 14 Plus (128GB)	5	Part 2 BHandset (only electricity)	1245
Apple	iPhone 14 Plus (128GB)	1	Mainboard	1246
Apple	iPhone 14 Plus (128GB) (Problematic)	1	Part 2 AHandset	1247
Apple	iPhone 14 Plus (128GB) (Problematic)	2	Part 2 BHandset (Power Up, Good LCD)	1248
Apple	iPhone 14 Total(Mostly Dual-Sim)	555	Summary	1249
Apple	iPhone 14 (128GB)SIM Free	1	AHandset (Good)(Full Fuction)	1250
Apple	iPhone 14 (256GB)SIM Free	1	AHandset (Good)(Broken Back Glass)(Full Fuction)	1251
Apple	iPhone 14 (128GB)SIM Free	3	In Warranty-AHandset (Good)(Broken Back Glass)(Full Fuction)	1252
Apple	iPhone 14 (128GB)SIM Free	1	AHandset (Good)(Full Fuction)(unknow part message)	1253
Apple	iPhone 14 (128GB)SIM Free	3	In Warranty-AHandset (Good 1)(Full Fuction)	1254
Apple	iPhone 14 (128GB)SIM Free	14	AHandset (Good 1)(Full Fuction)	1255
Apple	iPhone 14 (256GB)SIM Free	2	AHandset (Good 1)(Full Fuction)	1256
Apple	iPhone 14 (512GB)SIM Free	1	AHandset (Good 1)(Full Fuction)	1257
Apple	iPhone 14 (128GB)SIM Free	10	AHandset (Good 1)(Broken Back Glass)(Full Fuction)	1258
Apple	iPhone 14 (128GB)SIM Free	2	In Warranty-AHandset (Good 1)(Bad Back Camera Glass)(Full Fuction)	1259
Apple	iPhone 14 (128GB)SIM Free	6	In Warranty-AHandset (Good 1)(Broken Back Glass)(Full Fuction)	1260
Apple	iPhone 14 (128GB)SIM Free	2	AHandset (Good 1)	1261
Apple	iPhone 14 (128GB)SIM Free	1	AHandset (Good 1)(Bad Back Camera Glass)	1262
Apple	iPhone 14 (128GB)SIM Free	1	AHandset (Good 1)(Full Fuction)(unknow part message)	1263
Apple	iPhone 14 (256GB)SIM Free	2	AHandset (Good 1)(Full Fuction)(unknow part message)	1264
Apple	iPhone 14 (128GB)SIM Free	2	AHandset (Good 1)(Broken Back Glass)(Full Fuction)(unknow part message)	1265
Apple	iPhone 14 (128GB)SIM Free	4	In Warranty-AHandset (Full Fuction)	1266
Apple	iPhone 14 (256GB)SIM Free	1	In Warranty-AHandset (Full Fuction)	1267
Apple	iPhone 14 (128GB)SIM Free	4	AHandset (Full Fuction)	1268
Apple	iPhone 14 (128GB)SIM Free	1	AHandset (Bad Back Camera Glass)(Full Fuction)	1269
Apple	iPhone 14 (128GB)SIM Free	14	AHandset (Broken Back Glass)(Full Fuction)	1270
Apple	iPhone 14 (128GB)SIM Free	8	In Warranty-AHandset (Broken Back Glass)(Full Fuction)	1271
Apple	iPhone 14 (256GB)SIM Free	3	In Warranty-AHandset (Broken Back Glass)(Full Fuction)	1272
Apple	iPhone 14 (128GB)SIM Free	2	AHandset	1273
Apple	iPhone 14 (256GB)SIM Free	1	AHandset (Bad Back Camera Glass)	1274
Apple	iPhone 14 (128GB)SIM Free	2	AHandset (Broken Back Glass)	1275
Apple	iPhone 14 (256GB)SIM Free	1	AHandset (Broken Back Glass)	1276
Apple	iPhone 14 (128GB)SIM Free	5	AHandset (Full Fuction)(unknow part message)	1277
Apple	iPhone 14 (128GB)SIM Free	2	In Warranty-AHandset (Broken Back Glass)(Full Fuction)(unknow part message)	1278
Apple	iPhone 14 (128GB)SIM Free	4	AHandset (Broken Back Glass)(Full Fuction)(unknow part message)	1279
Apple	iPhone 14 (128GB)SIM Free	2	AHandset (unknow part message)	1280
Apple	iPhone 14 (256GB)SIM Free	1	AHandset (unknow part message)	1281
Apple	iPhone 14 (128GB)SIM Free	1	AHandset (Bad Back Camera Glass)(unknow part message)	1282
Apple	iPhone 14 (128GB)SIM Free	1	AHandset (Broken Back Glass)(unknow part message)	1283
Apple	iPhone 14 (256GB)SIM Free	2	AHandset (Broken Back Glass)(unknow part message)	1284
Apple	iPhone 14 (128GB)SIM Free	18	In Warranty-BHandset (Power Up, Good LCD)(Full Fuction)	1285
Apple	iPhone 14 (128GB)SIM Free	11	BHandset (Power Up, Good LCD)(Full Fuction)	1286
Apple	iPhone 14 (256GB)SIM Free	5	BHandset (Power Up, Good LCD)(Full Fuction)	1287
Apple	iPhone 14 (128GB)SIM Free	2	BHandset (Power Up, Good LCD)	1288

Apple	iPhone 14 (128GB)SIM Free	9	BHandset (Power Up, Good LCD)(Full Fuction)(unknow part message)	1289
Apple	iPhone 14 (256GB)SIM Free	1	BHandset (Power Up, Good LCD)(Full Fuction)(unknow part message)	1290
Apple	iPhone 14 (128GB)SIM Free	7	BHandset (Power Up, Good LCD)(unknow part message)	1291
Apple	iPhone 14 (256GB)SIM Free	1	BHandset (Power Up, Good LCD)(unknow part message)	1292
Apple	iPhone 14 (128GB)SIM Free	8	BHandset (Power Up, Bad LCD)(Full Fuction)	1293
Apple	iPhone 14 (128GB)SIM Free	17	In Warranty-BHandset (Power Up, Bad LCD)(FidWorking)	1294
Apple	iPhone 14 (256GB)SIM Free	1	In Warranty-BHandset (Power Up, Bad LCD)(FidWorking)	1295
Apple	iPhone 14 (128GB)SIM Free	3	BHandset (Power Up, Bad LCD)(FidWorking)	1296
Apple	iPhone 14 (128GB)SIM Free	17	In Warranty-BHandset (Power Up, Bad LCD)	1297
Apple	iPhone 14 (256GB)SIM Free	3	In Warranty-BHandset (Power Up, Bad LCD)	1298
Apple	iPhone 14 (512GB)SIM Free	1	In Warranty-BHandset (Power Up, Bad LCD)	1299
Apple	iPhone 14 (128GB)SIM Free	73	BHandset (Power Up, Bad LCD)	1300
Apple	iPhone 14 (256GB)SIM Free	18	BHandset (Power Up, Bad LCD)	1301
Apple	iPhone 14 (512GB)SIM Free	1	BHandset (Power Up, Bad LCD)	1302
Apple	iPhone 14 (128GB)SIM Free	52	BHandset (only electricity)	1303
Apple	iPhone 14 (256GB)SIM Free	1	BHandset (only electricity)	1304
Apple	iPhone 14 (512GB)SIM Free	1	BHandset (only electricity)	1305
Apple	iPhone 14 (128GB)SIM Free	57	SP Bid-No Power On-Change Battery(Reference Only)	1306
Apple	iPhone 14 (256GB)SIM Free	2	SP Bid-No Power On-Change Battery(Reference Only)	1307
Apple	iPhone 14 (512GB)SIM Free	1	SP Bid-No Power On-Change Battery(Reference Only)	1308
Apple	iPhone 14 (128GB) (SIM FreeProblematic)	2	Part 2 In Warranty-AHandset	1309
Apple	iPhone 14 (128GB) (SIM FreeProblematic)	50	Part 2 AHandset	1310
Apple	iPhone 14 (256GB) (SIM FreeProblematic)	1	Part 2 AHandset	1311
Apple	iPhone 14 (128GB) (SIM FreeProblematic)	21	Part 2 BHandset (Power Up, Good LCD)	1312
Apple	iPhone 14 (256GB) (SIM FreeProblematic)	4	Part 2 BHandset (Power Up, Good LCD)	1313
Apple	iPhone 14 (128GB) (SIM FreeProblematic)	13	Part 2 BHandset (Power Up, Bad LCD)	1314
Apple	iPhone 14 (256GB) (SIM FreeProblematic)	1	Part 2 BHandset (Power Up, Bad LCD)	1315
Apple	iPhone 14 (128GB) (SIM FreeProblematic)	3	Part 2 BHandset (only electricity)	1316
Apple	iPhone 14 (128GB) (SIM Freefid)	5	Part 2 AHandset	1317
Apple	iPhone 14 (128GB) (SIM Freefid)	4	Part 2 BHandset (Power Up, Good LCD)	1318
Apple	iPhone 14 (128GB)	2	Part 2 AHandset	1319
Apple	iPhone 14 (128GB)	4	Part 2 BHandset (Power Up, Good LCD)	1320
Apple	iPhone 14 (128GB)	9	Part 2 BHandset (Power Up, Bad LCD)	1321
Apple	iPhone 14 (256GB)	1	Part 2 BHandset (Power Up, Bad LCD)	1322
Apple	iPhone 14 (128GB)	5	Part 2 BHandset (only electricity)	1323
Apple	iPhone 14 (128GB)	1	Part 2 SP Bid-No Power On-Change Battery(Reference Only)	1324
Apple	iPhone 14 (128GB)	5	Mainboard	1325
Apple	iPhone 14 (128GB) (Problematic)	1	Part 2 BHandset (Power Up, Good LCD)	1326
Apple	iPhone 14 (128GB) (Problematic)	2	Part 2 BHandset (only electricity)	1327
Apple	iPhone 13 Pro Max Total	9268	Summary	1328
Apple	iPhone 13 Pro Max (128GB)SIM Free	1	Nearly New(Full Fuction)	1329
Apple	iPhone 13 Pro Max (128GB)SIM Free	45	AHandset (Good)(Full Fuction)	1330
Apple	iPhone 13 Pro Max (512GB)SIM Free	2	AHandset (Good)(Full Fuction)	1331
Apple	iPhone 13 Pro Max (128GB)SIM Free	2	AHandset (Good)(Bad Back Camera Glass)(Full Fuction)	1332
Apple	iPhone 13 Pro Max (1Tb)SIM Free	1	AHandset (Good)(Bad Back Camera Glass)(Full Fuction)	1333
Apple	iPhone 13 Pro Max (256GB)SIM Free	5	AHandset (Good)(Bad Back Camera Glass)(Full Fuction)	1334
Apple	iPhone 13 Pro Max (128GB)SIM Free	5	AHandset (Good)(Broken Back Glass)(Full Fuction)	1335
Apple	iPhone 13 Pro Max (1Tb)SIM Free	9	AHandset (Good)(Broken Back Glass)(Full Fuction)	1336
Apple	iPhone 13 Pro Max (256GB)SIM Free	2	AHandset (Good)(Broken Back Glass)(Full Fuction)	1337
Apple	iPhone 13 Pro Max (512GB)SIM Free	4	AHandset (Good)(Broken Back Glass)(Full Fuction)	1338
Apple	iPhone 13 Pro Max (128GB)SIM Free	1	AHandset (Good)	1339
Apple	iPhone 13 Pro Max (256GB)SIM Free	1	AHandset (Good)	1340
Apple	iPhone 13 Pro Max (128GB)SIM Free	5	AHandset (Good)(Broken Back Glass)	1341
Apple	iPhone 13 Pro Max (128GB)SIM Free	6	AHandset (Good)(Full Fuction)(unknow part message)	1342
Apple	iPhone 13 Pro Max (256GB)SIM Free	4	AHandset (Good)(Full Fuction)(unknow part message)	1343
Apple	iPhone 13 Pro Max (128GB)SIM Free	1	AHandset (Good)(Broken Back Glass)(Full Fuction)(unknow part message)	1344
Apple	iPhone 13 Pro Max (256GB)SIM Free	6	AHandset (Good)(Broken Back Glass)(Full Fuction)(unknow part message)	1345
Apple	iPhone 13 Pro Max (128GB)SIM Free	24	EU Ver-AHandset (Good 1)(Full Fuction)	1346
Apple	iPhone 13 Pro Max (128GB)SIM Free	162	AHandset (Good 1)(Full Fuction)	1347
Apple	iPhone 13 Pro Max (1Tb)SIM Free	13	AHandset (Good 1)(Full Fuction)	1348
Apple	iPhone 13 Pro Max (256GB)SIM Free	193	AHandset (Good 1)(Full Fuction)	1349
Apple	iPhone 13 Pro Max (512GB)SIM Free	64	AHandset (Good 1)(Full Fuction)	1350
Apple	iPhone 13 Pro Max (256GB)SIM Free	1	AHandset (Good 1)(Bad Back Camera Glass)(Full Fuction)	1351
Apple	iPhone 13 Pro Max (128GB)SIM Free	636	AHandset (Good 1)(Broken Back Glass)(Full Fuction)	1352
Apple	iPhone 13 Pro Max (1Tb)SIM Free	50	AHandset (Good 1)(Broken Back Glass)(Full Fuction)	1353
Apple	iPhone 13 Pro Max (256GB)SIM Free	756	AHandset (Good 1)(Broken Back Glass)(Full Fuction)	1354
Apple	iPhone 13 Pro Max (512GB)SIM Free	77	AHandset (Good 1)(Broken Back Glass)(Full Fuction)	1355
Apple	iPhone 13 Pro Max (128GB)SIM Free	1	AHandset (Good 1)	1356
Apple	iPhone 13 Pro Max (256GB)SIM Free	10	AHandset (Good 1)(Broken Back Glass)	1357
Apple	iPhone 13 Pro Max (128GB)SIM Free	89	AHandset (Good 1)(Full Fuction)(unknow part message)	1358
Apple	iPhone 13 Pro Max (1Tb)SIM Free	2	AHandset (Good 1)(Full Fuction)(unknow part message)	1359
Apple	iPhone 13 Pro Max (256GB)SIM Free	61	AHandset (Good 1)(Full Fuction)(unknow part message)	1360
Apple	iPhone 13 Pro Max (512GB)SIM Free	3	AHandset (Good 1)(Full Fuction)(unknow part message)	1361
Apple	iPhone 13 Pro Max (256GB)SIM Free	4	AHandset (Good 1)(Bad Back Camera Glass)(Full Fuction)(unknow part message)	1362
Apple	iPhone 13 Pro Max (512GB)SIM Free	1	AHandset (Good 1)(Bad Back Camera Glass)(Full Fuction)(unknow part message)	1363
Apple	iPhone 13 Pro Max (128GB)SIM Free	212	AHandset (Good 1)(Broken Back Glass)(Full Fuction)(unknow part message)	1364
Apple	iPhone 13 Pro Max (256GB)SIM Free	60	AHandset (Good 1)(Broken Back Glass)(Full Fuction)(unknow part message)	1365
Apple	iPhone 13 Pro Max (512GB)SIM Free	4	AHandset (Good 1)(Broken Back Glass)(Full Fuction)(unknow part message)	1366
Apple	iPhone 13 Pro Max (128GB)SIM Free	8	AHandset (Good 1)(unknow part message)	1367
Apple	iPhone 13 Pro Max (128GB)SIM Free	40	AHandset (Full Fuction)	1368
Apple	iPhone 13 Pro Max (1Tb)SIM Free	16	AHandset (Full Fuction)	1369
Apple	iPhone 13 Pro Max (256GB)SIM Free	302	AHandset (Full Fuction)	1370
Apple	iPhone 13 Pro Max (512GB)SIM Free	22	AHandset (Full Fuction)	1371
Apple	iPhone 13 Pro Max (128GB)SIM Free	2	AHandset (Bad Back Camera Glass)(Full Fuction)	1372
Apple	iPhone 13 Pro Max (256GB)SIM Free	4	AHandset (Bad Back Camera Glass)(Full Fuction)	1373
Apple	iPhone 13 Pro Max (512GB)SIM Free	1	AHandset (Bad Back Camera Glass)(Full Fuction)	1374

Apple	iPhone 13 Pro Max (128GB)SIM Free	527	AHandset (Broken Back Glass)(Full Fuction)	1375
Apple	iPhone 13 Pro Max (1Tb)SIM Free	76	AHandset (Broken Back Glass)(Full Fuction)	1376
Apple	iPhone 13 Pro Max (256GB)SIM Free	781	AHandset (Broken Back Glass)(Full Fuction)	1377
Apple	iPhone 13 Pro Max (512GB)SIM Free	149	AHandset (Broken Back Glass)(Full Fuction)	1378
Apple	iPhone 13 Pro Max (256GB)SIM Free	3	AHandset	1379
Apple	iPhone 13 Pro Max (128GB)SIM Free	1	AHandset (Bad Back Camera Glass)	1380
Apple	iPhone 13 Pro Max (1Tb)SIM Free	2	AHandset (Bad Back Camera Glass)	1381
Apple	iPhone 13 Pro Max (256GB)SIM Free	11	AHandset (Bad Back Camera Glass)	1382
Apple	iPhone 13 Pro Max (512GB)SIM Free	2	AHandset (Bad Back Camera Glass)	1383
Apple	iPhone 13 Pro Max (128GB)SIM Free	8	AHandset (Broken Back Glass)	1384
Apple	iPhone 13 Pro Max (256GB)SIM Free	2	AHandset (Broken Back Glass)	1385
Apple	iPhone 13 Pro Max (512GB)SIM Free	1	AHandset (Broken Back Glass)	1386
Apple	iPhone 13 Pro Max (128GB)SIM Free	25	AHandset (Full Fuction)(unknow part message)	1387
Apple	iPhone 13 Pro Max (1Tb)SIM Free	1	AHandset (Full Fuction)(unknow part message)	1388
Apple	iPhone 13 Pro Max (256GB)SIM Free	30	AHandset (Full Fuction)(unknow part message)	1389
Apple	iPhone 13 Pro Max (512GB)SIM Free	7	AHandset (Full Fuction)(unknow part message)	1390
Apple	iPhone 13 Pro Max (128GB)SIM Free	3	AHandset (Bad Back Camera Glass)(Full Fuction)(unknow part message)	1391
Apple	iPhone 13 Pro Max (256GB)SIM Free	1	AHandset (Bad Back Camera Glass)(Full Fuction)(unknow part message)	1392
Apple	iPhone 13 Pro Max (128GB)SIM Free	304	AHandset (Broken Back Glass)(Full Fuction)(unknow part message)	1393
Apple	iPhone 13 Pro Max (1Tb)SIM Free	4	AHandset (Broken Back Glass)(Full Fuction)(unknow part message)	1394
Apple	iPhone 13 Pro Max (256GB)SIM Free	145	AHandset (Broken Back Glass)(Full Fuction)(unknow part message)	1395
Apple	iPhone 13 Pro Max (512GB)SIM Free	8	AHandset (Broken Back Glass)(Full Fuction)(unknow part message)	1396
Apple	iPhone 13 Pro Max (128GB)SIM Free	52	AHandset (unknow part message)	1397
Apple	iPhone 13 Pro Max (1Tb)SIM Free	2	AHandset (unknow part message)	1398
Apple	iPhone 13 Pro Max (256GB)SIM Free	38	AHandset (unknow part message)	1399
Apple	iPhone 13 Pro Max (512GB)SIM Free	4	AHandset (unknow part message)	1400
Apple	iPhone 13 Pro Max (128GB)SIM Free	28	AHandset (Bad Back Camera Glass)(unknow part message)	1401
Apple	iPhone 13 Pro Max (1Tb)SIM Free	2	AHandset (Bad Back Camera Glass)(unknow part message)	1402
Apple	iPhone 13 Pro Max (256GB)SIM Free	29	AHandset (Bad Back Camera Glass)(unknow part message)	1403
Apple	iPhone 13 Pro Max (512GB)SIM Free	6	AHandset (Bad Back Camera Glass)(unknow part message)	1404
Apple	iPhone 13 Pro Max (128GB)SIM Free	418	AHandset (Broken Back Glass)(unknow part message)	1405
Apple	iPhone 13 Pro Max (1Tb)SIM Free	8	AHandset (Broken Back Glass)(unknow part message)	1406
Apple	iPhone 13 Pro Max (256GB)SIM Free	81	AHandset (Broken Back Glass)(unknow part message)	1407
Apple	iPhone 13 Pro Max (512GB)SIM Free	23	AHandset (Broken Back Glass)(unknow part message)	1408
Apple	iPhone 13 Pro Max (128GB)SIM Free	240	BHandset (Power Up, Good LCD)(Full Fuction)	1409
Apple	iPhone 13 Pro Max (256GB)SIM Free	332	BHandset (Power Up, Good LCD)(Full Fuction)	1410
Apple	iPhone 13 Pro Max (512GB)SIM Free	176	BHandset (Power Up, Good LCD)(Full Fuction)	1411
Apple	iPhone 13 Pro Max (256GB)SIM Free	5	BHandset (Power Up, Good LCD)(Broken Back Glass)(Full Fuction)	1412
Apple	iPhone 13 Pro Max (128GB)SIM Free	22	BHandset (Power Up, Good LCD)	1413
Apple	iPhone 13 Pro Max (1Tb)SIM Free	1	BHandset (Power Up, Good LCD)	1414
Apple	iPhone 13 Pro Max (256GB)SIM Free	16	BHandset (Power Up, Good LCD)	1415
Apple	iPhone 13 Pro Max (512GB)SIM Free	1	BHandset (Power Up, Good LCD)	1416
Apple	iPhone 13 Pro Max (128GB)SIM Free	175	BHandset (Power Up, Good LCD)(Full Fuction)(unknow part message)	1417
Apple	iPhone 13 Pro Max (256GB)SIM Free	66	BHandset (Power Up, Good LCD)(Full Fuction)(unknow part message)	1418
Apple	iPhone 13 Pro Max (512GB)SIM Free	10	BHandset (Power Up, Good LCD)(Full Fuction)(unknow part message)	1419
Apple	iPhone 13 Pro Max (128GB)SIM Free	235	BHandset (Power Up, Good LCD)(unknow part message)	1420
Apple	iPhone 13 Pro Max (1Tb)SIM Free	4	BHandset (Power Up, Good LCD)(unknow part message)	1421
Apple	iPhone 13 Pro Max (256GB)SIM Free	123	BHandset (Power Up, Good LCD)(unknow part message)	1422
Apple	iPhone 13 Pro Max (512GB)SIM Free	9	BHandset (Power Up, Good LCD)(unknow part message)	1423
Apple	iPhone 13 Pro Max (128GB)SIM Free	227	BHandset (Power Up, Bad LCD)(Full Fuction)	1424
Apple	iPhone 13 Pro Max (1Tb)SIM Free	3	BHandset (Power Up, Bad LCD)(Full Fuction)	1425
Apple	iPhone 13 Pro Max (256GB)SIM Free	135	BHandset (Power Up, Bad LCD)(Full Fuction)	1426
Apple	iPhone 13 Pro Max (512GB)SIM Free	13	BHandset (Power Up, Bad LCD)(Full Fuction)	1427
Apple	iPhone 13 Pro Max (128GB)SIM Free	55	BHandset (Power Up, Bad LCD)(FidWorking)	1428
Apple	iPhone 13 Pro Max (1Tb)SIM Free	22	BHandset (Power Up, Bad LCD)(FidWorking)	1429
Apple	iPhone 13 Pro Max (256GB)SIM Free	137	BHandset (Power Up, Bad LCD)(FidWorking)	1430
Apple	iPhone 13 Pro Max (512GB)SIM Free	52	BHandset (Power Up, Bad LCD)(FidWorking)	1431
Apple	iPhone 13 Pro Max (128GB)SIM Free	7	BHandset (Power Up, Bad LCD)	1432
Apple	iPhone 13 Pro Max (1Tb)SIM Free	57	BHandset (Power Up, Bad LCD)	1433
Apple	iPhone 13 Pro Max (256GB)SIM Free	123	BHandset (Power Up, Bad LCD)	1434
Apple	iPhone 13 Pro Max (512GB)SIM Free	8	BHandset (Power Up, Bad LCD)	1435
Apple	iPhone 13 Pro Max (128GB)SIM Free	1	BHandset (Power Up, Bad LCD)(unknow part message)	1436
Apple	iPhone 13 Pro Max (128GB)SIM Free	259	BHandset (only electricity)	1437
Apple	iPhone 13 Pro Max (256GB)SIM Free	87	BHandset (only electricity)	1438
Apple	iPhone 13 Pro Max (512GB)SIM Free	6	BHandset (only electricity)	1439
Apple	iPhone 13 Pro Max (128GB)SIM Free	184	SP Bid-No Power On-Change Battery(Reference Only)	1440
Apple	iPhone 13 Pro Max (256GB)SIM Free	76	SP Bid-No Power On-Change Battery(Reference Only)	1441
Apple	iPhone 13 Pro Max (512GB)SIM Free	4	SP Bid-No Power On-Change Battery(Reference Only)	1442
Apple	iPhone 13 Pro Max (1Tb)	2	Part 2 SP Bid-No Power On-Change Battery(Reference Only)	1443
Apple	iPhone 13 Pro Max (128GB) (SIM FreeProblematic)	2	Part 2 AHandset	1444
Apple	iPhone 13 Pro Max (1Tb) (SIM FreeProblematic)	1	Part 2 AHandset	1445
Apple	iPhone 13 Pro Max (256GB) (SIM FreeProblematic)	1	Part 2 AHandset	1446
Apple	iPhone 13 Pro Max (512GB) (SIM FreeProblematic)	33	Part 2 AHandset	1447
Apple	iPhone 13 Pro Max (128GB) (SIM FreeProblematic)	157	Part 2 BHandset (Power Up, Good LCD)	1448
Apple	iPhone 13 Pro Max (1Tb) (SIM FreeProblematic)	4	Part 2 BHandset (Power Up, Good LCD)	1449
Apple	iPhone 13 Pro Max (256GB) (SIM FreeProblematic)	166	Part 2 BHandset (Power Up, Good LCD)	1450
Apple	iPhone 13 Pro Max (512GB) (SIM FreeProblematic)	8	Part 2 BHandset (Power Up, Good LCD)	1451
Apple	iPhone 13 Pro Max (128GB) (SIM FreeProblematic)	34	Part 2 BHandset (Power Up, Bad LCD)	1452
Apple	iPhone 13 Pro Max (1Tb) (SIM FreeProblematic)	9	Part 2 BHandset (Power Up, Bad LCD)	1453
Apple	iPhone 13 Pro Max (256GB) (SIM FreeProblematic)	2	Part 2 BHandset (Power Up, Bad LCD)	1454
Apple	iPhone 13 Pro Max (512GB) (SIM FreeProblematic)	27	Part 2 BHandset (Power Up, Bad LCD)	1455
Apple	iPhone 13 Pro Max (128GB) (SIM FreeProblematic)	2	Part 2 BHandset (only electricity)	1456
Apple	iPhone 13 Pro Max (256GB) (SIM FreeProblematic)	2	Part 2 BHandset (only electricity)	1457
Apple	iPhone 13 Pro Max (128GB) (SIM Freefid)	10	Part 2 AHandset	1458
Apple	iPhone 13 Pro Max (256GB) (SIM Freefid)	2	Part 2 AHandset	1459
Apple	iPhone 13 Pro Max (128GB) (SIM Freefid)	69	Part 2 AHandset (unknow part message)	1460

Apple	iPhone 13 Pro Max (256GB) (SIM Freefid)	18	Part 2 AHandset (unknown part message)	1461
Apple	iPhone 13 Pro Max (128GB) (SIM Freefid)	4	Part 2 BHandset (Power Up, Good LCD)	1462
Apple	iPhone 13 Pro Max (256GB) (SIM Freefid)	3	Part 2 BHandset (Power Up, Good LCD)	1463
Apple	iPhone 13 Pro Max (128GB) (SIM Freefid)	6	Part 2 BHandset (Power Up, Good LCD)(unknown part message)	1464
Apple	iPhone 13 Pro Max (256GB) (SIM Freefid)	3	Part 2 BHandset (Power Up, Good LCD)(unknown part message)	1465
Apple	iPhone 13 Pro Max (128GB)	5	Part 2 AHandset	1466
Apple	iPhone 13 Pro Max (256GB)	1	Part 2 AHandset	1467
Apple	iPhone 13 Pro Max (128GB)	4	Part 2 BHandset (Power Up, Good LCD)	1468
Apple	iPhone 13 Pro Max (256GB)	3	Part 2 BHandset (Power Up, Good LCD)	1469
Apple	iPhone 13 Pro Max (512GB)	1	Part 2 BHandset (Power Up, Good LCD)	1470
Apple	iPhone 13 Pro Max (128GB)	34	Part 2 BHandset (Power Up, Bad LCD)	1471
Apple	iPhone 13 Pro Max (256GB)	7	Part 2 BHandset (Power Up, Bad LCD)	1472
Apple	iPhone 13 Pro Max (128GB)	2	Part 2 BHandset (only electricity)	1473
Apple	iPhone 13 Pro Max (256GB)	4	Part 2 BHandset (only electricity)	1474
Apple	iPhone 13 Pro Max (128GB)	16	Part 2 SP Bid-No Power On-Change Battery(Reference Only)	1475
Apple	iPhone 13 Pro Max (256GB)	6	Part 2 SP Bid-No Power On-Change Battery(Reference Only)	1476
Apple	iPhone 13 Pro Max (128GB)	21	Mainboard	1477
Apple	iPhone 13 Pro Max (256GB)	7	Mainboard	1478
Apple	iPhone 13 Pro Max (128GB) (Problematic)	5	Part 2 AHandset	1479
Apple	iPhone 13 Pro Max (128GB) (Problematic)	1	Part 2 BHandset (Power Up, Good LCD)	1480
Apple	iPhone 13 Pro Max (128GB) (Problematic)	3	Part 2 BHandset (Power Up, Bad LCD)	1481
Apple	iPhone 13 Pro Max (128GB)SIM Free	9	Mainboard	1482
Apple	iPhone 13 Pro Max (256GB)SIM Free	3	Mainboard	1483
Apple	iPhone 13 Pro Total	702	Summary	1484
Apple	iPhone 13 Pro (128GB)SIM Free	6	AHandset (Good)(Full Fuction)	1485
Apple	iPhone 13 Pro (256GB)SIM Free	9	AHandset (Good)(Full Fuction)	1486
Apple	iPhone 13 Pro (256GB)SIM Free	1	AHandset (Good)(Bad Back Camera Glass)(Full Fuction)	1487
Apple	iPhone 13 Pro (128GB)SIM Free	3	AHandset (Good)(Broken Back Glass)(Full Fuction)	1488
Apple	iPhone 13 Pro (256GB)SIM Free	4	AHandset (Good)(Broken Back Glass)(Full Fuction)	1489
Apple	iPhone 13 Pro (512GB)SIM Free	1	AHandset (Good)(Broken Back Glass)(Full Fuction)	1490
Apple	iPhone 13 Pro (128GB)SIM Free	3	AHandset (Good)(Full Fuction)(unknown part message)	1491
Apple	iPhone 13 Pro (128GB)SIM Free	2	AHandset (Good 1)(Full Fuction)	1492
Apple	iPhone 13 Pro (1Tb)SIM Free	1	AHandset (Good 1)(Full Fuction)	1493
Apple	iPhone 13 Pro (256GB)SIM Free	9	AHandset (Good 1)(Full Fuction)	1494
Apple	iPhone 13 Pro (512GB)SIM Free	2	AHandset (Good 1)(Full Fuction)	1495
Apple	iPhone 13 Pro (128GB)SIM Free	2	AHandset (Good 1)(Bad Back Camera Glass)(Full Fuction)	1496
Apple	iPhone 13 Pro (128GB)SIM Free	8	AHandset (Good 1)(Broken Back Glass)(Full Fuction)	1497
Apple	iPhone 13 Pro (128GB)SIM Free	1	AHandset (Good 1)(Bad Back Camera Glass)	1498
Apple	iPhone 13 Pro (256GB)SIM Free	2	AHandset (Good 1)(Bad Back Camera Glass)	1499
Apple	iPhone 13 Pro (128GB)SIM Free	3	AHandset (Good 1)(Broken Back Glass)	1500
Apple	iPhone 13 Pro (256GB)SIM Free	1	AHandset (Good 1)(Broken Back Glass)	1501
Apple	iPhone 13 Pro (128GB)SIM Free	3	AHandset (Good 1)(Full Fuction)(unknown part message)	1502
Apple	iPhone 13 Pro (256GB)SIM Free	3	AHandset (Good 1)(Full Fuction)(unknown part message)	1503
Apple	iPhone 13 Pro (128GB)SIM Free	7	AHandset (Good 1)(Broken Back Glass)(Full Fuction)(unknown part message)	1504
Apple	iPhone 13 Pro (256GB)SIM Free	1	AHandset (Good 1)(Broken Back Glass)(Full Fuction)(unknown part message)	1505
Apple	iPhone 13 Pro (128GB)SIM Free	5	AHandset (Full Fuction)	1506
Apple	iPhone 13 Pro (256GB)SIM Free	22	AHandset (Full Fuction)	1507
Apple	iPhone 13 Pro (512GB)SIM Free	1	AHandset (Full Fuction)	1508
Apple	iPhone 13 Pro (256GB)SIM Free	2	AHandset (Bad Back Camera Glass)(Full Fuction)	1509
Apple	iPhone 13 Pro (512GB)SIM Free	1	AHandset (Bad Back Camera Glass)(Full Fuction)	1510
Apple	iPhone 13 Pro (128GB)SIM Free	12	AHandset (Broken Back Glass)(Full Fuction)	1511
Apple	iPhone 13 Pro (256GB)SIM Free	19	AHandset (Broken Back Glass)(Full Fuction)	1512
Apple	iPhone 13 Pro (128GB)SIM Free	1	AHandset	1513
Apple	iPhone 13 Pro (256GB)SIM Free	2	AHandset	1514
Apple	iPhone 13 Pro (128GB)SIM Free	1	AHandset (Bad Back Camera Glass)	1515
Apple	iPhone 13 Pro (256GB)SIM Free	2	AHandset (Bad Back Camera Glass)	1516
Apple	iPhone 13 Pro (128GB)SIM Free	6	AHandset (Broken Back Glass)	1517
Apple	iPhone 13 Pro (128GB)SIM Free	2	AHandset (Full Fuction)(unknown part message)	1518
Apple	iPhone 13 Pro (128GB)SIM Free	7	AHandset (Broken Back Glass)(Full Fuction)(unknown part message)	1519
Apple	iPhone 13 Pro (256GB)SIM Free	4	AHandset (Broken Back Glass)(Full Fuction)(unknown part message)	1520
Apple	iPhone 13 Pro (128GB)SIM Free	16	AHandset (unknown part message)	1521
Apple	iPhone 13 Pro (256GB)SIM Free	4	AHandset (unknown part message)	1522
Apple	iPhone 13 Pro (512GB)SIM Free	2	AHandset (unknown part message)	1523
Apple	iPhone 13 Pro (256GB)SIM Free	1	AHandset (Bad Back Camera Glass)(unknown part message)	1524
Apple	iPhone 13 Pro (128GB)SIM Free	14	AHandset (Broken Back Glass)(unknown part message)	1525
Apple	iPhone 13 Pro (256GB)SIM Free	4	AHandset (Broken Back Glass)(unknown part message)	1526
Apple	iPhone 13 Pro (128GB)SIM Free	46	BHandset (Power Up, Good LCD)(Full Fuction)	1527
Apple	iPhone 13 Pro (256GB)SIM Free	3	BHandset (Power Up, Good LCD)(Full Fuction)	1528
Apple	iPhone 13 Pro (128GB)SIM Free	5	BHandset (Power Up, Good LCD)	1529
Apple	iPhone 13 Pro (256GB)SIM Free	2	BHandset (Power Up, Good LCD)	1530
Apple	iPhone 13 Pro (128GB)SIM Free	10	BHandset (Power Up, Good LCD)(Full Fuction)(unknown part message)	1531
Apple	iPhone 13 Pro (256GB)SIM Free	2	BHandset (Power Up, Good LCD)(Full Fuction)(unknown part message)	1532
Apple	iPhone 13 Pro (128GB)SIM Free	5	BHandset (Power Up, Good LCD)(unknown part message)	1533
Apple	iPhone 13 Pro (1Tb)SIM Free	1	BHandset (Power Up, Good LCD)(unknown part message)	1534
Apple	iPhone 13 Pro (256GB)SIM Free	7	BHandset (Power Up, Good LCD)(unknown part message)	1535
Apple	iPhone 13 Pro (128GB)SIM Free	5	BHandset (Power Up, Bad LCD)(Full Fuction)	1536
Apple	iPhone 13 Pro (128GB)SIM Free	18	BHandset (Power Up, Bad LCD)(FidWorking)	1537
Apple	iPhone 13 Pro (256GB)SIM Free	6	BHandset (Power Up, Bad LCD)(FidWorking)	1538
Apple	iPhone 13 Pro (512GB)SIM Free	4	BHandset (Power Up, Bad LCD)(FidWorking)	1539
Apple	iPhone 13 Pro (128GB)SIM Free	71	BHandset (Power Up, Bad LCD)	1540
Apple	iPhone 13 Pro (1Tb)SIM Free	2	BHandset (Power Up, Bad LCD)	1541
Apple	iPhone 13 Pro (256GB)SIM Free	25	BHandset (Power Up, Bad LCD)	1542
Apple	iPhone 13 Pro (512GB)SIM Free	3	BHandset (Power Up, Bad LCD)	1543
Apple	iPhone 13 Pro (128GB)SIM Free	2	BHandset (Power Up, Bad LCD)(FidWorking)(unknown part message)	1544
Apple	iPhone 13 Pro (128GB)SIM Free	5	BHandset (Power Up, Bad LCD)(unknown part message)	1545
Apple	iPhone 13 Pro (256GB)SIM Free	1	BHandset (Power Up, Bad LCD)(unknown part message)	1546

Apple	iPhone 13 Pro (512GB)SIM Free	1	BHandset (Power Up, Bad LCD)(unknow part message)	1547
Apple	iPhone 13 Pro (128GB)SIM Free	89	BHandset (only electricity)	1548
Apple	iPhone 13 Pro (256GB)SIM Free	9	BHandset (only electricity)	1549
Apple	iPhone 13 Pro (512GB)SIM Free	1	BHandset (only electricity)	1550
Apple	iPhone 13 Pro (128GB)SIM Free	66	SP Bid-No Power On-Change Battery(Reference Only)	1551
Apple	iPhone 13 Pro (1Tb)SIM Free	1	SP Bid-No Power On-Change Battery(Reference Only)	1552
Apple	iPhone 13 Pro (256GB)SIM Free	11	SP Bid-No Power On-Change Battery(Reference Only)	1553
Apple	iPhone 13 Pro (512GB)SIM Free	1	SP Bid-No Power On-Change Battery(Reference Only)	1554
Apple	iPhone 13 Pro (128GB) (SIM FreeProblematic)	13	Part 2 AHandset	1555
Apple	iPhone 13 Pro (256GB) (SIM FreeProblematic)	4	Part 2 AHandset	1556
Apple	iPhone 13 Pro (128GB) (SIM FreeProblematic)	12	Part 2 BHandset (Power Up, Good LCD)	1557
Apple	iPhone 13 Pro (256GB) (SIM FreeProblematic)	2	Part 2 BHandset (Power Up, Good LCD)	1558
Apple	iPhone 13 Pro (128GB) (SIM FreeProblematic)	2	Part 2 BHandset (Power Up, Bad LCD)	1559
Apple	iPhone 13 Pro (256GB) (SIM FreeProblematic)	1	Part 2 BHandset (Power Up, Bad LCD)	1560
Apple	iPhone 13 Pro (128GB) (SIM FreeProblematic)	3	Part 2 BHandset (only electricity)	1561
Apple	iPhone 13 Pro (128GB) (SIM Freefid)	8	Part 2 AHandset	1562
Apple	iPhone 13 Pro (256GB) (SIM Freefid)	1	Part 2 AHandset	1563
Apple	iPhone 13 Pro (512GB) (SIM Freefid)	1	Part 2 AHandset	1564
Apple	iPhone 13 Pro (128GB) (SIM Freefid)	1	Part 2 BHandset (Power Up, Good LCD)	1565
Apple	iPhone 13 Pro (128GB)	1	Part 2 BHandset (Power Up, Good LCD)	1566
Apple	iPhone 13 Pro (128GB)	21	Part 2 BHandset (Power Up, Bad LCD)	1567
Apple	iPhone 13 Pro (256GB)	9	Part 2 BHandset (Power Up, Bad LCD)	1568
Apple	iPhone 13 Pro (512GB)	1	Part 2 BHandset (Power Up, Bad LCD)	1569
Apple	iPhone 13 Pro (128GB)	6	Part 2 BHandset (only electricity)	1570
Apple	iPhone 13 Pro (256GB)	1	Part 2 BHandset (only electricity)	1571
Apple	iPhone 13 Pro (128GB)	2	Part 2 SP Bid-No Power On-Change Battery(Reference Only)	1572
Apple	iPhone 13 Pro (256GB)	2	Part 2 SP Bid-No Power On-Change Battery(Reference Only)	1573
Apple	iPhone 13 Pro (128GB)	5	Mainboard	1574
Apple	iPhone 13 Pro (256GB)	2	Mainboard	1575
Apple	iPhone 13 Pro (256GB) (Problematic)	1	Part 2 AHandset	1576
Apple	iPhone 13 Pro (128GB) (Problematic)	1	Part 2 BHandset (Power Up, Bad LCD)	1577
Apple	iPhone 13 Total	2549	Summary	1578
Apple	iPhone 13 (128GB)SIM Free	10	AHandset +(Full Fuction)	1579
Apple	iPhone 13 (128GB)SIM Free	16	AHandset (Good)(Full Fuction)	1580
Apple	iPhone 13 (256GB)SIM Free	3	AHandset (Good)(Full Fuction)	1581
Apple	iPhone 13 (128GB)SIM Free	3	AHandset (Good)(Bad Back Camera Glass)(Full Fuction)	1582
Apple	iPhone 13 (128GB)SIM Free	27	AHandset (Good)(Broken Back Glass)(Full Fuction)	1583
Apple	iPhone 13 (128GB)SIM Free	11	AHandset (Good)(Full Fuction)(unknow part message)	1584
Apple	iPhone 13 (128GB)SIM Free	2	AHandset (Good)(unknow part message)	1585
Apple	iPhone 13 (128GB)SIM Free	9	AHandset (Good 1)(Full Fuction)	1586
Apple	iPhone 13 (256GB)SIM Free	7	AHandset (Good 1)(Full Fuction)	1587
Apple	iPhone 13 (512GB)SIM Free	1	AHandset (Good 1)(Full Fuction)	1588
Apple	iPhone 13 (128GB)SIM Free	18	AHandset (Good 1)(Bad Back Camera Glass)(Full Fuction)	1589
Apple	iPhone 13 (128GB)SIM Free	12	AHandset (Good 1)(Broken Back Glass)(Full Fuction)	1590
Apple	iPhone 13 (256GB)SIM Free	17	AHandset (Good 1)(Broken Back Glass)(Full Fuction)	1591
Apple	iPhone 13 (128GB)SIM Free	74	AHandset (Good 1)(Full Fuction)(unknow part message)	1592
Apple	iPhone 13 (256GB)SIM Free	6	AHandset (Good 1)(Full Fuction)(unknow part message)	1593
Apple	iPhone 13 (128GB)SIM Free	22	AHandset (Good 1)(Broken Back Glass)(Full Fuction)(unknow part message)	1594
Apple	iPhone 13 (256GB)SIM Free	2	AHandset (Good 1)(Broken Back Glass)(Full Fuction)(unknow part message)	1595
Apple	iPhone 13 (128GB)SIM Free	339	AHandset (Full Fuction)	1596
Apple	iPhone 13 (256GB)SIM Free	7	AHandset (Full Fuction)	1597
Apple	iPhone 13 (512GB)SIM Free	2	AHandset (Full Fuction)	1598
Apple	iPhone 13 (128GB)SIM Free	22	AHandset (Bad Back Camera Glass)(Full Fuction)	1599
Apple	iPhone 13 (256GB)SIM Free	4	AHandset (Bad Back Camera Glass)(Full Fuction)	1600
Apple	iPhone 13 (512GB)SIM Free	1	AHandset (Bad Back Camera Glass)(Full Fuction)	1601
Apple	iPhone 13 (128GB)SIM Free	128	AHandset (Broken Back Glass)(Full Fuction)	1602
Apple	iPhone 13 (256GB)SIM Free	15	AHandset (Broken Back Glass)(Full Fuction)	1603
Apple	iPhone 13 (128GB)SIM Free	2	AHandset (Broken Back Glass)	1604
Apple	iPhone 13 (128GB)SIM Free	19	AHandset (Full Fuction)(unknow part message)	1605
Apple	iPhone 13 (256GB)SIM Free	4	AHandset (Full Fuction)(unknow part message)	1606
Apple	iPhone 13 (512GB)SIM Free	1	AHandset (Full Fuction)(unknow part message)	1607
Apple	iPhone 13 (128GB)SIM Free	2	AHandset (Bad Back Camera Glass)(Full Fuction)(unknow part message)	1608
Apple	iPhone 13 (128GB)SIM Free	68	AHandset (Broken Back Glass)(Full Fuction)(unknow part message)	1609
Apple	iPhone 13 (256GB)SIM Free	7	AHandset (Broken Back Glass)(Full Fuction)(unknow part message)	1610
Apple	iPhone 13 (128GB)SIM Free	12	AHandset (unknow part message)	1611
Apple	iPhone 13 (256GB)SIM Free	13	AHandset (unknow part message)	1612
Apple	iPhone 13 (128GB)SIM Free	8	AHandset (Bad Back Camera Glass)(unknow part message)	1613
Apple	iPhone 13 (128GB)SIM Free	16	AHandset (Broken Back Glass)(unknow part message)	1614
Apple	iPhone 13 (256GB)SIM Free	4	AHandset (Broken Back Glass)(unknow part message)	1615
Apple	iPhone 13 (128GB)SIM Free	22	BHandset (Power Up, Good LCD)(Full Fuction)	1616
Apple	iPhone 13 (256GB)SIM Free	13	BHandset (Power Up, Good LCD)(Full Fuction)	1617
Apple	iPhone 13 (512GB)SIM Free	1	BHandset (Power Up, Good LCD)(Full Fuction)	1618
Apple	iPhone 13 (128GB)SIM Free	1	BHandset (Power Up, Good LCD)	1619
Apple	iPhone 13 (256GB)SIM Free	1	BHandset (Power Up, Good LCD)	1620
Apple	iPhone 13 (128GB)SIM Free	90	BHandset (Power Up, Good LCD)(Full Fuction)(unknow part message)	1621
Apple	iPhone 13 (256GB)SIM Free	6	BHandset (Power Up, Good LCD)(Full Fuction)(unknow part message)	1622
Apple	iPhone 13 (512GB)SIM Free	1	BHandset (Power Up, Good LCD)(Full Fuction)(unknow part message)	1623
Apple	iPhone 13 (128GB)SIM Free	88	BHandset (Power Up, Good LCD)(unknow part message)	1624
Apple	iPhone 13 (256GB)SIM Free	5	BHandset (Power Up, Good LCD)(unknow part message)	1625
Apple	iPhone 13 (128GB)SIM Free	31	BHandset (Power Up, Bad LCD)(Full Fuction)	1626
Apple	iPhone 13 (128GB)SIM Free	292	BHandset (Power Up, Bad LCD)(FidWorking)	1627
Apple	iPhone 13 (256GB)SIM Free	11	BHandset (Power Up, Bad LCD)(FidWorking)	1628
Apple	iPhone 13 (512GB)SIM Free	6	BHandset (Power Up, Bad LCD)(FidWorking)	1629
Apple	iPhone 13 (128GB)SIM Free	502	BHandset (Power Up, Bad LCD)	1630
Apple	iPhone 13 (256GB)SIM Free	37	BHandset (Power Up, Bad LCD)	1631
Apple	iPhone 13 (512GB)SIM Free	4	BHandset (Power Up, Bad LCD)	1632

Apple	iPhone 13 (128GB)SIM Free	67	BHandset (only electricity)	1633
Apple	iPhone 13 (128GB)SIM Free	319	SP Bid-No Power On-Change Battery(Reference Only)	1634
Apple	iPhone 13 (256GB)SIM Free	19	SP Bid-No Power On-Change Battery(Reference Only)	1635
Apple	iPhone 13 (512GB)SIM Free	1	SP Bid-No Power On-Change Battery(Reference Only)	1636
Apple	iPhone 13 (128GB) (SIM FreeProblematic)	2	Part 2 AHandset	1637
Apple	iPhone 13 (128GB) (SIM FreeProblematic)	3	Part 2 BHandset (Power Up, Good LCD)	1638
Apple	iPhone 13 (256GB) (SIM FreeProblematic)	1	Part 2 BHandset (Power Up, Good LCD)	1639
Apple	iPhone 13 (256GB) (SIM FreeProblematic)	1	Part 2 BHandset (Power Up, Bad LCD)	1640
Apple	iPhone 13 (128GB) (SIM FreeProblematic)	4	Part 2 BHandset (only electricity)	1641
Apple	iPhone 13 (128GB) (SIM Freefid)	4	Part 2 AHandset	1642
Apple	iPhone 13 (256GB) (SIM Freefid)	2	Part 2 AHandset	1643
Apple	iPhone 13 (128GB) (SIM Freefid)	1	Part 2 AHandset (unknow part message)	1644
Apple	iPhone 13 (128GB) (SIM Freefid)	21	Part 2 BHandset (Power Up, Good LCD)	1645
Apple	iPhone 13 (256GB) (SIM Freefid)	1	Part 2 BHandset (Power Up, Good LCD)	1646
Apple	iPhone 13 (128GB) (SIM Freefid)	7	Part 2 BHandset (Power Up, Good LCD)(unknow part message)	1647
Apple	iPhone 13 (256GB) (SIM Freefid)	1	Part 2 BHandset (Power Up, Good LCD)(unknow part message)	1648
Apple	iPhone 13 (128GB)	4	Part 2 AHandset	1649
Apple	iPhone 13 (128GB)	3	Part 2 BHandset (Power Up, Good LCD)	1650
Apple	iPhone 13 (128GB)	23	Part 2 BHandset (Power Up, Bad LCD)	1651
Apple	iPhone 13 (256GB)	1	Part 2 BHandset (Power Up, Bad LCD)	1652
Apple	iPhone 13 (128GB)	15	Part 2 BHandset (only electricity)	1653
Apple	iPhone 13 (512GB)	1	Part 2 BHandset (only electricity)	1654
Apple	iPhone 13 (128GB)	3	Part 2 SP Bid-No Power On-Change Battery(Reference Only)	1655
Apple	iPhone 13 (128GB)	13	Mainboard	1656
Apple	iPhone 13 (256GB)	1	Mainboard	1657
Apple	iPhone 13 (128GB) (Problematic)	2	Part 2 AHandset	1658
Apple	iPhone 13 (128GB) (Problematic)	2	Part 2 BHandset (Power Up, Good LCD)	1659
Apple	iPhone 13 (256GB) (Problematic)	1	Part 2 BHandset (Power Up, Good LCD)	1660
Apple	iPhone 13 (256GB) (Problematic)	1	Part 2 BHandset (Power Up, Bad LCD)	1661
Apple	iPhone 13 Mini Total	509	Summary	1662
Apple	iPhone 13 Mini (128GB)SIM Free	2	AHandset (Good)	1663
Apple	iPhone 13 Mini (128GB)SIM Free	1	AHandset (Good)(Full Fuction)(unknow part message)	1664
Apple	iPhone 13 Mini (128GB)SIM Free	1	AHandset (Good)(unknow part message)	1665
Apple	iPhone 13 Mini (128GB)SIM Free	14	AHandset (Good 1)(Full Fuction)	1666
Apple	iPhone 13 Mini (256GB)SIM Free	1	AHandset (Good 1)(Full Fuction)	1667
Apple	iPhone 13 Mini (128GB)SIM Free	2	AHandset (Good 1)(Bad Back Camera Glass)(Full Fuction)	1668
Apple	iPhone 13 Mini (128GB)SIM Free	4	AHandset (Good 1)(Broken Back Glass)(Full Fuction)	1669
Apple	iPhone 13 Mini (128GB)SIM Free	3	AHandset (Good 1)	1670
Apple	iPhone 13 Mini (128GB)SIM Free	17	AHandset (Good 1)(Full Fuction)(unknow part message)	1671
Apple	iPhone 13 Mini (128GB)SIM Free	15	AHandset (Full Fuction)	1672
Apple	iPhone 13 Mini (256GB)SIM Free	2	AHandset (Full Fuction)	1673
Apple	iPhone 13 Mini (128GB)SIM Free	2	AHandset (Bad Back Camera Glass)(Full Fuction)	1674
Apple	iPhone 13 Mini (128GB)SIM Free	9	AHandset (Broken Back Glass)(Full Fuction)	1675
Apple	iPhone 13 Mini (512GB)SIM Free	1	AHandset (Broken Back Glass)(Full Fuction)	1676
Apple	iPhone 13 Mini (128GB)SIM Free	2	AHandset	1677
Apple	iPhone 13 Mini (128GB)SIM Free	7	AHandset (Bad Back Camera Glass)	1678
Apple	iPhone 13 Mini (128GB)SIM Free	8	AHandset (Full Fuction)(unknow part message)	1679
Apple	iPhone 13 Mini (128GB)SIM Free	3	AHandset (Bad Back Camera Glass)(Full Fuction)(unknow part message)	1680
Apple	iPhone 13 Mini (128GB)SIM Free	5	AHandset (unknow part message)	1681
Apple	iPhone 13 Mini (256GB)SIM Free	2	AHandset (unknow part message)	1682
Apple	iPhone 13 Mini (128GB)SIM Free	3	AHandset (Bad Back Camera Glass)(unknow part message)	1683
Apple	iPhone 13 Mini (128GB)SIM Free	2	AHandset (Broken Back Glass)(unknow part message)	1684
Apple	iPhone 13 Mini (128GB)SIM Free	7	BHandset (Power Up, Good LCD)(Full Fuction)	1685
Apple	iPhone 13 Mini (256GB)SIM Free	1	BHandset (Power Up, Good LCD)(Full Fuction)	1686
Apple	iPhone 13 Mini (128GB)SIM Free	5	BHandset (Power Up, Good LCD)(Full Fuction)(unknow part message)	1687
Apple	iPhone 13 Mini (128GB)SIM Free	10	BHandset (Power Up, Good LCD)(unknow part message)	1688
Apple	iPhone 13 Mini (256GB)SIM Free	1	BHandset (Power Up, Good LCD)(unknow part message)	1689
Apple	iPhone 13 Mini (128GB)SIM Free	8	BHandset (Power Up, Bad LCD)(Full Fuction)	1690
Apple	iPhone 13 Mini (128GB)SIM Free	81	BHandset (Power Up, Bad LCD)(FidWorking)	1691
Apple	iPhone 13 Mini (256GB)SIM Free	9	BHandset (Power Up, Bad LCD)(FidWorking)	1692
Apple	iPhone 13 Mini (128GB)SIM Free	121	BHandset (Power Up, Bad LCD)	1693
Apple	iPhone 13 Mini (256GB)SIM Free	21	BHandset (Power Up, Bad LCD)	1694
Apple	iPhone 13 Mini (512GB)SIM Free	2	BHandset (Power Up, Bad LCD)	1695
Apple	iPhone 13 Mini (128GB)SIM Free	44	BHandset (only electricity)	1696
Apple	iPhone 13 Mini (256GB)SIM Free	1	BHandset (only electricity)	1697
Apple	iPhone 13 Mini (512GB)SIM Free	1	BHandset (only electricity)	1698
Apple	iPhone 13 Mini (128GB)SIM Free	21	SP Bid-No Power On-Change Battery(Reference Only)	1699
Apple	iPhone 13 Mini (256GB)SIM Free	3	SP Bid-No Power On-Change Battery(Reference Only)	1700
Apple	iPhone 13 Mini (128GB) (SIM FreeProblematic)	17	Part 2 AHandset	1701
Apple	iPhone 13 Mini (256GB) (SIM FreeProblematic)	7	Part 2 AHandset	1702
Apple	iPhone 13 Mini (128GB) (SIM FreeProblematic)	3	Part 2 BHandset (Power Up, Good LCD)	1703
Apple	iPhone 13 Mini (256GB) (SIM FreeProblematic)	1	Part 2 BHandset (Power Up, Good LCD)	1704
Apple	iPhone 13 Mini (128GB) (SIM FreeProblematic)	11	Part 2 BHandset (Power Up, Bad LCD)	1705
Apple	iPhone 13 Mini (256GB) (SIM FreeProblematic)	3	Part 2 BHandset (Power Up, Bad LCD)	1706
Apple	iPhone 13 Mini (128GB) (SIM Freefid)	1	Part 2 AHandset	1707
Apple	iPhone 13 Mini (128GB) (SIM Freefid)	3	Part 2 BHandset (Power Up, Good LCD)	1708
Apple	iPhone 13 Mini (128GB)	5	Part 2 BHandset (Power Up, Bad LCD)	1709
Apple	iPhone 13 Mini (128GB)	5	Part 2 BHandset (only electricity)	1710
Apple	iPhone 13 Mini (128GB)	5	Part 2 SP Bid-No Power On-Change Battery(Reference Only)	1711
Apple	iPhone 13 Mini (128GB)	4	Mainboard	1712
Apple	iPhone 13 Mini (128GB) (Problematic)	2	Part 2 AHandset	1713
Apple	iPhone 12 Pro Max Total	1562	Summary	1714
Apple	iPhone 12 Pro Max (128GB)SIM Free	1	AHandset (Good)(Full Fuction)	1715
Apple	iPhone 12 Pro Max (256GB)SIM Free	1	AHandset (Good)(Full Fuction)	1716
Apple	iPhone 12 Pro Max (512GB)SIM Free	1	AHandset (Good)(Full Fuction)	1717
Apple	iPhone 12 Pro Max (256GB)SIM Free	2	AHandset (Good)(Broken Back Glass)(Full Fuction)	1718

Apple	iPhone 12 Pro Max (128GB)SIM Free	1	AHandset (Good)(Full Fuction)(unknow part message)	1719
Apple	iPhone 12 Pro Max (256GB)SIM Free	6	AHandset (Good)(unknow part message)	1720
Apple	iPhone 12 Pro Max (256GB)SIM Free	2	AHandset (Good 1)(Full Fuction)	1721
Apple	iPhone 12 Pro Max (128GB)SIM Free	2	AHandset (Good 1)(Broken Back Glass)(Full Fuction)	1722
Apple	iPhone 12 Pro Max (256GB)SIM Free	4	AHandset (Good 1)(Broken Back Glass)(Full Fuction)	1723
Apple	iPhone 12 Pro Max (128GB)SIM Free	1	AHandset (Good 1)	1724
Apple	iPhone 12 Pro Max (256GB)SIM Free	2	AHandset (Good 1)	1725
Apple	iPhone 12 Pro Max (256GB)SIM Free	1	AHandset (Good 1)(Broken Back Glass)	1726
Apple	iPhone 12 Pro Max (128GB)SIM Free	17	AHandset (Good 1)(Full Fuction)(unknow part message)	1727
Apple	iPhone 12 Pro Max (256GB)SIM Free	6	AHandset (Good 1)(Full Fuction)(unknow part message)	1728
Apple	iPhone 12 Pro Max (128GB)SIM Free	21	AHandset (Good 1)(Broken Back Glass)(Full Fuction)(unknow part message)	1729
Apple	iPhone 12 Pro Max (256GB)SIM Free	4	AHandset (Good 1)(Broken Back Glass)(Full Fuction)(unknow part message)	1730
Apple	iPhone 12 Pro Max (128GB)SIM Free	9	AHandset (Good 1)(unknow part message)	1731
Apple	iPhone 12 Pro Max (256GB)SIM Free	14	AHandset (Good 1)(unknow part message)	1732
Apple	iPhone 12 Pro Max (128GB)SIM Free	5	AHandset (Broken Back Glass)(Full Fuction)	1733
Apple	iPhone 12 Pro Max (256GB)SIM Free	7	AHandset (Broken Back Glass)(Full Fuction)	1734
Apple	iPhone 12 Pro Max (512GB)SIM Free	1	AHandset (Broken Back Glass)(Full Fuction)	1735
Apple	iPhone 12 Pro Max (128GB)SIM Free	11	AHandset	1736
Apple	iPhone 12 Pro Max (256GB)SIM Free	7	AHandset	1737
Apple	iPhone 12 Pro Max (512GB)SIM Free	1	AHandset	1738
Apple	iPhone 12 Pro Max (128GB)SIM Free	6	AHandset (Bad Back Camera Glass)	1739
Apple	iPhone 12 Pro Max (256GB)SIM Free	1	AHandset (Bad Back Camera Glass)	1740
Apple	iPhone 12 Pro Max (512GB)SIM Free	1	AHandset (Bad Back Camera Glass)	1741
Apple	iPhone 12 Pro Max (128GB)SIM Free	12	AHandset (Broken Back Glass)	1742
Apple	iPhone 12 Pro Max (256GB)SIM Free	2	AHandset (Broken Back Glass)	1743
Apple	iPhone 12 Pro Max (128GB)SIM Free	6	AHandset (Full Fuction)(unknow part message)	1744
Apple	iPhone 12 Pro Max (256GB)SIM Free	2	AHandset (Full Fuction)(unknow part message)	1745
Apple	iPhone 12 Pro Max (512GB)SIM Free	1	AHandset (Full Fuction)(unknow part message)	1746
Apple	iPhone 12 Pro Max (128GB)SIM Free	6	AHandset (Bad Back Camera Glass)(Full Fuction)(unknow part message)	1747
Apple	iPhone 12 Pro Max (128GB)SIM Free	22	AHandset (Broken Back Glass)(Full Fuction)(unknow part message)	1748
Apple	iPhone 12 Pro Max (256GB)SIM Free	2	AHandset (Broken Back Glass)(Full Fuction)(unknow part message)	1749
Apple	iPhone 12 Pro Max (512GB)SIM Free	1	AHandset (Broken Back Glass)(Full Fuction)(unknow part message)	1750
Apple	iPhone 12 Pro Max (128GB)SIM Free	15	AHandset (unknow part message)	1751
Apple	iPhone 12 Pro Max (256GB)SIM Free	9	AHandset (unknow part message)	1752
Apple	iPhone 12 Pro Max (512GB)SIM Free	3	AHandset (unknow part message)	1753
Apple	iPhone 12 Pro Max (128GB)SIM Free	2	AHandset (Bad Back Camera Glass)(unknow part message)	1754
Apple	iPhone 12 Pro Max (256GB)SIM Free	1	AHandset (Bad Back Camera Glass)(unknow part message)	1755
Apple	iPhone 12 Pro Max (128GB)SIM Free	42	AHandset (Broken Back Glass)(unknow part message)	1756
Apple	iPhone 12 Pro Max (256GB)SIM Free	14	AHandset (Broken Back Glass)(unknow part message)	1757
Apple	iPhone 12 Pro Max (512GB)SIM Free	1	BHandset (Power Up, Good LCD)	1758
Apple	iPhone 12 Pro Max (128GB)SIM Free	38	BHandset (Power Up, Good LCD)(Full Fuction)(unknow part message)	1759
Apple	iPhone 12 Pro Max (256GB)SIM Free	3	BHandset (Power Up, Good LCD)(Full Fuction)(unknow part message)	1760
Apple	iPhone 12 Pro Max (128GB)SIM Free	38	BHandset (Power Up, Good LCD)(unknow part message)	1761
Apple	iPhone 12 Pro Max (256GB)SIM Free	13	BHandset (Power Up, Good LCD)(unknow part message)	1762
Apple	iPhone 12 Pro Max (512GB)SIM Free	2	BHandset (Power Up, Good LCD)(unknow part message)	1763
Apple	iPhone 12 Pro Max (128GB)SIM Free	6	BHandset (Power Up, Bad LCD)(Full Fuction)	1764
Apple	iPhone 12 Pro Max (256GB)SIM Free	18	BHandset (Power Up, Bad LCD)(Full Fuction)	1765
Apple	iPhone 12 Pro Max (128GB)SIM Free	19	BHandset (Power Up, Bad LCD)(FidWorking)	1766
Apple	iPhone 12 Pro Max (256GB)SIM Free	10	BHandset (Power Up, Bad LCD)(FidWorking)	1767
Apple	iPhone 12 Pro Max (512GB)SIM Free	2	BHandset (Power Up, Bad LCD)(FidWorking)	1768
Apple	iPhone 12 Pro Max (128GB)SIM Free	290	BHandset (Power Up, Bad LCD)	1769
Apple	iPhone 12 Pro Max (256GB)SIM Free	118	BHandset (Power Up, Bad LCD)	1770
Apple	iPhone 12 Pro Max (512GB)SIM Free	22	BHandset (Power Up, Bad LCD)	1771
Apple	iPhone 12 Pro Max (128GB)SIM Free	19	BHandset (Power Up, Bad LCD)(FidWorking)(unknow part message)	1772
Apple	iPhone 12 Pro Max (128GB)SIM Free	16	BHandset (Power Up, Bad LCD)(unknow part message)	1773
Apple	iPhone 12 Pro Max (256GB)SIM Free	3	BHandset (Power Up, Bad LCD)(unknow part message)	1774
Apple	iPhone 12 Pro Max (512GB)SIM Free	1	BHandset (Power Up, Bad LCD)(unknow part message)	1775
Apple	iPhone 12 Pro Max (128GB)SIM Free	163	BHandset (only electricity)	1776
Apple	iPhone 12 Pro Max (256GB)SIM Free	38	BHandset (only electricity)	1777
Apple	iPhone 12 Pro Max (512GB)SIM Free	3	BHandset (only electricity)	1778
Apple	iPhone 12 Pro Max (128GB)SIM Free	216	SP Bid-No Power On-Change Battery(Reference Only)	1779
Apple	iPhone 12 Pro Max (256GB)SIM Free	38	SP Bid-No Power On-Change Battery(Reference Only)	1780
Apple	iPhone 12 Pro Max (512GB)SIM Free	4	SP Bid-No Power On-Change Battery(Reference Only)	1781
Apple	iPhone 12 Pro Max (128GB) (SIM FreeProblematic)	26	Part 2 AHandset	1782
Apple	iPhone 12 Pro Max (256GB) (SIM FreeProblematic)	6	Part 2 AHandset	1783
Apple	iPhone 12 Pro Max (512GB) (SIM FreeProblematic)	7	Part 2 AHandset	1784
Apple	iPhone 12 Pro Max (128GB) (SIM FreeProblematic)	6	Part 2 AHandset (unknow part message)	1785
Apple	iPhone 12 Pro Max (256GB) (SIM FreeProblematic)	4	Part 2 AHandset (unknow part message)	1786
Apple	iPhone 12 Pro Max (128GB) (SIM FreeProblematic)	14	Part 2 BHandset (Power Up, Good LCD)	1787
Apple	iPhone 12 Pro Max (256GB) (SIM FreeProblematic)	5	Part 2 BHandset (Power Up, Good LCD)	1788
Apple	iPhone 12 Pro Max (512GB) (SIM FreeProblematic)	1	Part 2 BHandset (Power Up, Good LCD)	1789
Apple	iPhone 12 Pro Max (128GB) (SIM FreeProblematic)	19	Part 2 BHandset (Power Up, Bad LCD)	1790
Apple	iPhone 12 Pro Max (256GB) (SIM FreeProblematic)	7	Part 2 BHandset (Power Up, Bad LCD)	1791
Apple	iPhone 12 Pro Max (512GB) (SIM FreeProblematic)	2	Part 2 BHandset (Power Up, Bad LCD)	1792
Apple	iPhone 12 Pro Max (128GB) (SIM FreeProblematic)	2	Part 2 BHandset (only electricity)	1793
Apple	iPhone 12 Pro Max (256GB) (SIM FreeProblematic)	1	Part 2 BHandset (only electricity)	1794
Apple	iPhone 12 Pro Max (128GB) (SIM Freefid)	3	Part 2 AHandset	1795
Apple	iPhone 12 Pro Max (256GB) (SIM Freefid)	2	Part 2 AHandset	1796
Apple	iPhone 12 Pro Max (512GB) (SIM Freefid)	1	Part 2 AHandset	1797
Apple	iPhone 12 Pro Max (128GB) (SIM Freefid)	29	Part 2 AHandset (unknow part message)	1798
Apple	iPhone 12 Pro Max (256GB) (SIM Freefid)	1	Part 2 AHandset (unknow part message)	1799
Apple	iPhone 12 Pro Max (512GB) (SIM Freefid)	1	Part 2 AHandset (unknow part message)	1800
Apple	iPhone 12 Pro Max (128GB) (SIM Freefid)	2	Part 2 BHandset (Power Up, Good LCD)	1801
Apple	iPhone 12 Pro Max (256GB) (SIM Freefid)	1	Part 2 BHandset (Power Up, Good LCD)	1802
Apple	iPhone 12 Pro Max (128GB) (SIM Freefid)	8	Part 2 BHandset (Power Up, Good LCD)(unknow part message)	1803
Apple	iPhone 12 Pro Max (256GB) (SIM Freefid)	1	Part 2 BHandset (Power Up, Good LCD)(unknow part message)	1804

Apple	iPhone 12 Pro Max (512GB) (SIM Freefid)	2	Part 2 BHandset (Power Up, Good LCD)(unknow part message)	1805
Apple	iPhone 12 Pro Max (128GB)	3	Part 2 AHandset	1806
Apple	iPhone 12 Pro Max (256GB)	3	Part 2 AHandset	1807
Apple	iPhone 12 Pro Max (128GB)	5	Part 2 BHandset (Power Up, Good LCD)	1808
Apple	iPhone 12 Pro Max (128GB)	10	Part 2 BHandset (Power Up, Bad LCD)	1809
Apple	iPhone 12 Pro Max (256GB)	2	Part 2 BHandset (Power Up, Bad LCD)	1810
Apple	iPhone 12 Pro Max (128GB)	6	Part 2 BHandset (only electricity)	1811
Apple	iPhone 12 Pro Max (256GB)	2	Part 2 BHandset (only electricity)	1812
Apple	iPhone 12 Pro Max (128GB)	6	Part 2 SP Bid-No Power On-Change Battery(Reference Only)	1813
Apple	iPhone 12 Pro Max (256GB)	4	Part 2 SP Bid-No Power On-Change Battery(Reference Only)	1814
Apple	iPhone 12 Pro Max (128GB)	3	Mainboard	1815
Apple	iPhone 12 Pro Max (256GB)	1	Mainboard	1816
Apple	iPhone 12 Pro Max (128GB) (Problematic)	4	Part 2 AHandset	1817
Apple	iPhone 12 Pro Max (256GB) (Problematic)	3	Part 2 AHandset	1818
Apple	iPhone 12 Pro Max (128GB) (Problematic)	1	Part 2 BHandset (Power Up, Good LCD)	1819
Apple	iPhone 12 Pro Max (128GB) (Problematic)	1	Part 2 BHandset (Power Up, Bad LCD)	1820
Apple	iPhone 12 Pro Max (256GB) (Problematic)	1	Part 2 BHandset (Power Up, Bad LCD)	1821
Apple	iPhone 12 Pro Total	1862	Summary	1822
Apple	iPhone 12 Pro (128GB)SIM Free	1	Nearly New Handset(Full Fuction)	1823
Apple	iPhone 12 Pro (128GB)SIM Free	1	Nearly New Handset	1824
Apple	iPhone 12 Pro (128GB)SIM Free	41	AHandset (Good)(Full Fuction)	1825
Apple	iPhone 12 Pro (256GB)SIM Free	6	AHandset (Good)(Full Fuction)	1826
Apple	iPhone 12 Pro (128GB)SIM Free	8	AHandset (Good)(Broken Back Glass)(Full Fuction)	1827
Apple	iPhone 12 Pro (128GB)SIM Free	4	AHandset (Good)	1828
Apple	iPhone 12 Pro (256GB)SIM Free	1	AHandset (Good)	1829
Apple	iPhone 12 Pro (128GB)SIM Free	7	AHandset (Good)(Full Fuction)(unknow part message)	1830
Apple	iPhone 12 Pro (128GB)SIM Free	1	AHandset (Good)(Broken Back Glass)(Full Fuction)(unknow part message)	1831
Apple	iPhone 12 Pro (128GB)SIM Free	208	AHandset (Good 1)(Full Fuction)	1832
Apple	iPhone 12 Pro (256GB)SIM Free	2	AHandset (Good 1)(Full Fuction)	1833
Apple	iPhone 12 Pro (512GB)SIM Free	3	AHandset (Good 1)(Full Fuction)	1834
Apple	iPhone 12 Pro (128GB)SIM Free	4	AHandset (Good 1)(Bad Back Camera Glass)(Full Fuction)	1835
Apple	iPhone 12 Pro (128GB)SIM Free	59	AHandset (Good 1)(Broken Back Glass)(Full Fuction)	1836
Apple	iPhone 12 Pro (256GB)SIM Free	5	AHandset (Good 1)(Broken Back Glass)(Full Fuction)	1837
Apple	iPhone 12 Pro (512GB)SIM Free	2	AHandset (Good 1)(Broken Back Glass)(Full Fuction)	1838
Apple	iPhone 12 Pro (128GB)SIM Free	2	AHandset (Good 1)	1839
Apple	iPhone 12 Pro (256GB)SIM Free	1	AHandset (Good 1)	1840
Apple	iPhone 12 Pro (128GB)SIM Free	1	AHandset (Good 1)(Broken Back Glass)	1841
Apple	iPhone 12 Pro (128GB)SIM Free	16	AHandset (Good 1)(Full Fuction)(unknow part message)	1842
Apple	iPhone 12 Pro (256GB)SIM Free	6	AHandset (Good 1)(Full Fuction)(unknow part message)	1843
Apple	iPhone 12 Pro (512GB)SIM Free	5	AHandset (Good 1)(Full Fuction)(unknow part message)	1844
Apple	iPhone 12 Pro (128GB)SIM Free	2	AHandset (Good 1)(Broken Back Glass)(Full Fuction)(unknow part message)	1845
Apple	iPhone 12 Pro (256GB)SIM Free	5	AHandset (Good 1)(Broken Back Glass)(Full Fuction)(unknow part message)	1846
Apple	iPhone 12 Pro (512GB)SIM Free	1	AHandset (Good 1)(Broken Back Glass)(Full Fuction)(unknow part message)	1847
Apple	iPhone 12 Pro (128GB)SIM Free	13	AHandset (Good 1)(unknow part message)	1848
Apple	iPhone 12 Pro (128GB)SIM Free	207	AHandset (Full Fuction)	1849
Apple	iPhone 12 Pro (256GB)SIM Free	4	AHandset (Full Fuction)	1850
Apple	iPhone 12 Pro (512GB)SIM Free	3	AHandset (Full Fuction)	1851
Apple	iPhone 12 Pro (128GB)SIM Free	8	AHandset (Bad Back Camera Glass)(Full Fuction)	1852
Apple	iPhone 12 Pro (256GB)SIM Free	1	AHandset (Bad Back Camera Glass)(Full Fuction)	1853
Apple	iPhone 12 Pro (128GB)SIM Free	76	AHandset (Broken Back Glass)(Full Fuction)	1854
Apple	iPhone 12 Pro (256GB)SIM Free	12	AHandset (Broken Back Glass)(Full Fuction)	1855
Apple	iPhone 12 Pro (512GB)SIM Free	1	AHandset (Broken Back Glass)(Full Fuction)	1856
Apple	iPhone 12 Pro (128GB)SIM Free	33	AHandset	1857
Apple	iPhone 12 Pro (256GB)SIM Free	5	AHandset	1858
Apple	iPhone 12 Pro (512GB)SIM Free	1	AHandset	1859
Apple	iPhone 12 Pro (128GB)SIM Free	6	AHandset (Bad Back Camera Glass)	1860
Apple	iPhone 12 Pro (256GB)SIM Free	1	AHandset (Bad Back Camera Glass)	1861
Apple	iPhone 12 Pro (512GB)SIM Free	7	AHandset (Bad Back Camera Glass)	1862
Apple	iPhone 12 Pro (128GB)SIM Free	12	AHandset (Broken Back Glass)	1863
Apple	iPhone 12 Pro (256GB)SIM Free	1	AHandset (Broken Back Glass)	1864
Apple	iPhone 12 Pro (512GB)SIM Free	1	AHandset (Broken Back Glass)	1865
Apple	iPhone 12 Pro (128GB)SIM Free	28	AHandset (Full Fuction)(unknow part message)	1866
Apple	iPhone 12 Pro (256GB)SIM Free	4	AHandset (Full Fuction)(unknow part message)	1867
Apple	iPhone 12 Pro (128GB)SIM Free	1	AHandset (Bad Back Camera Glass)(Full Fuction)(unknow part message)	1868
Apple	iPhone 12 Pro (128GB)SIM Free	11	AHandset (Broken Back Glass)(Full Fuction)(unknow part message)	1869
Apple	iPhone 12 Pro (256GB)SIM Free	3	AHandset (Broken Back Glass)(Full Fuction)(unknow part message)	1870
Apple	iPhone 12 Pro (128GB)SIM Free	52	AHandset (unknow part message)	1871
Apple	iPhone 12 Pro (256GB)SIM Free	14	AHandset (unknow part message)	1872
Apple	iPhone 12 Pro (512GB)SIM Free	2	AHandset (unknow part message)	1873
Apple	iPhone 12 Pro (128GB)SIM Free	6	AHandset (Bad Back Camera Glass)(unknow part message)	1874
Apple	iPhone 12 Pro (256GB)SIM Free	1	AHandset (Bad Back Camera Glass)(unknow part message)	1875
Apple	iPhone 12 Pro (128GB)SIM Free	24	AHandset (Broken Back Glass)(unknow part message)	1876
Apple	iPhone 12 Pro (256GB)SIM Free	2	AHandset (Broken Back Glass)(unknow part message)	1877
Apple	iPhone 12 Pro (512GB)SIM Free	1	AHandset (Broken Back Glass)(unknow part message)	1878
Apple	iPhone 12 Pro (128GB)SIM Free	43	BHandset (Power Up, Good LCD)(Full Fuction)	1879
Apple	iPhone 12 Pro (256GB)SIM Free	7	BHandset (Power Up, Good LCD)(Full Fuction)	1880
Apple	iPhone 12 Pro (512GB)SIM Free	3	BHandset (Power Up, Good LCD)(Full Fuction)	1881
Apple	iPhone 12 Pro (128GB)SIM Free	3	BHandset (Power Up, Good LCD)	1882
Apple	iPhone 12 Pro (256GB)SIM Free	2	BHandset (Power Up, Good LCD)	1883
Apple	iPhone 12 Pro (128GB)SIM Free	37	BHandset (Power Up, Good LCD)(Full Fuction)(unknow part message)	1884
Apple	iPhone 12 Pro (256GB)SIM Free	8	BHandset (Power Up, Good LCD)(Full Fuction)(unknow part message)	1885
Apple	iPhone 12 Pro (128GB)SIM Free	17	BHandset (Power Up, Good LCD)(unknow part message)	1886
Apple	iPhone 12 Pro (256GB)SIM Free	2	BHandset (Power Up, Good LCD)(unknow part message)	1887
Apple	iPhone 12 Pro (512GB)SIM Free	1	BHandset (Power Up, Good LCD)(unknow part message)	1888
Apple	iPhone 12 Pro (128GB)SIM Free	34	BHandset (Power Up, Bad LCD)(Full Fuction)	1889
Apple	iPhone 12 Pro (256GB)SIM Free	8	BHandset (Power Up, Bad LCD)(Full Fuction)	1890

Apple	iPhone 12 Pro (512GB)SIM Free	3	BHandset (Power Up, Bad LCD)(Full Fuction)	1891
Apple	iPhone 12 Pro (128GB)SIM Free	39	BHandset (Power Up, Bad LCD)(FidWorking)	1892
Apple	iPhone 12 Pro (256GB)SIM Free	3	BHandset (Power Up, Bad LCD)(FidWorking)	1893
Apple	iPhone 12 Pro (512GB)SIM Free	2	BHandset (Power Up, Bad LCD)(FidWorking)	1894
Apple	iPhone 12 Pro (128GB)SIM Free	285	BHandset (Power Up, Bad LCD)	1895
Apple	iPhone 12 Pro (256GB)SIM Free	86	BHandset (Power Up, Bad LCD)	1896
Apple	iPhone 12 Pro (512GB)SIM Free	18	BHandset (Power Up, Bad LCD)	1897
Apple	iPhone 12 Pro (128GB)SIM Free	71	BHandset (only electricity)	1898
Apple	iPhone 12 Pro (256GB)SIM Free	20	BHandset (only electricity)	1899
Apple	iPhone 12 Pro (128GB)SIM Free	78	SP Bid-No Power On-Change Battery(Reference Only)	1900
Apple	iPhone 12 Pro (256GB)SIM Free	15	SP Bid-No Power On-Change Battery(Reference Only)	1901
Apple	iPhone 12 Pro (512GB)SIM Free	1	SP Bid-No Power On-Change Battery(Reference Only)	1902
Apple	iPhone 12 Pro (128GB) (SIM FreeProblematic)	11	Part 2 AHandset	1903
Apple	iPhone 12 Pro (256GB) (SIM FreeProblematic)	7	Part 2 AHandset	1904
Apple	iPhone 12 Pro (512GB) (SIM FreeProblematic)	2	Part 2 AHandset	1905
Apple	iPhone 12 Pro (128GB) (SIM FreeProblematic)	6	Part 2 BHandset (Power Up, Good LCD)	1906
Apple	iPhone 12 Pro (256GB) (SIM FreeProblematic)	4	Part 2 BHandset (Power Up, Good LCD)	1907
Apple	iPhone 12 Pro (128GB) (SIM FreeProblematic)	21	Part 2 BHandset (Power Up, Bad LCD)	1908
Apple	iPhone 12 Pro (256GB) (SIM FreeProblematic)	2	Part 2 BHandset (Power Up, Bad LCD)	1909
Apple	iPhone 12 Pro (512GB) (SIM FreeProblematic)	1	Part 2 BHandset (Power Up, Bad LCD)	1910
Apple	iPhone 12 Pro (128GB) (SIM FreeProblematic)	1	Part 2 BHandset (only electricity)	1911
Apple	iPhone 12 Pro (128GB) (SIM Freefid)	13	Part 2 AHandset	1912
Apple	iPhone 12 Pro (256GB) (SIM Freefid)	4	Part 2 AHandset	1913
Apple	iPhone 12 Pro (512GB) (SIM Freefid)	1	Part 2 AHandset	1914
Apple	iPhone 12 Pro (256GB) (SIM Freefid)	1	Part 2 AHandset (unknow part message)	1915
Apple	iPhone 12 Pro (128GB) (SIM Freefid)	9	Part 2 BHandset (Power Up, Good LCD)	1916
Apple	iPhone 12 Pro (256GB) (SIM Freefid)	2	Part 2 BHandset (Power Up, Good LCD)	1917
Apple	iPhone 12 Pro (128GB)	1	Part 2 AHandset	1918
Apple	iPhone 12 Pro (128GB)	2	Part 2 BHandset (Power Up, Good LCD)	1919
Apple	iPhone 12 Pro (256GB)	2	Part 2 BHandset (Power Up, Good LCD)	1920
Apple	iPhone 12 Pro (128GB)	7	Part 2 BHandset (Power Up, Bad LCD)	1921
Apple	iPhone 12 Pro (256GB)	2	Part 2 BHandset (Power Up, Bad LCD)	1922
Apple	iPhone 12 Pro (128GB)	8	Part 2 BHandset (only electricity)	1923
Apple	iPhone 12 Pro (128GB)	17	Part 2 SP Bid-No Power On-Change Battery(Reference Only)	1924
Apple	iPhone 12 Pro (128GB)	15	Mainboard	1925
Apple	iPhone 12 Pro (256GB)	2	Mainboard	1926
Apple	iPhone 12 Pro (128GB) (Problematic)	1	Part 2 BHandset (Power Up, Good LCD)	1927
Apple	iPhone 12 Pro (256GB) (Problematic)	1	Part 2 BHandset (Power Up, Good LCD)	1928
Apple	iPhone 12 Total	1743	Summary	1929
Apple	iPhone 12 (128GB)SIM Free	2	AHandset (Good)(Full Fuction)	1930
Apple	iPhone 12 (64GB)SIM Free	2	AHandset (Good)(Full Fuction)	1931
Apple	iPhone 12 (128GB)SIM Free	1	AHandset (Good)(Full Fuction)(unknow part message)	1932
Apple	iPhone 12 (128GB)SIM Free	1	AHandset (Good 1)(Full Fuction)	1933
Apple	iPhone 12 (64GB)SIM Free	1	AHandset (Good 1)(Full Fuction)	1934
Apple	iPhone 12 (128GB)SIM Free	1	AHandset (Good 1)(Bad Back Camera Glass)(Full Fuction)	1935
Apple	iPhone 12 (128GB)SIM Free	1	AHandset (Good 1)(Broken Back Glass)(Full Fuction)	1936
Apple	iPhone 12 (256GB)SIM Free	3	AHandset (Good 1)(Broken Back Glass)(Full Fuction)	1937
Apple	iPhone 12 (64GB)SIM Free	34	AHandset (Good 1)(Broken Back Glass)(Full Fuction)	1938
Apple	iPhone 12 (64GB)SIM Free	5	AHandset (Good 1)(Full Fuction)(unknow part message)	1939
Apple	iPhone 12 (64GB)SIM Free	6	AHandset (Good 1)(Broken Back Glass)(Full Fuction)(unknow part message)	1940
Apple	iPhone 12 (128GB)SIM Free	41	AHandset (Full Fuction)	1941
Apple	iPhone 12 (256GB)SIM Free	6	AHandset (Full Fuction)	1942
Apple	iPhone 12 (64GB)SIM Free	7	AHandset (Full Fuction)	1943
Apple	iPhone 12 (64GB)SIM Free	1	AHandset (Bad Back Camera Glass)(Full Fuction)	1944
Apple	iPhone 12 (128GB)SIM Free	1	AHandset (Broken Back Glass)(Full Fuction)	1945
Apple	iPhone 12 (256GB)SIM Free	4	AHandset (Broken Back Glass)(Full Fuction)	1946
Apple	iPhone 12 (64GB)SIM Free	69	AHandset (Broken Back Glass)(Full Fuction)	1947
Apple	iPhone 12 (128GB)SIM Free	5	AHandset	1948
Apple	iPhone 12 (64GB)SIM Free	1	AHandset	1949
Apple	iPhone 12 (128GB)SIM Free	2	AHandset (Broken Back Glass)	1950
Apple	iPhone 12 (64GB)SIM Free	17	AHandset (Broken Back Glass)	1951
Apple	iPhone 12 (128GB)SIM Free	4	AHandset (Full Fuction)(unknow part message)	1952
Apple	iPhone 12 (64GB)SIM Free	16	AHandset (Full Fuction)(unknow part message)	1953
Apple	iPhone 12 (128GB)SIM Free	3	AHandset (Broken Back Glass)(Full Fuction)(unknow part message)	1954
Apple	iPhone 12 (64GB)SIM Free	18	AHandset (Broken Back Glass)(Full Fuction)(unknow part message)	1955
Apple	iPhone 12 (128GB)SIM Free	7	AHandset (unknow part message)	1956
Apple	iPhone 12 (64GB)SIM Free	13	AHandset (unknow part message)	1957
Apple	iPhone 12 (64GB)SIM Free	1	AHandset (Bad Back Camera Glass)(unknow part message)	1958
Apple	iPhone 12 (128GB)SIM Free	9	AHandset (Broken Back Glass)(unknow part message)	1959
Apple	iPhone 12 (256GB)SIM Free	1	AHandset (Broken Back Glass)(unknow part message)	1960
Apple	iPhone 12 (64GB)SIM Free	25	AHandset (Broken Back Glass)(unknow part message)	1961
Apple	iPhone 12 (128GB)SIM Free	8	BHandset (Power Up, Good LCD)(Full Fuction)	1962
Apple	iPhone 12 (256GB)SIM Free	4	BHandset (Power Up, Good LCD)(Full Fuction)	1963
Apple	iPhone 12 (64GB)SIM Free	29	BHandset (Power Up, Good LCD)(Full Fuction)	1964
Apple	iPhone 12 (128GB)SIM Free	1	BHandset (Power Up, Good LCD)	1965
Apple	iPhone 12 (64GB)SIM Free	10	BHandset (Power Up, Good LCD)	1966
Apple	iPhone 12 (128GB)SIM Free	3	BHandset (Power Up, Good LCD)(Full Fuction)(unknow part message)	1967
Apple	iPhone 12 (256GB)SIM Free	1	BHandset (Power Up, Good LCD)(Full Fuction)(unknow part message)	1968
Apple	iPhone 12 (64GB)SIM Free	6	BHandset (Power Up, Good LCD)(Full Fuction)(unknow part message)	1969
Apple	iPhone 12 (128GB)SIM Free	5	BHandset (Power Up, Good LCD)(unknow part message)	1970
Apple	iPhone 12 (256GB)SIM Free	1	BHandset (Power Up, Good LCD)(unknow part message)	1971
Apple	iPhone 12 (64GB)SIM Free	2	BHandset (Power Up, Good LCD)(unknow part message)	1972
Apple	iPhone 12 (128GB)SIM Free	37	BHandset (Power Up, Bad LCD)(Full Fuction)	1973
Apple	iPhone 12 (256GB)SIM Free	1	BHandset (Power Up, Bad LCD)(Full Fuction)	1974
Apple	iPhone 12 (64GB)SIM Free	47	BHandset (Power Up, Bad LCD)(Full Fuction)	1975
Apple	iPhone 12 (128GB)SIM Free	52	BHandset (Power Up, Bad LCD)(FidWorking)	1976

Apple	iPhone 12 (256GB)SIM Free	3	BHandset (Power Up, Bad LCD)(FidWorking)	1977
Apple	iPhone 12 (64GB)SIM Free	71	BHandset (Power Up, Bad LCD)(FidWorking)	1978
Apple	iPhone 12 (128GB)SIM Free	187	BHandset (Power Up, Bad LCD)	1979
Apple	iPhone 12 (256GB)SIM Free	9	BHandset (Power Up, Bad LCD)	1980
Apple	iPhone 12 (64GB)SIM Free	268	BHandset (Power Up, Bad LCD)	1981
Apple	iPhone 12 (64GB)SIM Free	1	BHandset (Power Up, Bad LCD)(unknow part message)	1982
Apple	iPhone 12 (128GB)SIM Free	58	BHandset (only electricity)	1983
Apple	iPhone 12 (256GB)SIM Free	12	BHandset (only electricity)	1984
Apple	iPhone 12 (64GB)SIM Free	86	BHandset (only electricity)	1985
Apple	iPhone 12 (128GB)SIM Free	41	SP Bid-No Power On-Change Battery(Reference Only)	1986
Apple	iPhone 12 (256GB)SIM Free	2	SP Bid-No Power On-Change Battery(Reference Only)	1987
Apple	iPhone 12 (64GB)SIM Free	233	SP Bid-No Power On-Change Battery(Reference Only)	1988
Apple	iPhone 12 (64GB) (SIM FreeProblematic)	5	Part 2 AHandset	1989
Apple	iPhone 12 (128GB) (SIM FreeProblematic)	1	Part 2 BHandset (Power Up, Good LCD)	1990
Apple	iPhone 12 (64GB) (SIM FreeProblematic)	2	Part 2 BHandset (Power Up, Good LCD)	1991
Apple	iPhone 12 (128GB) (SIM FreeProblematic)	23	Part 2 BHandset (Power Up, Bad LCD)	1992
Apple	iPhone 12 (256GB) (SIM FreeProblematic)	1	Part 2 BHandset (Power Up, Bad LCD)	1993
Apple	iPhone 12 (64GB) (SIM FreeProblematic)	21	Part 2 BHandset (Power Up, Bad LCD)	1994
Apple	iPhone 12 (128GB) (SIM FreeProblematic)	2	Part 2 BHandset (only electricity)	1995
Apple	iPhone 12 (64GB) (SIM FreeProblematic)	11	Part 2 BHandset (only electricity)	1996
Apple	iPhone 12 (128GB) (SIM Freefid)	3	Part 2 AHandset	1997
Apple	iPhone 12 (64GB) (SIM Freefid)	10	Part 2 AHandset	1998
Apple	iPhone 12 (128GB) (SIM Freefid)	2	Part 2 AHandset (unknow part message)	1999
Apple	iPhone 12 (64GB) (SIM Freefid)	1	Part 2 AHandset (unknow part message)	2000
Apple	iPhone 12 (128GB) (SIM Freefid)	2	Part 2 BHandset (Power Up, Good LCD)	2001
Apple	iPhone 12 (256GB) (SIM Freefid)	1	Part 2 BHandset (Power Up, Good LCD)	2002
Apple	iPhone 12 (64GB) (SIM Freefid)	7	Part 2 BHandset (Power Up, Good LCD)	2003
Apple	iPhone 12 (64GB) (SIM Freefid)	1	Part 2 BHandset (Power Up, Good LCD)(unknow part message)	2004
Apple	iPhone 12 (64GB)	1	Part 2 AHandset	2005
Apple	iPhone 12 (128GB)	3	Part 2 BHandset (Power Up, Bad LCD)	2006
Apple	iPhone 12 (64GB)	13	Part 2 BHandset (Power Up, Bad LCD)	2007
Apple	iPhone 12 (128GB)	4	Part 2 BHandset (only electricity)	2008
Apple	iPhone 12 (256GB)	2	Part 2 BHandset (only electricity)	2009
Apple	iPhone 12 (64GB)	28	Part 2 BHandset (only electricity)	2010
Apple	iPhone 12 (128GB)	15	Part 2 SP Bid-No Power On-Change Battery(Reference Only)	2011
Apple	iPhone 12 (256GB)	1	Part 2 SP Bid-No Power On-Change Battery(Reference Only)	2012
Apple	iPhone 12 (64GB)	38	Part 2 SP Bid-No Power On-Change Battery(Reference Only)	2013
Apple	iPhone 12 (128GB)	3	Mainboard	2014
Apple	iPhone 12 (256GB)	1	Mainboard	2015
Apple	iPhone 12 (64GB)	43	Mainboard	2016
Apple	iPhone 12 (128GB) (Problematic)	1	Part 2 AHandset	2017
Apple	iPhone 12 (256GB) (Problematic)	1	Part 2 AHandset	2018
Apple	iPhone 12 (64GB) (Problematic)	1	Part 2 AHandset	2019
Apple	iPhone 12 (128GB) (Problematic)	2	Part 2 BHandset (Power Up, Bad LCD)	2020
Apple	iPhone 12 (64GB) (Problematic)	6	Part 2 BHandset (Power Up, Bad LCD)	2021
Apple	iPhone 12 (64GB) (Problematic)	1	Part 2 BHandset (only electricity)	2022
Apple	iPhone 12 Mini Total	2044	Summary	2023
Apple	iPhone 12 Mini (128GB)SIM Free	1	Nearly New Handset(Full Fuction)	2024
Apple	iPhone 12 Mini (64GB)SIM Free	4	Nearly New Handset(Full Fuction)	2025
Apple	iPhone 12 Mini (128GB)SIM Free	6	Nearly New Handset	2026
Apple	iPhone 12 Mini (64GB)SIM Free	2	Nearly New Handset	2027
Apple	iPhone 12 Mini (128GB)SIM Free	3	AHandset (Good)(Full Fuction)	2028
Apple	iPhone 12 Mini (64GB)SIM Free	1	AHandset (Good)(Full Fuction)	2029
Apple	iPhone 12 Mini (128GB)SIM Free	18	AHandset (Good)	2030
Apple	iPhone 12 Mini (64GB)SIM Free	2	AHandset (Good)(Full Fuction)(unknow part message)	2031
Apple	iPhone 12 Mini (128GB)SIM Free	1	AHandset (Good)(Full Fuction)(unknow part message)	2032
Apple	iPhone 12 Mini (128GB)SIM Free	31	AHandset (Good 1)(Full Fuction)	2033
Apple	iPhone 12 Mini (64GB)SIM Free	356	AHandset (Good 1)(Full Fuction)	2034
Apple	iPhone 12 Mini (64GB)SIM Free	5	AHandset (Good 1)(Bad Back Camera Glass)(Full Fuction)	2035
Apple	iPhone 12 Mini (128GB)SIM Free	9	AHandset (Good 1)(Broken Back Glass)(Full Fuction)	2036
Apple	iPhone 12 Mini (64GB)SIM Free	10	AHandset (Good 1)(Broken Back Glass)(Full Fuction)	2037
Apple	iPhone 12 Mini (64GB)SIM Free	4	AHandset (Good 1)	2038
Apple	iPhone 12 Mini (128GB)SIM Free	46	AHandset (Good 1)(Full Fuction)(unknow part message)	2039
Apple	iPhone 12 Mini (256GB)SIM Free	1	AHandset (Good 1)(Full Fuction)(unknow part message)	2040
Apple	iPhone 12 Mini (64GB)SIM Free	76	AHandset (Good 1)(Full Fuction)(unknow part message)	2041
Apple	iPhone 12 Mini (128GB)SIM Free	1	AHandset (Good 1)(Bad Back Camera Glass)(Full Fuction)(unknow part message)	2042
Apple	iPhone 12 Mini (64GB)SIM Free	3	AHandset (Good 1)(Broken Back Glass)(Full Fuction)(unknow part message)	2043
Apple	iPhone 12 Mini (128GB)SIM Free	52	AHandset (Full Fuction)	2044
Apple	iPhone 12 Mini (256GB)SIM Free	4	AHandset (Full Fuction)	2045
Apple	iPhone 12 Mini (64GB)SIM Free	274	AHandset (Full Fuction)	2046
Apple	iPhone 12 Mini (128GB)SIM Free	1	AHandset (Bad Back Camera Glass)(Full Fuction)	2047
Apple	iPhone 12 Mini (64GB)SIM Free	5	AHandset (Bad Back Camera Glass)(Full Fuction)	2048
Apple	iPhone 12 Mini (128GB)SIM Free	8	AHandset (Broken Back Glass)(Full Fuction)	2049
Apple	iPhone 12 Mini (256GB)SIM Free	2	AHandset (Broken Back Glass)(Full Fuction)	2050
Apple	iPhone 12 Mini (64GB)SIM Free	15	AHandset (Broken Back Glass)(Full Fuction)	2051
Apple	iPhone 12 Mini (128GB)SIM Free	4	AHandset	2052
Apple	iPhone 12 Mini (256GB)SIM Free	7	AHandset	2053
Apple	iPhone 12 Mini (64GB)SIM Free	4	AHandset	2054
Apple	iPhone 12 Mini (128GB)SIM Free	2	AHandset (Broken Back Glass)	2055
Apple	iPhone 12 Mini (64GB)SIM Free	4	AHandset (Broken Back Glass)	2056
Apple	iPhone 12 Mini (128GB)SIM Free	20	AHandset (Full Fuction)(unknow part message)	2057
Apple	iPhone 12 Mini (256GB)SIM Free	2	AHandset (Full Fuction)(unknow part message)	2058
Apple	iPhone 12 Mini (64GB)SIM Free	9	AHandset (Full Fuction)(unknow part message)	2059
Apple	iPhone 12 Mini (128GB)SIM Free	5	AHandset (Bad Back Camera Glass)(Full Fuction)(unknow part message)	2060
Apple	iPhone 12 Mini (64GB)SIM Free	4	AHandset (Bad Back Camera Glass)(Full Fuction)(unknow part message)	2061
Apple	iPhone 12 Mini (64GB)SIM Free	3	AHandset (Broken Back Glass)(Full Fuction)(unknow part message)	2062

Apple	iPhone 12 Mini (128GB)SIM Free	23	AHandset (unknown part message)	2063
Apple	iPhone 12 Mini (64GB)SIM Free	14	AHandset (unknown part message)	2064
Apple	iPhone 12 Mini (64GB)SIM Free	1	AHandset (Bad Back Camera Glass)(unknown part message)	2065
Apple	iPhone 12 Mini (128GB)SIM Free	3	AHandset (Broken Back Glass)(unknown part message)	2066
Apple	iPhone 12 Mini (256GB)SIM Free	1	AHandset (Broken Back Glass)(unknown part message)	2067
Apple	iPhone 12 Mini (64GB)SIM Free	4	AHandset (Broken Back Glass)(unknown part message)	2068
Apple	iPhone 12 Mini (128GB)SIM Free	12	BHandset (Power Up, Good LCD)(Full Fuction)	2069
Apple	iPhone 12 Mini (256GB)SIM Free	1	BHandset (Power Up, Good LCD)(Full Fuction)	2070
Apple	iPhone 12 Mini (64GB)SIM Free	41	BHandset (Power Up, Good LCD)(Full Fuction)	2071
Apple	iPhone 12 Mini (128GB)SIM Free	2	BHandset (Power Up, Good LCD)	2072
Apple	iPhone 12 Mini (64GB)SIM Free	1	BHandset (Power Up, Good LCD)	2073
Apple	iPhone 12 Mini (128GB)SIM Free	2	BHandset (Power Up, Good LCD)(Full Fuction)(unknown part message)	2074
Apple	iPhone 12 Mini (64GB)SIM Free	6	BHandset (Power Up, Good LCD)(Full Fuction)(unknown part message)	2075
Apple	iPhone 12 Mini (128GB)SIM Free	15	BHandset (Power Up, Good LCD)(unknown part message)	2076
Apple	iPhone 12 Mini (256GB)SIM Free	3	BHandset (Power Up, Good LCD)(unknown part message)	2077
Apple	iPhone 12 Mini (64GB)SIM Free	22	BHandset (Power Up, Good LCD)(unknown part message)	2078
Apple	iPhone 12 Mini (128GB)SIM Free	2	BHandset (Power Up, Bad LCD)(Full Fuction)	2079
Apple	iPhone 12 Mini (64GB)SIM Free	1	BHandset (Power Up, Bad LCD)(Full Fuction)	2080
Apple	iPhone 12 Mini (128GB)SIM Free	26	BHandset (Power Up, Bad LCD)(FidWorking)	2081
Apple	iPhone 12 Mini (256GB)SIM Free	3	BHandset (Power Up, Bad LCD)(FidWorking)	2082
Apple	iPhone 12 Mini (64GB)SIM Free	30	BHandset (Power Up, Bad LCD)(FidWorking)	2083
Apple	iPhone 12 Mini (128GB)SIM Free	135	BHandset (Power Up, Bad LCD)	2084
Apple	iPhone 12 Mini (256GB)SIM Free	10	BHandset (Power Up, Bad LCD)	2085
Apple	iPhone 12 Mini (64GB)SIM Free	200	BHandset (Power Up, Bad LCD)	2086
Apple	iPhone 12 Mini (128GB)SIM Free	30	BHandset (only electricity)	2087
Apple	iPhone 12 Mini (256GB)SIM Free	8	BHandset (only electricity)	2088
Apple	iPhone 12 Mini (64GB)SIM Free	73	BHandset (only electricity)	2089
Apple	iPhone 12 Mini (128GB)SIM Free	29	SP Bid-No Power On-Change Battery(Reference Only)	2090
Apple	iPhone 12 Mini (256GB)SIM Free	3	SP Bid-No Power On-Change Battery(Reference Only)	2091
Apple	iPhone 12 Mini (64GB)SIM Free	61	SP Bid-No Power On-Change Battery(Reference Only)	2092
Apple	iPhone 12 Mini (128GB) (SIM FreeProblematic)	22	Part 2 AHandset	2093
Apple	iPhone 12 Mini (256GB) (SIM FreeProblematic)	14	Part 2 AHandset	2094
Apple	iPhone 12 Mini (64GB) (SIM FreeProblematic)	19	Part 2 AHandset	2095
Apple	iPhone 12 Mini (128GB) (SIM FreeProblematic)	2	Part 2 AHandset (unknown part message)	2096
Apple	iPhone 12 Mini (64GB) (SIM FreeProblematic)	10	Part 2 AHandset (unknown part message)	2097
Apple	iPhone 12 Mini (128GB) (SIM FreeProblematic)	7	Part 2 BHandset (Power Up, Good LCD)	2098
Apple	iPhone 12 Mini (256GB) (SIM FreeProblematic)	2	Part 2 BHandset (Power Up, Good LCD)	2099
Apple	iPhone 12 Mini (64GB) (SIM FreeProblematic)	30	Part 2 BHandset (Power Up, Good LCD)	2100
Apple	iPhone 12 Mini (128GB) (SIM FreeProblematic)	14	Part 2 BHandset (Power Up, Bad LCD)	2101
Apple	iPhone 12 Mini (256GB) (SIM FreeProblematic)	3	Part 2 BHandset (Power Up, Bad LCD)	2102
Apple	iPhone 12 Mini (64GB) (SIM FreeProblematic)	34	Part 2 BHandset (Power Up, Bad LCD)	2103
Apple	iPhone 12 Mini (64GB) (SIM FreeProblematic)	2	Part 2 BHandset (only electricity)	2104
Apple	iPhone 12 Mini (128GB) (SIM Freefid)	3	Part 2 AHandset	2105
Apple	iPhone 12 Mini (256GB) (SIM Freefid)	7	Part 2 AHandset	2106
Apple	iPhone 12 Mini (64GB) (SIM Freefid)	21	Part 2 AHandset	2107
Apple	iPhone 12 Mini (64GB) (SIM Freefid)	33	Part 2 AHandset (unknown part message)	2108
Apple	iPhone 12 Mini (128GB) (SIM Freefid)	16	Part 2 BHandset (Power Up, Good LCD)	2109
Apple	iPhone 12 Mini (256GB) (SIM Freefid)	1	Part 2 BHandset (Power Up, Good LCD)	2110
Apple	iPhone 12 Mini (64GB) (SIM Freefid)	9	Part 2 BHandset (Power Up, Good LCD)	2111
Apple	iPhone 12 Mini (64GB) (SIM Freefid)	2	Part 2 BHandset (Power Up, Bad LCD)	2112
Apple	iPhone 12 Mini (64GB)	1	Part 2 BHandset (Power Up, Bad LCD)	2113
Apple	iPhone 12 Mini (256GB)	1	Part 2 BHandset (only electricity)	2114
Apple	iPhone 12 Mini (64GB)	4	Part 2 BHandset (only electricity)	2115
Apple	iPhone 12 Mini (128GB)	1	Part 2 SP Bid-No Power On-Change Battery(Reference Only)	2116
Apple	iPhone 12 Mini (64GB)	8	Part 2 SP Bid-No Power On-Change Battery(Reference Only)	2117
Apple	iPhone 12 Mini (64GB)	5	Mainboard	2118
Apple	iPhone 12 Mini (64GB) (Problematic)	6	Part 2 AHandset	2119
Apple	iPhone 11 Pro Max Total	973	Summary	2120
Apple	iPhone 11 Pro Max (64GB)SIM Free	1	AHandset (Good)	2121
Apple	iPhone 11 Pro Max (256GB)SIM Free	2	AHandset (Good)(Full Fuction)(unknown part message)	2122
Apple	iPhone 11 Pro Max (64GB)SIM Free	33	AHandset (Good)(Full Fuction)(unknown part message)	2123
Apple	iPhone 11 Pro Max (256GB)SIM Free	3	AHandset (Good 1)(Broken Back Glass)(Full Fuction)	2124
Apple	iPhone 11 Pro Max (64GB)SIM Free	1	AHandset (Good 1)(Broken Back Glass)(Full Fuction)	2125
Apple	iPhone 11 Pro Max (256GB)SIM Free	1	AHandset (Good 1)	2126
Apple	iPhone 11 Pro Max (64GB)SIM Free	2	AHandset (Good 1)	2127
Apple	iPhone 11 Pro Max (256GB)SIM Free	21	AHandset (Good 1)(Full Fuction)(unknown part message)	2128
Apple	iPhone 11 Pro Max (512GB)SIM Free	1	AHandset (Good 1)(Full Fuction)(unknown part message)	2129
Apple	iPhone 11 Pro Max (64GB)SIM Free	94	AHandset (Good 1)(Full Fuction)(unknown part message)	2130
Apple	iPhone 11 Pro Max (64GB)SIM Free	2	AHandset (Good 1)(Bad Back Camera Glass)(Full Fuction)(unknown part message)	2131
Apple	iPhone 11 Pro Max (256GB)SIM Free	3	AHandset (Good 1)(Broken Back Glass)(Full Fuction)(unknown part message)	2132
Apple	iPhone 11 Pro Max (512GB)SIM Free	3	AHandset (Good 1)(Broken Back Glass)(Full Fuction)(unknown part message)	2133
Apple	iPhone 11 Pro Max (64GB)SIM Free	4	AHandset (Good 1)(Broken Back Glass)(Full Fuction)(unknown part message)	2134
Apple	iPhone 11 Pro Max (256GB)SIM Free	14	AHandset (Good 1)(unknown part message)	2135
Apple	iPhone 11 Pro Max (512GB)SIM Free	2	AHandset (Good 1)(unknown part message)	2136
Apple	iPhone 11 Pro Max (256GB)SIM Free	1	AHandset (Full Fuction)	2137
Apple	iPhone 11 Pro Max (512GB)SIM Free	3	AHandset (Full Fuction)	2138
Apple	iPhone 11 Pro Max (64GB)SIM Free	1	AHandset (Full Fuction)	2139
Apple	iPhone 11 Pro Max (512GB)SIM Free	1	AHandset (Bad Back Camera Glass)(Full Fuction)	2140
Apple	iPhone 11 Pro Max (64GB)SIM Free	1	AHandset (Bad Back Camera Glass)(Full Fuction)	2141
Apple	iPhone 11 Pro Max (512GB)SIM Free	1	AHandset (Broken Back Glass)(Full Fuction)	2142
Apple	iPhone 11 Pro Max (512GB)SIM Free	1	AHandset (Bad Back Camera Glass)	2143
Apple	iPhone 11 Pro Max (512GB)SIM Free	2	AHandset (Broken Back Glass)	2144
Apple	iPhone 11 Pro Max (256GB)SIM Free	9	AHandset (Full Fuction)(unknown part message)	2145
Apple	iPhone 11 Pro Max (512GB)SIM Free	5	AHandset (Full Fuction)(unknown part message)	2146
Apple	iPhone 11 Pro Max (64GB)SIM Free	8	AHandset (Full Fuction)(unknown part message)	2147
Apple	iPhone 11 Pro Max (256GB)SIM Free	1	AHandset (Bad Back Camera Glass)(Full Fuction)(unknown part message)	2148

Apple	iPhone 11 Pro Max (64GB)SIM Free	1	AHandset (Bad Back Camera Glass)(Full Fuction)(unknow part message)	2149
Apple	iPhone 11 Pro Max (256GB)SIM Free	3	AHandset (Broken Back Glass)(Full Fuction)(unknow part message)	2150
Apple	iPhone 11 Pro Max (512GB)SIM Free	2	AHandset (Broken Back Glass)(Full Fuction)(unknow part message)	2151
Apple	iPhone 11 Pro Max (64GB)SIM Free	30	AHandset (Broken Back Glass)(Full Fuction)(unknow part message)	2152
Apple	iPhone 11 Pro Max (256GB)SIM Free	94	AHandset (unknow part message)	2153
Apple	iPhone 11 Pro Max (512GB)SIM Free	12	AHandset (unknow part message)	2154
Apple	iPhone 11 Pro Max (64GB)SIM Free	186	AHandset (unknow part message)	2155
Apple	iPhone 11 Pro Max (256GB)SIM Free	9	AHandset (Bad Back Camera Glass)(unknow part message)	2156
Apple	iPhone 11 Pro Max (64GB)SIM Free	19	AHandset (Bad Back Camera Glass)(unknow part message)	2157
Apple	iPhone 11 Pro Max (256GB)SIM Free	37	AHandset (Broken Back Glass)(unknow part message)	2158
Apple	iPhone 11 Pro Max (512GB)SIM Free	2	AHandset (Broken Back Glass)(unknow part message)	2159
Apple	iPhone 11 Pro Max (64GB)SIM Free	23	AHandset (Broken Back Glass)(unknow part message)	2160
Apple	iPhone 11 Pro Max (256GB)SIM Free	1	BHandset (Power Up, Good LCD)(Full Fuction)	2161
Apple	iPhone 11 Pro Max (64GB)SIM Free	1	BHandset (Power Up, Good LCD)(Full Fuction)	2162
Apple	iPhone 11 Pro Max (256GB)SIM Free	1	BHandset (Power Up, Good LCD)	2163
Apple	iPhone 11 Pro Max (512GB)SIM Free	1	BHandset (Power Up, Good LCD)	2164
Apple	iPhone 11 Pro Max (256GB)SIM Free	18	BHandset (Power Up, Good LCD)(Full Fuction)(unknow part message)	2165
Apple	iPhone 11 Pro Max (64GB)SIM Free	18	BHandset (Power Up, Good LCD)(Full Fuction)(unknow part message)	2166
Apple	iPhone 11 Pro Max (256GB)SIM Free	18	BHandset (Power Up, Good LCD)(unknow part message)	2167
Apple	iPhone 11 Pro Max (512GB)SIM Free	5	BHandset (Power Up, Good LCD)(unknow part message)	2168
Apple	iPhone 11 Pro Max (64GB)SIM Free	30	BHandset (Power Up, Good LCD)(unknow part message)	2169
Apple	iPhone 11 Pro Max (256GB)SIM Free	1	BHandset (Power Up, Bad LCD)(FidWorking)	2170
Apple	iPhone 11 Pro Max (512GB)SIM Free	1	BHandset (Power Up, Bad LCD)(FidWorking)	2171
Apple	iPhone 11 Pro Max (64GB)SIM Free	1	BHandset (Power Up, Bad LCD)(FidWorking)	2172
Apple	iPhone 11 Pro Max (256GB)SIM Free	15	BHandset (Power Up, Bad LCD)	2173
Apple	iPhone 11 Pro Max (64GB)SIM Free	16	BHandset (Power Up, Bad LCD)	2174
Apple	iPhone 11 Pro Max (256GB)SIM Free	3	BHandset (Power Up, Bad LCD)(unknow part message)	2175
Apple	iPhone 11 Pro Max (64GB)SIM Free	15	BHandset (Power Up, Bad LCD)(unknow part message)	2176
Apple	iPhone 11 Pro Max (256GB)SIM Free	6	BHandset (only electricity)	2177
Apple	iPhone 11 Pro Max (512GB)SIM Free	9	BHandset (only electricity)	2178
Apple	iPhone 11 Pro Max (64GB)SIM Free	61	BHandset (only electricity)	2179
Apple	iPhone 11 Pro Max (512GB)SIM Free	4	SP Bid-No Power On-Change Battery(Reference Only)	2180
Apple	iPhone 11 Pro Max (64GB)SIM Free	68	SP Bid-No Power On-Change Battery(Reference Only)	2181
Apple	iPhone 11 Pro Max (256GB) (SIM FreeProblematic)	10	Part 2 AHandset	2182
Apple	iPhone 11 Pro Max (64GB) (SIM FreeProblematic)	3	Part 2 AHandset	2183
Apple	iPhone 11 Pro Max (256GB) (SIM FreeProblematic)	1	Part 2 BHandset (Power Up, Good LCD)	2184
Apple	iPhone 11 Pro Max (64GB) (SIM FreeProblematic)	3	Part 2 BHandset (Power Up, Good LCD)	2185
Apple	iPhone 11 Pro Max (64GB) (SIM Freefid)	4	Part 2 BHandset (Power Up, Good LCD)(unknow part message)	2186
Apple	iPhone 11 Pro Max (64GB)	2	Part 2 BHandset (Power Up, Good LCD)	2187
Apple	iPhone 11 Pro Max (256GB)	1	Part 2 BHandset (Power Up, Bad LCD)	2188
Apple	iPhone 11 Pro Max (64GB)	2	Part 2 BHandset (Power Up, Bad LCD)	2189
Apple	iPhone 11 Pro Max (64GB)	4	Part 2 BHandset (only electricity)	2190
Apple	iPhone 11 Pro Max (64GB)	2	Part 2 SP Bid-No Power On-Change Battery(Reference Only)	2191
Apple	iPhone 11 Pro Max (64GB)	2	Mainboard	2192
Apple	iPhone 11 Pro Max (256GB) (Problematic)	2	Part 2 AHandset	2193
Apple	iPhone 11 Pro Max (64GB) (Problematic)	3	Part 2 AHandset	2194
Apple	iPhone 11 Pro Max (64GB) (Problematic)	2	Part 2 BHandset (Power Up, Good LCD)	2195
Apple	iPhone 11 Pro Total	846	Summary	2196
Apple	iPhone 11 Pro (64GB)SIM Free	1	Nearly New(Full Fuction)	2197
Apple	iPhone 11 Pro (256GB)SIM Free	2	AHandset (Good)(Full Fuction)(unknow part message)	2198
Apple	iPhone 11 Pro (512GB)SIM Free	1	AHandset (Good)(Full Fuction)(unknow part message)	2199
Apple	iPhone 11 Pro (64GB)SIM Free	1	AHandset (Good)(Full Fuction)(unknow part message)	2200
Apple	iPhone 11 Pro (64GB)SIM Free	1	AHandset (Good 1)(Full Fuction)	2201
Apple	iPhone 11 Pro (256GB)SIM Free	2	AHandset (Good 1)(Broken Back Glass)(Full Fuction)	2202
Apple	iPhone 11 Pro (64GB)SIM Free	1	AHandset (Good 1)(Broken Back Glass)(Full Fuction)	2203
Apple	iPhone 11 Pro (256GB)SIM Free	1	AHandset (Good 1)	2204
Apple	iPhone 11 Pro (512GB)SIM Free	7	AHandset (Good 1)(Full Fuction)(unknow part message)	2205
Apple	iPhone 11 Pro (64GB)SIM Free	3	AHandset (Good 1)(Full Fuction)(unknow part message)	2206
Apple	iPhone 11 Pro (64GB)SIM Free	1	AHandset (Good 1)(Bad Back Camera Glass)(Full Fuction)(unknow part message)	2207
Apple	iPhone 11 Pro (256GB)SIM Free	2	AHandset (Good 1)(Broken Back Glass)(Full Fuction)(unknow part message)	2208
Apple	iPhone 11 Pro (64GB)SIM Free	7	AHandset (Good 1)(Broken Back Glass)(Full Fuction)(unknow part message)	2209
Apple	iPhone 11 Pro (256GB)SIM Free	5	AHandset (Good 1)(unknow part message)	2210
Apple	iPhone 11 Pro (64GB)SIM Free	25	AHandset (Good 1)(unknow part message)	2211
Apple	iPhone 11 Pro (256GB)SIM Free	8	AHandset (Full Fuction)	2212
Apple	iPhone 11 Pro (512GB)SIM Free	2	AHandset (Full Fuction)	2213
Apple	iPhone 11 Pro (64GB)SIM Free	3	AHandset (Full Fuction)	2214
Apple	iPhone 11 Pro (64GB)SIM Free	1	AHandset (Bad Back Camera Glass)(Full Fuction)	2215
Apple	iPhone 11 Pro (256GB)SIM Free	2	AHandset (Broken Back Glass)(Full Fuction)	2216
Apple	iPhone 11 Pro (64GB)SIM Free	7	AHandset (Broken Back Glass)(Full Fuction)	2217
Apple	iPhone 11 Pro (256GB)SIM Free	3	AHandset	2218
Apple	iPhone 11 Pro (512GB)SIM Free	4	AHandset	2219
Apple	iPhone 11 Pro (64GB)SIM Free	17	AHandset	2220
Apple	iPhone 11 Pro (256GB)SIM Free	4	AHandset (Bad Back Camera Glass)	2221
Apple	iPhone 11 Pro (512GB)SIM Free	1	AHandset (Bad Back Camera Glass)	2222
Apple	iPhone 11 Pro (512GB)SIM Free	2	AHandset (Broken Back Glass)	2223
Apple	iPhone 11 Pro (64GB)SIM Free	5	AHandset (Broken Back Glass)	2224
Apple	iPhone 11 Pro (256GB)SIM Free	4	AHandset (Full Fuction)(unknow part message)	2225
Apple	iPhone 11 Pro (64GB)SIM Free	28	AHandset (Full Fuction)(unknow part message)	2226
Apple	iPhone 11 Pro (512GB)SIM Free	1	AHandset (Bad Back Camera Glass)(Full Fuction)(unknow part message)	2227
Apple	iPhone 11 Pro (64GB)SIM Free	5	AHandset (Bad Back Camera Glass)(Full Fuction)(unknow part message)	2228
Apple	iPhone 11 Pro (256GB)SIM Free	19	AHandset (Broken Back Glass)(Full Fuction)(unknow part message)	2229
Apple	iPhone 11 Pro (512GB)SIM Free	1	AHandset (Broken Back Glass)(Full Fuction)(unknow part message)	2230
Apple	iPhone 11 Pro (64GB)SIM Free	36	AHandset (Broken Back Glass)(Full Fuction)(unknow part message)	2231
Apple	iPhone 11 Pro (256GB)SIM Free	77	AHandset (unknow part message)	2232
Apple	iPhone 11 Pro (512GB)SIM Free	2	AHandset (unknow part message)	2233
Apple	iPhone 11 Pro (64GB)SIM Free	96	AHandset (unknow part message)	2234

Apple	iPhone 11 Pro (256GB)SIM Free	2	AHandset (Bad Back Camera Glass)(unknown part message)	2235
Apple	iPhone 11 Pro (64GB)SIM Free	6	AHandset (Bad Back Camera Glass)(unknown part message)	2236
Apple	iPhone 11 Pro (256GB)SIM Free	14	AHandset (Broken Back Glass)(unknown part message)	2237
Apple	iPhone 11 Pro (512GB)SIM Free	1	AHandset (Broken Back Glass)(unknown part message)	2238
Apple	iPhone 11 Pro (64GB)SIM Free	15	AHandset (Broken Back Glass)(unknown part message)	2239
Apple	iPhone 11 Pro (256GB)SIM Free	11	BHandset (Power Up, Good LCD)(Full Fuction)	2240
Apple	iPhone 11 Pro (64GB)SIM Free	17	BHandset (Power Up, Good LCD)(Full Fuction)	2241
Apple	iPhone 11 Pro (256GB)SIM Free	2	BHandset (Power Up, Good LCD)	2242
Apple	iPhone 11 Pro (512GB)SIM Free	2	BHandset (Power Up, Good LCD)	2243
Apple	iPhone 11 Pro (64GB)SIM Free	3	BHandset (Power Up, Good LCD)	2244
Apple	iPhone 11 Pro (256GB)SIM Free	8	BHandset (Power Up, Good LCD)(Full Fuction)(unknown part message)	2245
Apple	iPhone 11 Pro (512GB)SIM Free	2	BHandset (Power Up, Good LCD)(Full Fuction)(unknown part message)	2246
Apple	iPhone 11 Pro (64GB)SIM Free	25	BHandset (Power Up, Good LCD)(Full Fuction)(unknown part message)	2247
Apple	iPhone 11 Pro (256GB)SIM Free	10	BHandset (Power Up, Good LCD)(unknown part message)	2248
Apple	iPhone 11 Pro (64GB)SIM Free	16	BHandset (Power Up, Good LCD)(unknown part message)	2249
Apple	iPhone 11 Pro (256GB)SIM Free	2	BHandset (Power Up, Bad LCD)(Full Fuction)	2250
Apple	iPhone 11 Pro (64GB)SIM Free	9	BHandset (Power Up, Bad LCD)(Full Fuction)	2251
Apple	iPhone 11 Pro (256GB)SIM Free	6	BHandset (Power Up, Bad LCD)(FidWorking)	2252
Apple	iPhone 11 Pro (512GB)SIM Free	3	BHandset (Power Up, Bad LCD)(FidWorking)	2253
Apple	iPhone 11 Pro (64GB)SIM Free	30	BHandset (Power Up, Bad LCD)(FidWorking)	2254
Apple	iPhone 11 Pro (256GB)SIM Free	70	BHandset (Power Up, Bad LCD)	2255
Apple	iPhone 11 Pro (512GB)SIM Free	3	BHandset (Power Up, Bad LCD)	2256
Apple	iPhone 11 Pro (64GB)SIM Free	26	BHandset (Power Up, Bad LCD)	2257
Apple	iPhone 11 Pro (256GB)SIM Free	6	BHandset (only electricity)	2258
Apple	iPhone 11 Pro (64GB)SIM Free	6	BHandset (only electricity)	2259
Apple	iPhone 11 Pro (256GB)SIM Free	29	SP Bid-No Power On-Change Battery(Reference Only)	2260
Apple	iPhone 11 Pro (512GB)SIM Free	1	SP Bid-No Power On-Change Battery(Reference Only)	2261
Apple	iPhone 11 Pro (64GB)SIM Free	84	SP Bid-No Power On-Change Battery(Reference Only)	2262
Apple	iPhone 11 Pro (256GB) (SIM FreeProblematic)	5	Part 2 AHandset	2263
Apple	iPhone 11 Pro (512GB) (SIM FreeProblematic)	4	Part 2 AHandset	2264
Apple	iPhone 11 Pro (64GB) (SIM FreeProblematic)	16	Part 2 AHandset	2265
Apple	iPhone 11 Pro (256GB) (SIM FreeProblematic)	2	Part 2 BHandset (Power Up, Good LCD)	2266
Apple	iPhone 11 Pro (512GB) (SIM FreeProblematic)	1	Part 2 BHandset (Power Up, Good LCD)	2267
Apple	iPhone 11 Pro (64GB) (SIM FreeProblematic)	1	Part 2 BHandset (Power Up, Good LCD)	2268
Apple	iPhone 11 Pro (256GB) (SIM FreeProblematic)	1	Part 2 BHandset (Power Up, Bad LCD)	2269
Apple	iPhone 11 Pro (512GB) (SIM FreeProblematic)	2	Part 2 BHandset (Power Up, Bad LCD)	2270
Apple	iPhone 11 Pro (64GB) (SIM FreeProblematic)	1	Part 2 BHandset (Power Up, Bad LCD)	2271
Apple	iPhone 11 Pro (64GB) (SIM FreeProblematic)	3	Part 2 BHandset (only electricity)	2272
Apple	iPhone 11 Pro (256GB)	3	Part 2 BHandset (Power Up, Bad LCD)	2273
Apple	iPhone 11 Pro (64GB)	4	Part 2 BHandset (Power Up, Bad LCD)	2274
Apple	iPhone 11 Pro (64GB)	4	Part 2 BHandset (only electricity)	2275
Apple	iPhone 11 Pro (64GB)	1	Part 2 SP Bid-No Power On-Change Battery(Reference Only)	2276
Apple	iPhone 11 Pro (256GB) (Problematic)	1	Part 2 AHandset	2277
Apple	iPhone 11 Total	1259	Summary	2278
Apple	iPhone 11 (64GB)SIM Free	1	Nearly New(Full Fuction)	2279
Apple	iPhone 11 (64GB)SIM Free	2	Nearly New Handset(unknown part message)	2280
Apple	iPhone 11 (128GB)SIM Free	3	AHandset (Good)(Full Fuction)(unknown part message)	2281
Apple	iPhone 11 (256GB)SIM Free	1	AHandset (Good)(Full Fuction)(unknown part message)	2282
Apple	iPhone 11 (64GB)SIM Free	1	AHandset (Good)(Full Fuction)(unknown part message)	2283
Apple	iPhone 11 (128GB)SIM Free	1	AHandset (Good)(unknown part message)	2284
Apple	iPhone 11 (64GB)SIM Free	2	AHandset (Good)(unknown part message)	2285
Apple	iPhone 11 (128GB)SIM Free	1	AHandset (Good 1)(Full Fuction)	2286
Apple	iPhone 11 (64GB)SIM Free	6	AHandset (Good 1)(Full Fuction)	2287
Apple	iPhone 11 (128GB)SIM Free	3	AHandset (Good 1)(Broken Back Glass)(Full Fuction)	2288
Apple	iPhone 11 (64GB)SIM Free	2	AHandset (Good 1)(Broken Back Glass)(Full Fuction)	2289
Apple	iPhone 11 (128GB)SIM Free	6	AHandset (Good 1)	2290
Apple	iPhone 11 (256GB)SIM Free	1	AHandset (Good 1)	2291
Apple	iPhone 11 (64GB)SIM Free	1	AHandset (Good 1)	2292
Apple	iPhone 11 (256GB)SIM Free	2	AHandset (Good 1)(Full Fuction)(unknown part message)	2293
Apple	iPhone 11 (64GB)SIM Free	1	AHandset (Good 1)(Full Fuction)(unknown part message)	2294
Apple	iPhone 11 (128GB)SIM Free	1	AHandset (Good 1)(Broken Back Glass)(Full Fuction)(unknown part message)	2295
Apple	iPhone 11 (64GB)SIM Free	3	AHandset (Good 1)(Broken Back Glass)(Full Fuction)(unknown part message)	2296
Apple	iPhone 11 (128GB)SIM Free	1	AHandset (Good 1)(unknown part message)	2297
Apple	iPhone 11 (128GB)SIM Free	28	AHandset (Full Fuction)	2298
Apple	iPhone 11 (256GB)SIM Free	23	AHandset (Full Fuction)	2299
Apple	iPhone 11 (64GB)SIM Free	3	AHandset (Full Fuction)	2300
Apple	iPhone 11 (128GB)SIM Free	1	AHandset (Bad Back Camera Glass)(Full Fuction)	2301
Apple	iPhone 11 (64GB)SIM Free	1	AHandset (Bad Back Camera Glass)(Full Fuction)	2302
Apple	iPhone 11 (128GB)SIM Free	8	AHandset (Broken Back Glass)(Full Fuction)	2303
Apple	iPhone 11 (64GB)SIM Free	7	AHandset (Broken Back Glass)(Full Fuction)	2304
Apple	iPhone 11 (256GB)SIM Free	2	AHandset	2305
Apple	iPhone 11 (64GB)SIM Free	4	AHandset	2306
Apple	iPhone 11 (128GB)SIM Free	2	AHandset (Broken Back Glass)	2307
Apple	iPhone 11 (64GB)SIM Free	1	AHandset (Broken Back Glass)	2308
Apple	iPhone 11 (128GB)SIM Free	4	AHandset (Full Fuction)(unknown part message)	2309
Apple	iPhone 11 (64GB)SIM Free	1	AHandset (Full Fuction)(unknown part message)	2310
Apple	iPhone 11 (64GB)SIM Free	1	AHandset (Bad Back Camera Glass)(Full Fuction)(unknown part message)	2311
Apple	iPhone 11 (128GB)SIM Free	1	AHandset (Broken Back Glass)(Full Fuction)(unknown part message)	2312
Apple	iPhone 11 (128GB)SIM Free	9	AHandset (unknown part message)	2313
Apple	iPhone 11 (256GB)SIM Free	2	AHandset (unknown part message)	2314
Apple	iPhone 11 (64GB)SIM Free	1	AHandset (unknown part message)	2315
Apple	iPhone 11 (128GB)SIM Free	2	AHandset (Bad Back Camera Glass)(unknown part message)	2316
Apple	iPhone 11 (64GB)SIM Free	6	AHandset (Bad Back Camera Glass)(unknown part message)	2317
Apple	iPhone 11 (128GB)SIM Free	3	AHandset (Broken Back Glass)(unknown part message)	2318
Apple	iPhone 11 (64GB)SIM Free	1	AHandset (Broken Back Glass)(unknown part message)	2319
Apple	iPhone 11 (128GB)SIM Free	1	BHandset (Power Up, Good LCD)(Full Fuction)	2320

Apple	iPhone 11 (256GB)SIM Free	2	BHandset (Power Up, Good LCD)(Full Fuction)	2321
Apple	iPhone 11 (64GB)SIM Free	3	BHandset (Power Up, Good LCD)(Full Fuction)	2322
Apple	iPhone 11 (64GB)SIM Free	5	BHandset (Power Up, Good LCD)	2323
Apple	iPhone 11 (128GB)SIM Free	2	BHandset (Power Up, Good LCD)(Full Fuction)(unknow part message)	2324
Apple	iPhone 11 (128GB)SIM Free	5	BHandset (Power Up, Good LCD)(unknow part message)	2325
Apple	iPhone 11 (256GB)SIM Free	2	BHandset (Power Up, Good LCD)(unknow part message)	2326
Apple	iPhone 11 (128GB)SIM Free	3	BHandset (Power Up, Bad LCD)(Full Fuction)	2327
Apple	iPhone 11 (64GB)SIM Free	3	BHandset (Power Up, Bad LCD)(Full Fuction)	2328
Apple	iPhone 11 (128GB)SIM Free	4	BHandset (Power Up, Bad LCD)(FidWorking)	2329
Apple	iPhone 11 (256GB)SIM Free	15	BHandset (Power Up, Bad LCD)(FidWorking)	2330
Apple	iPhone 11 (64GB)SIM Free	21	BHandset (Power Up, Bad LCD)(FidWorking)	2331
Apple	iPhone 11 (128GB)SIM Free	6	BHandset (Power Up, Bad LCD)	2332
Apple	iPhone 11 (256GB)SIM Free	6	BHandset (Power Up, Bad LCD)	2333
Apple	iPhone 11 (64GB)SIM Free	33	BHandset (Power Up, Bad LCD)	2334
Apple	iPhone 11 (256GB)SIM Free	2	BHandset (Power Up, Bad LCD)(FidWorking)(unknow part message)	2335
Apple	iPhone 11 (256GB)SIM Free	2	BHandset (Power Up, Bad LCD)(unknow part message)	2336
Apple	iPhone 11 (128GB)SIM Free	40	BHandset (only electricity)	2337
Apple	iPhone 11 (256GB)SIM Free	2	BHandset (only electricity)	2338
Apple	iPhone 11 (64GB)SIM Free	30	BHandset (only electricity)	2339
Apple	iPhone 11 (128GB)SIM Free	70	SP Bid-No Power On-Change Battery(Reference Only)	2340
Apple	iPhone 11 (64GB)SIM Free	573	SP Bid-No Power On-Change Battery(Reference Only)	2341
Apple	iPhone 11 (128GB) (SIM FreeProblematic)	9	Part 2 AHandset	2342
Apple	iPhone 11 (256GB) (SIM FreeProblematic)	9	Part 2 AHandset	2343
Apple	iPhone 11 (64GB) (SIM FreeProblematic)	13	Part 2 AHandset	2344
Apple	iPhone 11 (128GB) (SIM FreeProblematic)	12	Part 2 BHandset (Power Up, Good LCD)	2345
Apple	iPhone 11 (64GB) (SIM FreeProblematic)	6	Part 2 BHandset (Power Up, Good LCD)	2346
Apple	iPhone 11 (128GB) (SIM FreeProblematic)	21	Part 2 BHandset (Power Up, Bad LCD)	2347
Apple	iPhone 11 (256GB) (SIM FreeProblematic)	1	Part 2 BHandset (Power Up, Bad LCD)	2348
Apple	iPhone 11 (128GB) (SIM FreeProblematic)	3	Part 2 BHandset (only electricity)	2349
Apple	iPhone 11 (64GB) (SIM FreeProblematic)	22	Part 2 BHandset (only electricity)	2350
Apple	iPhone 11 (64GB) (SIM Freefid)	3	Part 2 AHandset	2351
Apple	iPhone 11 (64GB) (SIM Freefid)	1	Part 2 AHandset (unknow part message)	2352
Apple	iPhone 11 (128GB)	8	Part 2 AHandset	2353
Apple	iPhone 11 (256GB)	15	Part 2 AHandset	2354
Apple	iPhone 11 (64GB)	13	Part 2 AHandset	2355
Apple	iPhone 11 (128GB)	2	Part 2 BHandset (Power Up, Good LCD)	2356
Apple	iPhone 11 (128GB)	6	Part 2 BHandset (Power Up, Bad LCD)	2357
Apple	iPhone 11 (256GB)	2	Part 2 BHandset (Power Up, Bad LCD)	2358
Apple	iPhone 11 (64GB)	9	Part 2 BHandset (Power Up, Bad LCD)	2359
Apple	iPhone 11 (128GB)	6	Part 2 BHandset (only electricity)	2360
Apple	iPhone 11 (64GB)	25	Part 2 BHandset (only electricity)	2361
Apple	iPhone 11 (128GB)	2	Part 2 SP Bid-No Power On-Change Battery(Reference Only)	2362
Apple	iPhone 11 (256GB)	3	Part 2 SP Bid-No Power On-Change Battery(Reference Only)	2363
Apple	iPhone 11 (64GB)	17	Part 2 SP Bid-No Power On-Change Battery(Reference Only)	2364
Apple	iPhone 11 (128GB)	1	Mainboard	2365
Apple	iPhone 11 (64GB)	62	Mainboard	2366
Apple	iPhone 11 (128GB) (Problematic)	1	Part 2 BHandset (Power Up, Good LCD)	2367
Apple	iPhone 11 (64GB) (Problematic)	1	Part 2 BHandset (Power Up, Good LCD)	2368
Apple	iPhone 11 (128GB) (Problematic)	1	Part 2 BHandset (Power Up, Bad LCD)	2369
Apple	iPhone 11 (64GB) (Problematic)	5	Part 2 BHandset (Power Up, Bad LCD)	2370
Apple	iPhone Xs Max Total	580	Summary	2371
Apple	iPhone Xs Max (256GB)SIM Free	1	AHandset (Good)(Full Fuction)	2372
Apple	iPhone Xs Max (512GB)SIM Free	1	AHandset (Good)(Full Fuction)	2373
Apple	iPhone Xs Max (64GB)SIM Free	4	AHandset (Good)(Full Fuction)	2374
Apple	iPhone Xs Max (256GB)SIM Free	4	AHandset (Good)	2375
Apple	iPhone Xs Max (512GB)SIM Free	1	AHandset (Good)	2376
Apple	iPhone Xs Max (256GB)SIM Free	1	AHandset (Good)(unknow part message)	2377
Apple	iPhone Xs Max (64GB)SIM Free	2	AHandset (Good)(unknow part message)	2378
Apple	iPhone Xs Max (256GB)SIM Free	22	AHandset (Good 1)(Full Fuction)	2379
Apple	iPhone Xs Max (64GB)SIM Free	6	AHandset (Good 1)(Full Fuction)	2380
Apple	iPhone Xs Max (256GB)SIM Free	1	AHandset (Good 1)(Bad Back Camera Glass)(Full Fuction)	2381
Apple	iPhone Xs Max (512GB)SIM Free	1	AHandset (Good 1)(Bad Back Camera Glass)(Full Fuction)	2382
Apple	iPhone Xs Max (64GB)SIM Free	1	AHandset (Good 1)(Bad Back Camera Glass)(Full Fuction)	2383
Apple	iPhone Xs Max (256GB)SIM Free	2	AHandset (Good 1)(Broken Back Glass)(Full Fuction)	2384
Apple	iPhone Xs Max (64GB)SIM Free	6	AHandset (Good 1)(Broken Back Glass)(Full Fuction)	2385
Apple	iPhone Xs Max (256GB)SIM Free	1	AHandset (Good 1)	2386
Apple	iPhone Xs Max (64GB)SIM Free	6	AHandset (Good 1)	2387
Apple	iPhone Xs Max (256GB)SIM Free	1	AHandset (Full Fuction)	2388
Apple	iPhone Xs Max (256GB)SIM Free	2	AHandset (Bad Back Camera Glass)(Full Fuction)	2389
Apple	iPhone Xs Max (256GB)SIM Free	2	AHandset (Broken Back Glass)(Full Fuction)	2390
Apple	iPhone Xs Max (512GB)SIM Free	3	AHandset (Broken Back Glass)(Full Fuction)	2391
Apple	iPhone Xs Max (64GB)SIM Free	12	AHandset (Broken Back Glass)(Full Fuction)	2392
Apple	iPhone Xs Max (256GB)SIM Free	13	AHandset	2393
Apple	iPhone Xs Max (512GB)SIM Free	5	AHandset	2394
Apple	iPhone Xs Max (64GB)SIM Free	13	AHandset	2395
Apple	iPhone Xs Max (256GB)SIM Free	6	AHandset (Bad Back Camera Glass)	2396
Apple	iPhone Xs Max (64GB)SIM Free	6	AHandset (Bad Back Camera Glass)	2397
Apple	iPhone Xs Max (256GB)SIM Free	14	AHandset (Broken Back Glass)	2398
Apple	iPhone Xs Max (512GB)SIM Free	2	AHandset (Broken Back Glass)	2399
Apple	iPhone Xs Max (64GB)SIM Free	8	AHandset (Broken Back Glass)	2400
Apple	iPhone Xs Max (256GB)SIM Free	6	AHandset (Full Fuction)(unknow part message)	2401
Apple	iPhone Xs Max (64GB)SIM Free	3	AHandset (Full Fuction)(unknow part message)	2402
Apple	iPhone Xs Max (256GB)SIM Free	1	AHandset (Bad Back Camera Glass)(Full Fuction)(unknow part message)	2403
Apple	iPhone Xs Max (512GB)SIM Free	1	AHandset (unknow part message)	2404
Apple	iPhone Xs Max (64GB)SIM Free	10	AHandset (unknow part message)	2405
Apple	iPhone Xs Max (64GB)SIM Free	2	AHandset (Bad Back Camera Glass)(unknow part message)	2406

Apple	iPhone Xs Max (256GB)SIM Free	2	AHandset (Broken Back Glass)(unknow part message)	2407
Apple	iPhone Xs Max (64GB)SIM Free	1	AHandset (Broken Back Glass)(unknow part message)	2408
Apple	iPhone Xs Max (256GB)SIM Free	3	BHandset (Power Up, Good LCD)	2409
Apple	iPhone Xs Max (512GB)SIM Free	1	BHandset (Power Up, Good LCD)	2410
Apple	iPhone Xs Max (64GB)SIM Free	10	BHandset (Power Up, Good LCD)	2411
Apple	iPhone Xs Max (256GB)SIM Free	2	BHandset (Power Up, Good LCD)(unknow part message)	2412
Apple	iPhone Xs Max (256GB)SIM Free	22	BHandset (Power Up, Bad LCD)(FidWorking)	2413
Apple	iPhone Xs Max (64GB)SIM Free	17	BHandset (Power Up, Bad LCD)(FidWorking)	2414
Apple	iPhone Xs Max (256GB)SIM Free	32	BHandset (Power Up, Bad LCD)	2415
Apple	iPhone Xs Max (512GB)SIM Free	5	BHandset (Power Up, Bad LCD)	2416
Apple	iPhone Xs Max (64GB)SIM Free	41	BHandset (Power Up, Bad LCD)	2417
Apple	iPhone Xs Max (512GB)SIM Free	1	BHandset (Power Up, Bad LCD)(FidWorking)(unknow part message)	2418
Apple	iPhone Xs Max (256GB)SIM Free	33	BHandset (only electricity)	2419
Apple	iPhone Xs Max (512GB)SIM Free	1	BHandset (only electricity)	2420
Apple	iPhone Xs Max (64GB)SIM Free	43	BHandset (only electricity)	2421
Apple	iPhone Xs Max (256GB)SIM Free	26	SP Bid-No Power On-Change Battery(Reference Only)	2422
Apple	iPhone Xs Max (64GB)SIM Free	71	SP Bid-No Power On-Change Battery(Reference Only)	2423
Apple	iPhone Xs Max (256GB) (SIM FreeProblematic)	8	Part 2 AHandset	2424
Apple	iPhone Xs Max (512GB) (SIM FreeProblematic)	13	Part 2 AHandset	2425
Apple	iPhone Xs Max (64GB) (SIM FreeProblematic)	11	Part 2 AHandset	2426
Apple	iPhone Xs Max (256GB) (SIM FreeProblematic)	1	Part 2 AHandset (unknow part message)	2427
Apple	iPhone Xs Max (256GB) (SIM FreeProblematic)	4	Part 2 BHandset (Power Up, Good LCD)	2428
Apple	iPhone Xs Max (64GB) (SIM FreeProblematic)	12	Part 2 BHandset (Power Up, Good LCD)	2429
Apple	iPhone Xs Max (256GB) (SIM FreeProblematic)	2	Part 2 BHandset (Power Up, Bad LCD)	2430
Apple	iPhone Xs Max (64GB) (SIM FreeProblematic)	7	Part 2 BHandset (Power Up, Bad LCD)	2431
Apple	iPhone Xs Max (64GB) (SIM FreeProblematic)	2	Part 2 BHandset (only electricity)	2432
Apple	iPhone Xs Max (64GB) (SIM Freefid)	1	Part 2 AHandset (unknow part message)	2433
Apple	iPhone Xs Max (256GB)	1	Part 2 AHandset	2434
Apple	iPhone Xs Max (256GB)	4	Part 2 BHandset (Power Up, Bad LCD)	2435
Apple	iPhone Xs Max (64GB)	5	Part 2 BHandset (Power Up, Bad LCD)	2436
Apple	iPhone Xs Max (64GB)	6	Part 2 BHandset (only electricity)	2437
Apple	iPhone Xs Max (256GB)	2	Part 2 SP Bid-No Power On-Change Battery(Reference Only)	2438
Apple	iPhone Xs Max (64GB)	9	Part 2 SP Bid-No Power On-Change Battery(Reference Only)	2439
Apple	iPhone Xs Max (256GB)	1	Mainboard	2440
Apple	iPhone Xs Max (64GB)	8	Mainboard	2441
Apple	iPhone Xs Max (256GB) (Problematic)	1	Part 2 AHandset	2442
Apple	iPhone Xs Max (64GB) (Problematic)	1	Part 2 BHandset (Power Up, Good LCD)	2443
Apple	iPhone Xs Total	343	Summary	2444
Apple	iPhone Xs (64GB)SIM Free	5	AHandset (Good)(Full Fuction)	2445
Apple	iPhone Xs (256GB)SIM Free	10	AHandset (Good 1)(Full Fuction)	2446
Apple	iPhone Xs (64GB)SIM Free	49	AHandset (Good 1)(Full Fuction)	2447
Apple	iPhone Xs (64GB)SIM Free	2	AHandset (Good 1)(Bad Back Camera Glass)(Full Fuction)	2448
Apple	iPhone Xs (256GB)SIM Free	2	AHandset (Good 1)(Broken Back Glass)(Full Fuction)	2449
Apple	iPhone Xs (64GB)SIM Free	4	AHandset (Good 1)(Broken Back Glass)(Full Fuction)	2450
Apple	iPhone Xs (512GB)SIM Free	2	AHandset (Good 1)	2451
Apple	iPhone Xs (256GB)SIM Free	1	AHandset (Full Fuction)	2452
Apple	iPhone Xs (512GB)SIM Free	1	AHandset (Full Fuction)	2453
Apple	iPhone Xs (64GB)SIM Free	10	AHandset (Full Fuction)	2454
Apple	iPhone Xs (64GB)SIM Free	1	AHandset (Bad Back Camera Glass)(Full Fuction)	2455
Apple	iPhone Xs (256GB)SIM Free	3	AHandset (Broken Back Glass)(Full Fuction)	2456
Apple	iPhone Xs (64GB)SIM Free	9	AHandset (Broken Back Glass)(Full Fuction)	2457
Apple	iPhone Xs (256GB)SIM Free	2	AHandset	2458
Apple	iPhone Xs (64GB)SIM Free	2	AHandset	2459
Apple	iPhone Xs (256GB)SIM Free	1	AHandset (Broken Back Glass)	2460
Apple	iPhone Xs (64GB)SIM Free	1	AHandset (Broken Back Glass)(unknow part message)	2461
Apple	iPhone Xs (256GB)SIM Free	1	BHandset (Power Up, Good LCD)(Full Fuction)	2462
Apple	iPhone Xs (64GB)SIM Free	4	BHandset (Power Up, Good LCD)(Full Fuction)	2463
Apple	iPhone Xs (64GB)SIM Free	6	BHandset (Power Up, Good LCD)	2464
Apple	iPhone Xs (64GB)SIM Free	1	BHandset (Power Up, Good LCD)(unknow part message)	2465
Apple	iPhone Xs (64GB)SIM Free	6	BHandset (Power Up, Bad LCD)(FidWorking)	2466
Apple	iPhone Xs (256GB)SIM Free	18	BHandset (Power Up, Bad LCD)	2467
Apple	iPhone Xs (512GB)SIM Free	1	BHandset (Power Up, Bad LCD)	2468
Apple	iPhone Xs (64GB)SIM Free	40	BHandset (Power Up, Bad LCD)	2469
Apple	iPhone Xs (64GB)SIM Free	1	BHandset (Power Up, Bad LCD)(unknow part message)	2470
Apple	iPhone Xs (256GB)SIM Free	4	BHandset (only electricity)	2471
Apple	iPhone Xs (64GB)SIM Free	10	BHandset (only electricity)	2472
Apple	iPhone Xs (256GB)SIM Free	36	SP Bid-No Power On-Change Battery(Reference Only)	2473
Apple	iPhone Xs (512GB)SIM Free	4	SP Bid-No Power On-Change Battery(Reference Only)	2474
Apple	iPhone Xs (64GB)SIM Free	20	SP Bid-No Power On-Change Battery(Reference Only)	2475
Apple	iPhone Xs (256GB) (SIM FreeProblematic)	1	Part 2 AHandset	2476
Apple	iPhone Xs (64GB) (SIM FreeProblematic)	22	Part 2 AHandset	2477
Apple	iPhone Xs (64GB) (SIM FreeProblematic)	3	Part 2 BHandset (Power Up, Good LCD)	2478
Apple	iPhone Xs (256GB) (SIM FreeProblematic)	3	Part 2 BHandset (only electricity)	2479
Apple	iPhone Xs (64GB) (SIM FreeProblematic)	9	Part 2 BHandset (only electricity)	2480
Apple	iPhone Xs (512GB) (SIM Freefid)	1	Part 2 AHandset	2481
Apple	iPhone Xs (256GB) (SIM Freefid)	1	Part 2 BHandset (Power Up, Good LCD)	2482
Apple	iPhone Xs (64GB) (SIM Freefid)	1	Part 2 BHandset (Power Up, Good LCD)	2483
Apple	iPhone Xs (64GB)	2	Part 2 BHandset (only electricity)	2484
Apple	iPhone Xs (256GB)	2	Part 2 SP Bid-No Power On-Change Battery(Reference Only)	2485
Apple	iPhone Xs (64GB)	20	Part 2 SP Bid-No Power On-Change Battery(Reference Only)	2486
Apple	iPhone Xs (256GB)	1	Mainboard	2487
Apple	iPhone Xs (64GB)	18	Mainboard	2488
Apple	iPhone Xs (64GB) (Problematic)	1	Part 2 AHandset	2489
Apple	iPhone Xs (256GB) (Problematic)	1	Part 2 BHandset (Power Up, Bad LCD)	2490
Apple	iPhone Xr Total	493	Summary	2491
Apple	iPhone Xr (64GB)SIM Free	10	AHandset (Good)(Full Fuction)	2492

Apple	iPhone Xr (128GB)SIM Free	1	AHandset (Good)	2493
Apple	iPhone Xr (64GB)SIM Free	2	AHandset (Good)	2494
Apple	iPhone Xr (64GB)SIM Free	6	AHandset (Good)(Full Fuction)(unknow part message)	2495
Apple	iPhone Xr (128GB)SIM Free	1	AHandset (Good 1)(Broken Back Glass)(Full Fuction)	2496
Apple	iPhone Xr (128GB)SIM Free	1	AHandset (Good 1)	2497
Apple	iPhone Xr (128GB)SIM Free	1	AHandset (Good 1)(unknow part message)	2498
Apple	iPhone Xr (64GB)SIM Free	1	AHandset (Good 1)(unknow part message)	2499
Apple	iPhone Xr (128GB)SIM Free	1	AHandset (Bad Back Camera Glass)(Full Fuction)	2500
Apple	iPhone Xr (64GB)SIM Free	2	AHandset (Bad Back Camera Glass)(Full Fuction)	2501
Apple	iPhone Xr (64GB)SIM Free	2	AHandset (Broken Back Glass)(Full Fuction)	2502
Apple	iPhone Xr (128GB)SIM Free	10	AHandset	2503
Apple	iPhone Xr (64GB)SIM Free	3	AHandset	2504
Apple	iPhone Xr (128GB)SIM Free	8	AHandset (Broken Back Glass)	2505
Apple	iPhone Xr (256GB)SIM Free	1	AHandset (Broken Back Glass)	2506
Apple	iPhone Xr (64GB)SIM Free	1	AHandset (Broken Back Glass)	2507
Apple	iPhone Xr (128GB)SIM Free	1	AHandset (Full Fuction)(unknow part message)	2508
Apple	iPhone Xr (256GB)SIM Free	1	AHandset (Full Fuction)(unknow part message)	2509
Apple	iPhone Xr (64GB)SIM Free	3	AHandset (Full Fuction)(unknow part message)	2510
Apple	iPhone Xr (128GB)SIM Free	1	AHandset (Broken Back Glass)(Full Fuction)(unknow part message)	2511
Apple	iPhone Xr (128GB)SIM Free	5	AHandset (unknow part message)	2512
Apple	iPhone Xr (256GB)SIM Free	1	AHandset (unknow part message)	2513
Apple	iPhone Xr (64GB)SIM Free	1	AHandset (unknow part message)	2514
Apple	iPhone Xr (128GB)SIM Free	2	AHandset (Broken Back Glass)(unknow part message)	2515
Apple	iPhone Xr (256GB)SIM Free	1	AHandset (Broken Back Glass)(unknow part message)	2516
Apple	iPhone Xr (64GB)SIM Free	5	AHandset (Broken Back Glass)(unknow part message)	2517
Apple	iPhone Xr (128GB)SIM Free	1	BHandset (Power Up, Good LCD)	2518
Apple	iPhone Xr (64GB)SIM Free	1	BHandset (Power Up, Good LCD)	2519
Apple	iPhone Xr (128GB)SIM Free	1	BHandset (Power Up, Good LCD)(unknow part message)	2520
Apple	iPhone Xr (64GB)SIM Free	5	BHandset (Power Up, Good LCD)(unknow part message)	2521
Apple	iPhone Xr (256GB)SIM Free	1	BHandset (Power Up, Bad LCD)(FidWorking)	2522
Apple	iPhone Xr (64GB)SIM Free	1	BHandset (Power Up, Bad LCD)(FidWorking)	2523
Apple	iPhone Xr (128GB)SIM Free	4	BHandset (Power Up, Bad LCD)	2524
Apple	iPhone Xr (256GB)SIM Free	2	BHandset (Power Up, Bad LCD)	2525
Apple	iPhone Xr (64GB)SIM Free	27	BHandset (Power Up, Bad LCD)	2526
Apple	iPhone Xr (128GB)SIM Free	5	BHandset (Power Up, Bad LCD)(FidWorking)(unknow part message)	2527
Apple	iPhone Xr (64GB)SIM Free	14	BHandset (Power Up, Bad LCD)(FidWorking)(unknow part message)	2528
Apple	iPhone Xr (128GB)SIM Free	2	BHandset (Power Up, Bad LCD)(unknow part message)	2529
Apple	iPhone Xr (128GB)SIM Free	5	BHandset (only electricity)	2530
Apple	iPhone Xr (256GB)SIM Free	2	BHandset (only electricity)	2531
Apple	iPhone Xr (64GB)SIM Free	41	BHandset (only electricity)	2532
Apple	iPhone Xr (128GB)SIM Free	40	SP Bid-No Power On-Change Battery(Reference Only)	2533
Apple	iPhone Xr (256GB)SIM Free	6	SP Bid-No Power On-Change Battery(Reference Only)	2534
Apple	iPhone Xr (64GB)SIM Free	77	SP Bid-No Power On-Change Battery(Reference Only)	2535
Apple	iPhone Xr (64GB) (SIM FreeProblematic)	16	Part 2 AHandset	2536
Apple	iPhone Xr (128GB) (SIM FreeProblematic)	2	Part 2 BHandset (Power Up, Good LCD)	2537
Apple	iPhone Xr (256GB) (SIM FreeProblematic)	1	Part 2 BHandset (Power Up, Good LCD)	2538
Apple	iPhone Xr (128GB) (SIM FreeProblematic)	1	Part 2 BHandset (Power Up, Bad LCD)	2539
Apple	iPhone Xr (64GB) (SIM FreeProblematic)	4	Part 2 BHandset (Power Up, Bad LCD)	2540
Apple	iPhone Xr (128GB) (SIM FreeProblematic)	1	Part 2 BHandset (only electricity)	2541
Apple	iPhone Xr (64GB) (SIM FreeProblematic)	5	Part 2 BHandset (only electricity)	2542
Apple	iPhone Xr (64GB) (SIM Freefid)	2	Part 2 AHandset	2543
Apple	iPhone Xr (64GB)	1	Part 2 AHandset	2544
Apple	iPhone Xr (64GB)	47	Part 2 BHandset (Power Up, Bad LCD)	2545
Apple	iPhone Xr (64GB)	29	Part 2 BHandset (only electricity)	2546
Apple	iPhone Xr (64GB)	53	Part 2 SP Bid-No Power On-Change Battery(Reference Only)	2547
Apple	iPhone Xr (64GB)	9	Mainboard	2548
Apple	iPhone Xr (64GB) (Problematic)	3	Part 2 AHandset	2549
Apple	iPhone Xr (64GB) (Problematic)	6	Part 2 BHandset (Power Up, Good LCD)	2550
Apple	iPhone Xr (64GB) (Problematic)	6	Part 2 BHandset (Power Up, Bad LCD)	2551
Apple	iPhone X Total	418	Summary	2552
Apple	iPhone X (256GB)SIM Free	2	Nearly New Handset(Full Fuction)	2553
Apple	iPhone X (256GB)SIM Free	15	AHandset (Good)(Full Fuction)	2554
Apple	iPhone X (64GB)SIM Free	5	AHandset (Good)(Full Fuction)	2555
Apple	iPhone X (64GB)SIM Free	4	AHandset (Good)	2556
Apple	iPhone X (64GB)SIM Free	2	AHandset (Good)(Full Fuction)(unknow part message)	2557
Apple	iPhone X (256GB)SIM Free	8	AHandset (Good 1)(Full Fuction)	2558
Apple	iPhone X (64GB)SIM Free	16	AHandset (Good 1)(Full Fuction)	2559
Apple	iPhone X (256GB)SIM Free	1	AHandset (Good 1)(Bad Back Camera Glass)(Full Fuction)	2560
Apple	iPhone X (64GB)SIM Free	2	AHandset (Good 1)(Bad Back Camera Glass)(Full Fuction)	2561
Apple	iPhone X (64GB)SIM Free	4	AHandset (Good 1)(Broken Back Glass)(Full Fuction)	2562
Apple	iPhone X (64GB)SIM Free	4	AHandset (Good 1)	2563
Apple	iPhone X (256GB)SIM Free	4	AHandset (Full Fuction)	2564
Apple	iPhone X (64GB)SIM Free	18	AHandset (Full Fuction)	2565
Apple	iPhone X (256GB)SIM Free	2	AHandset (Bad Back Camera Glass)(Full Fuction)	2566
Apple	iPhone X (256GB)SIM Free	8	AHandset (Broken Back Glass)(Full Fuction)	2567
Apple	iPhone X (64GB)SIM Free	19	AHandset (Broken Back Glass)(Full Fuction)	2568
Apple	iPhone X (64GB)SIM Free	2	AHandset	2569
Apple	iPhone X (64GB)SIM Free	9	AHandset (Full Fuction)(unknow part message)	2570
Apple	iPhone X (256GB)SIM Free	3	BHandset (Power Up, Good LCD)	2571
Apple	iPhone X (64GB)SIM Free	2	BHandset (Power Up, Good LCD)	2572
Apple	iPhone X (256GB)SIM Free	2	BHandset (Power Up, Bad LCD)	2573
Apple	iPhone X (64GB)SIM Free	17	BHandset (Power Up, Bad LCD)	2574
Apple	iPhone X (256GB)SIM Free	36	BHandset (only electricity)	2575
Apple	iPhone X (64GB)SIM Free	29	BHandset (only electricity)	2576
Apple	iPhone X (256GB)SIM Free	20	SP Bid-No Power On-Change Battery(Reference Only)	2577
Apple	iPhone X (64GB)SIM Free	55	SP Bid-No Power On-Change Battery(Reference Only)	2578

Apple	iPhone X (256GB) (SIM FreeProblematic)	7	Part 2 AHandset	2579
Apple	iPhone X (64GB) (SIM FreeProblematic)	11	Part 2 AHandset	2580
Apple	iPhone X (64GB) (SIM FreeProblematic)	3	Part 2 BHandset (Power Up, Good LCD)	2581
Apple	iPhone X (256GB) (SIM FreeProblematic)	16	Part 2 BHandset (Power Up, Bad LCD)	2582
Apple	iPhone X (64GB) (SIM FreeProblematic)	14	Part 2 BHandset (Power Up, Bad LCD)	2583
Apple	iPhone X (64GB) (SIM FreeProblematic)	10	Part 2 BHandset (only electricity)	2584
Apple	iPhone X (256GB) (SIM Freefid)	1	Part 2 AHandset	2585
Apple	iPhone X (64GB) (SIM Freefid)	1	Part 2 AHandset	2586
Apple	iPhone X (64GB) (SIM Freefid)	1	Part 2 BHandset (Power Up, Good LCD)	2587
Apple	iPhone X (256GB)	2	Part 2 AHandset	2588
Apple	iPhone X (64GB)	3	Part 2 AHandset	2589
Apple	iPhone X (64GB)	1	Part 2 BHandset (Power Up, Good LCD)	2590
Apple	iPhone X (64GB)	4	Part 2 BHandset (Power Up, Bad LCD)	2591
Apple	iPhone X (64GB)	8	Part 2 BHandset (only electricity)	2592
Apple	iPhone X (256GB)	6	Part 2 SP Bid-No Power On-Change Battery(Reference Only)	2593
Apple	iPhone X (64GB)	11	Part 2 SP Bid-No Power On-Change Battery(Reference Only)	2594
Apple	iPhone X (256GB)	4	Mainboard	2595
Apple	iPhone X (64GB)	12	Mainboard	2596
Apple	iPhone X (256GB) (Problematic)	2	Part 2 AHandset	2597
Apple	iPhone X (64GB) (Problematic)	6	Part 2 AHandset	2598
Apple	iPhone X (64GB) (Problematic)	4	Part 2 BHandset (Power Up, Good LCD)	2599
Apple	iPhone X (64GB) (Problematic)	2	Part 2 BHandset (Power Up, Bad LCD)	2600
Apple	iPhone 8 Plus Total	301	Summary	2601
Apple	iPhone 8 Plus (64GB)SIM Free	4	AHandset (Good)(Full Fuction)	2602
Apple	iPhone 8 Plus (256GB)SIM Free	3	AHandset (Good 1)(Full Fuction)	2603
Apple	iPhone 8 Plus (64GB)SIM Free	11	AHandset (Good 1)(Full Fuction)	2604
Apple	iPhone 8 Plus (256GB)SIM Free	5	AHandset	2605
Apple	iPhone 8 Plus (64GB)SIM Free	14	AHandset	2606
Apple	iPhone 8 Plus (64GB)SIM Free	3	AHandset (Broken Back Glass)	2607
Apple	iPhone 8 Plus (256GB)SIM Free	1	AHandset (unknow part message)	2608
Apple	iPhone 8 Plus (64GB)SIM Free	5	AHandset (unknow part message)	2609
Apple	iPhone 8 Plus (64GB)SIM Free	1	AHandset (Broken Back Glass)(unknow part message)	2610
Apple	iPhone 8 Plus (64GB)SIM Free	5	BHandset (Power Up, Good LCD)	2611
Apple	iPhone 8 Plus (256GB)SIM Free	1	BHandset (Power Up, Good LCD)(unknow part message)	2612
Apple	iPhone 8 Plus (256GB)SIM Free	1	BHandset (Power Up, Bad LCD)	2613
Apple	iPhone 8 Plus (64GB)SIM Free	2	BHandset (Power Up, Bad LCD)	2614
Apple	iPhone 8 Plus (64GB)SIM Free	1	BHandset (only electricity)	2615
Apple	iPhone 8 Plus (128GB)SIM Free	4	SP Bid-No Power On-Change Battery(Reference Only)	2616
Apple	iPhone 8 Plus (256GB)SIM Free	13	SP Bid-No Power On-Change Battery(Reference Only)	2617
Apple	iPhone 8 Plus (64GB)SIM Free	114	SP Bid-No Power On-Change Battery(Reference Only)	2618
Apple	iPhone 8 Plus (64GB) (SIM FreeProblematic)	1	Part 2 BHandset (Power Up, Bad LCD)	2619
Apple	iPhone 8 Plus (64GB) (SIM FreeProblematic)	1	Part 2 BHandset (only electricity)	2620
Apple	iPhone 8 Plus (64GB) (Unlocked, Bad Fingerprint Sensor)	1	Part 2 AHandset	2621
Apple	iPhone 8 Plus (256GB) (Unlocked, Bad Fingerprint Sensor)	1	Part 2 BHandset (Power Up, Good LCD)	2622
Apple	iPhone 8 Plus (64GB) (Unlocked, Bad Fingerprint Sensor)	1	Part 2 BHandset (Power Up, Good LCD)	2623
Apple	iPhone 8 Plus (256GB)	1	Part 2 BHandset (Power Up, Bad LCD)	2624
Apple	iPhone 8 Plus (64GB)	21	Part 2 BHandset (Power Up, Bad LCD)	2625
Apple	iPhone 8 Plus (256GB)	1	Part 2 BHandset (only electricity)	2626
Apple	iPhone 8 Plus (64GB)	15	Part 2 BHandset (only electricity)	2627
Apple	iPhone 8 Plus (64GB)	54	Part 2 SP Bid-No Power On-Change Battery(Reference Only)	2628
Apple	iPhone 8 Plus (256GB)	1	Mainboard	2629
Apple	iPhone 8 Plus (64GB)	6	Mainboard	2630
Apple	iPhone 8 Plus (64GB) (Problematic)	2	Part 2 AHandset	2631
Apple	iPhone 8 Plus (64GB) (Problematic)	1	Part 2 BHandset (Power Up, Good LCD)	2632
Apple	iPhone 8 Plus (64GB) (Problematic)	6	Part 2 BHandset (Power Up, Bad LCD)	2633
Apple	iPhone 8 Total	246	Summary	2634
Apple	iPhone 8 (256GB)SIM Free	26	AHandset (Good)(Full Fuction)	2635
Apple	iPhone 8 (256GB)SIM Free	58	AHandset (Good 1)(Full Fuction)	2636
Apple	iPhone 8 (64GB)SIM Free	5	AHandset (Good 1)(Full Fuction)	2637
Apple	iPhone 8 (128GB)SIM Free	1	AHandset (Full Fuction)	2638
Apple	iPhone 8 (256GB)SIM Free	22	AHandset (Full Fuction)	2639
Apple	iPhone 8 (64GB)SIM Free	1	AHandset	2640
Apple	iPhone 8 (64GB)SIM Free	1	AHandset (Broken Back Glass)	2641
Apple	iPhone 8 (64GB)SIM Free	1	BHandset (Power Up, Good LCD)	2642
Apple	iPhone 8 (256GB)SIM Free	2	BHandset (Power Up, Bad LCD)	2643
Apple	iPhone 8 (64GB)SIM Free	11	BHandset (Power Up, Bad LCD)	2644
Apple	iPhone 8 (128GB)SIM Free	1	SP Bid-No Power On-Change Battery(Reference Only)	2645
Apple	iPhone 8 (64GB)SIM Free	77	SP Bid-No Power On-Change Battery(Reference Only)	2646
Apple	iPhone 8 (64GB) (SIM FreeProblematic)	2	Part 2 AHandset	2647
Apple	iPhone 8 (64GB) (SIM FreeProblematic)	3	Part 2 BHandset (Power Up, Good LCD)	2648
Apple	iPhone 8 (64GB) (Unlocked, Bad Fingerprint Sensor)	1	Part 2 AHandset	2649
Apple	iPhone 8 (64GB)	3	Part 2 AHandset	2650
Apple	iPhone 8 (64GB)	9	Part 2 BHandset (Power Up, Bad LCD)	2651
Apple	iPhone 8 (64GB)	1	Part 2 SP Bid-No Power On-Change Battery(Reference Only)	2652
Apple	iPhone 8 (64GB)	18	Mainboard	2653
Apple	iPhone 8 (64GB) (Problematic)	2	Part 2 AHandset	2654
Apple	iPhone 8 (64GB) (Problematic)	1	Part 2 BHandset (Power Up, Good LCD)	2655
Apple	iPhone 7 Plus Total	469	Summary	2656
Apple	iPhone 7 Plus (32GB)SIM Free	1	AHandset (Good)	2657
Apple	iPhone 7 Plus (128GB)SIM Free	3	AHandset (Good 1)	2658
Apple	iPhone 7 Plus (128GB)SIM Free	16	AHandset	2659
Apple	iPhone 7 Plus (256GB)SIM Free	13	AHandset	2660
Apple	iPhone 7 Plus (32GB)SIM Free	18	AHandset	2661
Apple	iPhone 7 Plus (128GB)SIM Free	1	AHandset (Bad Back Camera Glass)	2662
Apple	iPhone 7 Plus (32GB)SIM Free	2	AHandset (Bad Back Camera Glass)	2663
Apple	iPhone 7 Plus (128GB)SIM Free	4	AHandset (unknow part message)	2664

Apple	iPhone 7 Plus (128GB)SIM Free	50	BHandset (Power Up, Good LCD)	2665
Apple	iPhone 7 Plus (256GB)SIM Free	6	BHandset (Power Up, Good LCD)	2666
Apple	iPhone 7 Plus (32GB)SIM Free	60	BHandset (Power Up, Good LCD)	2667
Apple	iPhone 7 Plus (256GB)SIM Free	1	BHandset (Power Up, Bad LCD)	2668
Apple	iPhone 7 Plus (32GB)SIM Free	58	BHandset (Power Up, Bad LCD)	2669
Apple	iPhone 7 Plus (128GB)SIM Free	42	SP Bid-No Power On-Change Battery(Reference Only)	2670
Apple	iPhone 7 Plus (256GB)SIM Free	6	SP Bid-No Power On-Change Battery(Reference Only)	2671
Apple	iPhone 7 Plus (32GB)SIM Free	76	SP Bid-No Power On-Change Battery(Reference Only)	2672
Apple	iPhone 7 Plus (128GB) (SIM FreeProblematic)	1	Part 2 AHandset	2673
Apple	iPhone 7 Plus (128GB) (SIM FreeProblematic)	3	Part 2 BHandset (Power Up, Good LCD)	2674
Apple	iPhone 7 Plus (256GB) (SIM FreeProblematic)	1	Part 2 BHandset (Power Up, Good LCD)	2675
Apple	iPhone 7 Plus (32GB) (SIM FreeProblematic)	4	Part 2 BHandset (Power Up, Good LCD)	2676
Apple	iPhone 7 Plus (128GB) (Unlocked, Bad Fingerprint Sensor)	5	Part 2 AHandset	2677
Apple	iPhone 7 Plus (256GB) (Unlocked, Bad Fingerprint Sensor)	1	Part 2 AHandset	2678
Apple	iPhone 7 Plus (32GB) (Unlocked, Bad Fingerprint Sensor)	7	Part 2 AHandset	2679
Apple	iPhone 7 Plus (128GB) (Unlocked, Bad Fingerprint Sensor)	1	Part 2 BHandset (Power Up, Good LCD)	2680
Apple	iPhone 7 Plus (32GB) (Unlocked, Bad Fingerprint Sensor)	6	Part 2 BHandset (Power Up, Good LCD)	2681
Apple	iPhone 7 Plus (128GB)	1	Part 2 BHandset (Power Up, Good LCD)	2682
Apple	iPhone 7 Plus (32GB)	1	Part 2 BHandset (Power Up, Good LCD)	2683
Apple	iPhone 7 Plus (128GB)	2	Part 2 BHandset (Power Up, Bad LCD)	2684
Apple	iPhone 7 Plus (32GB)	3	Part 2 BHandset (Power Up, Bad LCD)	2685
Apple	iPhone 7 Plus (128GB)	3	Part 2 SP Bid-No Power On-Change Battery(Reference Only)	2686
Apple	iPhone 7 Plus (32GB)	43	Part 2 SP Bid-No Power On-Change Battery(Reference Only)	2687
Apple	iPhone 7 Plus (128GB)	1	Mainboard	2688
Apple	iPhone 7 Plus (32GB)	23	Mainboard	2689
Apple	iPhone 7 Plus (32GB) (Problematic)	2	Part 2 AHandset	2690
Apple	iPhone 7 Plus (128GB) (Problematic)	2	Part 2 BHandset (Power Up, Good LCD)	2691
Apple	iPhone 7 Plus (32GB) (Problematic)	2	Part 2 BHandset (Power Up, Good LCD)	2692
Apple	iPhone 7 Total	3775	Summary	2693
Apple	iPhone 7 (128GB)SIM Free	28	AHandset	2694
Apple	iPhone 7 (256GB)SIM Free	34	AHandset	2695
Apple	iPhone 7 (32GB)SIM Free	1999	AHandset	2696
Apple	iPhone 7 (128GB)SIM Free	1	AHandset (unknow part message)	2697
Apple	iPhone 7 (128GB)SIM Free	1	BHandset (Power Up, Good LCD)(Full Fuction)	2698
Apple	iPhone 7 (128GB)SIM Free	151	BHandset (Power Up, Good LCD)	2699
Apple	iPhone 7 (256GB)SIM Free	10	BHandset (Power Up, Good LCD)	2700
Apple	iPhone 7 (32GB)SIM Free	709	BHandset (Power Up, Good LCD)	2701
Apple	iPhone 7 (128GB)SIM Free	98	BHandset (Power Up, Bad LCD)	2702
Apple	iPhone 7 (256GB)SIM Free	4	BHandset (Power Up, Bad LCD)	2703
Apple	iPhone 7 (32GB)SIM Free	414	BHandset (Power Up, Bad LCD)	2704
Apple	iPhone 7 (128GB)SIM Free	19	SP Bid-No Power On-Change Battery(Reference Only)	2705
Apple	iPhone 7 (256GB)SIM Free	4	SP Bid-No Power On-Change Battery(Reference Only)	2706
Apple	iPhone 7 (32GB)SIM Free	105	SP Bid-No Power On-Change Battery(Reference Only)	2707
Apple	iPhone 7 (128GB) (SIM FreeProblematic)	18	Part 2 AHandset	2708
Apple	iPhone 7 (256GB) (SIM FreeProblematic)	1	Part 2 AHandset	2709
Apple	iPhone 7 (32GB) (SIM FreeProblematic)	37	Part 2 AHandset	2710
Apple	iPhone 7 (128GB) (SIM FreeProblematic)	4	Part 2 BHandset (Power Up, Good LCD)	2711
Apple	iPhone 7 (32GB) (SIM FreeProblematic)	28	Part 2 BHandset (Power Up, Good LCD)	2712
Apple	iPhone 7 (128GB) (Unlocked, Bad Fingerprint Sensor)	2	Part 2 AHandset	2713
Apple	iPhone 7 (32GB) (Unlocked, Bad Fingerprint Sensor)	3	Part 2 AHandset	2714
Apple	iPhone 7 (128GB) (Unlocked, Bad Fingerprint Sensor)	1	Part 2 BHandset (Power Up, Good LCD)	2715
Apple	iPhone 7 (32GB) (Unlocked, Bad Fingerprint Sensor)	3	Part 2 BHandset (Power Up, Good LCD)	2716
Apple	iPhone 7 (256GB)	1	Part 2 AHandset	2717
Apple	iPhone 7 (32GB)	1	Part 2 AHandset	2718
Apple	iPhone 7 (128GB)	3	Part 2 BHandset (Power Up, Good LCD)	2719
Apple	iPhone 7 (32GB)	19	Part 2 BHandset (Power Up, Good LCD)	2720
Apple	iPhone 7 (128GB)	4	Part 2 BHandset (Power Up, Bad LCD)	2721
Apple	iPhone 7 (32GB)	17	Part 2 BHandset (Power Up, Bad LCD)	2722
Apple	iPhone 7 (32GB)	5	Part 2 SP Bid-No Power On-Change Battery(Reference Only)	2723
Apple	iPhone 7 (32GB)	42	Mainboard	2724
Apple	iPhone 7 (128GB) (Problematic)	2	Part 2 AHandset	2725
Apple	iPhone 7 (32GB) (Problematic)	3	Part 2 AHandset	2726
Apple	iPhone 7 (128GB) (Problematic)	1	Part 2 BHandset (Power Up, Good LCD)	2727
Apple	iPhone 7 (32GB) (Problematic)	3	Part 2 BHandset (Power Up, Good LCD)	2728
Apple	iPhone 6s Plus Total	675	Summary	2729
Apple	iPhone 6s Plus (16GB)SIM Free	1	Nearly New	2730
Apple	iPhone 6s Plus (128GB)SIM Free	1	AHandset (Full Fuction)	2731
Apple	iPhone 6s Plus (128GB)SIM Free	5	AHandset	2732
Apple	iPhone 6s Plus (16GB)SIM Free	25	AHandset	2733
Apple	iPhone 6s Plus (32GB)SIM Free	34	AHandset	2734
Apple	iPhone 6s Plus (64GB)SIM Free	10	AHandset	2735
Apple	iPhone 6s Plus (16GB)SIM Free	1	BHandset (Power Up, Good LCD)(Full Fuction)	2736
Apple	iPhone 6s Plus (32GB)SIM Free	1	BHandset (Power Up, Good LCD)(Full Fuction)	2737
Apple	iPhone 6s Plus (64GB)SIM Free	1	BHandset (Power Up, Good LCD)(Full Fuction)	2738
Apple	iPhone 6s Plus (128GB)SIM Free	23	BHandset (Power Up, Good LCD)	2739
Apple	iPhone 6s Plus (16GB)SIM Free	16	BHandset (Power Up, Good LCD)	2740
Apple	iPhone 6s Plus (32GB)SIM Free	30	BHandset (Power Up, Good LCD)	2741
Apple	iPhone 6s Plus (64GB)SIM Free	28	BHandset (Power Up, Good LCD)	2742
Apple	iPhone 6s Plus (128GB)SIM Free	17	BHandset (Power Up, Bad LCD)	2743
Apple	iPhone 6s Plus (16GB)SIM Free	44	BHandset (Power Up, Bad LCD)	2744
Apple	iPhone 6s Plus (32GB)SIM Free	23	BHandset (Power Up, Bad LCD)	2745
Apple	iPhone 6s Plus (64GB)SIM Free	33	BHandset (Power Up, Bad LCD)	2746
Apple	iPhone 6s Plus (128GB)SIM Free	7	SP Bid-No Power On-Change Battery(Reference Only)	2747
Apple	iPhone 6s Plus (16GB)SIM Free	26	SP Bid-No Power On-Change Battery(Reference Only)	2748
Apple	iPhone 6s Plus (32GB)SIM Free	51	SP Bid-No Power On-Change Battery(Reference Only)	2749
Apple	iPhone 6s Plus (64GB)SIM Free	39	SP Bid-No Power On-Change Battery(Reference Only)	2750

Apple	iPhone 6s Plus (128GB) (SIM FreeProblematic)	12	Part 2 AHandset	2751
Apple	iPhone 6s Plus (16GB) (SIM FreeProblematic)	33	Part 2 AHandset	2752
Apple	iPhone 6s Plus (32GB) (SIM FreeProblematic)	24	Part 2 AHandset	2753
Apple	iPhone 6s Plus (64GB) (SIM FreeProblematic)	33	Part 2 AHandset	2754
Apple	iPhone 6s Plus (128GB) (SIM FreeProblematic)	3	Part 2 BHandset (Power Up, Good LCD)	2755
Apple	iPhone 6s Plus (16GB) (SIM FreeProblematic)	7	Part 2 BHandset (Power Up, Good LCD)	2756
Apple	iPhone 6s Plus (32GB) (SIM FreeProblematic)	10	Part 2 BHandset (Power Up, Good LCD)	2757
Apple	iPhone 6s Plus (64GB) (SIM FreeProblematic)	16	Part 2 BHandset (Power Up, Good LCD)	2758
Apple	Phone 6s Plus (128GB) (Unlocked, Bad Fingerprint Sensor)	2	Part 2 AHandset	2759
Apple	iPhone 6s Plus (16GB) (Unlocked, Bad Fingerprint Sensor)	9	Part 2 AHandset	2760
Apple	iPhone 6s Plus (32GB) (Unlocked, Bad Fingerprint Sensor)	9	Part 2 AHandset	2761
Apple	iPhone 6s Plus (64GB) (Unlocked, Bad Fingerprint Sensor)	9	Part 2 AHandset	2762
Apple	Phone 6s Plus (128GB) (Unlocked, Bad Fingerprint Sensor)	4	Part 2 BHandset (Power Up, Good LCD)	2763
Apple	iPhone 6s Plus (16GB) (Unlocked, Bad Fingerprint Sensor)	6	Part 2 BHandset (Power Up, Good LCD)	2764
Apple	iPhone 6s Plus (32GB) (Unlocked, Bad Fingerprint Sensor)	3	Part 2 BHandset (Power Up, Good LCD)	2765
Apple	iPhone 6s Plus (64GB) (Unlocked, Bad Fingerprint Sensor)	12	Part 2 BHandset (Power Up, Good LCD)	2766
Apple	iPhone 6s Plus (16GB)	2	Part 2 Nearly New Handset	2767
Apple	iPhone 6s Plus (16GB)	10	Part 2 AHandset	2768
Apple	iPhone 6s Plus (32GB)	2	Part 2 AHandset	2769
Apple	iPhone 6s Plus (64GB)	7	Part 2 AHandset	2770
Apple	iPhone 6s Plus (16GB)	2	Part 2 BHandset (Power Up, Good LCD)	2771
Apple	iPhone 6s Plus (32GB)	1	Part 2 BHandset (Power Up, Good LCD)	2772
Apple	iPhone 6s Plus (64GB)	2	Part 2 BHandset (Power Up, Good LCD)	2773
Apple	iPhone 6s Plus (128GB)	2	Part 2 BHandset (Power Up, Bad LCD)	2774
Apple	iPhone 6s Plus (16GB)	1	Part 2 BHandset (Power Up, Bad LCD)	2775
Apple	iPhone 6s Plus (32GB)	1	Part 2 BHandset (Power Up, Bad LCD)	2776
Apple	iPhone 6s Plus (64GB)	6	Part 2 BHandset (Power Up, Bad LCD)	2777
Apple	iPhone 6s Plus (16GB)	3	Part 2 SP Bid-No Power On-Change Battery(Reference Only)	2778
Apple	iPhone 6s Plus (64GB)	1	Part 2 SP Bid-No Power On-Change Battery(Reference Only)	2779
Apple	iPhone 6s Plus (16GB)	12	Mainboard	2780
Apple	iPhone 6s Plus (16GB) (Problematic)	11	Part 2 AHandset	2781
Apple	iPhone 6s Plus (64GB) (Problematic)	1	Part 2 AHandset	2782
Apple	iPhone 6s Plus (16GB) (Problematic)	2	Part 2 BHandset (Power Up, Good LCD)	2783
Apple	iPhone 6s Plus (32GB) (Problematic)	1	Part 2 BHandset (Power Up, Good LCD)	2784
Apple	iPhone 6s Total	1493	Summary	2785
Apple	iPhone 6s (16GB)SIM Free	1	Nearly New	2786
Apple	iPhone 6s (128GB)SIM Free	17	AHandset	2787
Apple	iPhone 6s (16GB)SIM Free	174	AHandset	2788
Apple	iPhone 6s (32GB)SIM Free	67	AHandset	2789
Apple	iPhone 6s (64GB)SIM Free	17	AHandset	2790
Apple	iPhone 6s (32GB)SIM Free	1	Part 2 AHandset	2791
Apple	iPhone 6s (128GB)SIM Free	15	BHandset (Power Up, Good LCD)	2792
Apple	iPhone 6s (16GB)SIM Free	39	BHandset (Power Up, Good LCD)	2793
Apple	iPhone 6s (32GB)SIM Free	95	BHandset (Power Up, Good LCD)	2794
Apple	iPhone 6s (64GB)SIM Free	48	BHandset (Power Up, Good LCD)	2795
Apple	iPhone 6s (128GB)SIM Free	14	BHandset (Power Up, Bad LCD)	2796
Apple	iPhone 6s (16GB)SIM Free	121	BHandset (Power Up, Bad LCD)	2797
Apple	iPhone 6s (32GB)SIM Free	173	BHandset (Power Up, Bad LCD)	2798
Apple	iPhone 6s (64GB)SIM Free	118	BHandset (Power Up, Bad LCD)	2799
Apple	iPhone 6s (128GB)SIM Free	4	SP Bid-No Power On-Change Battery(Reference Only)	2800
Apple	iPhone 6s (16GB)SIM Free	34	SP Bid-No Power On-Change Battery(Reference Only)	2801
Apple	iPhone 6s (32GB)SIM Free	47	SP Bid-No Power On-Change Battery(Reference Only)	2802
Apple	iPhone 6s (64GB)SIM Free	24	SP Bid-No Power On-Change Battery(Reference Only)	2803
Apple	iPhone 6s (128GB) (SIM FreeProblematic)	2	Part 2 AHandset	2804
Apple	iPhone 6s (16GB) (SIM FreeProblematic)	25	Part 2 AHandset	2805
Apple	iPhone 6s (32GB) (SIM FreeProblematic)	37	Part 2 AHandset	2806
Apple	iPhone 6s (64GB) (SIM FreeProblematic)	15	Part 2 AHandset	2807
Apple	iPhone 6s (128GB) (SIM FreeProblematic)	4	Part 2 BHandset (Power Up, Good LCD)	2808
Apple	iPhone 6s (16GB) (SIM FreeProblematic)	5	Part 2 BHandset (Power Up, Good LCD)	2809
Apple	iPhone 6s (32GB) (SIM FreeProblematic)	12	Part 2 BHandset (Power Up, Good LCD)	2810
Apple	iPhone 6s (64GB) (SIM FreeProblematic)	3	Part 2 BHandset (Power Up, Good LCD)	2811
Apple	iPhone 6s (16GB) (Unlocked, Bad Fingerprint Sensor)	7	Part 2 AHandset	2812
Apple	iPhone 6s (32GB) (Unlocked, Bad Fingerprint Sensor)	9	Part 2 AHandset	2813
Apple	iPhone 6s (64GB) (Unlocked, Bad Fingerprint Sensor)	2	Part 2 AHandset	2814
Apple	iPhone 6s (16GB) (Unlocked, Bad Fingerprint Sensor)	5	Part 2 BHandset (Power Up, Good LCD)	2815
Apple	iPhone 6s (32GB) (Unlocked, Bad Fingerprint Sensor)	7	Part 2 BHandset (Power Up, Good LCD)	2816
Apple	iPhone 6s (64GB) (Unlocked, Bad Fingerprint Sensor)	5	Part 2 BHandset (Power Up, Good LCD)	2817
Apple	iPhone 6s (16GB)	17	Part 2 AHandset	2818
Apple	iPhone 6s (32GB)	2	Part 2 AHandset	2819
Apple	iPhone 6s (128GB)	2	Part 2 BHandset (Power Up, Good LCD)	2820
Apple	iPhone 6s (16GB)	24	Part 2 BHandset (Power Up, Good LCD)	2821
Apple	iPhone 6s (32GB)	26	Part 2 BHandset (Power Up, Good LCD)	2822
Apple	iPhone 6s (64GB)	18	Part 2 BHandset (Power Up, Good LCD)	2823
Apple	iPhone 6s (128GB)	4	Part 2 BHandset (Power Up, Bad LCD)	2824
Apple	iPhone 6s (16GB)	17	Part 2 BHandset (Power Up, Bad LCD)	2825
Apple	iPhone 6s (32GB)	24	Part 2 BHandset (Power Up, Bad LCD)	2826
Apple	iPhone 6s (64GB)	12	Part 2 BHandset (Power Up, Bad LCD)	2827
Apple	iPhone 6s (128GB)	1	Part 2 SP Bid-No Power On-Change Battery(Reference Only)	2828
Apple	iPhone 6s (16GB)	13	Part 2 SP Bid-No Power On-Change Battery(Reference Only)	2829
Apple	iPhone 6s (32GB)	25	Part 2 SP Bid-No Power On-Change Battery(Reference Only)	2830
Apple	iPhone 6s (64GB)	1	Part 2 SP Bid-No Power On-Change Battery(Reference Only)	2831
Apple	iPhone 6s (16GB)	76	Mainboard	2832
Apple	iPhone 6s (128GB) (Problematic)	1	Part 2 AHandset	2833
Apple	iPhone 6s (16GB) (Problematic)	32	Part 2 AHandset	2834
Apple	iPhone 6s (32GB) (Problematic)	36	Part 2 AHandset	2835
Apple	iPhone 6s (64GB) (Problematic)	6	Part 2 AHandset	2836

Apple	iPhone 6s (128GB) (Problematic)	1	Part 2 BHandset (Power Up, Good LCD)	2837
Apple	iPhone 6s (32GB) (Problematic)	3	Part 2 BHandset (Power Up, Good LCD)	2838
Apple	iPhone 6s (64GB) (Problematic)	5	Part 2 BHandset (Power Up, Good LCD)	2839
Apple	iPhone 6 Plus Total	697	Summary	2840
Apple	iPhone 6 Plus (128GB)SIM Free	1	AHandset	2841
Apple	iPhone 6 Plus (16GB)SIM Free	2	AHandset	2842
Apple	iPhone 6 Plus (64GB)SIM Free	1	AHandset	2843
Apple	iPhone 6 Plus (16GB)SIM Free	43	BHandset (Power Up, Good LCD)(Full Fuction)	2844
Apple	iPhone 6 Plus (128GB)SIM Free	2	BHandset (Power Up, Good LCD)	2845
Apple	iPhone 6 Plus (16GB)SIM Free	28	BHandset (Power Up, Good LCD)	2846
Apple	iPhone 6 Plus (64GB)SIM Free	9	BHandset (Power Up, Good LCD)	2847
Apple	iPhone 6 Plus (128GB)SIM Free	3	BHandset (Power Up, Bad LCD)	2848
Apple	iPhone 6 Plus (16GB)SIM Free	121	BHandset (Power Up, Bad LCD)	2849
Apple	iPhone 6 Plus (64GB)SIM Free	9	BHandset (Power Up, Bad LCD)	2850
Apple	iPhone 6 Plus (128GB)SIM Free	7	SP Bid-No Power On-Change Battery(Reference Only)	2851
Apple	iPhone 6 Plus (16GB)SIM Free	62	SP Bid-No Power On-Change Battery(Reference Only)	2852
Apple	iPhone 6 Plus (64GB)SIM Free	28	SP Bid-No Power On-Change Battery(Reference Only)	2853
Apple	iPhone 6 Plus (128GB) (SIM FreeProblematic)	12	Part 2 AHandset	2854
Apple	iPhone 6 Plus (16GB) (SIM FreeProblematic)	69	Part 2 AHandset	2855
Apple	iPhone 6 Plus (64GB) (SIM FreeProblematic)	29	Part 2 AHandset	2856
Apple	iPhone 6 Plus (128GB) (SIM FreeProblematic)	3	Part 2 BHandset (Power Up, Good LCD)	2857
Apple	iPhone 6 Plus (16GB) (SIM FreeProblematic)	25	Part 2 BHandset (Power Up, Good LCD)	2858
Apple	iPhone 6 Plus (64GB) (SIM FreeProblematic)	14	Part 2 BHandset (Power Up, Good LCD)	2859
Apple	iPhone 6 Plus (16GB) (Unlocked, Bad Fingerprint Sensor)	2	Part 2 AHandset	2860
Apple	iPhone 6 Plus (128GB) (Unlocked, Bad Fingerprint Sensor)	2	Part 2 BHandset (Power Up, Good LCD)	2861
Apple	iPhone 6 Plus (16GB) (Unlocked, Bad Fingerprint Sensor)	7	Part 2 BHandset (Power Up, Good LCD)	2862
Apple	iPhone 6 Plus (64GB) (Unlocked, Bad Fingerprint Sensor)	2	Part 2 BHandset (Power Up, Good LCD)	2863
Apple	iPhone 6 Plus (128GB)	7	Part 2 AHandset	2864
Apple	iPhone 6 Plus (16GB)	18	Part 2 AHandset	2865
Apple	iPhone 6 Plus (64GB)	4	Part 2 AHandset	2866
Apple	iPhone 6 Plus (128GB)	2	Part 2 BHandset (Power Up, Good LCD)	2867
Apple	iPhone 6 Plus (16GB)	4	Part 2 BHandset (Power Up, Good LCD)	2868
Apple	iPhone 6 Plus (64GB)	3	Part 2 BHandset (Power Up, Good LCD)	2869
Apple	iPhone 6 Plus (128GB)	4	Part 2 BHandset (Power Up, Bad LCD)	2870
Apple	iPhone 6 Plus (16GB)	86	Part 2 BHandset (Power Up, Bad LCD)	2871
Apple	iPhone 6 Plus (64GB)	14	Part 2 BHandset (Power Up, Bad LCD)	2872
Apple	iPhone 6 Plus (16GB)	21	Part 2 SP Bid-No Power On-Change Battery(Reference Only)	2873
Apple	iPhone 6 Plus (64GB)	2	Part 2 SP Bid-No Power On-Change Battery(Reference Only)	2874
Apple	iPhone 6 Plus (16GB)	28	Mainboard	2875
Apple	iPhone 6 Plus (128GB) (Problematic)	2	Part 2 AHandset	2876
Apple	iPhone 6 Plus (16GB) (Problematic)	5	Part 2 AHandset	2877
Apple	iPhone 6 Plus (64GB) (Problematic)	2	Part 2 AHandset	2878
Apple	iPhone 6 Plus (128GB) (Problematic)	2	Part 2 BHandset (Power Up, Good LCD)	2879
Apple	iPhone 6 Plus (16GB) (Problematic)	10	Part 2 BHandset (Power Up, Good LCD)	2880
Apple	iPhone 6 Plus (64GB) (Problematic)	2	Part 2 BHandset (Power Up, Good LCD)	2881
Apple	iPhone 6 Total	3858	Summary	2882
Apple	iPhone 6 (16GB)SIM Free	1	Nearly New(Full Fuction)	2883
Apple	iPhone 6 (128GB)SIM Free	2	AHandset	2884
Apple	iPhone 6 (16GB)SIM Free	404	AHandset	2885
Apple	iPhone 6 (32GB)SIM Free	25	AHandset	2886
Apple	iPhone 6 (64GB)SIM Free	9	AHandset	2887
Apple	iPhone 6 (128GB)SIM Free	10	BHandset (Power Up, Good LCD)(Full Fuction)	2888
Apple	iPhone 6 (16GB)SIM Free	184	BHandset (Power Up, Good LCD)(Full Fuction)	2889
Apple	iPhone 6 (32GB)SIM Free	38	BHandset (Power Up, Good LCD)(Full Fuction)	2890
Apple	iPhone 6 (64GB)SIM Free	53	BHandset (Power Up, Good LCD)(Full Fuction)	2891
Apple	iPhone 6 (128GB)SIM Free	9	BHandset (Power Up, Good LCD)	2892
Apple	iPhone 6 (16GB)SIM Free	209	BHandset (Power Up, Good LCD)	2893
Apple	iPhone 6 (32GB)SIM Free	68	BHandset (Power Up, Good LCD)	2894
Apple	iPhone 6 (64GB)SIM Free	161	BHandset (Power Up, Good LCD)	2895
Apple	iPhone 6 (128GB)SIM Free	17	BHandset (Power Up, Bad LCD)	2896
Apple	iPhone 6 (16GB)SIM Free	37	BHandset (Power Up, Bad LCD)	2897
Apple	iPhone 6 (32GB)SIM Free	89	BHandset (Power Up, Bad LCD)	2898
Apple	iPhone 6 (64GB)SIM Free	9	BHandset (Power Up, Bad LCD)	2899
Apple	iPhone 6 (128GB)SIM Free	24	SP Bid-No Power On-Change Battery(Reference Only)	2900
Apple	iPhone 6 (16GB)SIM Free	319	SP Bid-No Power On-Change Battery(Reference Only)	2901
Apple	iPhone 6 (32GB)SIM Free	76	SP Bid-No Power On-Change Battery(Reference Only)	2902
Apple	iPhone 6 (64GB)SIM Free	319	SP Bid-No Power On-Change Battery(Reference Only)	2903
Apple	iPhone 6 (128GB) (SIM FreeProblematic)	36	Part 2 AHandset	2904
Apple	iPhone 6 (16GB) (SIM FreeProblematic)	299	Part 2 AHandset	2905
Apple	iPhone 6 (32GB) (SIM FreeProblematic)	84	Part 2 AHandset	2906
Apple	iPhone 6 (64GB) (SIM FreeProblematic)	210	Part 2 AHandset	2907
Apple	iPhone 6 (128GB) (SIM FreeProblematic)	10	Part 2 BHandset (Power Up, Good LCD)	2908
Apple	iPhone 6 (16GB) (SIM FreeProblematic)	130	Part 2 BHandset (Power Up, Good LCD)	2909
Apple	iPhone 6 (32GB) (SIM FreeProblematic)	33	Part 2 BHandset (Power Up, Good LCD)	2910
Apple	iPhone 6 (64GB) (SIM FreeProblematic)	79	Part 2 BHandset (Power Up, Good LCD)	2911
Apple	iPhone 6 (16GB) (SIM FreeProblematic)	1	Part 2 BHandset (Power Up, Bad LCD)	2912
Apple	iPhone 6 (128GB) (Unlocked, Bad Fingerprint Sensor)	15	Part 2 AHandset	2913
Apple	iPhone 6 (16GB) (Unlocked, Bad Fingerprint Sensor)	8	Part 2 AHandset	2914
Apple	iPhone 6 (32GB) (Unlocked, Bad Fingerprint Sensor)	29	Part 2 AHandset	2915
Apple	iPhone 6 (64GB) (Unlocked, Bad Fingerprint Sensor)	12	Part 2 AHandset	2916
Apple	iPhone 6 (128GB) (Unlocked, Bad Fingerprint Sensor)	4	Part 2 BHandset (Power Up, Good LCD)	2917
Apple	iPhone 6 (16GB) (Unlocked, Bad Fingerprint Sensor)	59	Part 2 BHandset (Power Up, Good LCD)	2918
Apple	iPhone 6 (32GB) (Unlocked, Bad Fingerprint Sensor)	20	Part 2 BHandset (Power Up, Good LCD)	2919
Apple	iPhone 6 (64GB) (Unlocked, Bad Fingerprint Sensor)	57	Part 2 BHandset (Power Up, Good LCD)	2920
Apple	iPhone 6 (128GB)	2	Part 2 AHandset	2921
Apple	iPhone 6 (16GB)	82	Part 2 AHandset	2922

Apple	iPhone 6 (32GB)	38	Part 2 AHandset	2923
Apple	iPhone 6 (64GB)	35	Part 2 AHandset	2924
Apple	iPhone 6 (16GB)	60	Part 2 BHandset (Power Up, Good LCD)	2925
Apple	iPhone 6 (32GB)	4	Part 2 BHandset (Power Up, Good LCD)	2926
Apple	iPhone 6 (64GB)	29	Part 2 BHandset (Power Up, Good LCD)	2927
Apple	iPhone 6 (128GB)	4	Part 2 BHandset (Power Up, Bad LCD)	2928
Apple	iPhone 6 (16GB)	82	Part 2 BHandset (Power Up, Bad LCD)	2929
Apple	iPhone 6 (32GB)	14	Part 2 BHandset (Power Up, Bad LCD)	2930
Apple	iPhone 6 (64GB)	69	Part 2 BHandset (Power Up, Bad LCD)	2931
Apple	iPhone 6 (128GB)	1	Part 2 SP Bid-No Power On-Change Battery(Reference Only)	2932
Apple	iPhone 6 (16GB)	42	Part 2 SP Bid-No Power On-Change Battery(Reference Only)	2933
Apple	iPhone 6 (32GB)	6	Part 2 SP Bid-No Power On-Change Battery(Reference Only)	2934
Apple	iPhone 6 (64GB)	8	Part 2 SP Bid-No Power On-Change Battery(Reference Only)	2935
Apple	iPhone 6 (16GB)	122	Mainboard	2936
Apple	iPhone 6 (128GB) (Problematic)	2	Part 2 AHandset	2937
Apple	iPhone 6 (16GB) (Problematic)	29	Part 2 AHandset	2938
Apple	iPhone 6 (32GB) (Problematic)	6	Part 2 AHandset	2939
Apple	iPhone 6 (64GB) (Problematic)	15	Part 2 AHandset	2940
Apple	iPhone 6 (16GB) (Problematic)	28	Part 2 BHandset (Power Up, Good LCD)	2941
Apple	iPhone 6 (32GB) (Problematic)	23	Part 2 BHandset (Power Up, Good LCD)	2942
Apple	iPhone 6 (64GB) (Problematic)	8	Part 2 BHandset (Power Up, Good LCD)	2943
Apple	iPhone Se3 Total	232	Summary	2944
Apple	iPhone Se3 (64GB)SIM Free	1	Non-Active-AHandset (Good)	2945
Apple	iPhone Se3 (128GB)SIM Free	3	AHandset (Good 1)(Full Fuction)	2946
Apple	iPhone Se3 (64GB)SIM Free	1	AHandset (Good 1)(Full Fuction)	2947
Apple	iPhone Se3 (64GB)SIM Free	5	AHandset (Good 1)(Broken Back Glass)(Full Fuction)	2948
Apple	iPhone Se3 (128GB)SIM Free	2	AHandset (Full Fuction)	2949
Apple	iPhone Se3 (64GB)SIM Free	17	AHandset (Full Fuction)	2950
Apple	iPhone Se3 (64GB)SIM Free	13	AHandset (Broken Back Glass)(Full Fuction)	2951
Apple	iPhone Se3 (128GB)SIM Free	1	AHandset	2952
Apple	iPhone Se3 (64GB)SIM Free	5	AHandset	2953
Apple	iPhone Se3 (128GB)SIM Free	1	AHandset (Broken Back Glass)	2954
Apple	iPhone Se3 (64GB)SIM Free	1	AHandset (Broken Back Glass)	2955
Apple	iPhone Se3 (128GB)SIM Free	6	BHandset (Power Up, Good LCD)(Full Fuction)	2956
Apple	iPhone Se3 (256GB)SIM Free	1	BHandset (Power Up, Good LCD)(Full Fuction)	2957
Apple	iPhone Se3 (64GB)SIM Free	32	BHandset (Power Up, Good LCD)(Full Fuction)	2958
Apple	iPhone Se3 (64GB)SIM Free	5	BHandset (Power Up, Good LCD)	2959
Apple	iPhone Se3 (128GB)SIM Free	6	BHandset (Power Up, Bad LCD)	2960
Apple	iPhone Se3 (256GB)SIM Free	2	BHandset (Power Up, Bad LCD)	2961
Apple	iPhone Se3 (64GB)SIM Free	32	BHandset (Power Up, Bad LCD)	2962
Apple	iPhone Se3 (64GB)SIM Free	4	BHandset (only electricity)	2963
Apple	iPhone Se3 (128GB)SIM Free	14	SP Bid-No Power On-Change Battery(Reference Only)	2964
Apple	iPhone Se3 (256GB)SIM Free	4	SP Bid-No Power On-Change Battery(Reference Only)	2965
Apple	iPhone Se3 (64GB)SIM Free	55	SP Bid-No Power On-Change Battery(Reference Only)	2966
Apple	iPhone Se3 (128GB) (SIM FreeProblematic)	2	Part 2 AHandset	2967
Apple	iPhone Se3 (64GB) (SIM FreeProblematic)	9	Part 2 AHandset	2968
Apple	iPhone Se3 (64GB) (SIM FreeProblematic)	4	Part 2 BHandset (Power Up, Good LCD)	2969
Apple	iPhone Se3 (64GB) (SIM FreeProblematic)	1	Part 2 BHandset (Power Up, Bad LCD)	2970
Apple	iPhone Se3 (256GB) (Unlocked, Bad Fingerprint Sensor)	1	Part 2 AHandset	2971
Apple	iPhone Se3 (64GB) (Unlocked, Bad Fingerprint Sensor)	1	Part 2 AHandset	2972
Apple	iPhone Se3 (64GB) (Unlocked, Bad Fingerprint Sensor)	1	Part 2 BHandset (Power Up, Good LCD)	2973
Apple	iPhone Se3 (128GB)	1	Part 2 BHandset (Power Up, Bad LCD)	2974
Apple	iPhone Se3 (64GB) (Problematic)	1	Part 2 BHandset (Power Up, Good LCD)	2975
Apple	iPhone Se2 Total	117	Summary	2976
Apple	iPhone Se2 (64GB)SIM Free	2	AHandset (Full Fuction)	2977
Apple	iPhone Se2 (128GB)SIM Free	1	AHandset (Broken Back Glass)(Full Fuction)	2978
Apple	iPhone Se2 (256GB)SIM Free	1	AHandset (Broken Back Glass)	2979
Apple	iPhone Se2 (64GB)SIM Free	1	AHandset (Broken Back Glass)	2980
Apple	iPhone Se2 (128GB)SIM Free	1	BHandset (Power Up, Good LCD)(Full Fuction)	2981
Apple	iPhone Se2 (256GB)SIM Free	2	BHandset (Power Up, Good LCD)(Full Fuction)	2982
Apple	iPhone Se2 (64GB)SIM Free	3	BHandset (Power Up, Good LCD)(Full Fuction)	2983
Apple	iPhone Se2 (64GB)SIM Free	3	BHandset (Power Up, Good LCD)	2984
Apple	iPhone Se2 (64GB)SIM Free	8	BHandset (Power Up, Bad LCD)	2985
Apple	iPhone Se2 (128GB)SIM Free	8	SP Bid-No Power On-Change Battery(Reference Only)	2986
Apple	iPhone Se2 (256GB)SIM Free	1	SP Bid-No Power On-Change Battery(Reference Only)	2987
Apple	iPhone Se2 (64GB)SIM Free	54	SP Bid-No Power On-Change Battery(Reference Only)	2988
Apple	iPhone Se2 (128GB) (SIM FreeProblematic)	3	Part 2 AHandset	2989
Apple	iPhone Se2 (64GB) (SIM FreeProblematic)	2	Part 2 AHandset	2990
Apple	iPhone Se2 (64GB) (SIM FreeProblematic)	1	Part 2 BHandset (Power Up, Good LCD)	2991
Apple	iPhone Se2 (64GB) (Unlocked, Bad Fingerprint Sensor)	1	Part 2 AHandset	2992
Apple	iPhone Se2 (64GB)	2	Part 2 AHandset	2993
Apple	iPhone Se2 (128GB)	1	Part 2 BHandset (Power Up, Bad LCD)	2994
Apple	iPhone Se2 (256GB)	1	Part 2 BHandset (Power Up, Bad LCD)	2995
Apple	iPhone Se2 (64GB)	3	Part 2 BHandset (Power Up, Bad LCD)	2996
Apple	iPhone Se2 (64GB)	4	Part 2 SP Bid-No Power On-Change Battery(Reference Only)	2997
Apple	iPhone Se2 (64GB)	13	Mainboard	2998
Apple	iPhone Se2 (64GB) (Problematic)	1	Part 2 BHandset (Power Up, Good LCD)	2999
Apple	iPhone SE Total	84	Summary	3000
Apple	iPhone SE (128GB)SIM Free	1	AHandset	3001
Apple	iPhone SE (16GB)SIM Free	7	AHandset	3002
Apple	iPhone SE (32GB)SIM Free	16	AHandset	3003
Apple	iPhone SE (64GB)SIM Free	4	AHandset	3004
Apple	iPhone SE (16GB)SIM Free	1	BHandset (Power Up, Good LCD)	3005
Apple	iPhone SE (32GB)SIM Free	1	BHandset (Power Up, Good LCD)	3006
Apple	iPhone SE (64GB)SIM Free	3	BHandset (Power Up, Good LCD)	3007
Apple	iPhone SE (16GB)SIM Free	3	BHandset (Power Up, Bad LCD)	3008

Apple	iPhone SE (32GB)SIM Free	4	BHandset (Power Up, Bad LCD)	3009
Apple	iPhone SE (64GB)SIM Free	9	BHandset (Power Up, Bad LCD)	3010
Apple	iPhone SE (16GB)SIM Free	1	SP Bid-No Power On-Change Battery(Reference Only)	3011
Apple	iPhone SE (32GB)SIM Free	4	SP Bid-No Power On-Change Battery(Reference Only)	3012
Apple	iPhone SE (32GB) (SIM FreeProblematic)	1	Part 2 AHandset	3013
Apple	iPhone SE (16GB) (Unlocked, Bad Fingerprint Sensor)	1	Part 2 BHandset (Power Up, Good LCD)	3014
Apple	iPhone SE (32GB) (Unlocked, Bad Fingerprint Sensor)	1	Part 2 BHandset (Power Up, Good LCD)	3015
Apple	iPhone SE (64GB) (Unlocked, Bad Fingerprint Sensor)	1	Part 2 BHandset (Power Up, Good LCD)	3016
Apple	iPhone SE (16GB)	4	Part 2 AHandset	3017
Apple	iPhone SE (32GB)	16	Part 2 AHandset	3018
Apple	iPhone SE (64GB)	3	Part 2 AHandset	3019
Apple	iPhone SE (128GB)	1	Part 2 BHandset (Power Up, Bad LCD)	3020
Apple	iPhone SE (16GB)	2	Part 2 BHandset (Power Up, Bad LCD)	3021
Apple	iPhone 5s Total	2996	Summary	3022
Apple	iPhone 5s (16GB)SIM Free	7	AHandset	3023
Apple	iPhone 5s (32GB)SIM Free	11	AHandset	3024
Apple	iPhone 5s (16GB)SIM Free	7	BHandset (Power Up, Good LCD)	3025
Apple	iPhone 5s (16GB)SIM Free	1284	BHandset (Power Up, Bad LCD)	3026
Apple	iPhone 5s (32GB)SIM Free	174	BHandset (Power Up, Bad LCD)	3027
Apple	iPhone 5s (64GB)SIM Free	35	BHandset (Power Up, Bad LCD)	3028
Apple	iPhone 5s (16GB)SIM Free	277	SP Bid-No Power On-Change Battery(Reference Only)	3029
Apple	iPhone 5s (32GB)SIM Free	29	SP Bid-No Power On-Change Battery(Reference Only)	3030
Apple	iPhone 5s (64GB)SIM Free	10	SP Bid-No Power On-Change Battery(Reference Only)	3031
Apple	iPhone 5s (16GB) (SIM FreeProblematic)	20	Part 2 AHandset	3032
Apple	iPhone 5s (32GB) (SIM FreeProblematic)	35	Part 2 AHandset	3033
Apple	iPhone 5s (64GB) (SIM FreeProblematic)	11	Part 2 AHandset	3034
Apple	iPhone 5s (16GB) (SIM FreeProblematic)	53	Part 2 BHandset (Power Up, Good LCD)	3035
Apple	iPhone 5s (32GB) (SIM FreeProblematic)	9	Part 2 BHandset (Power Up, Good LCD)	3036
Apple	iPhone 5s (64GB) (SIM FreeProblematic)	2	Part 2 BHandset (Power Up, Good LCD)	3037
Apple	iPhone 5s (16GB) (Unlocked, Bad Fingerprint Sensor)	8	Part 2 AHandset	3038
Apple	iPhone 5s (32GB) (Unlocked, Bad Fingerprint Sensor)	3	Part 2 AHandset	3039
Apple	iPhone 5s (16GB) (Unlocked, Bad Fingerprint Sensor)	36	Part 2 BHandset (Power Up, Good LCD)	3040
Apple	iPhone 5s (32GB) (Unlocked, Bad Fingerprint Sensor)	7	Part 2 BHandset (Power Up, Good LCD)	3041
Apple	iPhone 5s (64GB) (Unlocked, Bad Fingerprint Sensor)	1	Part 2 BHandset (Power Up, Good LCD)	3042
Apple	iPhone 5s (16GB)	470	Part 2 AHandset	3043
Apple	iPhone 5s (32GB)	7	Part 2 AHandset	3044
Apple	iPhone 5s (64GB)	2	Part 2 AHandset	3045
Apple	iPhone 5s (16GB)	31	Part 2 BHandset (Power Up, Good LCD)	3046
Apple	iPhone 5s (32GB)	1	Part 2 BHandset (Power Up, Good LCD)	3047
Apple	iPhone 5s (16GB)	271	Part 2 BHandset (Power Up, Bad LCD)	3048
Apple	iPhone 5s (32GB)	22	Part 2 BHandset (Power Up, Bad LCD)	3049
Apple	iPhone 5s (64GB)	4	Part 2 BHandset (Power Up, Bad LCD)	3050
Apple	iPhone 5s (16GB)	60	Part 2 SP Bid-No Power On-Change Battery(Reference Only)	3051
Apple	iPhone 5s (32GB)	3	Part 2 SP Bid-No Power On-Change Battery(Reference Only)	3052
Apple	iPhone 5s (64GB)	3	Part 2 SP Bid-No Power On-Change Battery(Reference Only)	3053
Apple	iPhone 5s (16GB)	90	Mainboard	3054
Apple	iPhone 5s (16GB) (Problematic)	12	Part 2 BHandset (Power Up, Good LCD)	3055
Apple	iPhone 5s (32GB) (Problematic)	1	Part 2 BHandset (Power Up, Good LCD)	3056
Apple	iPhone 5c Total	1582	Summary	3057
Apple	iPhone 5c (16GB)SIM Free	48	AHandset	3058
Apple	iPhone 5c (32GB)SIM Free	6	AHandset	3059
Apple	iPhone 5c (8GB)SIM Free	67	AHandset	3060
Apple	iPhone 5c (8GB)SIM Free	2	Part 2 AHandset	3061
Apple	iPhone 5c (16GB)SIM Free	79	BHandset (Power Up, Good LCD)	3062
Apple	iPhone 5c (32GB)SIM Free	2	BHandset (Power Up, Good LCD)	3063
Apple	iPhone 5c (8GB)SIM Free	153	BHandset (Power Up, Good LCD)	3064
Apple	iPhone 5c (16GB)SIM Free	145	BHandset (Power Up, Bad LCD)	3065
Apple	iPhone 5c (32GB)SIM Free	39	BHandset (Power Up, Bad LCD)	3066
Apple	iPhone 5c (8GB)SIM Free	178	BHandset (Power Up, Bad LCD)	3067
Apple	iPhone 5c (16GB)SIM Free	34	SP Bid-No Power On-Change Battery(Reference Only)	3068
Apple	iPhone 5c (32GB)SIM Free	6	SP Bid-No Power On-Change Battery(Reference Only)	3069
Apple	iPhone 5c (8GB)SIM Free	35	SP Bid-No Power On-Change Battery(Reference Only)	3070
Apple	iPhone 5c (16GB) (SIM FreeProblematic)	56	Part 2 AHandset	3071
Apple	iPhone 5c (32GB) (SIM FreeProblematic)	17	Part 2 AHandset	3072
Apple	iPhone 5c (8GB) (SIM FreeProblematic)	56	Part 2 AHandset	3073
Apple	iPhone 5c (16GB) (SIM FreeProblematic)	15	Part 2 BHandset (Power Up, Good LCD)	3074
Apple	iPhone 5c (32GB) (SIM FreeProblematic)	2	Part 2 BHandset (Power Up, Good LCD)	3075
Apple	iPhone 5c (8GB) (SIM FreeProblematic)	2	Part 2 BHandset (Power Up, Good LCD)	3076
Apple	iPhone 5c (16GB)	151	Part 2 AHandset	3077
Apple	iPhone 5c (32GB)	12	Part 2 AHandset	3078
Apple	iPhone 5c (8GB)	147	Part 2 AHandset	3079
Apple	iPhone 5c (16GB)	28	Part 2 BHandset (Power Up, Good LCD)	3080
Apple	iPhone 5c (32GB)	10	Part 2 BHandset (Power Up, Good LCD)	3081
Apple	iPhone 5c (8GB)	50	Part 2 BHandset (Power Up, Good LCD)	3082
Apple	iPhone 5c (16GB)	67	Part 2 BHandset (Power Up, Bad LCD)	3083
Apple	iPhone 5c (32GB)	10	Part 2 BHandset (Power Up, Bad LCD)	3084
Apple	iPhone 5c (8GB)	70	Part 2 BHandset (Power Up, Bad LCD)	3085
Apple	iPhone 5c (16GB)	14	Part 2 SP Bid-No Power On-Change Battery(Reference Only)	3086
Apple	iPhone 5c (32GB)	1	Part 2 SP Bid-No Power On-Change Battery(Reference Only)	3087
Apple	iPhone 5c (8GB)	12	Part 2 SP Bid-No Power On-Change Battery(Reference Only)	3088
Apple	iPhone 5c (16GB)	1	Mainboard	3089
Apple	iPhone 5c (8GB)	27	Mainboard	3090
Apple	iPhone 5c (16GB) (Problematic)	17	Part 2 AHandset	3091
Apple	iPhone 5c (32GB) (Problematic)	2	Part 2 AHandset	3092
Apple	iPhone 5c (8GB) (Problematic)	11	Part 2 AHandset	3093
Apple	iPhone 5c (16GB) (Problematic)	3	Part 2 BHandset (Power Up, Good LCD)	3094

Apple	iPhone 5c (8GB) (Problematic)	7	Part 2 BHandset (Power Up, Good LCD)	3095
Apple	iPhone 5 Total	1407	Summary	3096
Apple	iPhone 5 (16GB)SIM Free	107	AHandset	3097
Apple	iPhone 5 (32GB)SIM Free	32	AHandset	3098
Apple	iPhone 5 (64GB)SIM Free	15	AHandset	3099
Apple	iPhone 5 (16GB)SIM Free	1	Part 2 AHandset	3100
Apple	iPhone 5 (16GB)SIM Free	21	BHandset (Power Up, Good LCD)	3101
Apple	iPhone 5 (32GB)SIM Free	3	BHandset (Power Up, Good LCD)	3102
Apple	iPhone 5 (64GB)SIM Free	5	BHandset (Power Up, Good LCD)	3103
Apple	iPhone 5 (16GB)SIM Free	152	BHandset (Power Up, Bad LCD)	3104
Apple	iPhone 5 (32GB)SIM Free	18	BHandset (Power Up, Bad LCD)	3105
Apple	iPhone 5 (64GB)SIM Free	2	BHandset (Power Up, Bad LCD)	3106
Apple	iPhone 5 (16GB)SIM Free	47	SP Bid-No Power On-Change Battery(Reference Only)	3107
Apple	iPhone 5 (32GB)SIM Free	5	SP Bid-No Power On-Change Battery(Reference Only)	3108
Apple	iPhone 5 (64GB)SIM Free	5	SP Bid-No Power On-Change Battery(Reference Only)	3109
Apple	iPhone 5 (16GB) (SIM FreeProblematic)	79	Part 2 AHandset	3110
Apple	iPhone 5 (32GB) (SIM FreeProblematic)	19	Part 2 AHandset	3111
Apple	iPhone 5 (64GB) (SIM FreeProblematic)	3	Part 2 AHandset	3112
Apple	iPhone 5 (16GB) (SIM FreeProblematic)	25	Part 2 BHandset (Power Up, Good LCD)	3113
Apple	iPhone 5 (32GB) (SIM FreeProblematic)	2	Part 2 BHandset (Power Up, Good LCD)	3114
Apple	iPhone 5 (64GB) (SIM FreeProblematic)	5	Part 2 BHandset (Power Up, Good LCD)	3115
Apple	iPhone 5 (16GB)	426	Part 2 AHandset	3116
Apple	iPhone 5 (32GB)	48	Part 2 AHandset	3117
Apple	iPhone 5 (64GB)	28	Part 2 AHandset	3118
Apple	iPhone 5 (16GB)	98	Part 2 BHandset (Power Up, Good LCD)	3119
Apple	iPhone 5 (32GB)	5	Part 2 BHandset (Power Up, Good LCD)	3120
Apple	iPhone 5 (64GB)	4	Part 2 BHandset (Power Up, Good LCD)	3121
Apple	iPhone 5 (16GB)	82	Part 2 BHandset (Power Up, Bad LCD)	3122
Apple	iPhone 5 (32GB)	16	Part 2 BHandset (Power Up, Bad LCD)	3123
Apple	iPhone 5 (64GB)	6	Part 2 BHandset (Power Up, Bad LCD)	3124
Apple	iPhone 5 (16GB)	33	Part 2 SP Bid-No Power On-Change Battery(Reference Only)	3125
Apple	iPhone 5 (32GB)	3	Part 2 SP Bid-No Power On-Change Battery(Reference Only)	3126
Apple	iPhone 5 (64GB)	1	Part 2 SP Bid-No Power On-Change Battery(Reference Only)	3127
Apple	iPhone 5 (16GB)	28	Mainboard	3128
Apple	iPhone 5 (16GB) (Problematic)	59	Part 2 AHandset	3129
Apple	iPhone 5 (32GB) (Problematic)	2	Part 2 AHandset	3130
Apple	iPhone 5 (64GB) (Problematic)	2	Part 2 AHandset	3131
Apple	iPhone 5 (16GB) (Problematic)	18	Part 2 BHandset (Power Up, Good LCD)	3132
Apple	iPhone 5 (32GB) (Problematic)	2	Part 2 BHandset (Power Up, Good LCD)	3133
Apple	iPhone 4s Total	276	Summary	3134
Apple	iPhone 4s (16GB)SIM Free	7	AHandset	3135
Apple	iPhone 4s (8GB)SIM Free	1	AHandset	3136
Apple	iPhone 4s (16GB)SIM Free	1	BHandset (Power Up, Bad LCD)	3137
Apple	iPhone 4s (16GB)SIM Free	1	SP Bid-No Power On-Change Battery(Reference Only)	3138
Apple	iPhone 4s (32GB)SIM Free	1	SP Bid-No Power On-Change Battery(Reference Only)	3139
Apple	iPhone 4s (16GB)	13	Part 2 AHandset	3140
Apple	iPhone 4s (32GB)	4	Part 2 AHandset	3141
Apple	iPhone 4s (8GB)	10	Part 2 AHandset	3142
Apple	iPhone 4s (16GB)	65	Part 2 BHandset (Power Up, Good LCD)	3143
Apple	iPhone 4s (32GB)	7	Part 2 BHandset (Power Up, Good LCD)	3144
Apple	iPhone 4s (8GB)	14	Part 2 BHandset (Power Up, Good LCD)	3145
Apple	iPhone 4s (16GB)	62	Part 2 BHandset (Power Up, Bad LCD)	3146
Apple	iPhone 4s (32GB)	5	Part 2 BHandset (Power Up, Bad LCD)	3147
Apple	iPhone 4s (64GB)	1	Part 2 BHandset (Power Up, Bad LCD)	3148
Apple	iPhone 4s (8GB)	28	Part 2 BHandset (Power Up, Bad LCD)	3149
Apple	iPhone 4s (16GB)	6	Part 2 SP Bid-No Power On-Change Battery(Reference Only)	3150
Apple	iPhone 4s (32GB)	1	Part 2 SP Bid-No Power On-Change Battery(Reference Only)	3151
Apple	iPhone 4s (8GB)	11	Part 2 SP Bid-No Power On-Change Battery(Reference Only)	3152
Apple	iPhone 4s (8GB)	28	Mainboard	3153
Apple	iPhone 4s (8GB) (Problematic)	3	Part 2 AHandset	3154
Apple	iPhone 4s (16GB) (Problematic)	5	Part 2 BHandset (Power Up, Good LCD)	3155
Apple	iPhone 4s (8GB) (Problematic)	2	Part 2 BHandset (Power Up, Good LCD)	3156
Apple	iPhone 4 Total	266	Summary	3157
Apple	iPhone 4 (8GB) (SIM FreeProblematic)	1	Part 2 BHandset (Power Up, Good LCD)	3158
Apple	iPhone 4 (16GB)	5	Part 2 AHandset	3159
Apple	iPhone 4 (8GB)	20	Part 2 AHandset	3160
Apple	iPhone 4 (16GB)	33	Part 2 BHandset (Power Up, Good LCD)	3161
Apple	iPhone 4 (32GB)	6	Part 2 BHandset (Power Up, Good LCD)	3162
Apple	iPhone 4 (8GB)	50	Part 2 BHandset (Power Up, Good LCD)	3163
Apple	iPhone 4 (16GB)	18	Part 2 BHandset (Power Up, Bad LCD)	3164
Apple	iPhone 4 (32GB)	6	Part 2 BHandset (Power Up, Bad LCD)	3165
Apple	iPhone 4 (8GB)	42	Part 2 BHandset (Power Up, Bad LCD)	3166
Apple	iPhone 4 (16GB)	4	Part 2 SP Bid-No Power On-Change Battery(Reference Only)	3167
Apple	iPhone 4 (8GB)	24	Part 2 SP Bid-No Power On-Change Battery(Reference Only)	3168
Apple	iPhone 4 (16GB)	1	Mainboard	3169
Apple	iPhone 4 (8GB)	25	Mainboard	3170
Apple	iPhone 4 (16GB) (Problematic)	1	Part 2 AHandset	3171
Apple	iPhone 4 (8GB) (Problematic)	10	Part 2 AHandset	3172
Apple	iPhone 4 (16GB) (Problematic)	2	Part 2 BHandset (Power Up, Good LCD)	3173
Apple	iPhone 4 (8GB) (Problematic)	18	Part 2 BHandset (Power Up, Good LCD)	3174
Apple	iCloud Lock Total	14087	Summary	3175
Apple	iPhone 16 (128GB)iCloud Lock	1	Part 2 BHandset (Power Up, Bad LCD)	3176
Apple	iPhone 15 Pro Max (256GB)iCloud Lock	1	Part 2 AHandset	3177
Apple	iPhone 15 Pro Max (256GB)iCloud Lock	3	Part 2 BHandset (Power Up, Bad LCD)	3178
Apple	iPhone 15 Pro Max (256GB)iCloud Lock	4	Part 2 BHandset (only electricity)	3179
Apple	iPhone 15 Pro Max (512GB)iCloud Lock	2	Part 2 BHandset (only electricity)	3180

Apple	iPhone 15 Pro Max (256GB)iCloud Lock	1	Part 2 SP Bid-No Power On-Change Battery(Reference Only)	3181
Apple	iPhone 15 Pro (128GB)iCloud Lock	1	Part 2 AHandset	3182
Apple	iPhone 15 Pro (128GB)iCloud Lock	4	Part 2 BHandset (Power Up, Bad LCD)	3183
Apple	iPhone 15 Pro (256GB)iCloud Lock	1	Part 2 BHandset (Power Up, Bad LCD)	3184
Apple	iPhone 15 Pro (128GB)iCloud Lock	2	Part 2 BHandset (only electricity)	3185
Apple	iPhone 15 Pro (128GB)iCloud Lock	2	Part 2 SP Bid-No Power On-Change Battery(Reference Only)	3186
Apple	iPhone 15 Plus (128GB)iCloud Lock	1	Part 2 AHandset	3187
Apple	iPhone 15 Plus (128GB)iCloud Lock	2	Part 2 BHandset (Power Up, Bad LCD)	3188
Apple	iPhone 15 Plus (128GB)iCloud Lock	1	Part 2 BHandset (only electricity)	3189
Apple	iPhone 15 (128GB)iCloud Lock	1	Part 2 AHandset	3190
Apple	iPhone 15 (128GB)iCloud Lock	1	Part 2 BHandset (Power Up, Good LCD)	3191
Apple	iPhone 15 (128GB)iCloud Lock	4	Part 2 BHandset (Power Up, Bad LCD)	3192
Apple	iPhone 15 (128GB)iCloud Lock	3	Part 2 BHandset (only electricity)	3193
Apple	iPhone 15 (128GB)iCloud Lock	4	Part 2 SP Bid-No Power On-Change Battery(Reference Only)	3194
Apple	iPhone 14 Pro Max (128GB)iCloud Lock	1	Part 2 AHandset	3195
Apple	iPhone 14 Pro Max (512GB)iCloud Lock	1	Part 2 AHandset	3196
Apple	iPhone 14 Pro Max (128GB)iCloud Lock	8	Part 2 BHandset (Power Up, Bad LCD)	3197
Apple	iPhone 14 Pro Max (256GB)iCloud Lock	6	Part 2 BHandset (Power Up, Bad LCD)	3198
Apple	iPhone 14 Pro Max (512GB)iCloud Lock	1	Part 2 BHandset (Power Up, Bad LCD)	3199
Apple	iPhone 14 Pro Max (128GB)iCloud Lock	1	Part 2 BHandset (only electricity)	3200
Apple	iPhone 14 Pro Max (128GB)iCloud Lock	2	Part 2 SP Bid-No Power On-Change Battery(Reference Only)	3201
Apple	iPhone 14 Pro Max (256GB)iCloud Lock	4	Part 2 SP Bid-No Power On-Change Battery(Reference Only)	3202
Apple	iPhone 14 Pro (128GB)iCloud Lock	5	Part 2 AHandset	3203
Apple	iPhone 14 Pro (128GB)iCloud Lock	3	Part 2 BHandset (Power Up, Bad LCD)	3204
Apple	iPhone 14 Pro (256GB)iCloud Lock	2	Part 2 BHandset (Power Up, Bad LCD)	3205
Apple	iPhone 14 Pro (512GB)iCloud Lock	1	Part 2 BHandset (Power Up, Bad LCD)	3206
Apple	iPhone 14 Pro (128GB)iCloud Lock	1	Part 2 BHandset (only electricity)	3207
Apple	iPhone 14 Pro (128GB)iCloud Lock	2	Part 2 SP Bid-No Power On-Change Battery(Reference Only)	3208
Apple	iPhone 14 Pro (1Tb)iCloud Lock	1	Part 2 SP Bid-No Power On-Change Battery(Reference Only)	3209
Apple	iPhone 14 Plus (128GB)iCloud Lock	4	Part 2 AHandset	3210
Apple	iPhone 14 Plus (128GB)iCloud Lock	10	Part 2 BHandset (Power Up, Bad LCD)	3211
Apple	iPhone 14 Plus (256GB)iCloud Lock	1	Part 2 BHandset (Power Up, Bad LCD)	3212
Apple	iPhone 14 Plus (128GB)iCloud Lock	1	Part 2 BHandset (only electricity)	3213
Apple	iPhone 14 Plus (128GB)iCloud Lock	1	Part 2 SP Bid-No Power On-Change Battery(Reference Only)	3214
Apple	iPhone 14 (128GB)iCloud Lock	16	Part 2 AHandset	3215
Apple	iPhone 14 (256GB)iCloud Lock	2	Part 2 AHandset	3216
Apple	iPhone 14 (128GB)iCloud Lock	2	Part 2 BHandset (Power Up, Good LCD)	3217
Apple	iPhone 14 (128GB)iCloud Lock	23	Part 2 BHandset (Power Up, Bad LCD)	3218
Apple	iPhone 14 (256GB)iCloud Lock	3	Part 2 BHandset (Power Up, Bad LCD)	3219
Apple	iPhone 14 (128GB)iCloud Lock	3	Part 2 BHandset (only electricity)	3220
Apple	iPhone 14 (128GB)iCloud Lock	4	Part 2 SP Bid-No Power On-Change Battery(Reference Only)	3221
Apple	iPhone 13 Pro Max (128GB)iCloud Lock	1	Part 2 AHandset	3222
Apple	iPhone 13 Pro Max (128GB)iCloud Lock	12	Part 2 BHandset (Power Up, Bad LCD)	3223
Apple	iPhone 13 Pro Max (256GB)iCloud Lock	2	Part 2 BHandset (Power Up, Bad LCD)	3224
Apple	iPhone 13 Pro Max (128GB)iCloud Lock	5	Part 2 BHandset (only electricity)	3225
Apple	iPhone 13 Pro Max (512GB)iCloud Lock	2	Part 2 BHandset (only electricity)	3226
Apple	iPhone 13 Pro Max (128GB)iCloud Lock	4	Part 2 SP Bid-No Power On-Change Battery(Reference Only)	3227
Apple	iPhone 13 Pro Max (1Tb)iCloud Lock	1	Part 2 SP Bid-No Power On-Change Battery(Reference Only)	3228
Apple	iPhone 13 Pro Max (256GB)iCloud Lock	2	Part 2 SP Bid-No Power On-Change Battery(Reference Only)	3229
Apple	iPhone 13 Pro (128GB)iCloud Lock	2	Part 2 AHandset	3230
Apple	iPhone 13 Pro (128GB)iCloud Lock	6	Part 2 BHandset (Power Up, Bad LCD)	3231
Apple	iPhone 13 Pro (256GB)iCloud Lock	2	Part 2 BHandset (Power Up, Bad LCD)	3232
Apple	iPhone 13 Pro (128GB)iCloud Lock	6	Part 2 BHandset (only electricity)	3233
Apple	iPhone 13 Pro (1Tb)iCloud Lock	1	Part 2 BHandset (only electricity)	3234
Apple	iPhone 13 Pro (512GB)iCloud Lock	1	Part 2 BHandset (only electricity)	3235
Apple	iPhone 13 Pro (256GB)iCloud Lock	3	Part 2 SP Bid-No Power On-Change Battery(Reference Only)	3236
Apple	iPhone 13 (128GB)iCloud Lock	28	Part 2 AHandset	3237
Apple	iPhone 13 (256GB)iCloud Lock	1	Part 2 AHandset	3238
Apple	iPhone 13 (128GB)iCloud Lock	7	Part 2 BHandset (Power Up, Good LCD)	3239
Apple	iPhone 13 (256GB)iCloud Lock	1	Part 2 BHandset (Power Up, Good LCD)	3240
Apple	iPhone 13 (128GB)iCloud Lock	25	Part 2 BHandset (Power Up, Bad LCD)	3241
Apple	iPhone 13 (128GB)iCloud Lock	7	Part 2 BHandset (only electricity)	3242
Apple	iPhone 13 (256GB)iCloud Lock	2	Part 2 BHandset (only electricity)	3243
Apple	iPhone 13 (128GB)iCloud Lock	8	Part 2 SP Bid-No Power On-Change Battery(Reference Only)	3244
Apple	iPhone 13 (256GB)iCloud Lock	2	Part 2 SP Bid-No Power On-Change Battery(Reference Only)	3245
Apple	iPhone 13 Mini (128GB)iCloud Lock	2	Part 2 BHandset (Power Up, Good LCD)	3246
Apple	iPhone 13 Mini (128GB)iCloud Lock	2	Part 2 BHandset (only electricity)	3247
Apple	iPhone 13 Mini (128GB)iCloud Lock	5	Part 2 SP Bid-No Power On-Change Battery(Reference Only)	3248
Apple	iPhone 12 Pro Max (128GB)iCloud Lock	3	Part 2 AHandset	3249
Apple	iPhone 12 Pro Max (256GB)iCloud Lock	1	Part 2 AHandset	3250
Apple	iPhone 12 Pro Max (128GB)iCloud Lock	2	Part 2 BHandset (Power Up, Bad LCD)	3251
Apple	iPhone 12 Pro Max (256GB)iCloud Lock	1	Part 2 BHandset (Power Up, Bad LCD)	3252
Apple	iPhone 12 Pro Max (128GB)iCloud Lock	1	Part 2 BHandset (only electricity)	3253
Apple	iPhone 12 Pro Max (512GB)iCloud Lock	1	Part 2 BHandset (only electricity)	3254
Apple	iPhone 12 Pro Max (128GB)iCloud Lock	6	Part 2 SP Bid-No Power On-Change Battery(Reference Only)	3255
Apple	iPhone 12 Pro (128GB)iCloud Lock	3	Part 2 AHandset	3256
Apple	iPhone 12 Pro (128GB)iCloud Lock	8	Part 2 BHandset (Power Up, Good LCD)	3257
Apple	iPhone 12 Pro (128GB)iCloud Lock	4	Part 2 BHandset (Power Up, Bad LCD)	3258
Apple	iPhone 12 Pro (256GB)iCloud Lock	1	Part 2 BHandset (Power Up, Bad LCD)	3259
Apple	iPhone 12 Pro (128GB)iCloud Lock	7	Part 2 BHandset (only electricity)	3260
Apple	iPhone 12 Pro (128GB)iCloud Lock	25	Part 2 SP Bid-No Power On-Change Battery(Reference Only)	3261
Apple	iPhone 12 (128GB)iCloud Lock	14	Part 2 AHandset	3262
Apple	iPhone 12 (256GB)iCloud Lock	1	Part 2 AHandset	3263
Apple	iPhone 12 (64GB)iCloud Lock	40	Part 2 AHandset	3264
Apple	iPhone 12 (128GB)iCloud Lock	1	Part 2 BHandset (Power Up, Good LCD)	3265
Apple	iPhone 12 (256GB)iCloud Lock	1	Part 2 BHandset (Power Up, Good LCD)	3266

Apple	iPhone 12 (64GB)iCloud Lock	13	Part 2 BHandset (Power Up, Good LCD)	3267
Apple	iPhone 12 (256GB)iCloud Lock	5	Part 2 BHandset (Power Up, Bad LCD)	3268
Apple	iPhone 12 (64GB)iCloud Lock	18	Part 2 BHandset (Power Up, Bad LCD)	3269
Apple	iPhone 12 (128GB)iCloud Lock	5	Part 2 BHandset (only electricity)	3270
Apple	iPhone 12 (64GB)iCloud Lock	26	Part 2 BHandset (only electricity)	3271
Apple	iPhone 12 (128GB)iCloud Lock	8	Part 2 SP Bid-No Power On-Change Battery(Reference Only)	3272
Apple	iPhone 12 (64GB)iCloud Lock	17	Part 2 SP Bid-No Power On-Change Battery(Reference Only)	3273
Apple	iPhone 12 Mini (128GB)iCloud Lock	1	Part 2 AHandset	3274
Apple	iPhone 12 Mini (64GB)iCloud Lock	1	Part 2 AHandset	3275
Apple	iPhone 12 Mini (64GB)iCloud Lock	7	Part 2 BHandset (Power Up, Good LCD)	3276
Apple	iPhone 12 Mini (128GB)iCloud Lock	2	Part 2 BHandset (Power Up, Bad LCD)	3277
Apple	iPhone 12 Mini (64GB)iCloud Lock	4	Part 2 BHandset (Power Up, Bad LCD)	3278
Apple	iPhone 12 Mini (128GB)iCloud Lock	2	Part 2 BHandset (only electricity)	3279
Apple	iPhone 12 Mini (64GB)iCloud Lock	2	Part 2 BHandset (only electricity)	3280
Apple	iPhone 12 Mini (64GB)iCloud Lock	9	Part 2 SP Bid-No Power On-Change Battery(Reference Only)	3281
Apple	iPhone 11 Pro Max (256GB)iCloud Lock	6	Part 2 BHandset (Power Up, Good LCD)	3282
Apple	iPhone 11 Pro Max (512GB)iCloud Lock	1	Part 2 BHandset (Power Up, Good LCD)	3283
Apple	iPhone 11 Pro Max (64GB)iCloud Lock	21	Part 2 BHandset (Power Up, Good LCD)	3284
Apple	iPhone 11 Pro Max (256GB)iCloud Lock	1	Part 2 BHandset (Power Up, Bad LCD)	3285
Apple	iPhone 11 Pro Max (64GB)iCloud Lock	2	Part 2 BHandset (Power Up, Bad LCD)	3286
Apple	iPhone 11 Pro Max (256GB)iCloud Lock	3	Part 2 BHandset (only electricity)	3287
Apple	iPhone 11 Pro Max (64GB)iCloud Lock	9	Part 2 BHandset (only electricity)	3288
Apple	iPhone 11 Pro Max (256GB)iCloud Lock	4	Part 2 SP Bid-No Power On-Change Battery(Reference Only)	3289
Apple	iPhone 11 Pro Max (512GB)iCloud Lock	1	Part 2 SP Bid-No Power On-Change Battery(Reference Only)	3290
Apple	iPhone 11 Pro Max (64GB)iCloud Lock	1	Part 2 SP Bid-No Power On-Change Battery(Reference Only)	3291
Apple	iPhone 11 Pro (256GB)iCloud Lock	6	Part 2 AHandset	3292
Apple	iPhone 11 Pro (64GB)iCloud Lock	7	Part 2 AHandset	3293
Apple	iPhone 11 Pro (256GB)iCloud Lock	6	Part 2 BHandset (Power Up, Good LCD)	3294
Apple	iPhone 11 Pro (64GB)iCloud Lock	20	Part 2 BHandset (Power Up, Good LCD)	3295
Apple	iPhone 11 Pro (64GB)iCloud Lock	6	Part 2 BHandset (Power Up, Bad LCD)	3296
Apple	iPhone 11 Pro (64GB)iCloud Lock	7	Part 2 BHandset (only electricity)	3297
Apple	iPhone 11 Pro (256GB)iCloud Lock	1	Part 2 SP Bid-No Power On-Change Battery(Reference Only)	3298
Apple	iPhone 11 Pro (64GB)iCloud Lock	14	Part 2 SP Bid-No Power On-Change Battery(Reference Only)	3299
Apple	iPhone 11 (128GB)iCloud Lock	25	Part 2 AHandset	3300
Apple	iPhone 11 (256GB)iCloud Lock	1	Part 2 AHandset	3301
Apple	iPhone 11 (64GB)iCloud Lock	210	Part 2 AHandset	3302
Apple	iPhone 11 (128GB)iCloud Lock	10	Part 2 BHandset (Power Up, Good LCD)	3303
Apple	iPhone 11 (256GB)iCloud Lock	2	Part 2 BHandset (Power Up, Good LCD)	3304
Apple	iPhone 11 (64GB)iCloud Lock	97	Part 2 BHandset (Power Up, Good LCD)	3305
Apple	iPhone 11 (128GB)iCloud Lock	11	Part 2 BHandset (Power Up, Bad LCD)	3306
Apple	iPhone 11 (256GB)iCloud Lock	4	Part 2 BHandset (Power Up, Bad LCD)	3307
Apple	iPhone 11 (64GB)iCloud Lock	125	Part 2 BHandset (Power Up, Bad LCD)	3308
Apple	iPhone 11 (128GB)iCloud Lock	9	Part 2 BHandset (only electricity)	3309
Apple	iPhone 11 (64GB)iCloud Lock	66	Part 2 BHandset (only electricity)	3310
Apple	iPhone 11 (128GB)iCloud Lock	9	Part 2 SP Bid-No Power On-Change Battery(Reference Only)	3311
Apple	iPhone 11 (256GB)iCloud Lock	5	Part 2 SP Bid-No Power On-Change Battery(Reference Only)	3312
Apple	iPhone 11 (64GB)iCloud Lock	116	Part 2 SP Bid-No Power On-Change Battery(Reference Only)	3313
Apple	iPhone Xs Max (64GB)iCloud Lock	1	Part 2 AHandset	3314
Apple	iPhone Xs Max (256GB)iCloud Lock	13	Part 2 BHandset (Power Up, Good LCD)	3315
Apple	iPhone Xs Max (64GB)iCloud Lock	18	Part 2 BHandset (Power Up, Good LCD)	3316
Apple	iPhone Xs Max (256GB)iCloud Lock	10	Part 2 BHandset (Power Up, Bad LCD)	3317
Apple	iPhone Xs Max (512GB)iCloud Lock	1	Part 2 BHandset (Power Up, Bad LCD)	3318
Apple	iPhone Xs Max (64GB)iCloud Lock	7	Part 2 BHandset (Power Up, Bad LCD)	3319
Apple	iPhone Xs Max (64GB)iCloud Lock	5	Part 2 BHandset (only electricity)	3320
Apple	iPhone Xs Max (256GB)iCloud Lock	1	Part 2 SP Bid-No Power On-Change Battery(Reference Only)	3321
Apple	iPhone Xs Max (64GB)iCloud Lock	21	Part 2 SP Bid-No Power On-Change Battery(Reference Only)	3322
Apple	iPhone Xs (256GB)iCloud Lock	15	Part 2 AHandset	3323
Apple	iPhone Xs (512GB)iCloud Lock	4	Part 2 AHandset	3324
Apple	iPhone Xs (64GB)iCloud Lock	41	Part 2 AHandset	3325
Apple	iPhone Xs (256GB)iCloud Lock	11	Part 2 BHandset (Power Up, Good LCD)	3326
Apple	iPhone Xs (64GB)iCloud Lock	30	Part 2 BHandset (Power Up, Good LCD)	3327
Apple	iPhone Xs (256GB)iCloud Lock	7	Part 2 BHandset (Power Up, Bad LCD)	3328
Apple	iPhone Xs (64GB)iCloud Lock	23	Part 2 BHandset (Power Up, Bad LCD)	3329
Apple	iPhone Xs (256GB)iCloud Lock	6	Part 2 BHandset (only electricity)	3330
Apple	iPhone Xs (64GB)iCloud Lock	45	Part 2 BHandset (only electricity)	3331
Apple	iPhone Xs (256GB)iCloud Lock	4	Part 2 SP Bid-No Power On-Change Battery(Reference Only)	3332
Apple	iPhone Xs (512GB)iCloud Lock	1	Part 2 SP Bid-No Power On-Change Battery(Reference Only)	3333
Apple	iPhone Xs (64GB)iCloud Lock	21	Part 2 SP Bid-No Power On-Change Battery(Reference Only)	3334
Apple	iPhone X (256GB)iCloud Lock	1	Part 2 BHandset (Power Up, Good LCD)	3335
Apple	iPhone X (64GB)iCloud Lock	3	Part 2 BHandset (Power Up, Good LCD)	3336
Apple	iPhone X (64GB)iCloud Lock	1	Part 2 BHandset (only electricity)	3337
Apple	iPhone Xr (128GB)iCloud Lock	20	Part 2 AHandset	3338
Apple	iPhone Xr (64GB)iCloud Lock	106	Part 2 AHandset	3339
Apple	iPhone Xr (128GB)iCloud Lock	20	Part 2 BHandset (Power Up, Good LCD)	3340
Apple	iPhone Xr (256GB)iCloud Lock	4	Part 2 BHandset (Power Up, Good LCD)	3341
Apple	iPhone Xr (64GB)iCloud Lock	271	Part 2 BHandset (Power Up, Good LCD)	3342
Apple	iPhone Xr (128GB)iCloud Lock	43	Part 2 BHandset (Power Up, Bad LCD)	3343
Apple	iPhone Xr (256GB)iCloud Lock	8	Part 2 BHandset (Power Up, Bad LCD)	3344
Apple	iPhone Xr (64GB)iCloud Lock	492	Part 2 BHandset (Power Up, Bad LCD)	3345
Apple	iPhone Xr (128GB)iCloud Lock	8	Part 2 BHandset (only electricity)	3346
Apple	iPhone Xr (64GB)iCloud Lock	50	Part 2 BHandset (only electricity)	3347
Apple	iPhone Xr (128GB)iCloud Lock	13	Part 2 SP Bid-No Power On-Change Battery(Reference Only)	3348
Apple	iPhone Xr (64GB)iCloud Lock	105	Part 2 SP Bid-No Power On-Change Battery(Reference Only)	3349
Apple	iPhone 8 Plus (64GB)iCloud Lock	1	Part 2 AHandset	3350
Apple	iPhone 8 Plus (128GB)iCloud Lock	1	Part 2 BHandset (Power Up, Good LCD)	3351
Apple	iPhone 8 Plus (64GB)iCloud Lock	2	Part 2 BHandset (Power Up, Good LCD)	3352

Apple	iPhone 8 Plus (128GB)iCloud Lock	1	Part 2 BHandset (Power Up, Bad LCD)	3353
Apple	iPhone 8 Plus (256GB)iCloud Lock	4	Part 2 BHandset (Power Up, Bad LCD)	3354
Apple	iPhone 8 Plus (64GB)iCloud Lock	62	Part 2 BHandset (Power Up, Bad LCD)	3355
Apple	iPhone 8 Plus (256GB)iCloud Lock	2	Part 2 BHandset (only electricity)	3356
Apple	iPhone 8 Plus (64GB)iCloud Lock	12	Part 2 BHandset (only electricity)	3357
Apple	iPhone 8 Plus (64GB)iCloud Lock	27	Part 2 SP Bid-No Power On-Change Battery(Reference Only)	3358
Apple	iPhone 8 (256GB)iCloud Lock	1	Part 2 AHandset	3359
Apple	iPhone 8 (64GB)iCloud Lock	88	Part 2 AHandset	3360
Apple	iPhone 8 (128GB)iCloud Lock	4	Part 2 BHandset (Power Up, Good LCD)	3361
Apple	iPhone 8 (256GB)iCloud Lock	6	Part 2 BHandset (Power Up, Good LCD)	3362
Apple	iPhone 8 (64GB)iCloud Lock	185	Part 2 BHandset (Power Up, Good LCD)	3363
Apple	iPhone 8 (256GB)iCloud Lock	1	Part 2 BHandset (Power Up, Bad LCD)	3364
Apple	iPhone 8 (64GB)iCloud Lock	3	Part 2 BHandset (Power Up, Bad LCD)	3365
Apple	iPhone 8 (256GB)iCloud Lock	2	Part 2 SP Bid-No Power On-Change Battery(Reference Only)	3366
Apple	iPhone 8 (64GB)iCloud Lock	4	Part 2 SP Bid-No Power On-Change Battery(Reference Only)	3367
Apple	iPhone 7 Plus (32GB)iCloud Lock	1	Part 2 AHandset	3368
Apple	iPhone 7 Plus (128GB)iCloud Lock	17	Part 2 BHandset (Power Up, Good LCD)	3369
Apple	iPhone 7 Plus (256GB)iCloud Lock	2	Part 2 BHandset (Power Up, Good LCD)	3370
Apple	iPhone 7 Plus (32GB)iCloud Lock	45	Part 2 BHandset (Power Up, Good LCD)	3371
Apple	iPhone 7 Plus (128GB)iCloud Lock	10	Part 2 BHandset (Power Up, Bad LCD)	3372
Apple	iPhone 7 Plus (256GB)iCloud Lock	1	Part 2 BHandset (Power Up, Bad LCD)	3373
Apple	iPhone 7 Plus (32GB)iCloud Lock	36	Part 2 BHandset (Power Up, Bad LCD)	3374
Apple	iPhone 7 Plus (128GB)iCloud Lock	10	Part 2 SP Bid-No Power On-Change Battery(Reference Only)	3375
Apple	iPhone 7 Plus (256GB)iCloud Lock	2	Part 2 SP Bid-No Power On-Change Battery(Reference Only)	3376
Apple	iPhone 7 Plus (32GB)iCloud Lock	57	Part 2 SP Bid-No Power On-Change Battery(Reference Only)	3377
Apple	iPhone 7 (128GB)iCloud Lock	199	Part 2 AHandset	3378
Apple	iPhone 7 (32GB)iCloud Lock	623	Part 2 AHandset	3379
Apple	iPhone 7 (128GB)iCloud Lock	68	Part 2 BHandset (Power Up, Good LCD)	3380
Apple	iPhone 7 (256GB)iCloud Lock	6	Part 2 BHandset (Power Up, Good LCD)	3381
Apple	iPhone 7 (32GB)iCloud Lock	353	Part 2 BHandset (Power Up, Good LCD)	3382
Apple	iPhone 7 (128GB)iCloud Lock	45	Part 2 BHandset (Power Up, Bad LCD)	3383
Apple	iPhone 7 (256GB)iCloud Lock	6	Part 2 BHandset (Power Up, Bad LCD)	3384
Apple	iPhone 7 (32GB)iCloud Lock	427	Part 2 BHandset (Power Up, Bad LCD)	3385
Apple	iPhone 7 (128GB)iCloud Lock	26	Part 2 SP Bid-No Power On-Change Battery(Reference Only)	3386
Apple	iPhone 7 (256GB)iCloud Lock	2	Part 2 SP Bid-No Power On-Change Battery(Reference Only)	3387
Apple	iPhone 7 (32GB)iCloud Lock	210	Part 2 SP Bid-No Power On-Change Battery(Reference Only)	3388
Apple	iPhone Se2 (128GB)iCloud Lock	17	Part 2 AHandset	3389
Apple	iPhone Se2 (256GB)iCloud Lock	4	Part 2 AHandset	3390
Apple	iPhone Se2 (64GB)iCloud Lock	193	Part 2 AHandset	3391
Apple	iPhone Se2 (128GB)iCloud Lock	17	Part 2 BHandset (Power Up, Good LCD)	3392
Apple	iPhone Se2 (256GB)iCloud Lock	1	Part 2 BHandset (Power Up, Good LCD)	3393
Apple	iPhone Se2 (64GB)iCloud Lock	361	Part 2 BHandset (Power Up, Good LCD)	3394
Apple	iPhone Se2 (128GB)iCloud Lock	24	Part 2 BHandset (Power Up, Bad LCD)	3395
Apple	iPhone Se2 (256GB)iCloud Lock	3	Part 2 BHandset (Power Up, Bad LCD)	3396
Apple	iPhone Se2 (64GB)iCloud Lock	180	Part 2 BHandset (Power Up, Bad LCD)	3397
Apple	iPhone Se2 (128GB)iCloud Lock	1	Part 2 BHandset (only electricity)	3398
Apple	iPhone Se2 (64GB)iCloud Lock	4	Part 2 BHandset (only electricity)	3399
Apple	iPhone Se2 (128GB)iCloud Lock	2	Part 2 SP Bid-No Power On-Change Battery(Reference Only)	3400
Apple	iPhone Se2 (64GB)iCloud Lock	50	Part 2 SP Bid-No Power On-Change Battery(Reference Only)	3401
Apple	iPhone 6s Plus (128GB)iCloud Lock	1	Part 2 AHandset	3402
Apple	iPhone 6s Plus (32GB)iCloud Lock	1	Part 2 AHandset	3403
Apple	iPhone 6s Plus (128GB)iCloud Lock	4	Part 2 BHandset (Power Up, Good LCD)	3404
Apple	iPhone 6s Plus (16GB)iCloud Lock	29	Part 2 BHandset (Power Up, Good LCD)	3405
Apple	iPhone 6s Plus (32GB)iCloud Lock	15	Part 2 BHandset (Power Up, Good LCD)	3406
Apple	iPhone 6s Plus (64GB)iCloud Lock	12	Part 2 BHandset (Power Up, Good LCD)	3407
Apple	iPhone 6s Plus (128GB)iCloud Lock	2	Part 2 BHandset (Power Up, Bad LCD)	3408
Apple	iPhone 6s Plus (16GB)iCloud Lock	110	Part 2 BHandset (Power Up, Bad LCD)	3409
Apple	iPhone 6s Plus (32GB)iCloud Lock	17	Part 2 BHandset (Power Up, Bad LCD)	3410
Apple	iPhone 6s Plus (64GB)iCloud Lock	23	Part 2 BHandset (Power Up, Bad LCD)	3411
Apple	iPhone 6s Plus (16GB)iCloud Lock	44	Part 2 SP Bid-No Power On-Change Battery(Reference Only)	3412
Apple	iPhone 6s Plus (32GB)iCloud Lock	7	Part 2 SP Bid-No Power On-Change Battery(Reference Only)	3413
Apple	iPhone 6s Plus (64GB)iCloud Lock	3	Part 2 SP Bid-No Power On-Change Battery(Reference Only)	3414
Apple	iPhone 6s (16GB)iCloud Lock	9	Part 2 AHandset	3415
Apple	iPhone 6s (32GB)iCloud Lock	11	Part 2 AHandset	3416
Apple	iPhone 6s (64GB)iCloud Lock	11	Part 2 AHandset	3417
Apple	iPhone 6s (128GB)iCloud Lock	13	Part 2 BHandset (Power Up, Good LCD)	3418
Apple	iPhone 6s (16GB)iCloud Lock	162	Part 2 BHandset (Power Up, Good LCD)	3419
Apple	iPhone 6s (32GB)iCloud Lock	107	Part 2 BHandset (Power Up, Good LCD)	3420
Apple	iPhone 6s (64GB)iCloud Lock	57	Part 2 BHandset (Power Up, Good LCD)	3421
Apple	iPhone 6s (128GB)iCloud Lock	11	Part 2 BHandset (Power Up, Bad LCD)	3422
Apple	iPhone 6s (16GB)iCloud Lock	225	Part 2 BHandset (Power Up, Bad LCD)	3423
Apple	iPhone 6s (32GB)iCloud Lock	64	Part 2 BHandset (Power Up, Bad LCD)	3424
Apple	iPhone 6s (64GB)iCloud Lock	40	Part 2 BHandset (Power Up, Bad LCD)	3425
Apple	iPhone 6s (128GB)iCloud Lock	3	Part 2 SP Bid-No Power On-Change Battery(Reference Only)	3426
Apple	iPhone 6s (16GB)iCloud Lock	62	Part 2 SP Bid-No Power On-Change Battery(Reference Only)	3427
Apple	iPhone 6s (32GB)iCloud Lock	2	Part 2 SP Bid-No Power On-Change Battery(Reference Only)	3428
Apple	iPhone 6 Plus (16GB)iCloud Lock	1	Part 2 AHandset	3429
Apple	iPhone 6 Plus (128GB)iCloud Lock	8	Part 2 BHandset (Power Up, Good LCD)	3430
Apple	iPhone 6 Plus (16GB)iCloud Lock	97	Part 2 BHandset (Power Up, Good LCD)	3431
Apple	iPhone 6 Plus (64GB)iCloud Lock	14	Part 2 BHandset (Power Up, Good LCD)	3432
Apple	iPhone 6 Plus (128GB)iCloud Lock	5	Part 2 BHandset (Power Up, Bad LCD)	3433
Apple	iPhone 6 Plus (16GB)iCloud Lock	158	Part 2 BHandset (Power Up, Bad LCD)	3434
Apple	iPhone 6 Plus (64GB)iCloud Lock	33	Part 2 BHandset (Power Up, Bad LCD)	3435
Apple	iPhone 6 Plus (16GB)iCloud Lock	61	Part 2 SP Bid-No Power On-Change Battery(Reference Only)	3436
Apple	iPhone 6 Plus (64GB)iCloud Lock	5	Part 2 SP Bid-No Power On-Change Battery(Reference Only)	3437
Apple	iPhone 6 (16GB)iCloud Lock	1244	Part 2 AHandset	3438

Apple	iPhone 6 (32GB)iCloud Lock	2	Part 2 AHandset	3439
Apple	iPhone 6 (128GB)iCloud Lock	10	Part 2 BHandset (Power Up, Good LCD)	3440
Apple	iPhone 6 (16GB)iCloud Lock	1036	Part 2 BHandset (Power Up, Good LCD)	3441
Apple	iPhone 6 (32GB)iCloud Lock	68	Part 2 BHandset (Power Up, Good LCD)	3442
Apple	iPhone 6 (64GB)iCloud Lock	111	Part 2 BHandset (Power Up, Good LCD)	3443
Apple	iPhone 6 (128GB)iCloud Lock	17	Part 2 BHandset (Power Up, Bad LCD)	3444
Apple	iPhone 6 (16GB)iCloud Lock	1310	Part 2 BHandset (Power Up, Bad LCD)	3445
Apple	iPhone 6 (32GB)iCloud Lock	97	Part 2 BHandset (Power Up, Bad LCD)	3446
Apple	iPhone 6 (64GB)iCloud Lock	144	Part 2 BHandset (Power Up, Bad LCD)	3447
Apple	iPhone 6 (128GB)iCloud Lock	2	Part 2 SP Bid-No Power On-Change Battery(Reference Only)	3448
Apple	iPhone 6 (16GB)iCloud Lock	554	Part 2 SP Bid-No Power On-Change Battery(Reference Only)	3449
Apple	iPhone 6 (32GB)iCloud Lock	16	Part 2 SP Bid-No Power On-Change Battery(Reference Only)	3450
Apple	iPhone 6 (64GB)iCloud Lock	37	Part 2 SP Bid-No Power On-Change Battery(Reference Only)	3451
Apple	iPhone 5s (16GB)iCloud Lock	1	Part 2 AHandset	3452
Apple	iPhone 5s (16GB)iCloud Lock	1	Part 2 BHandset (Power Up, Good LCD)	3453
Apple	iPhone 5s (16GB)iCloud Lock	4	Part 2 BHandset (Power Up, Bad LCD)	3454
Apple	iPhone 5s (16GB)iCloud Lock	3	Part 2 SP Bid-No Power On-Change Battery(Reference Only)	3455
Apple	iPhone Se3 (128GB)iCloud Lock	1	Part 2 AHandset	3456
Apple	iPhone Se3 (64GB)iCloud Lock	87	Part 2 AHandset	3457
Apple	iPhone Se3 (128GB)iCloud Lock	3	Part 2 BHandset (Power Up, Good LCD)	3458
Apple	iPhone Se3 (64GB)iCloud Lock	12	Part 2 BHandset (Power Up, Good LCD)	3459
Apple	iPhone Se3 (128GB)iCloud Lock	3	Part 2 BHandset (Power Up, Bad LCD)	3460
Apple	iPhone Se3 (64GB)iCloud Lock	41	Part 2 BHandset (Power Up, Bad LCD)	3461
Apple	iPhone Se3 (128GB)iCloud Lock	1	Part 2 BHandset (only electricity)	3462
Apple	iPhone Se3 (64GB)iCloud Lock	8	Part 2 SP Bid-No Power On-Change Battery(Reference Only)	3463
Apple	iPhone SE (16GB)iCloud Lock	1	Part 2 AHandset	3464
Apple	iPhone SE (32GB)iCloud Lock	2	Part 2 AHandset	3465
Apple	iPhone SE (16GB)iCloud Lock	3	Part 2 BHandset (Power Up, Bad LCD)	3466
Apple	iPhone SE (16GB)iCloud Lock	1	Part 2 SP Bid-No Power On-Change Battery(Reference Only)	3467
Apple	iPhone 5c (8GB)iCloud Lock	1	Part 2 BHandset (Power Up, Bad LCD)	3468
Apple	iPhone 5c (8GB)iCloud Lock	3	Part 2 SP Bid-No Power On-Change Battery(Reference Only)	3469
Apple	iPhone 5 (16GB)iCloud Lock	6	Part 2 BHandset (Power Up, Bad LCD)	3470
Apple	iPhone 5 (16GB)iCloud Lock	1	Part 2 SP Bid-No Power On-Change Battery(Reference Only)	3471
Apple	iPhone 4s (16GB)iCloud Lock	1	Part 2 AHandset	3472
Apple	iPhone 4s (8GB)iCloud Lock	1	Part 2 SP Bid-No Power On-Change Battery(Reference Only)	3473
Apple	The New iPad WiFi (16GB)iCloud Lock	28	Part 2 BHandset (Power Up, Good LCD)	3474
Apple	The New iPad WiFi (32GB)iCloud Lock	15	Part 2 BHandset (Power Up, Good LCD)	3475
Apple	The New iPad WiFi (64GB)iCloud Lock	6	Part 2 BHandset (Power Up, Good LCD)	3476
Apple	The New iPad WiFi (16GB)iCloud Lock	9	Part 2 BHandset (Power Up, Bad LCD)	3477
Apple	The New iPad WiFi (32GB)iCloud Lock	6	Part 2 BHandset (Power Up, Bad LCD)	3478
Apple	The New iPad WiFi (16GB)iCloud Lock	1	Part 2 BHandset (No Power)	3479
Apple	The New iPad WiFi 4G (16GB)iCloud Lock	4	Part 2 BHandset (Power Up, Good LCD)	3480
Apple	The New iPad WiFi 4G (32GB)iCloud Lock	9	Part 2 BHandset (Power Up, Good LCD)	3481
Apple	The New iPad WiFi 4G (64GB)iCloud Lock	6	Part 2 BHandset (Power Up, Good LCD)	3482
Apple	The New iPad WiFi 4G (16GB)iCloud Lock	5	Part 2 BHandset (Power Up, Bad LCD)	3483
Apple	The New iPad WiFi 4G (32GB)iCloud Lock	3	Part 2 BHandset (Power Up, Bad LCD)	3484
Apple	The New iPad WiFi 4G (64GB)iCloud Lock	1	Part 2 BHandset (Power Up, Bad LCD)	3485
Apple	The New iPad WiFi 4G (16GB)iCloud Lock	1	Part 2 BHandset (No Power)	3486
Apple	The New iPad WiFi 4G (32GB)iCloud Lock	1	Part 2 BHandset (No Power)	3487
Apple	iPad WiFi (32GB)iCloud Lock	2	Part 2 AHandset	3488
Apple	iPad WiFi (16GB)iCloud Lock	1	Part 2 BHandset (Power Up, Good LCD)	3489
Apple	iPad WiFi (16GB)iCloud Lock	2	Part 2 BHandset (Power Up, Bad LCD)	3490
Apple	iPad WiFi (32GB)iCloud Lock	1	Part 2 BHandset (Power Up, Bad LCD)	3491
Apple	iPad WiFi 3G (16GB)iCloud Lock	1	Part 2 BHandset (Power Up, Bad LCD)	3492
Apple	iPad WiFi 3G (32GB)iCloud Lock	1	Part 2 BHandset (Power Up, Bad LCD)	3493
Apple	iPad Pro WiFi (128GB)iCloud Lock	1	Part 2 AHandset	3494
Apple	iPad Pro WiFi (128GB)iCloud Lock	1	Part 2 BHandset (Power Up, Good LCD)	3495
Apple	iPad Pro WiFi (256GB)iCloud Lock	1	Part 2 BHandset (Power Up, Good LCD)	3496
Apple	iPad Pro WiFi (32GB)iCloud Lock	1	Part 2 BHandset (Power Up, Good LCD)	3497
Apple	iPad Pro WiFi (128GB)iCloud Lock	4	Part 2 BHandset (Power Up, Bad LCD)	3498
Apple	iPad Pro WiFi (256GB)iCloud Lock	1	Part 2 BHandset (Power Up, Bad LCD)	3499
Apple	iPad Pro WiFi (32GB)iCloud Lock	3	Part 2 BHandset (Power Up, Bad LCD)	3500
Apple	iPad Pro WiFi (32GB)iCloud Lock	1	Part 2 BHandset (No Power)	3501
Apple	iPad Pro WiFi 4G (32GB)iCloud Lock	1	Part 2 AHandset	3502
Apple	iPad Pro WiFi 4G (128GB)iCloud Lock	2	Part 2 BHandset (Power Up, Bad LCD)	3503
Apple	iPad Pro WiFi 4G (256GB)iCloud Lock	1	Part 2 BHandset (Power Up, Bad LCD)	3504
Apple	iPad Pro 9.7 WiFi (32GB)iCloud Lock	1	Part 2 BHandset (Power Up, Good LCD)	3505
Apple	iPad Pro 9.7 WiFi (256GB)iCloud Lock	1	Part 2 BHandset (Power Up, Bad LCD)	3506
Apple	iPad Pro 9.7 WiFi (32GB)iCloud Lock	6	Part 2 BHandset (Power Up, Bad LCD)	3507
Apple	iPad Pro 9.7 WiFi (256GB)iCloud Lock	1	Part 2 BHandset (No Power)	3508
Apple	iPad Pro 9.7 WiFi (32GB)iCloud Lock	1	Part 2 BHandset (No Power)	3509
Apple	iPad Pro 9.7 WiFi 4G (128GB)iCloud Lock	1	Part 2 AHandset	3510
Apple	iPad Pro 9.7 WiFi 4G (128GB)iCloud Lock	1	Part 2 BHandset (Power Up, Good LCD)	3511
Apple	iPad Pro 9.7 WiFi 4G (256GB)iCloud Lock	1	Part 2 BHandset (Power Up, Good LCD)	3512
Apple	iPad Pro 9.7 WiFi 4G (128GB)iCloud Lock	1	Part 2 BHandset (Power Up, Bad LCD)	3513
Apple	iPad Pro 9.7 WiFi 4G (32GB)iCloud Lock	2	Part 2 BHandset (Power Up, Bad LCD)	3514
Apple	iPad Pro 9.7 WiFi 4G (128GB)iCloud Lock	1	Part 2 BHandset (No Power)	3515
Apple	iPad Pro 6 WiFi 5G (128GB)iCloud Lock	2	Part 2 BHandset (Power Up, Bad LCD)	3516
Apple	iPad Pro 6 11 WiFi (128GB)iCloud Lock	1	Part 2 BHandset (Power Up, Bad LCD)	3517
Apple	iPad Pro 5 11 WiFi (128GB)iCloud Lock	1	Part 2 BHandset (Power Up, Bad LCD)	3518
Apple	iPad Pro 4 WiFi (128GB)iCloud Lock	1	Part 2 BHandset (Power Up, Bad LCD)	3519
Apple	iPad Pro 4 WiFi 4G (256GB)iCloud Lock	1	Part 2 BHandset (Power Up, Good LCD)	3520
Apple	iPad Pro 4 WiFi 4G (256GB)iCloud Lock	1	Part 2 BHandset (Power Up, Bad LCD)	3521
Apple	iPad Pro 3 WiFi (256GB)iCloud Lock	1	Part 2 BHandset (Power Up, Bad LCD)	3522
Apple	iPad Pro 3 WiFi (512GB)iCloud Lock	1	Part 2 BHandset (Power Up, Bad LCD)	3523
Apple	iPad Pro 3 WiFi 4G (64GB)iCloud Lock	1	Part 2 AHandset	3524

Apple	iPad Pro 3 WiFi 4G (256GB)iCloud Lock	1	Part 2 BHandset (Power Up, Bad LCD)	3525
Apple	iPad Pro 3 WiFi 4G (512GB)iCloud Lock	1	Part 2 BHandset (Power Up, Bad LCD)	3526
Apple	iPad Pro 3 WiFi 4G (64GB)iCloud Lock	1	Part 2 BHandset (Power Up, Bad LCD)	3527
Apple	iPad Pro 3 11 WiFi 4G (256GB)iCloud Lock	1	Part 2 BHandset (Power Up, Bad LCD)	3528
Apple	iPad Pro 2 WiFi 4G (256GB)iCloud Lock	1	Part 2 BHandset (Power Up, Bad LCD)	3529
Apple	iPad Pro 2 WiFi 4G (512GB)iCloud Lock	2	Part 2 BHandset (Power Up, Bad LCD)	3530
Apple	iPad Pro 2 WiFi (256GB)iCloud Lock	2	Part 2 BHandset (Power Up, Bad LCD)	3531
Apple	iPad Pro 2 WiFi (64GB)iCloud Lock	4	Part 2 BHandset (Power Up, Bad LCD)	3532
Apple	iPad Pro 2 WiFi (64GB)iCloud Lock	1	Part 2 BHandset (No Power)	3533
Apple	iPad Pro 10.5 WiFi (256GB)iCloud Lock	3	Part 2 BHandset (Power Up, Bad LCD)	3534
Apple	iPad Pro 10.5 WiFi (64GB)iCloud Lock	8	Part 2 BHandset (Power Up, Bad LCD)	3535
Apple	iPad Pro 10.5 WiFi 4G (256GB)iCloud Lock	1	Part 2 BHandset (Power Up, Bad LCD)	3536
Apple	iPad Pro 10.5 WiFi 4G (64GB)iCloud Lock	8	Part 2 BHandset (Power Up, Bad LCD)	3537
Apple	iPad Pro 10.5 WiFi 4G (64GB)iCloud Lock	1	Part 2 BHandset (No Power)	3538
Apple	iPad Mini 6 WiFi (256GB)iCloud Lock	2	Part 2 BHandset (Power Up, Bad LCD)	3539
Apple	iPad Mini 5 WiFi (64GB)iCloud Lock	7	Part 2 BHandset (Power Up, Bad LCD)	3540
Apple	iPad Mini 4 WiFi (128GB)iCloud Lock	3	Part 2 AHandset	3541
Apple	iPad Mini 4 WiFi (16GB)iCloud Lock	2	Part 2 AHandset	3542
Apple	iPad Mini 4 WiFi (128GB)iCloud Lock	2	Part 2 BHandset (Power Up, Good LCD)	3543
Apple	iPad Mini 4 WiFi (16GB)iCloud Lock	1	Part 2 BHandset (Power Up, Good LCD)	3544
Apple	iPad Mini 4 WiFi (64GB)iCloud Lock	1	Part 2 BHandset (Power Up, Good LCD)	3545
Apple	iPad Mini 4 WiFi (128GB)iCloud Lock	7	Part 2 BHandset (Power Up, Bad LCD)	3546
Apple	iPad Mini 4 WiFi (16GB)iCloud Lock	1	Part 2 BHandset (Power Up, Bad LCD)	3547
Apple	iPad Mini 4 WiFi (64GB)iCloud Lock	4	Part 2 BHandset (Power Up, Bad LCD)	3548
Apple	iPad Mini 4 WiFi (128GB)iCloud Lock	1	Part 2 BHandset (No Power)	3549
Apple	iPad Mini 4 WiFi (16GB)iCloud Lock	1	Part 2 BHandset (No Power)	3550
Apple	iPad Mini 4 WiFi 4G (128GB)iCloud Lock	1	Part 2 AHandset	3551
Apple	iPad Mini 4 WiFi 4G (128GB)iCloud Lock	2	Part 2 BHandset (Power Up, Good LCD)	3552
Apple	iPad Mini 4 WiFi 4G (16GB)iCloud Lock	1	Part 2 BHandset (Power Up, Good LCD)	3553
Apple	iPad Mini 4 WiFi 4G (16GB)iCloud Lock	1	Part 2 BHandset (Power Up, Bad LCD)	3554
Apple	iPad Mini 4 WiFi 4G (32GB)iCloud Lock	1	Part 2 BHandset (Power Up, Bad LCD)	3555
Apple	iPad Mini 3 WiFi (16GB)iCloud Lock	1	Part 2 AHandset	3556
Apple	iPad Mini 3 WiFi (16GB)iCloud Lock	4	Part 2 BHandset (Power Up, Good LCD)	3557
Apple	iPad Mini 3 WiFi (64GB)iCloud Lock	2	Part 2 BHandset (Power Up, Good LCD)	3558
Apple	iPad Mini 3 WiFi (16GB)iCloud Lock	1	Part 2 BHandset (Power Up, Bad LCD)	3559
Apple	iPad Mini 3 WiFi (64GB)iCloud Lock	2	Part 2 BHandset (Power Up, Bad LCD)	3560
Apple	iPad Mini 3 WiFi 4G (16GB)iCloud Lock	5	Part 2 AHandset	3561
Apple	iPad Mini 3 WiFi 4G (64GB)iCloud Lock	1	Part 2 AHandset	3562
Apple	iPad Mini 3 WiFi 4G (16GB)iCloud Lock	5	Part 2 BHandset (Power Up, Good LCD)	3563
Apple	iPad Mini 3 WiFi 4G (64GB)iCloud Lock	1	Part 2 BHandset (Power Up, Good LCD)	3564
Apple	iPad Mini 3 WiFi 4G (16GB)iCloud Lock	5	Part 2 BHandset (Power Up, Bad LCD)	3565
Apple	iPad Mini 3 WiFi 4G (16GB)iCloud Lock	1	Part 2 BHandset (No Power)	3566
Apple	iPad Mini 2 WiFi (128GB)iCloud Lock	1	Part 2 AHandset	3567
Apple	iPad Mini 2 WiFi (16GB)iCloud Lock	49	Part 2 AHandset	3568
Apple	iPad Mini 2 WiFi (32GB)iCloud Lock	30	Part 2 AHandset	3569
Apple	iPad Mini 2 WiFi (64GB)iCloud Lock	2	Part 2 AHandset	3570
Apple	iPad Mini 2 WiFi (128GB)iCloud Lock	1	Part 2 BHandset (Power Up, Good LCD)	3571
Apple	iPad Mini 2 WiFi (16GB)iCloud Lock	35	Part 2 BHandset (Power Up, Good LCD)	3572
Apple	iPad Mini 2 WiFi (32GB)iCloud Lock	31	Part 2 BHandset (Power Up, Good LCD)	3573
Apple	iPad Mini 2 WiFi (16GB)iCloud Lock	18	Part 2 BHandset (Power Up, Bad LCD)	3574
Apple	iPad Mini 2 WiFi (32GB)iCloud Lock	12	Part 2 BHandset (Power Up, Bad LCD)	3575
Apple	iPad Mini 2 WiFi (64GB)iCloud Lock	1	Part 2 BHandset (Power Up, Bad LCD)	3576
Apple	iPad Mini 2 WiFi (32GB)iCloud Lock	1	Part 2 BHandset (No Power)	3577
Apple	iPad Mini 2 WiFi (64GB)iCloud Lock	1	Part 2 BHandset (No Power)	3578
Apple	iPad Mini 2 WiFi 4G (16GB)iCloud Lock	9	Part 2 AHandset	3579
Apple	iPad Mini 2 WiFi 4G (32GB)iCloud Lock	3	Part 2 AHandset	3580
Apple	iPad Mini 2 WiFi 4G (128GB)iCloud Lock	1	Part 2 BHandset (Power Up, Good LCD)	3581
Apple	iPad Mini 2 WiFi 4G (16GB)iCloud Lock	5	Part 2 BHandset (Power Up, Good LCD)	3582
Apple	iPad Mini 2 WiFi 4G (32GB)iCloud Lock	3	Part 2 BHandset (Power Up, Good LCD)	3583
Apple	iPad Mini 2 WiFi 4G (64GB)iCloud Lock	1	Part 2 BHandset (Power Up, Good LCD)	3584
Apple	iPad Mini 2 WiFi 4G (16GB)iCloud Lock	10	Part 2 BHandset (Power Up, Bad LCD)	3585
Apple	iPad Mini 2 WiFi 4G (32GB)iCloud Lock	1	Part 2 BHandset (Power Up, Bad LCD)	3586
Apple	iPad Mini WiFi (16GB)iCloud Lock	183	Part 2 BHandset (Power Up, Good LCD)	3587
Apple	iPad Mini WiFi (32GB)iCloud Lock	9	Part 2 BHandset (Power Up, Good LCD)	3588
Apple	iPad Mini WiFi (64GB)iCloud Lock	1	Part 2 BHandset (Power Up, Good LCD)	3589
Apple	iPad Mini WiFi (16GB)iCloud Lock	47	Part 2 BHandset (Power Up, Bad LCD)	3590
Apple	iPad Mini WiFi (32GB)iCloud Lock	6	Part 2 BHandset (Power Up, Bad LCD)	3591
Apple	iPad Mini WiFi (16GB)iCloud Lock	12	Part 2 BHandset (No Power)	3592
Apple	iPad Mini WiFi (32GB)iCloud Lock	1	Part 2 BHandset (No Power)	3593
Apple	iPad Mini WiFi 4G (16GB)iCloud Lock	1	Part 2 AHandset	3594
Apple	iPad Mini WiFi 4G (32GB)iCloud Lock	1	Part 2 AHandset	3595
Apple	iPad Mini WiFi 4G (16GB)iCloud Lock	32	Part 2 BHandset (Power Up, Good LCD)	3596
Apple	iPad Mini WiFi 4G (32GB)iCloud Lock	2	Part 2 BHandset (Power Up, Good LCD)	3597
Apple	iPad Mini WiFi 4G (64GB)iCloud Lock	3	Part 2 BHandset (Power Up, Good LCD)	3598
Apple	iPad Mini WiFi 4G (16GB)iCloud Lock	3	Part 2 BHandset (Power Up, Bad LCD)	3599
Apple	iPad Mini WiFi 4G (64GB)iCloud Lock	1	Part 2 BHandset (Power Up, Bad LCD)	3600
Apple	iPad Mini WiFi 4G (16GB)iCloud Lock	1	Part 2 BHandset (No Power)	3601
Apple	iPad Mini WiFi 4G (32GB)iCloud Lock	1	Part 2 BHandset (No Power)	3602
Apple	iPad Air WiFi (16GB)iCloud Lock	67	Part 2 AHandset	3603
Apple	iPad Air WiFi (32GB)iCloud Lock	3	Part 2 AHandset	3604
Apple	iPad Air WiFi (64GB)iCloud Lock	1	Part 2 AHandset	3605
Apple	iPad Air WiFi (16GB)iCloud Lock	33	Part 2 BHandset (Power Up, Good LCD)	3606
Apple	iPad Air WiFi (32GB)iCloud Lock	19	Part 2 BHandset (Power Up, Good LCD)	3607
Apple	iPad Air WiFi (64GB)iCloud Lock	1	Part 2 BHandset (Power Up, Good LCD)	3608
Apple	iPad Air WiFi (128GB)iCloud Lock	2	Part 2 BHandset (Power Up, Bad LCD)	3609
Apple	iPad Air WiFi (16GB)iCloud Lock	22	Part 2 BHandset (Power Up, Bad LCD)	3610

Apple	iPad Air WiFi (32GB)iCloud Lock	9	Part 2 BHandset (Power Up, Bad LCD)	3611
Apple	iPad Air WiFi (64GB)iCloud Lock	2	Part 2 BHandset (Power Up, Bad LCD)	3612
Apple	iPad Air WiFi (16GB)iCloud Lock	5	Part 2 BHandset (No Power)	3613
Apple	iPad Air WiFi (32GB)iCloud Lock	2	Part 2 BHandset (No Power)	3614
Apple	iPad Air WiFi (64GB)iCloud Lock	1	Part 2 BHandset (No Power)	3615
Apple	iPad Air WiFi 4G (128GB)iCloud Lock	1	Part 2 AHandset	3616
Apple	iPad Air WiFi 4G (16GB)iCloud Lock	7	Part 2 AHandset	3617
Apple	iPad Air WiFi 4G (32GB)iCloud Lock	5	Part 2 AHandset	3618
Apple	iPad Air WiFi 4G (64GB)iCloud Lock	1	Part 2 AHandset	3619
Apple	iPad Air WiFi 4G (16GB)iCloud Lock	13	Part 2 BHandset (Power Up, Good LCD)	3620
Apple	iPad Air WiFi 4G (32GB)iCloud Lock	6	Part 2 BHandset (Power Up, Good LCD)	3621
Apple	iPad Air WiFi 4G (64GB)iCloud Lock	1	Part 2 BHandset (Power Up, Good LCD)	3622
Apple	iPad Air WiFi 4G (16GB)iCloud Lock	8	Part 2 BHandset (Power Up, Bad LCD)	3623
Apple	iPad Air WiFi 4G (32GB)iCloud Lock	2	Part 2 BHandset (Power Up, Bad LCD)	3624
Apple	iPad Air 5 WiFi 5G (256GB)iCloud Lock	2	Part 2 BHandset (Power Up, Bad LCD)	3625
Apple	iPad Air 5 WiFi 5G (64GB)iCloud Lock	1	Part 2 BHandset (Power Up, Bad LCD)	3626
Apple	iPad Air 4 WiFi (64GB)iCloud Lock	1	Part 2 AHandset	3627
Apple	iPad Air 4 WiFi (64GB)iCloud Lock	2	Part 2 BHandset (Power Up, Bad LCD)	3628
Apple	iPad Air 4 WiFi 4G (256GB)iCloud Lock	2	Part 2 BHandset (Power Up, Bad LCD)	3629
Apple	iPad Air 4 WiFi 4G (64GB)iCloud Lock	1	Part 2 BHandset (Power Up, Bad LCD)	3630
Apple	iPad Air 3 WiFi 4G (256GB)iCloud Lock	1	Part 2 BHandset (Power Up, Good LCD)	3631
Apple	iPad Air 3 WiFi 4G (64GB)iCloud Lock	1	Part 2 BHandset (Power Up, Good LCD)	3632
Apple	iPad Air 3 WiFi 4G (256GB)iCloud Lock	1	Part 2 BHandset (Power Up, Bad LCD)	3633
Apple	iPad Air 3 WiFi 4G (64GB)iCloud Lock	1	Part 2 BHandset (Power Up, Bad LCD)	3634
Apple	iPad Air 3 WiFi (256GB)iCloud Lock	1	Part 2 BHandset (Power Up, Good LCD)	3635
Apple	iPad Air 3 WiFi (64GB)iCloud Lock	3	Part 2 BHandset (Power Up, Good LCD)	3636
Apple	iPad Air 3 WiFi (256GB)iCloud Lock	1	Part 2 BHandset (Power Up, Bad LCD)	3637
Apple	iPad Air 3 WiFi (64GB)iCloud Lock	8	Part 2 BHandset (Power Up, Bad LCD)	3638
Apple	iPad Air 2 WiFi (128GB)iCloud Lock	3	Part 2 BHandset (Power Up, Good LCD)	3639
Apple	iPad Air 2 WiFi (16GB)iCloud Lock	2	Part 2 BHandset (Power Up, Good LCD)	3640
Apple	iPad Air 2 WiFi (64GB)iCloud Lock	6	Part 2 BHandset (Power Up, Good LCD)	3641
Apple	iPad Air 2 WiFi (128GB)iCloud Lock	3	Part 2 BHandset (Power Up, Bad LCD)	3642
Apple	iPad Air 2 WiFi (16GB)iCloud Lock	9	Part 2 BHandset (Power Up, Bad LCD)	3643
Apple	iPad Air 2 WiFi (32GB)iCloud Lock	3	Part 2 BHandset (Power Up, Bad LCD)	3644
Apple	iPad Air 2 WiFi (64GB)iCloud Lock	5	Part 2 BHandset (Power Up, Bad LCD)	3645
Apple	iPad Air 2 WiFi (16GB)iCloud Lock	3	Part 2 BHandset (No Power)	3646
Apple	iPad Air 2 WiFi (32GB)iCloud Lock	2	Part 2 BHandset (No Power)	3647
Apple	iPad Air 2 WiFi (64GB)iCloud Lock	1	Part 2 BHandset (No Power)	3648
Apple	iPad Air 2 WiFi 4G (128GB)iCloud Lock	1	Part 2 BHandset (Power Up, Good LCD)	3649
Apple	iPad Air 2 WiFi 4G (16GB)iCloud Lock	1	Part 2 BHandset (Power Up, Good LCD)	3650
Apple	iPad Air 2 WiFi 4G (64GB)iCloud Lock	2	Part 2 BHandset (Power Up, Good LCD)	3651
Apple	iPad Air 2 WiFi 4G (128GB)iCloud Lock	3	Part 2 BHandset (Power Up, Bad LCD)	3652
Apple	iPad Air 2 WiFi 4G (16GB)iCloud Lock	12	Part 2 BHandset (Power Up, Bad LCD)	3653
Apple	iPad Air 2 WiFi 4G (32GB)iCloud Lock	3	Part 2 BHandset (Power Up, Bad LCD)	3654
Apple	iPad Air 2 WiFi 4G (64GB)iCloud Lock	3	Part 2 BHandset (Power Up, Bad LCD)	3655
Apple	iPad Air 2 WiFi 4G (16GB)iCloud Lock	2	Part 2 BHandset (No Power)	3656
Apple	iPad Air 2 WiFi 4G (64GB)iCloud Lock	1	Part 2 BHandset (No Power)	3657
Apple	iPad 7 WiFi 4G (32GB)iCloud Lock	3	Part 2 BHandset (Power Up, Bad LCD)	3658
Apple	iPad 10 WiFi (64GB)iCloud Lock	2	Part 2 BHandset (Power Up, Bad LCD)	3659
Apple	iPad 10 WiFi 5G (64GB)iCloud Lock	5	Part 2 BHandset (Power Up, Bad LCD)	3660
Apple	iPad 9 WiFi (64GB)iCloud Lock	2	Part 2 AHandset	3661
Apple	iPad 9 WiFi (64GB)iCloud Lock	4	Part 2 BHandset (Power Up, Good LCD)	3662
Apple	iPad 9 WiFi (64GB)iCloud Lock	16	Part 2 BHandset (Power Up, Bad LCD)	3663
Apple	iPad 9 WiFi (64GB)iCloud Lock	3	Part 2 BHandset (No Power)	3664
Apple	iPad 9 WiFi 4G (256GB)iCloud Lock	1	Part 2 BHandset (Power Up, Bad LCD)	3665
Apple	iPad 9 WiFi 4G (64GB)iCloud Lock	13	Part 2 BHandset (Power Up, Bad LCD)	3666
Apple	iPad 8 WiFi (128GB)iCloud Lock	2	Part 2 AHandset	3667
Apple	iPad 8 WiFi (32GB)iCloud Lock	5	Part 2 AHandset	3668
Apple	iPad 8 WiFi (128GB)iCloud Lock	1	Part 2 BHandset (Power Up, Good LCD)	3669
Apple	iPad 8 WiFi (32GB)iCloud Lock	1	Part 2 BHandset (Power Up, Good LCD)	3670
Apple	iPad 8 WiFi (32GB)iCloud Lock	3	Part 2 BHandset (Power Up, Bad LCD)	3671
Apple	iPad 8 WiFi 4G (32GB)iCloud Lock	2	Part 2 AHandset	3672
Apple	iPad 8 WiFi 4G (32GB)iCloud Lock	1	Part 2 BHandset (Power Up, Bad LCD)	3673
Apple	iPad 7 WiFi (32GB)iCloud Lock	3	Part 2 BHandset (Power Up, Good LCD)	3674
Apple	iPad 7 WiFi (32GB)iCloud Lock	2	Part 2 BHandset (Power Up, Bad LCD)	3675
Apple	iPad 6 WiFi 4G (32GB)iCloud Lock	7	Part 2 AHandset	3676
Apple	iPad 6 WiFi 4G (128GB)iCloud Lock	2	Part 2 BHandset (Power Up, Bad LCD)	3677
Apple	iPad 6 WiFi 4G (32GB)iCloud Lock	2	Part 2 BHandset (Power Up, Bad LCD)	3678
Apple	iPad 6 WiFi (128GB)iCloud Lock	1	Part 2 BHandset (Power Up, Good LCD)	3679
Apple	iPad 6 WiFi (32GB)iCloud Lock	1	Part 2 BHandset (Power Up, Good LCD)	3680
Apple	iPad 6 WiFi (128GB)iCloud Lock	1	Part 2 BHandset (Power Up, Bad LCD)	3681
Apple	iPad 6 WiFi (32GB)iCloud Lock	7	Part 2 BHandset (Power Up, Bad LCD)	3682
Apple	iPad 6 WiFi (32GB)iCloud Lock	3	Part 2 BHandset (No Power)	3683
Apple	iPad 5 WiFi (128GB)iCloud Lock	1	Part 2 BHandset (Power Up, Good LCD)	3684
Apple	iPad 5 WiFi (32GB)iCloud Lock	6	Part 2 BHandset (Power Up, Good LCD)	3685
Apple	iPad 5 WiFi (32GB)iCloud Lock	10	Part 2 BHandset (Power Up, Bad LCD)	3686
Apple	iPad 5 WiFi (32GB)iCloud Lock	2	Part 2 BHandset (No Power)	3687
Apple	iPad 5 WiFi 4G (128GB)iCloud Lock	3	Part 2 AHandset	3688
Apple	iPad 5 WiFi 4G (32GB)iCloud Lock	2	Part 2 AHandset	3689
Apple	iPad 5 WiFi 4G (32GB)iCloud Lock	3	Part 2 BHandset (Power Up, Good LCD)	3690
Apple	iPad 5 WiFi 4G (128GB)iCloud Lock	2	Part 2 BHandset (Power Up, Bad LCD)	3691
Apple	iPad 5 WiFi 4G (32GB)iCloud Lock	2	Part 2 BHandset (Power Up, Bad LCD)	3692
Apple	iPad 5 WiFi 4G (32GB)iCloud Lock	2	Part 2 BHandset (No Power)	3693
Apple	iPad 4 WiFi (128GB)iCloud Lock	1	Part 2 BHandset (Power Up, Good LCD)	3694
Apple	iPad 4 WiFi (16GB)iCloud Lock	112	Part 2 BHandset (Power Up, Good LCD)	3695
Apple	iPad 4 WiFi (32GB)iCloud Lock	33	Part 2 BHandset (Power Up, Good LCD)	3696

Apple	iPad 4 WiFi (64GB)iCloud Lock	6	Part 2 BHandset (Power Up, Good LCD)	3697
Apple	iPad 4 WiFi (16GB)iCloud Lock	14	Part 2 BHandset (Power Up, Bad LCD)	3698
Apple	iPad 4 WiFi (32GB)iCloud Lock	7	Part 2 BHandset (Power Up, Bad LCD)	3699
Apple	iPad 4 WiFi (16GB)iCloud Lock	4	Part 2 BHandset (No Power)	3700
Apple	iPad 4 WiFi (64GB)iCloud Lock	1	Part 2 BHandset (No Power)	3701
Apple	iPad 4 WiFi 4G (16GB)iCloud Lock	1	Part 2 AHandset	3702
Apple	iPad 4 WiFi 4G (16GB)iCloud Lock	6	Part 2 BHandset (Power Up, Good LCD)	3703
Apple	iPad 4 WiFi 4G (32GB)iCloud Lock	7	Part 2 BHandset (Power Up, Good LCD)	3704
Apple	iPad 4 WiFi 4G (64GB)iCloud Lock	2	Part 2 BHandset (Power Up, Good LCD)	3705
Apple	iPad 4 WiFi 4G (16GB)iCloud Lock	3	Part 2 BHandset (Power Up, Bad LCD)	3706
Apple	iPad 4 WiFi 4G (64GB)iCloud Lock	1	Part 2 BHandset (Power Up, Bad LCD)	3707
Apple	iPad 4 WiFi 4G (32GB)iCloud Lock	1	Part 2 BHandset (No Power)	3708
Apple	iPad 2 WiFi (16GB)iCloud Lock	116	Part 2 BHandset (Power Up, Good LCD)	3709
Apple	iPad 2 WiFi (32GB)iCloud Lock	15	Part 2 BHandset (Power Up, Good LCD)	3710
Apple	iPad 2 WiFi (64GB)iCloud Lock	12	Part 2 BHandset (Power Up, Good LCD)	3711
Apple	iPad 2 WiFi (16GB)iCloud Lock	60	Part 2 BHandset (Power Up, Bad LCD)	3712
Apple	iPad 2 WiFi (32GB)iCloud Lock	6	Part 2 BHandset (Power Up, Bad LCD)	3713
Apple	iPad 2 WiFi (64GB)iCloud Lock	2	Part 2 BHandset (Power Up, Bad LCD)	3714
Apple	iPad 2 WiFi (16GB)iCloud Lock	5	Part 2 BHandset (No Power)	3715
Apple	iPad 2 WiFi (32GB)iCloud Lock	2	Part 2 BHandset (No Power)	3716
Apple	iPad 2 WiFi 3G (16GB)iCloud Lock	14	Part 2 BHandset (Power Up, Good LCD)	3717
Apple	iPad 2 WiFi 3G (32GB)iCloud Lock	7	Part 2 BHandset (Power Up, Good LCD)	3718
Apple	iPad 2 WiFi 3G (64GB)iCloud Lock	7	Part 2 BHandset (Power Up, Good LCD)	3719
Apple	iPad 2 WiFi 3G (16GB)iCloud Lock	7	Part 2 BHandset (Power Up, Bad LCD)	3720
Apple	iPad 2 WiFi 3G (32GB)iCloud Lock	3	Part 2 BHandset (Power Up, Bad LCD)	3721
Apple	iPad 2 WiFi 3G (64GB)iCloud Lock	4	Part 2 BHandset (Power Up, Bad LCD)	3722
Apple	iPad Total	1229	Summary	3723
Apple	iPad 10 WiFi 5G (64GB)	1	14A	3724
Apple	iPad 10 WiFi 5G (64GB)	1	BHandset (Power Up, Good LCD)	3725
Apple	iPad 10 WiFi 5G (256GB)	1	BHandset (Power Up, Bad LCD)	3726
Apple	iPad 10 WiFi 5G (64GB)	7	BHandset (Power Up, Bad LCD)	3727
Apple	iPad 10 WiFi (64GB)	2	BHandset (Power Up, Bad LCD)	3728
Apple	iPad 9 WiFi 4G (256GB)	1	14A	3729
Apple	iPad 9 WiFi 4G (64GB)	1	AHandset	3730
Apple	iPad 9 WiFi 4G (256GB)	1	BHandset (Power Up, Good LCD)	3731
Apple	iPad 9 WiFi 4G (64GB)	1	BHandset (Power Up, Good LCD)	3732
Apple	iPad 9 WiFi 4G (256GB)	1	BHandset (Power Up, Bad LCD)	3733
Apple	iPad 9 WiFi 4G (64GB)	3	BHandset (Power Up, Bad LCD)	3734
Apple	iPad 9 WiFi (64GB)	5	BHandset (Power Up, Bad LCD)	3735
Apple	iPad 8 WiFi 4G (128GB)	1	14A	3736
Apple	iPad 8 WiFi 4G (32GB)	1	BHandset (Power Up, Bad LCD)	3737
Apple	iPad 8 WiFi (32GB)	2	AHandset	3738
Apple	iPad 8 WiFi (32GB)	2	BHandset (Power Up, Bad LCD)	3739
Apple	iPad 8 WiFi (32GB)	1	BHandset (No Power)	3740
Apple	iPad 7 WiFi 4G (128GB)	1	BHandset (Power Up, Good LCD)	3741
Apple	iPad 7 WiFi 4G (32GB)	1	BHandset (Power Up, Bad LCD)	3742
Apple	iPad 7 WiFi 4G (32GB)	2	BHandset (No Power)	3743
Apple	iPad 7 WiFi (32GB)	1	AHandset	3744
Apple	iPad 7 WiFi (128GB)	1	BHandset (Power Up, Bad LCD)	3745
Apple	iPad 7 WiFi (32GB)	4	BHandset (Power Up, Bad LCD)	3746
Apple	iPad 7 WiFi (128GB)	2	BHandset (No Power)	3747
Apple	iPad 7 WiFi (32GB)	1	BHandset (No Power)	3748
Apple	iPad 6 WiFi 4G (32GB)	1	BHandset (No Power)	3749
Apple	iPad 6 WiFi (128GB)	2	AHandset	3750
Apple	iPad 6 WiFi (32GB)	8	AHandset	3751
Apple	iPad 6 WiFi (32GB)	5	BHandset (Power Up, Bad LCD)	3752
Apple	iPad 6 WiFi (32GB)	2	BHandset (No Power)	3753
Apple	iPad 5 WiFi 4G (32GB)	5	AHandset	3754
Apple	iPad 5 WiFi 4G (32GB)	12	BHandset (Power Up, Bad LCD)	3755
Apple	iPad 5 WiFi 4G (32GB)	1	BHandset (No Power)	3756
Apple	iPad 5 WiFi 4G (32GB)	1	Mainboard	3757
Apple	iPad 5 WiFi (32GB)	3	AHandset	3758
Apple	iPad 5 WiFi (128GB)	1	BHandset (Power Up, Bad LCD)	3759
Apple	iPad 5 WiFi (32GB)	19	BHandset (Power Up, Bad LCD)	3760
Apple	iPad 5 WiFi (32GB)	4	BHandset (No Power)	3761
Apple	iPad 4 WiFi 4G (16GB)	1	AHandset	3762
Apple	iPad 4 WiFi 4G (16GB)	20	BHandset (Power Up, Good LCD)	3763
Apple	iPad 4 WiFi 4G (32GB)	4	BHandset (Power Up, Good LCD)	3764
Apple	iPad 4 WiFi 4G (64GB)	2	BHandset (Power Up, Good LCD)	3765
Apple	iPad 4 WiFi 4G (16GB)	11	BHandset (Power Up, Bad LCD)	3766
Apple	iPad 4 WiFi 4G (16GB)	5	BHandset (No Power)	3767
Apple	iPad 4 WiFi 4G (32GB)	3	BHandset (No Power)	3768
Apple	iPad 4 WiFi (16GB)	32	BHandset (Power Up, Good LCD)	3769
Apple	iPad 4 WiFi (32GB)	3	BHandset (Power Up, Good LCD)	3770
Apple	iPad 4 WiFi (128GB)	1	BHandset (Power Up, Bad LCD)	3771
Apple	iPad 4 WiFi (16GB)	10	BHandset (Power Up, Bad LCD)	3772
Apple	iPad 4 WiFi (32GB)	2	BHandset (Power Up, Bad LCD)	3773
Apple	iPad 4 WiFi (64GB)	1	BHandset (Power Up, Bad LCD)	3774
Apple	iPad 4 WiFi (16GB)	4	BHandset (No Power)	3775
Apple	iPad 2 WiFi 3G (32GB)	1	AHandset	3776
Apple	iPad 2 WiFi 3G (16GB)	7	BHandset (Power Up, Good LCD)	3777
Apple	iPad 2 WiFi 3G (32GB)	3	BHandset (Power Up, Good LCD)	3778
Apple	iPad 2 WiFi 3G (16GB)	1	BHandset (Power Up, Bad LCD)	3779
Apple	iPad 2 WiFi 3G (16GB)	2	BHandset (No Power)	3780
Apple	iPad 2 WiFi (16GB)	2	AHandset	3781
Apple	iPad 2 WiFi (16GB)	48	BHandset (Power Up, Good LCD)	3782

Apple	iPad 2 WiFi (32GB)	6	BHandset (Power Up, Good LCD)	3783
Apple	iPad 2 WiFi (64GB)	6	BHandset (Power Up, Good LCD)	3784
Apple	iPad 2 WiFi (16GB)	24	BHandset (Power Up, Bad LCD)	3785
Apple	iPad 2 WiFi (32GB)	2	BHandset (Power Up, Bad LCD)	3786
Apple	iPad 2 WiFi (64GB)	2	BHandset (Power Up, Bad LCD)	3787
Apple	iPad 2 WiFi (16GB)	4	BHandset (No Power)	3788
Apple	iPad 2 WiFi (16GB)	2	Mainboard	3789
Apple	iPad Air 6 WiFi 5G (256GB)	2	BHandset (Power Up, Bad LCD)	3790
Apple	iPad Air 5 WiFi 5G (64GB)	2	BHandset (Power Up, Good LCD)	3791
Apple	iPad Air 5 WiFi 5G (64GB)	1	BHandset (Power Up, Bad LCD)	3792
Apple	iPad Air 4 WiFi 4G (64GB)	1	14A	3793
Apple	iPad Air 4 WiFi 4G (64GB)	1	BHandset (Power Up, Bad LCD)	3794
Apple	iPad Air 4 WiFi (64GB)	2	BHandset (Power Up, Bad LCD)	3795
Apple	iPad Air 3 WiFi 4G (64GB)	16	AHandset	3796
Apple	iPad Air 3 WiFi 4G (64GB)	1	BHandset (Power Up, Bad LCD)	3797
Apple	iPad Air 3 WiFi (64GB)	6	BHandset (Power Up, Bad LCD)	3798
Apple	iPad Air 3 WiFi (64GB)	1	BHandset (No Power)	3799
Apple	iPad Air 2 WiFi 4G (16GB)	6	BHandset (Power Up, Good LCD)	3800
Apple	iPad Air 2 WiFi 4G (64GB)	1	BHandset (Power Up, Good LCD)	3801
Apple	iPad Air 2 WiFi 4G (128GB)	1	BHandset (Power Up, Bad LCD)	3802
Apple	iPad Air 2 WiFi 4G (16GB)	19	BHandset (Power Up, Bad LCD)	3803
Apple	iPad Air 2 WiFi 4G (32GB)	2	BHandset (Power Up, Bad LCD)	3804
Apple	iPad Air 2 WiFi 4G (64GB)	3	BHandset (Power Up, Bad LCD)	3805
Apple	iPad Air 2 WiFi 4G (16GB)	1	BHandset (No Power)	3806
Apple	iPad Air 2 WiFi (128GB)	1	AHandset	3807
Apple	iPad Air 2 WiFi (32GB)	1	AHandset	3808
Apple	iPad Air 2 WiFi (64GB)	2	AHandset	3809
Apple	iPad Air 2 WiFi (128GB)	3	BHandset (Power Up, Good LCD)	3810
Apple	iPad Air 2 WiFi (16GB)	7	BHandset (Power Up, Good LCD)	3811
Apple	iPad Air 2 WiFi (32GB)	9	BHandset (Power Up, Good LCD)	3812
Apple	iPad Air 2 WiFi (64GB)	11	BHandset (Power Up, Good LCD)	3813
Apple	iPad Air 2 WiFi (128GB)	3	BHandset (Power Up, Bad LCD)	3814
Apple	iPad Air 2 WiFi (16GB)	5	BHandset (Power Up, Bad LCD)	3815
Apple	iPad Air 2 WiFi (32GB)	2	BHandset (Power Up, Bad LCD)	3816
Apple	iPad Air 2 WiFi (64GB)	1	BHandset (Power Up, Bad LCD)	3817
Apple	iPad Air 2 WiFi (16GB)	1	BHandset (No Power)	3818
Apple	iPad Air 2 WiFi (32GB)	2	BHandset (No Power)	3819
Apple	iPad Air 2 WiFi (16GB)	2	Mainboard	3820
Apple	iPad Air WiFi 4G (64GB)	1	BHandset (Power Up, Good LCD)	3821
Apple	iPad Air WiFi 4G (128GB)	1	BHandset (Power Up, Bad LCD)	3822
Apple	iPad Air WiFi 4G (16GB)	9	BHandset (Power Up, Bad LCD)	3823
Apple	iPad Air WiFi 4G (32GB)	1	BHandset (Power Up, Bad LCD)	3824
Apple	iPad Air WiFi 4G (16GB)	5	BHandset (No Power)	3825
Apple	iPad Air WiFi (128GB)	2	BHandset (Power Up, Good LCD)	3826
Apple	iPad Air WiFi (16GB)	62	BHandset (Power Up, Good LCD)	3827
Apple	iPad Air WiFi (32GB)	16	BHandset (Power Up, Good LCD)	3828
Apple	iPad Air WiFi (64GB)	6	BHandset (Power Up, Good LCD)	3829
Apple	iPad Air WiFi (16GB)	12	BHandset (Power Up, Bad LCD)	3830
Apple	iPad Air WiFi (32GB)	3	BHandset (Power Up, Bad LCD)	3831
Apple	iPad Air WiFi (16GB)	14	BHandset (No Power)	3832
Apple	iPad Air WiFi (32GB)	4	BHandset (No Power)	3833
Apple	iPad Mini 6 WiFi 5G (64GB)	1	14A	3834
Apple	iPad Mini 6 WiFi 5G (256GB)	1	BHandset (Power Up, Bad LCD)	3835
Apple	iPad Mini 6 WiFi 5G (64GB)	1	BHandset (Power Up, Bad LCD)	3836
Apple	iPad Mini 6 WiFi (64GB)	1	BHandset (Power Up, Bad LCD)	3837
Apple	iPad Mini 5 WiFi 4G (256GB)	2	AHandset	3838
Apple	iPad Mini 5 WiFi 4G (64GB)	2	BHandset (Power Up, Bad LCD)	3839
Apple	iPad Mini 5 WiFi 4G (64GB)	1	BHandset (No Power)	3840
Apple	iPad Mini 5 WiFi (64GB)	8	BHandset (Power Up, Bad LCD)	3841
Apple	iPad Mini 4 WiFi 4G (128GB)	2	AHandset	3842
Apple	iPad Mini 4 WiFi 4G (64GB)	1	BHandset (Power Up, Good LCD)	3843
Apple	iPad Mini 4 WiFi 4G (128GB)	3	BHandset (Power Up, Bad LCD)	3844
Apple	iPad Mini 4 WiFi 4G (16GB)	19	BHandset (Power Up, Bad LCD)	3845
Apple	iPad Mini 4 WiFi 4G (32GB)	4	BHandset (Power Up, Bad LCD)	3846
Apple	iPad Mini 4 WiFi 4G (64GB)	3	BHandset (Power Up, Bad LCD)	3847
Apple	iPad Mini 4 WiFi 4G (128GB)	3	BHandset (No Power)	3848
Apple	iPad Mini 4 WiFi 4G (16GB)	14	BHandset (No Power)	3849
Apple	iPad Mini 4 WiFi 4G (32GB)	2	BHandset (No Power)	3850
Apple	iPad Mini 4 WiFi (32GB)	2	AHandset	3851
Apple	iPad Mini 4 WiFi (128GB)	10	BHandset (Power Up, Good LCD)	3852
Apple	iPad Mini 4 WiFi (16GB)	1	BHandset (Power Up, Good LCD)	3853
Apple	iPad Mini 4 WiFi (32GB)	2	BHandset (Power Up, Good LCD)	3854
Apple	iPad Mini 4 WiFi (64GB)	1	BHandset (Power Up, Good LCD)	3855
Apple	iPad Mini 4 WiFi (128GB)	3	BHandset (Power Up, Bad LCD)	3856
Apple	iPad Mini 4 WiFi (16GB)	9	BHandset (Power Up, Bad LCD)	3857
Apple	iPad Mini 4 WiFi (32GB)	3	BHandset (Power Up, Bad LCD)	3858
Apple	iPad Mini 4 WiFi (64GB)	2	BHandset (Power Up, Bad LCD)	3859
Apple	iPad Mini 4 WiFi (128GB)	5	BHandset (No Power)	3860
Apple	iPad Mini 4 WiFi (64GB)	2	BHandset (No Power)	3861
Apple	iPad Mini 3 WiFi 4G (128GB)	1	BHandset (Power Up, Bad LCD)	3862
Apple	iPad Mini 3 WiFi 4G (16GB)	1	BHandset (Power Up, Bad LCD)	3863
Apple	iPad Mini 3 WiFi (128GB)	1	BHandset (Power Up, Good LCD)	3864
Apple	iPad Mini 3 WiFi (16GB)	6	BHandset (Power Up, Bad LCD)	3865
Apple	iPad Mini 3 WiFi (64GB)	1	BHandset (Power Up, Bad LCD)	3866
Apple	iPad Mini 3 WiFi (16GB)	2	BHandset (No Power)	3867
Apple	iPad Mini 3 WiFi (64GB)	2	BHandset (No Power)	3868

Apple	iPad Mini 2 WiFi 4G (16GB)	1	AHandset	3869
Apple	iPad Mini 2 WiFi 4G (16GB)	2	BHandset (Power Up, Good LCD)	3870
Apple	iPad Mini 2 WiFi 4G (32GB)	5	BHandset (Power Up, Good LCD)	3871
Apple	iPad Mini 2 WiFi 4G (16GB)	9	BHandset (Power Up, Bad LCD)	3872
Apple	iPad Mini 2 WiFi 4G (32GB)	1	BHandset (Power Up, Bad LCD)	3873
Apple	iPad Mini 2 WiFi 4G (16GB)	2	BHandset (No Power)	3874
Apple	iPad Mini 2 WiFi (16GB)	10	AHandset	3875
Apple	iPad Mini 2 WiFi (32GB)	13	AHandset	3876
Apple	iPad Mini 2 WiFi (16GB)	17	BHandset (Power Up, Good LCD)	3877
Apple	iPad Mini 2 WiFi (32GB)	12	BHandset (Power Up, Good LCD)	3878
Apple	iPad Mini 2 WiFi (64GB)	1	BHandset (Power Up, Good LCD)	3879
Apple	iPad Mini 2 WiFi (16GB)	9	BHandset (Power Up, Bad LCD)	3880
Apple	iPad Mini 2 WiFi (32GB)	2	BHandset (Power Up, Bad LCD)	3881
Apple	iPad Mini 2 WiFi (16GB)	7	BHandset (No Power)	3882
Apple	iPad Mini 2 WiFi (32GB)	1	BHandset (No Power)	3883
Apple	iPad Mini 2 WiFi (64GB)	2	BHandset (No Power)	3884
Apple	iPad Mini 2 WiFi (16GB)	1	Mainboard	3885
Apple	iPad Mini WiFi 4G (16GB)	1	AHandset	3886
Apple	iPad Mini WiFi 4G (32GB)	1	AHandset	3887
Apple	iPad Mini WiFi 4G (16GB)	8	BHandset (Power Up, Good LCD)	3888
Apple	iPad Mini WiFi 4G (32GB)	1	BHandset (Power Up, Good LCD)	3889
Apple	iPad Mini WiFi 4G (16GB)	4	BHandset (Power Up, Bad LCD)	3890
Apple	iPad Mini WiFi 4G (16GB)	7	BHandset (No Power)	3891
Apple	iPad Mini WiFi 4G (16GB)	1	Mainboard	3892
Apple	iPad Mini WiFi (16GB)	36	AHandset	3893
Apple	iPad Mini WiFi (16GB)	42	BHandset (Power Up, Good LCD)	3894
Apple	iPad Mini WiFi (32GB)	4	BHandset (Power Up, Good LCD)	3895
Apple	iPad Mini WiFi (16GB)	32	BHandset (Power Up, Bad LCD)	3896
Apple	iPad Mini WiFi (32GB)	3	BHandset (Power Up, Bad LCD)	3897
Apple	iPad Mini WiFi (16GB)	23	BHandset (No Power)	3898
Apple	iPad Mini WiFi (32GB)	6	BHandset (No Power)	3899
Apple	iPad Pro 6 WiFi 5G (256GB)	2	BHandset (Power Up, Bad LCD)	3900
Apple	iPad Pro 6 11 WiFi 5G (256GB)	1	14A	3901
Apple	iPad Pro 6 11 WiFi 5G (128GB)	1	BHandset (Power Up, Good LCD)	3902
Apple	iPad Pro 6 11 WiFi 5G (128GB)	1	BHandset (Power Up, Bad LCD)	3903
Apple	iPad Pro 5 WiFi 5G (128GB)	1	BHandset (Power Up, Good LCD)	3904
Apple	iPad Pro 5 11 WiFi 5G (128GB)	1	14A	3905
Apple	iPad Pro 5 11 WiFi 5G (128GB)	1	BHandset (Power Up, Good LCD)	3906
Apple	iPad Pro 5 11 WiFi 5G (256GB)	1	BHandset (Power Up, Good LCD)	3907
Apple	iPad Pro 4 WiFi 4G (128GB)	1	BHandset (Power Up, Bad LCD)	3908
Apple	iPad Pro 2 WiFi 4G (256GB)	1	BHandset (Power Up, Bad LCD)	3909
Apple	iPad Pro 2 WiFi (256GB)	1	BHandset (Power Up, Bad LCD)	3910
Apple	iPad Pro 2 WiFi (512GB)	2	BHandset (Power Up, Bad LCD)	3911
Apple	iPad Pro 2 WiFi (64GB)	5	BHandset (Power Up, Bad LCD)	3912
Apple	iPad Pro 10.5 WiFi (64GB)	2	AHandset	3913
Apple	iPad Pro 10.5 WiFi (256GB)	3	BHandset (Power Up, Bad LCD)	3914
Apple	iPad Pro 10.5 WiFi (256GB)	1	BHandset (No Power)	3915
Apple	iPad Pro 10.5 WiFi 4G (256GB)	1	BHandset (Power Up, Good LCD)	3916
Apple	iPad Pro 10.5 WiFi 4G (64GB)	3	BHandset (Power Up, Bad LCD)	3917
Apple	iPad Pro 9.7 WiFi (32GB)	1	AHandset	3918
Apple	iPad Pro 9.7 WiFi (128GB)	1	BHandset (Power Up, Good LCD)	3919
Apple	iPad Pro 9.7 WiFi (128GB)	2	BHandset (Power Up, Bad LCD)	3920
Apple	iPad Pro 9.7 WiFi (256GB)	1	BHandset (Power Up, Bad LCD)	3921
Apple	iPad Pro 9.7 WiFi (32GB)	4	BHandset (Power Up, Bad LCD)	3922
Apple	iPad Pro 9.7 WiFi 4G (128GB)	4	BHandset (Power Up, Good LCD)	3923
Apple	iPad Pro 9.7 WiFi 4G (32GB)	2	BHandset (Power Up, Good LCD)	3924
Apple	iPad Pro 9.7 WiFi 4G (128GB)	3	BHandset (Power Up, Bad LCD)	3925
Apple	iPad Pro 9.7 WiFi 4G (32GB)	10	BHandset (Power Up, Bad LCD)	3926
Apple	iPad Pro 9.7 WiFi 4G (32GB)	1	BHandset (No Power)	3927
Apple	iPad Pro 9.7 WiFi 4G (32GB)	3	Mainboard	3928
Apple	iPad Pro WiFi (128GB)	2	BHandset (Power Up, Bad LCD)	3929
Apple	iPad Pro WiFi (32GB)	3	BHandset (Power Up, Bad LCD)	3930
Apple	iPad Pro WiFi 4G (128GB)	2	BHandset (Power Up, Good LCD)	3931
Apple	iPad Pro WiFi 4G (128GB)	2	BHandset (Power Up, Bad LCD)	3932
Apple	iPad WiFi (16GB)	11	AHandset	3933
Apple	iPad WiFi (32GB)	1	AHandset	3934
Apple	iPad WiFi (16GB)	2	BHandset (Power Up, Good LCD)	3935
Apple	iPad WiFi (32GB)	1	BHandset (Power Up, Good LCD)	3936
Apple	iPad WiFi (64GB)	1	BHandset (Power Up, Good LCD)	3937
Apple	iPad WiFi (16GB)	5	BHandset (Power Up, Bad LCD)	3938
Apple	iPad WiFi (32GB)	7	BHandset (Power Up, Bad LCD)	3939
Apple	iPad WiFi (64GB)	6	BHandset (Power Up, Bad LCD)	3940
Apple	iPad WiFi (32GB)	2	BHandset (No Power)	3941
Apple	iPad WiFi (64GB)	8	BHandset (No Power)	3942
Apple	iPad WiFi (16GB)	8	Mainboard	3943
Apple	iPad WiFi (64GB)	1	Mainboard	3944
Apple	iPad WiFi 3G (16GB)	6	AHandset	3945
Apple	iPad WiFi 3G (32GB)	9	AHandset	3946
Apple	iPad WiFi 3G (64GB)	11	AHandset	3947
Apple	iPad WiFi 3G (16GB)	4	BHandset (Power Up, Bad LCD)	3948
Apple	iPad WiFi 3G (32GB)	3	BHandset (Power Up, Bad LCD)	3949
Apple	iPad WiFi 3G (64GB)	4	BHandset (Power Up, Bad LCD)	3950
Apple	iPad WiFi 3G (16GB)	2	BHandset (No Power)	3951
Apple	iPad WiFi 3G (64GB)	2	BHandset (No Power)	3952
Apple	The New iPad WiFi (16GB)	17	AHandset	3953
Apple	The New iPad WiFi (32GB)	2	AHandset	3954

Apple	The New iPad WiFi (64GB)	2	AHandset	3955
Apple	The New iPad WiFi (16GB)	16	BHandset (Power Up, Good LCD)	3956
Apple	The New iPad WiFi (32GB)	10	BHandset (Power Up, Good LCD)	3957
Apple	The New iPad WiFi (64GB)	2	BHandset (Power Up, Good LCD)	3958
Apple	The New iPad WiFi (16GB)	5	BHandset (Power Up, Bad LCD)	3959
Apple	The New iPad WiFi (32GB)	2	BHandset (Power Up, Bad LCD)	3960
Apple	The New iPad WiFi (64GB)	1	BHandset (Power Up, Bad LCD)	3961
Apple	The New iPad WiFi (16GB)	4	BHandset (No Power)	3962
Apple	The New iPad WiFi (32GB)	2	BHandset (No Power)	3963
Apple	The New iPad WiFi (16GB)	1	Mainboard	3964
Apple	The New iPad WiFi 4G (16GB)	4	AHandset	3965
Apple	The New iPad WiFi 4G (32GB)	8	AHandset	3966
Apple	The New iPad WiFi 4G (64GB)	9	AHandset	3967
Apple	The New iPad WiFi 4G (16GB)	4	BHandset (Power Up, Good LCD)	3968
Apple	The New iPad WiFi 4G (32GB)	1	BHandset (Power Up, Good LCD)	3969
Apple	The New iPad WiFi 4G (64GB)	1	BHandset (Power Up, Good LCD)	3970
Apple	The New iPad WiFi 4G (16GB)	2	BHandset (Power Up, Bad LCD)	3971
Apple	The New iPad WiFi 4G (32GB)	4	BHandset (Power Up, Bad LCD)	3972
Apple	The New iPad WiFi 4G (64GB)	1	BHandset (Power Up, Bad LCD)	3973
Apple	The New iPad WiFi 4G (16GB)	4	BHandset (No Power)	3974
Apple	The New iPad WiFi 4G (32GB)	4	BHandset (No Power)	3975
Apple	The New iPad WiFi 4G (64GB)	2	BHandset (No Power)	3976
Apple	The New iPad WiFi 4G (16GB)	1	Mainboard	3977
Apple	iPhone 3GS (16GB)	133	BHandset	3978
Apple	iPhone 3GS (32GB)	53	BHandset	3979
Apple	iPhone 3GS (8GB)	121	BHandset	3980
Apple	iPhone 3GS (16GB)	4	BHandset (Power Up, Bad LCD) (No Power)	3981
Apple	iPhone 3GS (32GB)	4	BHandset (Power Up, Bad LCD) (No Power)	3982
Apple	iPhone 3GS (8GB)	9	BHandset (Power Up, Bad LCD) (No Power)	3983
Apple	iPhone 3G (16GB)	38	BHandset	3984
Apple	iPhone 3G (8GB)	73	BHandset	3985
Apple	iPhone 3G (16GB)	5	BHandset (Power Up, Bad LCD) (No Power)	3986
Apple	iPhone 3G (8GB)	3	BHandset (Power Up, Bad LCD) (No Power)	3987
Apple	iPod Touch III (60GB)	1	BHandset	3988
Apple	iPod Touch III (40GB)	1	BHandset	3989
Apple	iPod Touch III (30GB)	1	BHandset	3990
Apple	iPod Touch III (32GB)	15	BHandset	3991
Apple	iPod Touch III (64GB)	4	BHandset	3992
Apple	iPod Touch II (16GB)	11	BHandset	3993
Apple	iPod Touch II (32GB)	6	BHandset	3994
Apple	iPod Touch II (8GB)	67	BHandset	3995
Apple	iPod Touch II (16GB)	1	BHandset (Power Up, Bad LCD) (No Power)	3996
Apple	iPod Touch II (8GB)	1	BHandset (Power Up, Bad LCD) (No Power)	3997
Apple	iPod Touch 6 (16GB)	15	BHandset	3998
Apple	iPod Touch 6 (32GB)	8	BHandset	3999
Apple	iPod Touch 6 (64GB)	2	BHandset	4000
Apple	iPod Touch 6 (16GB)	1	BHandset (Power Up, Bad LCD) (No Power)	4001
Apple	iPod Touch 6 (32GB)	1	BHandset (Power Up, Bad LCD) (No Power)	4002
Apple	iPod Touch 5 (16GB)	17	BHandset	4003
Apple	iPod Touch 5 (32GB)	10	BHandset	4004
Apple	iPod Touch 5 (16GB)	1	BHandset (Power Up, Bad LCD) (No Power)	4005
Apple	iPod Touch 4 (16GB)	26	BHandset	4006
Apple	iPod Touch 4 (32GB)	37	BHandset	4007
Apple	iPod Touch 4 (64GB)	4	BHandset	4008
Apple	iPod Touch 4 (8GB)	98	BHandset	4009
Apple	iPod Touch 4 (8GB)	1	BHandset (Power Up, Bad LCD) (No Power)	4010
Apple	iPod Touch (16GB)	24	BHandset	4011
Apple	iPod Touch (32GB)	1	BHandset	4012
Apple	iPod Touch (8GB)	10	BHandset	4013
Apple	iPod nano 4 (16GB)	1	BHandset	4014
Apple	iPod Mini II (4GB)	2	BHandset	4015
Apple	iPod (20GB)	2	BHandset	4016
Apple	iPod Classic (30GB)	3	BHandset	4017
Apple	iPod nano (4GB)	2	BHandset	4018
Apple	iPod nano 2 (4GB)	1	BHandset	4019
Apple	iPod nano 3 (4GB)	1	BHandset	4020
Apple	iPod Touch 5 (30GB)	1	BHandset	4021
Alcatel	OT4034	3	New	4022
Alcatel	OT4035	1	New	4023
Ericsson	F3213	1	New	4024
Huawei	Y635	2	New	4025
Lg	D802	1	New	4026
Nokia	111	5	New	4027
Nokia	435	1	New	4028
Other	Bmobile K355	1	New	4029
Other	Bmobile K360	2	New	4030
Other	Go Mobile 181	7	New	4031
Other	Go Mobile 190	2	New	4032
Other	Imo Q2 Pro	1	New	4033
Other	Mobile Ax1015	2	New	4034
Other	Mobile Ax1016	2	New	4035
Other	Mobile Ax1017	1	New	4036
Other	Mobile Ax1070E	1	New	4037
Other	Mobile Ax1076+	1	New	4038
Other	Mobile Ax685	1	New	4039
Other	Mobiwire Kanuna	1	New	4040

Other	Zamko Z11	1	New	4041
Zte	Blade A33	2	NewHandset	4042
Alcatel	OT3040	1	Nearly New	4043
Alcatel	OT4009	1	Nearly New	4044
Alcatel	OT4015	1	Nearly New	4045
Alcatel	OT4034	4	Nearly New	4046
Alcatel	OT4035	2	Nearly New	4047
Alcatel	OT5050	1	Nearly New	4048
Alcatel	OT6012	1	Nearly New	4049
Alcatel	OT6034	1	Nearly New	4050
Alcatel	OT9027	1	Nearly New	4051
Blackberry	BB9720	2	Nearly New	4052
Ericsson	C1505	2	Nearly New	4053
Ericsson	E2003	3	Nearly New	4054
Ericsson	E2303	3	Nearly New	4055
Ericsson	XQ-DC54	1	Nearly New	4056
Ericsson	XQ-EC54	1	Nearly New	4057
Ericsson	XQ-ES54	1	Nearly New	4058
Lg	LMX410	1	Nearly New	4059
Motorola	XT2321	1	Nearly New	4060
Motorola	XT2341	1	Nearly New	4061
Motorola	XT2421	1	Nearly New	4062
Motorola	XT2427	1	Nearly New	4063
Motorola	XT890	1	Nearly New	4064
Nokia	435	2	Nearly New	4065
Nokia	520	3	Nearly New	4066
Nokia	530	16	Nearly New	4067
Nokia	550	2	Nearly New	4068
Nokia	610	1	Nearly New	4069
Nokia	625	3	Nearly New	4070
Nokia	630	2	Nearly New	4071
Nokia	635	35	Nearly New	4072
Nokia	640	10	Nearly New	4073
Nokia	650	22	Nearly New	4074
Nokia	820	2	Nearly New	4075
Nokia	435(SIM Free)	22	Nearly New	4076
Nokia	535(SIM Free)	40	Nearly New	4077
Nokia	550(SIM Free)	5	Nearly New	4078
Nokia	640XL	1	Nearly New	4079
Other	Go Mobile 181	1	Nearly New	4080
Other	Go Mobile 190	1	Nearly New	4081
Other	Go Mobile 963	3	Nearly New	4082
Other	Go Mobile 980	3	Nearly New	4083
Other	Google G025I	1	Nearly New	4084
Other	Google G025N	1	Nearly New	4085
Other	Google G6Gpr	1	Nearly New	4086
Other	Google GB7N6	1	Nearly New	4087
Other	Google Gc3Ve	1	Nearly New	4088
Other	Google Ghl1X	1	Nearly New	4089
Other	Google Glu0G	2	Nearly New	4090
Other	Google Gpj41	1	Nearly New	4091
Other	Google Gtt9Q	1	Nearly New	4092
Other	Google Gur25	1	Nearly New	4093
Other	Harrier	1	Nearly New	4094
Other	Harrier Mini	1	Nearly New	4095
Other	Harrier Rook	1	Nearly New	4096
Other	HMd Pulse	1	Nearly New	4097
Other	Maxcom Classic mm128	5	Nearly New	4098
Other	Maxcom Classic mm129	1	Nearly New	4099
Other	Maxcom Classic mm134	4	Nearly New	4100
Other	Maxcom mm721 3G	1	Nearly New	4101
Other	Mobile Ax1016	8	Nearly New	4102
Other	Mobile Ax1075X	4	Nearly New	4103
Other	Mobile Ax1080	1	Nearly New	4104
Other	Mobile Ax1082	1	Nearly New	4105
Other	Mtt L402	2	Nearly New	4106
Other	Mtt M14D	10	Nearly New	4107
Other	Mtt S25	5	Nearly New	4108
Other	Own F1016	1	Nearly New	4109
Other	Own F1021	1	Nearly New	4110
Other	Sky Elite M5 Plus	1	Nearly New	4111
Other	Sky F3P	3	Nearly New	4112
Other	Stk R45I	1	Nearly New	4113
Other	Welcome A5s	1	Nearly New	4114
Sfr	STARSHINE IV	1	Nearly New	4115
Sharp	550Sh	60	Nearly New	4116
Vodafone	V527	1080	Nearly New	4117
Zte	Blade A110	1	Nearly New	4118
Zte	Kis III	1	Nearly New	4119
Alcatel	OT4003	1	Nearly New Handset	4120
Alcatel	OT815	2	Nearly New Handset	4121
Ericsson	C1505	2	Nearly New Handset	4122
Ericsson	CK13i	302	Nearly New Handset	4123
Ericsson	G3121	1	Nearly New Handset	4124
Ericsson	G3221	1	Nearly New Handset	4125
Ericsson	W150A(高頻With Code)	125	Nearly New Handset	4126

Hp	Ipaq Data Messenger	36	Nearly New Handset	4127
Hp	Ipaq Voice Messenger	92	Nearly New Handset	4128
Htc	Desire C	3	Nearly New Handset	4129
Htc	Diamond	210	Nearly New Handset	4130
Huawei	CAG-L03	1	Nearly New Handset	4131
Lg	X210	1	Nearly New Handset	4132
Motorola	I420	300	Nearly New Handset	4133
Motorola	I460	18	Nearly New Handset	4134
Motorola	I475	26	Nearly New Handset	4135
Motorola	I485	26	Nearly New Handset	4136
Motorola	I706	40	Nearly New Handset	4137
Motorola	I867	228	Nearly New Handset	4138
Motorola	I897	154	Nearly New Handset	4139
Motorola	I940	60	Nearly New Handset	4140
Motorola	XT605	250	Nearly New Handset	4141
Motorola	XT626	23	Nearly New Handset	4142
Motorola	XT627	8	Nearly New Handset	4143
Nokia	550	3	Nearly New Handset	4144
Nokia	635	1	Nearly New Handset	4145
Other	Imo Dash	1	Nearly New Handset	4146
Other	Mobile Ax1070E	1	Nearly New Handset	4147
Other	Mobile Ax1071	1	Nearly New Handset	4148
Other	Mobile Ax685	8	Nearly New Handset	4149
Other	Mobiwire Ayasha	19	Nearly New Handset	4150
Other	Pantech Md Cube	11	Nearly New Handset	4151
Sagem	421Z	1674	Nearly New Handset	4152
Sagem	W-8	256	Nearly New Handset	4153
Sharp	880Sh	108	Nearly New Handset	4154
Vodafone	V527	500	Nearly New Handset	4155
Vodafone	V533	300	Nearly New Handset	4156
Zte	R303	49	Nearly New Handset	4157
Zte	R880	52	Nearly New Handset	4158
Zte	S50	55	Nearly New Handset	4159
Alcatel	OT9022	1	AHandset (Good)	4160
Ericsson	D6616	1	AHandset (Good)	4161
Ericsson	F5321	1	AHandset (Good)	4162
Ericsson	G3311	2	AHandset (Good)	4163
Htc	Desire 610	1	AHandset (Good)	4164
Htc	One M8	2	AHandset (Good)	4165
Lg	D415	2	AHandset (Good)	4166
Lg	H918	2	AHandset (Good)	4167
Lg	K330	1	AHandset (Good)	4168
Lg	MS330	1	AHandset (Good)	4169
Lg	TP260	1	AHandset (Good)	4170
Motorola	XT1034	1	AHandset (Good)	4171
Motorola	XT1103	1	AHandset (Good)	4172
Motorola	XT1254	1	AHandset (Good)	4173
Motorola	XT1528	1	AHandset (Good)	4174
Other	Altice S33	1	AHandset (Good)	4175
Other	Doro PE820 Mini	1	AHandset (Good)	4176
Other	Imo Q2 Pro	7	AHandset (Good)	4177
Sfr	STARXTREM IV	1	AHandset (Good)	4178
Other	Doro 7030	1	14A	4179
Other	Google G1AZg	1	14A	4180
Other	Google Gh11X	1	14A	4181
Other	Lenovo Tb-8505	1	14A	4182
Other	Tcl 501	1	14A	4183
Other	Vivo Y36 5G	1	14A	4184
Other	Xiaomi Mi 11T 5G	1	14A	4185
Other	Xiaomi Mi 12T 5G	1	14A	4186
Pc	Microsoft Surface Laptop 7	1	14A	4187
Acer	A510	1	AHandset	4188
Acer	B3-A20	1	AHandset	4189
Acer	E310	4	AHandset	4190
Alcatel	OT1013	1	AHandset	4191
Alcatel	OT1054	1	AHandset	4192
Alcatel	OT1066	1	AHandset	4193
Alcatel	OT1068	1	AHandset	4194
Alcatel	OT2035	2	AHandset	4195
Alcatel	OT2045	1	AHandset	4196
Alcatel	OT4009	3	AHandset	4197
Alcatel	OT4013	1	AHandset	4198
Alcatel	OT4024	1	AHandset	4199
Alcatel	OT4030	1	AHandset	4200
Alcatel	OT4033	3	AHandset	4201
Alcatel	OT4034	1	AHandset	4202
Alcatel	OT4035	1	AHandset	4203
Alcatel	OT4087	1	AHandset	4204
Alcatel	OT5009	1	AHandset	4205
Alcatel	OT5015	1	AHandset	4206
Alcatel	OT5033	15	AHandset	4207
Alcatel	OT5045	1	AHandset	4208
Alcatel	OT5051	2	AHandset	4209
Alcatel	OT5056	1	AHandset	4210
Alcatel	OT6037	2	AHandset	4211
Alcatel	OT9008	1	AHandset	4212

Asus	A007	1	AHandset	4213
Asus	K00F	1	AHandset	4214
Asus	K01E	1	AHandset	4215
Asus	Nexus 7	2	AHandset	4216
Asus	Nexus 7 K009	2	AHandset	4217
Asus	P023	1	AHandset	4218
Asus	Tf101	1	AHandset	4219
Blackberry	BB9000	1	AHandset	4220
Blackberry	BB9360	4	AHandset	4221
Blackberry	BB9700	2	AHandset	4222
Blackberry	BB9720	3	AHandset	4223
Blackberry	BB9720 (倒键)	2	AHandset	4224
Blackberry	BB9790	5	AHandset	4225
Blackberry	DTEK50	37	AHandset	4226
Blackberry	DTEK60	1	AHandset	4227
Blackberry	Z10	1	AHandset	4228
Blackberry	Z10 4G	235	AHandset	4229
Blackberry	Z3	33	AHandset	4230
Blackberry	Z30 4G	51	AHandset	4231
Ericsson	C2105	1	AHandset	4232
Ericsson	C5303	4	AHandset	4233
Ericsson	C6833	3	AHandset	4234
Ericsson	C6903	12	AHandset	4235
Ericsson	D2005	3	AHandset	4236
Ericsson	D2203	1	AHandset	4237
Ericsson	D2203(SIM Free)	1	AHandset	4238
Ericsson	D2303	9	AHandset	4239
Ericsson	D2403	4	AHandset	4240
Ericsson	D5103	3	AHandset	4241
Ericsson	D5503	7	AHandset	4242
Ericsson	D5803	7	AHandset	4243
Ericsson	D6503	13	AHandset	4244
Ericsson	D6603	9	AHandset	4245
Ericsson	E2105	5	AHandset	4246
Ericsson	E2303	14	AHandset	4247
Ericsson	E2333	3	AHandset	4248
Ericsson	E5303(SIM Free)	1	AHandset	4249
Ericsson	E5506	1	AHandset	4250
Ericsson	E5533	1	AHandset	4251
Ericsson	E5533(SIM Free)	2	AHandset	4252
Ericsson	E5603	23	AHandset	4253
Ericsson	E5603(SIM Free)	5	AHandset	4254
Ericsson	E5606	1	AHandset	4255
Ericsson	E5653(SIM Free)	3	AHandset	4256
Ericsson	E5803(SIM Free)	1	AHandset	4257
Ericsson	E5823	22	AHandset	4258
Ericsson	E6533	2	AHandset	4259
Ericsson	E6553	1	AHandset	4260
Ericsson	E6553(SIM Free)	1	AHandset	4261
Ericsson	E6603	1	AHandset	4262
Ericsson	E6633	2	AHandset	4263
Ericsson	E6633(SIM Free)	2	AHandset	4264
Ericsson	E6653	24	AHandset	4265
Ericsson	E6653(SIM Free)	13	AHandset	4266
Ericsson	E6683(SIM Free)	1	AHandset	4267
Ericsson	E6833(SIM Free)	1	AHandset	4268
Ericsson	E6853	11	AHandset	4269
Ericsson	F3111	128	AHandset	4270
Ericsson	F3111(SIM Free)	2	AHandset	4271
Ericsson	F3113	12	AHandset	4272
Ericsson	F3115	13	AHandset	4273
Ericsson	F3121	1	AHandset	4274
Ericsson	F3211	10	AHandset	4275
Ericsson	F3213	4	AHandset	4276
Ericsson	F3311	51	AHandset	4277
Ericsson	F3311(SIM Free)	7	AHandset	4278
Ericsson	F3313	11	AHandset	4279
Ericsson	F5121	2	AHandset	4280
Ericsson	F5121(SIM Free)	1	AHandset	4281
Ericsson	F5321	101	AHandset	4282
Ericsson	F5321(SIM Free)	1	AHandset	4283
Ericsson	F8131(SIM Free)	1	AHandset	4284
Ericsson	F8231(SIM Free)	2	AHandset	4285
Ericsson	F8331	35	AHandset	4286
Ericsson	F8331(SIM Free)	64	AHandset	4287
Ericsson	F8332(SIM Free)	2	AHandset	4288
Ericsson	G3112	1	AHandset	4289
Ericsson	G3112(SIM Free)	9	AHandset	4290
Ericsson	G3121	172	AHandset	4291
Ericsson	G3121(SIM Free)	97	AHandset	4292
Ericsson	G3123(SIM Free)	2	AHandset	4293
Ericsson	G3125	1	AHandset	4294
Ericsson	G3125(SIM Free)	1	AHandset	4295
Ericsson	G3221	1	AHandset	4296
Ericsson	G3221(SIM Free)	2	AHandset	4297
Ericsson	G3223	4	AHandset	4298

Ericsson	G3311	105	AHandset	4299
Ericsson	G3311(SIM Free)	59	AHandset	4300
Ericsson	G3312(SIM Free)	1	AHandset	4301
Ericsson	G3313	3	AHandset	4302
Ericsson	G3421	1	AHandset	4303
Ericsson	G8231(SIM Free)	1	AHandset	4304
Ericsson	G8232(SIM Free)	4	AHandset	4305
Ericsson	G8341	1	AHandset	4306
Ericsson	H3113	4	AHandset	4307
Ericsson	H3311	3	AHandset	4308
Ericsson	H3311(SIM Free)	1	AHandset	4309
Ericsson	H4311	2	AHandset	4310
Ericsson	H8331	2	AHandset	4311
Ericsson	i3312	44	AHandset	4312
Ericsson	i3312(SIM Free)	5	AHandset	4313
Ericsson	J8210(SIM Free)	1	AHandset	4314
Ericsson	LT25i	3	AHandset	4315
Ericsson	LT26i	6	AHandset	4316
Ericsson	LT30p	3	AHandset	4317
Ericsson	LT36	10	AHandset	4318
Ericsson	MT11i	1	AHandset	4319
Ericsson	MT15i	3	AHandset	4320
Ericsson	SGPT611	1	AHandset	4321
Ericsson	ST18i	1	AHandset	4322
Ericsson	ST21i	2	AHandset	4323
Ericsson	ST23i	3	AHandset	4324
Ericsson	ST27i	2	AHandset	4325
Ericsson	X12	15	AHandset	4326
Ericsson	X8	3	AHandset	4327
Ericsson	XQ-AD51	3	AHandset	4328
Ericsson	XQ-BT52(SIM Free)	1	AHandset	4329
Htc	7 Mozart	1	AHandset	4330
Htc	8S	2	AHandset	4331
Htc	8X	1	AHandset	4332
Htc	ChaCha	2	AHandset	4333
Htc	Desire 310	28	AHandset	4334
Htc	Desire 500	88	AHandset	4335
Htc	Desire 510	84	AHandset	4336
Htc	Desire 516	1	AHandset	4337
Htc	Desire 530	3	AHandset	4338
Htc	Desire 610	1	AHandset	4339
Htc	Desire 620	1	AHandset	4340
Htc	Desire 728	1	AHandset	4341
Htc	Desire 816	1	AHandset	4342
Htc	Desire 820	1	AHandset	4343
Htc	Desire 825	2	AHandset	4344
Htc	Desire C	19	AHandset	4345
Htc	Desire HD	2	AHandset	4346
Htc	Desire S	4	AHandset	4347
Htc	Desire Z	20	AHandset	4348
Htc	Explorer	4	AHandset	4349
Htc	One A9	1	AHandset	4350
Htc	One A9S	1	AHandset	4351
Htc	One M8S	10	AHandset	4352
Htc	One Mini	40	AHandset	4353
Htc	One Mini II	112	AHandset	4354
Htc	One S	54	AHandset	4355
Htc	One SV	11	AHandset	4356
Htc	One SV 4G	20	AHandset	4357
Htc	One X	49	AHandset	4358
Htc	One X+	2	AHandset	4359
Htc	Sensation	3	AHandset	4360
Htc	Sensation XE	2	AHandset	4361
Htc	U11	1	AHandset	4362
Htc	Wildfire	8	AHandset	4363
Htc	Wildfire S	2	AHandset	4364
Huawei	ALP-L29	1	AHandset	4365
Huawei	CAM-L21	3	AHandset	4366
Huawei	COL-L29	2	AHandset	4367
Huawei	CRR-L09	1	AHandset	4368
Huawei	DIG-L21	1	AHandset	4369
Huawei	DRA-L21	1	AHandset	4370
Huawei	FRL-L23	1	AHandset	4371
Huawei	G510	1	AHandset	4372
Huawei	G535	1	AHandset	4373
Huawei	G620	1	AHandset	4374
Huawei	G630	1	AHandset	4375
Huawei	HONOR 90 SMART	1	AHandset	4376
Huawei	HONOR X7C 5G	1	AHandset	4377
Huawei	LUA-L21	2	AHandset	4378
Huawei	LYA-L09	1	AHandset	4379
Huawei	MT1-U06	8	AHandset	4380
Huawei	MYA-L41	4	AHandset	4381
Huawei	P2	1	AHandset	4382
Huawei	PCT-L29	1	AHandset	4383
Huawei	PE-TL10	1	AHandset	4384

Huawei	S7-721	2	AHandset	4385
Huawei	SCL-L01	3	AHandset	4386
Huawei	SCL-L21	5	AHandset	4387
Huawei	T1-821	1	AHandset	4388
Huawei	Y530	1	AHandset	4389
Huawei	Y550	1	AHandset	4390
Huawei	Y625	1	AHandset	4391
Huawei	Y635	3	AHandset	4392
Lg	D331	5	AHandset	4393
Lg	D335	1	AHandset	4394
Lg	E400	1	AHandset	4395
Lg	E460	1	AHandset	4396
Lg	E610	2	AHandset	4397
Lg	E960	48	AHandset	4398
Lg	H420	4	AHandset	4399
Lg	H440	1	AHandset	4400
Lg	H500	11	AHandset	4401
Lg	H525	2	AHandset	4402
Lg	H735	1	AHandset	4403
Lg	H791	1	AHandset	4404
Lg	H815	3	AHandset	4405
Lg	H818	1	AHandset	4406
Lg	H850	4	AHandset	4407
Lg	H955	1	AHandset	4408
Lg	K350N	5	AHandset	4409
Lg	K420N	4	AHandset	4410
Lg	K500	1	AHandset	4411
Lg	K500N	1	AHandset	4412
Lg	P500	1	AHandset	4413
Lg	P710	1	AHandset	4414
Lg	P880	1	AHandset	4415
Lg	P920	1	AHandset	4416
Lg	P970	1	AHandset	4417
Lg	X150	1	AHandset	4418
Lg	X410EO	1	AHandset	4419
Motorola	XT1068	1	AHandset	4420
Motorola	XT1541	5	AHandset	4421
Motorola	XT1542	3	AHandset	4422
Motorola	XT1562	1	AHandset	4423
Motorola	XT1622	3	AHandset	4424
Motorola	XT1650	3	AHandset	4425
Motorola	XT1675	1	AHandset	4426
Motorola	XT1676	4	AHandset	4427
Motorola	XT1685	1	AHandset	4428
Motorola	XT1794	7	AHandset	4429
Motorola	XT1920	1	AHandset	4430
Motorola	XT2000	6	AHandset	4431
Motorola	XT2013	1	AHandset	4432
Motorola	XT2019	26	AHandset	4433
Motorola	XT2025	49	AHandset	4434
Motorola	XT2027	3	AHandset	4435
Motorola	XT2029	8	AHandset	4436
Motorola	XT2041	13	AHandset	4437
Motorola	XT2041DL	2	AHandset	4438
Motorola	XT2053	1	AHandset	4439
Motorola	XT2075	1	AHandset	4440
Motorola	XT2081	1	AHandset	4441
Motorola	XT2083	1	AHandset	4442
Motorola	XT2091	3	AHandset	4443
Motorola	XT2093	1	AHandset	4444
Motorola	XT2095	5	AHandset	4445
Motorola	XT2097	12	AHandset	4446
Motorola	XT2129	1	AHandset	4447
Motorola	XT2149	9	AHandset	4448
Motorola	XT2155	1	AHandset	4449
Motorola	XT2159	2	AHandset	4450
Motorola	XT2227	1	AHandset	4451
Motorola	XT2239	6	AHandset	4452
Motorola	XT2341	1	AHandset	4453
Nokia	110	1	AHandset	4454
Nokia	111	2	AHandset	4455
Nokia	207	1	AHandset	4456
Nokia	301	1	AHandset	4457
Nokia	435	2	AHandset	4458
Nokia	503	1	AHandset	4459
Nokia	520	5	AHandset	4460
Nokia	530	1	AHandset	4461
Nokia	532	1	AHandset	4462
Nokia	625	5	AHandset	4463
Nokia	635	3	AHandset	4464
Nokia	640	8	AHandset	4465
Nokia	650	6	AHandset	4466
Nokia	720	1	AHandset	4467
Nokia	800	1	AHandset	4468
Nokia	900	1	AHandset	4469
Nokia	1320	1	AHandset	4470

Nokia	105(2019)	1	AHandset	4471
Nokia	1320(SIM Free)	3	AHandset	4472
Nokia	520(SIM Free)	4	AHandset	4473
Nokia	530(SIM Free)	6	AHandset	4474
Nokia	535(SIM Free)	5	AHandset	4475
Nokia	550(SIM Free)	25	AHandset	4476
Nokia	625(SIM Free)	3	AHandset	4477
Nokia	630(SIM Free)	7	AHandset	4478
Nokia	635(SIM Free)	9	AHandset	4479
Nokia	640(SIM Free)	18	AHandset	4480
Nokia	640XL	5	AHandset	4481
Nokia	640XL(SIM Free)	12	AHandset	4482
Nokia	650(SIM Free)	13	AHandset	4483
Nokia	710(SIM Free)	1	AHandset	4484
Nokia	720(SIM Free)	2	AHandset	4485
Nokia	C1-01	1	AHandset	4486
Nokia	3.1(2018) (SIM Free)	1	AHandset	4487
Nokia	X20(SIM Free)	1	AHandset	4488
Other	Altice E54	1	AHandset	4489
Other	Altice S10	2	AHandset	4490
Other	Altice S61	8	AHandset	4491
Other	Altice S70	3	AHandset	4492
Other	Altice Sx41	2	AHandset	4493
Other	ARCHOS 55 Helium	1	AHandset	4494
Other	AZ210	1	AHandset	4495
Other	Blaupunkt Bs04	12	AHandset	4496
Other	Blaupunkt Bs041	47	AHandset	4497
Other	Blaupunkt FI04	8	AHandset	4498
Other	Blaupunkt FI07	2	AHandset	4499
Other	Blaupunkt FI08	49	AHandset	4500
Other	Blaupunkt Fm03I	2	AHandset	4501
Other	Blaupunkt OT16	4	AHandset	4502
Other	Blaupunkt Sf01	1	AHandset	4503
Other	Blaupunkt Sf02	12	AHandset	4504
Other	Blaupunkt Sf04	430	AHandset	4505
Other	Blaupunkt Sf04 4G	237	AHandset	4506
Other	Blaupunkt SI05	2	AHandset	4507
Other	Blaupunkt SM01	4	AHandset	4508
Other	Blaupunkt SM02	2	AHandset	4509
Other	Blaupunkt SM05	45	AHandset	4510
Other	Blaupunkt V18	1	AHandset	4511
Other	Cat B15	2	AHandset	4512
Other	Crosscall Trekker M1 Core	3	AHandset	4513
Other	Doro 7030	1	AHandset	4514
Other	Doro 8050	3	AHandset	4515
Other	Doro PE810	1	AHandset	4516
Other	Doro PE820	1	AHandset	4517
Other	Emporia SMart 4	1	AHandset	4518
Other	Google G020M	1	AHandset	4519
Other	Google G025I	1	AHandset	4520
Other	Google GB7N6	1	AHandset	4521
Other	Google Gc3Ve	8	AHandset	4522
Other	Google Gh11X	5	AHandset	4523
Other	Google Glu0G	2	AHandset	4524
Other	Google Gp4Bc	3	AHandset	4525
Other	Google Gpj41	2	AHandset	4526
Other	Google Gtt9Q	1	AHandset	4527
Other	Google Gvu6C	3	AHandset	4528
Other	Harrier	2	AHandset	4529
Other	Imo Q2 Pro	30	AHandset	4530
Other	Mobile Ax1091	1	AHandset	4531
Other	Mobile C40	12	AHandset	4532
Other	Mobiwire Kanuna	1	AHandset	4533
Other	Mobiwire Klah	1	AHandset	4534
Other	Mtt L506	1	AHandset	4535
Other	Navon Spt1100	227	AHandset	4536
Other	Navon T310	26	AHandset	4537
Other	One Plus	12	AHandset	4538
Other	One Plus 3	6	AHandset	4539
Other	One Plus X	9	AHandset	4540
Other	Oppo A78 5G	5	AHandset	4541
Other	Oppo A9(2020)	2	AHandset	4542
Other	Oppo Find X3 Pro 5G	3	AHandset	4543
Other	Oppo Find X5 Lite 5G	3	AHandset	4544
Other	Oppo Find X5 Pro	1	AHandset	4545
Other	Oppo Find X5 Pro 5G	2	AHandset	4546
Other	Oppo Reno 10 5G	2	AHandset	4547
Other	Oppo Reno 5 Lite	1	AHandset	4548
Other	Oppo Reno 5 Z	1	AHandset	4549
Other	Oppo Reno 6 Pro 5G	2	AHandset	4550
Other	Oppo Reno 7 5G	1	AHandset	4551
Other	Oppo Reno 8 Lite 5G	1	AHandset	4552
Other	Oppo Reno 8 Z 5G	2	AHandset	4553
Other	Oppo Reno Z	1	AHandset	4554
Other	Ovn F1016	6	AHandset	4555
Other	Ovn F1021	1	AHandset	4556

Other	Own F1023	1	AHandset	4557
Other	Own F1024	4	AHandset	4558
Other	Own F1026	6	AHandset	4559
Other	Own Fun 6	2	AHandset	4560
Other	Own S4010	2	AHandset	4561
Other	Own S5010	1	AHandset	4562
Other	Own SMart	1	AHandset	4563
Other	Own SMart Plus Lte	6	AHandset	4564
Other	Qube Ncp01	2	AHandset	4565
Other	Razer Rz35-0215	9	AHandset	4566
Other	Wiko TOMMY 2	1	AHandset	4567
Other	Windows Surface 1516	5	AHandset	4568
Other	Windows Surface 1572	1	AHandset	4569
Other	Windows Surface 1601	1	AHandset	4570
Other	Windows Surface 1631	1	AHandset	4571
Other	Windows Surface 1645	1	AHandset	4572
Other	Windows Surface 1824	1	AHandset	4573
Other	Xiaomi Mi 11 Lite	7	AHandset	4574
Other	Xiaomi Redmi 12C	1	AHandset	4575
Other	Xiaomi Redmi 8A	1	AHandset	4576
Other	Xiaomi Redmi Note 12	1	AHandset	4577
Sfr	STARACTIVE II	1	AHandset	4578
Sfr	STARADDICT V	1	AHandset	4579
Sfr	STARNAUTE IV	2	AHandset	4580
Sfr	STARSHINE V	1	AHandset	4581
Sfr	STARTRAIL 8	1	AHandset	4582
Sfr	STARXTREM 5	3	AHandset	4583
Sfr	STARXTREM II	1	AHandset	4584
Vodafone	V860	1	AHandset	4585
Vodafone	V865	1	AHandset	4586
Vodafone	V890	1	AHandset	4587
Vodafone	V985	1	AHandset	4588
Zte	Blade A3 Lite	1	AHandset	4589
Zte	Blade A3(2019)	1	AHandset	4590
Zte	Blade A31 Plus	5	AHandset	4591
Zte	Blade A510	1	AHandset	4592
Zte	Blade C341	1	AHandset	4593
Zte	Blade G	2	AHandset	4594
Zte	Blade V10 Vita	1	AHandset	4595
Zte	Grand Memo Lte	1	AHandset	4596
Pc	Aspire D257	1	14B	4597
Pc	Cp513-1Hl	2	14B	4598
Pc	E3-112	1	14B	4599
Pc	Icl50	1	14B	4600
Pc	R721T	1	14B	4601
Pc	Sp111-33	1	14B	4602
Pc	Apple Mac Mini 2013	3	14B	4603
Pc	Apple Macbook	2	14B	4604
Pc	Apple Macbook Air 13 2017	3	14B	4605
Pc	Apple Macbook Pro 13 2015	1	14B	4606
Pc	Apple Macbook Pro 13 2016	4	14B	4607
Pc	Apple Macbook Pro 13 2017	7	14B	4608
Pc	Apple Macbook Pro 15 2017	5	14B	4609
Pc	Apple Macbook Pro 16 2019	2	14B	4610
Pc	C214M	1	14B	4611
Pc	C434T	2	14B	4612
Pc	Compaq Cq10	1	14B	4613
Pc	N5110	1	14B	4614
Pc	Fujitsu Q702	1	14B	4615
Pc	15-Ay034	1	14B	4616
Pc	4530S	1	14B	4617
Pc	620	1	14B	4618
Pc	G6 2372Sa	1	14B	4619
Pc	Lenovo X250	1	14B	4620
Pc	Samsung Np345XLa	1	14B	4621
Pc	Samsung Np965Qfg	1	14B	4622
Pc	Samsung XE345Xda	14	14B	4623
Pc	Samsung XE525Qea	2	14B	4624
Pc	Toshiba L775-119	1	14B	4625
Alcatel	OT2003	1	BHandset (Power Up, Good LCD)	4626
Blackberry	Z10	8	BHandset (Power Up, Good LCD)	4627
Ericsson	E5303	1	BHandset (Power Up, Good LCD)	4628
Ericsson	E5603	2	BHandset (Power Up, Good LCD)	4629
Ericsson	E5603(SIM Free)	4	BHandset (Power Up, Good LCD)	4630
Ericsson	E5606(SIM Free)	1	BHandset (Power Up, Good LCD)	4631
Ericsson	E5653(SIM Free)	1	BHandset (Power Up, Good LCD)	4632
Ericsson	E5823	4	BHandset (Power Up, Good LCD)	4633
Ericsson	E5823(SIM Free)	1	BHandset (Power Up, Good LCD)	4634
Ericsson	E6633(SIM Free)	1	BHandset (Power Up, Good LCD)	4635
Ericsson	E6653	9	BHandset (Power Up, Good LCD)	4636
Ericsson	E6653(SIM Free)	3	BHandset (Power Up, Good LCD)	4637
Ericsson	E6853(SIM Free)	1	BHandset (Power Up, Good LCD)	4638
Ericsson	F3111	34	BHandset (Power Up, Good LCD)	4639
Ericsson	F3111(SIM Free)	13	BHandset (Power Up, Good LCD)	4640
Ericsson	F3113	4	BHandset (Power Up, Good LCD)	4641
Ericsson	F3115(SIM Free)	2	BHandset (Power Up, Good LCD)	4642

Ericsson	F3213	1	BHandset (Power Up, Good LCD)	4643
Ericsson	F3311	6	BHandset (Power Up, Good LCD)	4644
Ericsson	F3311(SIM Free)	4	BHandset (Power Up, Good LCD)	4645
Ericsson	F3313	1	BHandset (Power Up, Good LCD)	4646
Ericsson	F5121	4	BHandset (Power Up, Good LCD)	4647
Ericsson	F5121(SIM Free)	2	BHandset (Power Up, Good LCD)	4648
Ericsson	F5122(SIM Free)	1	BHandset (Power Up, Good LCD)	4649
Ericsson	F8131(SIM Free)	1	BHandset (Power Up, Good LCD)	4650
Ericsson	F8331	9	BHandset (Power Up, Good LCD)	4651
Ericsson	F8331(SIM Free)	4	BHandset (Power Up, Good LCD)	4652
Ericsson	G3121	5	BHandset (Power Up, Good LCD)	4653
Ericsson	G3121(SIM Free)	4	BHandset (Power Up, Good LCD)	4654
Ericsson	G3221	4	BHandset (Power Up, Good LCD)	4655
Ericsson	G3221(SIM Free)	2	BHandset (Power Up, Good LCD)	4656
Ericsson	G3223	1	BHandset (Power Up, Good LCD)	4657
Ericsson	G3223(SIM Free)	1	BHandset (Power Up, Good LCD)	4658
Ericsson	G3311	38	BHandset (Power Up, Good LCD)	4659
Ericsson	G3311(SIM Free)	14	BHandset (Power Up, Good LCD)	4660
Ericsson	G3313	1	BHandset (Power Up, Good LCD)	4661
Ericsson	G8331	1	BHandset (Power Up, Good LCD)	4662
Ericsson	G8341	3	BHandset (Power Up, Good LCD)	4663
Ericsson	H3113	5	BHandset (Power Up, Good LCD)	4664
Ericsson	H3311(SIM Free)	3	BHandset (Power Up, Good LCD)	4665
Ericsson	H3321	1	BHandset (Power Up, Good LCD)	4666
Ericsson	H4413(SIM Free)	1	BHandset (Power Up, Good LCD)	4667
Ericsson	H8216	1	BHandset (Power Up, Good LCD)	4668
Ericsson	H8216(SIM Free)	1	BHandset (Power Up, Good LCD)	4669
Ericsson	H8416	1	BHandset (Power Up, Good LCD)	4670
Ericsson	i3312	29	BHandset (Power Up, Good LCD)	4671
Ericsson	i3312(SIM Free)	7	BHandset (Power Up, Good LCD)	4672
Ericsson	i4312(SIM Free)	1	BHandset (Power Up, Good LCD)	4673
Ericsson	XQ-AD51	1	BHandset (Power Up, Good LCD)	4674
Ericsson	XQ-AD51(SIM Free)	2	BHandset (Power Up, Good LCD)	4675
Ericsson	XQ-AD52(SIM Free)	1	BHandset (Power Up, Good LCD)	4676
Ericsson	XQ-DQ54(SIM Free)	1	BHandset (Power Up, Good LCD)	4677
Htc	Desire X	1	BHandset (Power Up, Good LCD)	4678
Huawei	ALP-L29	1	BHandset (Power Up, Good LCD)	4679
Huawei	COL-L29	2	BHandset (Power Up, Good LCD)	4680
Huawei	COR-L29	1	BHandset (Power Up, Good LCD)	4681
Huawei	HMA-L09	1	BHandset (Power Up, Good LCD)	4682
Huawei	HMA-L29	1	BHandset (Power Up, Good LCD)	4683
Huawei	HONOR 9X	2	BHandset (Power Up, Good LCD)	4684
Huawei	LYA-L09	1	BHandset (Power Up, Good LCD)	4685
Huawei	LYA-L29	1	BHandset (Power Up, Good LCD)	4686
Huawei	P10	3	BHandset (Power Up, Good LCD)	4687
Huawei	P10 Lite	888	BHandset (Power Up, Good LCD)	4688
Huawei	P10 PLUS	10	BHandset (Power Up, Good LCD)	4689
Huawei	P20	3	BHandset (Power Up, Good LCD)	4690
Huawei	P20 Lite	6	BHandset (Power Up, Good LCD)	4691
Huawei	PCT-L29	4	BHandset (Power Up, Good LCD)	4692
Huawei	SNE-LX1	13	BHandset (Power Up, Good LCD)	4693
Huawei	SNE-LX3	1	BHandset (Power Up, Good LCD)	4694
Huawei	YAL-L21	5	BHandset (Power Up, Good LCD)	4695
Lg	D373	1	BHandset (Power Up, Good LCD)	4696
Lg	E975	1	BHandset (Power Up, Good LCD)	4697
Lg	G350	1	BHandset (Power Up, Good LCD)	4698
Lg	Q710	33	BHandset (Power Up, Good LCD)	4699
Motorola	XT2005	1	BHandset (Power Up, Good LCD)	4700
Motorola	XT2013	8	BHandset (Power Up, Good LCD)	4701
Motorola	XT2015	6	BHandset (Power Up, Good LCD)	4702
Motorola	XT2016	12	BHandset (Power Up, Good LCD)	4703
Motorola	XT2019	47	BHandset (Power Up, Good LCD)	4704
Motorola	XT2025	32	BHandset (Power Up, Good LCD)	4705
Motorola	XT2027	3	BHandset (Power Up, Good LCD)	4706
Motorola	XT2029	11	BHandset (Power Up, Good LCD)	4707
Motorola	XT2041	1	BHandset (Power Up, Good LCD)	4708
Motorola	XT2043	2	BHandset (Power Up, Good LCD)	4709
Motorola	XT2045	10	BHandset (Power Up, Good LCD)	4710
Motorola	XT2052	1	BHandset (Power Up, Good LCD)	4711
Motorola	XT2053	20	BHandset (Power Up, Good LCD)	4712
Motorola	XT2055	12	BHandset (Power Up, Good LCD)	4713
Motorola	XT2075	5	BHandset (Power Up, Good LCD)	4714
Motorola	XT2081	2	BHandset (Power Up, Good LCD)	4715
Motorola	XT2083	3	BHandset (Power Up, Good LCD)	4716
Motorola	XT2091	1	BHandset (Power Up, Good LCD)	4717
Motorola	XT2093	1	BHandset (Power Up, Good LCD)	4718
Motorola	XT2095	41	BHandset (Power Up, Good LCD)	4719
Motorola	XT2097	41	BHandset (Power Up, Good LCD)	4720
Motorola	XT2117	12	BHandset (Power Up, Good LCD)	4721
Motorola	XT2127	15	BHandset (Power Up, Good LCD)	4722
Motorola	XT2128	10	BHandset (Power Up, Good LCD)	4723
Motorola	XT2129	2	BHandset (Power Up, Good LCD)	4724
Motorola	XT2149	9	BHandset (Power Up, Good LCD)	4725
Motorola	XT2155	3	BHandset (Power Up, Good LCD)	4726
Motorola	XT2159	25	BHandset (Power Up, Good LCD)	4727
Motorola	XT2173	1	BHandset (Power Up, Good LCD)	4728

Motorola	XT2192	7	BHandset (Power Up, Good LCD)	4729
Motorola	XT2223	1	BHandset (Power Up, Good LCD)	4730
Motorola	XT2227	3	BHandset (Power Up, Good LCD)	4731
Motorola	XT2231	8	BHandset (Power Up, Good LCD)	4732
Motorola	XT2235	2	BHandset (Power Up, Good LCD)	4733
Motorola	XT2239	1	BHandset (Power Up, Good LCD)	4734
Motorola	XT2245	1	BHandset (Power Up, Good LCD)	4735
Motorola	XT2341	1	BHandset (Power Up, Good LCD)	4736
Motorola	XT2345	10	BHandset (Power Up, Good LCD)	4737
Motorola	XT2421	2	BHandset (Power Up, Good LCD)	4738
Nokia	100	5	BHandset (Power Up, Good LCD)	4739
Nokia	108	3	BHandset (Power Up, Good LCD)	4740
Nokia	215	1	BHandset (Power Up, Good LCD)	4741
Nokia	311	1	BHandset (Power Up, Good LCD)	4742
Nokia	435	16	BHandset (Power Up, Good LCD)	4743
Nokia	503	4	BHandset (Power Up, Good LCD)	4744
Nokia	520	3	BHandset (Power Up, Good LCD)	4745
Nokia	530	34	BHandset (Power Up, Good LCD)	4746
Nokia	625	11	BHandset (Power Up, Good LCD)	4747
Nokia	635	3	BHandset (Power Up, Good LCD)	4748
Nokia	640	14	BHandset (Power Up, Good LCD)	4749
Nokia	650	8	BHandset (Power Up, Good LCD)	4750
Nokia	710	31	BHandset (Power Up, Good LCD)	4751
Nokia	720	38	BHandset (Power Up, Good LCD)	4752
Nokia	800	4	BHandset (Power Up, Good LCD)	4753
Nokia	105(2017)	1	BHandset (Power Up, Good LCD)	4754
Nokia	105(2017) (SIM Free)	1	BHandset (Power Up, Good LCD)	4755
Nokia	105(2019) (SIM Free)	1	BHandset (Power Up, Good LCD)	4756
Nokia	105(2023) (SIM Free)	2	BHandset (Power Up, Good LCD)	4757
Nokia	105(SIM Free)	1	BHandset (Power Up, Good LCD)	4758
Nokia	106(2018) (SIM Free)	1	BHandset (Power Up, Good LCD)	4759
Nokia	111(SIM Free)	3	BHandset (Power Up, Good LCD)	4760
Nokia	1320(SIM Free)	5	BHandset (Power Up, Good LCD)	4761
Nokia	206(SIM Free)	2	BHandset (Power Up, Good LCD)	4762
Nokia	208(SIM Free)	10	BHandset (Power Up, Good LCD)	4763
Nokia	225(SIM Free)	2	BHandset (Power Up, Good LCD)	4764
Nokia	2660 Flip(SIM Free)	1	BHandset (Power Up, Good LCD)	4765
Nokia	2720 Flip(SIM Free)	2	BHandset (Power Up, Good LCD)	4766
Nokia	435(SIM Free)	10	BHandset (Power Up, Good LCD)	4767
Nokia	520(SIM Free)	315	BHandset (Power Up, Good LCD)	4768
Nokia	530(SIM Free)	3	BHandset (Power Up, Good LCD)	4769
Nokia	532(SIM Free)	2	BHandset (Power Up, Good LCD)	4770
Nokia	535(SIM Free)	44	BHandset (Power Up, Good LCD)	4771
Nokia	550(SIM Free)	85	BHandset (Power Up, Good LCD)	4772
Nokia	620(SIM Free)	15	BHandset (Power Up, Good LCD)	4773
Nokia	625(SIM Free)	59	BHandset (Power Up, Good LCD)	4774
Nokia	630(SIM Free)	47	BHandset (Power Up, Good LCD)	4775
Nokia	635(SIM Free)	165	BHandset (Power Up, Good LCD)	4776
Nokia	640(SIM Free)	281	BHandset (Power Up, Good LCD)	4777
Nokia	640XL	6	BHandset (Power Up, Good LCD)	4778
Nokia	640XL(SIM Free)	86	BHandset (Power Up, Good LCD)	4779
Nokia	650(SIM Free)	91	BHandset (Power Up, Good LCD)	4780
Nokia	710(SIM Free)	6	BHandset (Power Up, Good LCD)	4781
Nokia	720(SIM Free)	5	BHandset (Power Up, Good LCD)	4782
Nokia	730(SIM Free)	1	BHandset (Power Up, Good LCD)	4783
Nokia	735(SIM Free)	1	BHandset (Power Up, Good LCD)	4784
Nokia	800(SIM Free)	6	BHandset (Power Up, Good LCD)	4785
Nokia	820(SIM Free)	23	BHandset (Power Up, Good LCD)	4786
Nokia	830(SIM Free)	3	BHandset (Power Up, Good LCD)	4787
Nokia	900(SIM Free)	1	BHandset (Power Up, Good LCD)	4788
Nokia	920(SIM Free)	3	BHandset (Power Up, Good LCD)	4789
Nokia	925(SIM Free)	1	BHandset (Power Up, Good LCD)	4790
Nokia	1 Plus(SIM Free)	9	BHandset (Power Up, Good LCD)	4791
Nokia	1(SIM Free)	9	BHandset (Power Up, Good LCD)	4792
Nokia	1.3(SIM Free)	13	BHandset (Power Up, Good LCD)	4793
Nokia	1.4(SIM Free)	2	BHandset (Power Up, Good LCD)	4794
Nokia	2(SIM Free)	17	BHandset (Power Up, Good LCD)	4795
Nokia	2.1(SIM Free)	10	BHandset (Power Up, Good LCD)	4796
Nokia	2.2(SIM Free)	9	BHandset (Power Up, Good LCD)	4797
Nokia	2.3(SIM Free)	10	BHandset (Power Up, Good LCD)	4798
Nokia	2.4(SIM Free)	10	BHandset (Power Up, Good LCD)	4799
Nokia	3	3	BHandset (Power Up, Good LCD)	4800
Nokia	3(SIM Free)	2	BHandset (Power Up, Good LCD)	4801
Nokia	3.1(2018) (SIM Free)	1	BHandset (Power Up, Good LCD)	4802
Nokia	3.4(SIM Free)	2	BHandset (Power Up, Good LCD)	4803
Nokia	4.2(SIM Free)	1	BHandset (Power Up, Good LCD)	4804
Nokia	5	1	BHandset (Power Up, Good LCD)	4805
Nokia	5(SIM Free)	2	BHandset (Power Up, Good LCD)	4806
Nokia	5.1(SIM Free)	1	BHandset (Power Up, Good LCD)	4807
Nokia	6	3	BHandset (Power Up, Good LCD)	4808
Nokia	6(SIM Free)	1	BHandset (Power Up, Good LCD)	4809
Nokia	6.1(SIM Free)	4	BHandset (Power Up, Good LCD)	4810
Nokia	7 Plus	1	BHandset (Power Up, Good LCD)	4811
Nokia	7 Plus(SIM Free)	4	BHandset (Power Up, Good LCD)	4812
Nokia	7.1	1	BHandset (Power Up, Good LCD)	4813
Nokia	7.2	1	BHandset (Power Up, Good LCD)	4814

Nokia	8.1(SIM Free)	1	BHandset (Power Up, Good LCD)	4815
Nokia	C01 Plus(SIM Free)	17	BHandset (Power Up, Good LCD)	4816
Nokia	C02(SIM Free)	1	BHandset (Power Up, Good LCD)	4817
Nokia	C2(SIM Free)	1	BHandset (Power Up, Good LCD)	4818
Nokia	C21 Plus(SIM Free)	8	BHandset (Power Up, Good LCD)	4819
Nokia	C30(SIM Free)	1	BHandset (Power Up, Good LCD)	4820
Nokia	G10	3	BHandset (Power Up, Good LCD)	4821
Nokia	G10(SIM Free)	1	BHandset (Power Up, Good LCD)	4822
Nokia	G11	1	BHandset (Power Up, Good LCD)	4823
Nokia	G20(SIM Free)	2	BHandset (Power Up, Good LCD)	4824
Nokia	G21	1	BHandset (Power Up, Good LCD)	4825
Nokia	G50	1	BHandset (Power Up, Good LCD)	4826
Other	Blaupunkt OT16	22	BHandset (Power Up, Good LCD)	4827
Other	Doro 5516	2	BHandset (Power Up, Good LCD)	4828
Other	Doro 6520	1	BHandset (Power Up, Good LCD)	4829
Other	Doro PE810	1	BHandset (Power Up, Good LCD)	4830
Other	Google G013A	1	BHandset (Power Up, Good LCD)	4831
Other	Google G020P	1	BHandset (Power Up, Good LCD)	4832
Other	Google G025N	1	BHandset (Power Up, Good LCD)	4833
Other	Google G1AZg	2	BHandset (Power Up, Good LCD)	4834
Other	Google G6Gpr	1	BHandset (Power Up, Good LCD)	4835
Other	Google G6Gpr(SIM Free)	1	BHandset (Power Up, Good LCD)	4836
Other	Google GB7N6	2	BHandset (Power Up, Good LCD)	4837
Other	Google Gc3Ve	1	BHandset (Power Up, Good LCD)	4838
Other	Google Gh11X	2	BHandset (Power Up, Good LCD)	4839
Other	Google Gp4Bc	5	BHandset (Power Up, Good LCD)	4840
Other	Google Gvu6C	1	BHandset (Power Up, Good LCD)	4841
Other	One Plus	6	BHandset (Power Up, Good LCD)	4842
Other	One Plus 2	6	BHandset (Power Up, Good LCD)	4843
Other	One Plus 5	1	BHandset (Power Up, Good LCD)	4844
Other	One Plus 5T	1	BHandset (Power Up, Good LCD)	4845
Other	One Plus Nord N100	5	BHandset (Power Up, Good LCD)	4846
Other	One Plus X	5	BHandset (Power Up, Good LCD)	4847
Other	Oppo A16s	3	BHandset (Power Up, Good LCD)	4848
Other	Oppo A52	2	BHandset (Power Up, Good LCD)	4849
Other	Oppo A54s	2	BHandset (Power Up, Good LCD)	4850
Other	Oppo A77	2	BHandset (Power Up, Good LCD)	4851
Other	Oppo A78 5G	2	BHandset (Power Up, Good LCD)	4852
Other	Oppo A94 5G	2	BHandset (Power Up, Good LCD)	4853
Other	Oppo Find X3 Neo 5G	2	BHandset (Power Up, Good LCD)	4854
Other	Oppo Reno 4 Pro 5G	1	BHandset (Power Up, Good LCD)	4855
Other	Oppo Reno 8 5G	1	BHandset (Power Up, Good LCD)	4856
Other	Own F1014	2	BHandset (Power Up, Good LCD)	4857
Other	Own F1016	3	BHandset (Power Up, Good LCD)	4858
Other	Own F1026	28	BHandset (Power Up, Good LCD)	4859
Other	Own F1035	1	BHandset (Power Up, Good LCD)	4860
Other	Razer Rz35-0215	2	BHandset (Power Up, Good LCD)	4861
Other	Tel 20 R 5G	1	BHandset (Power Up, Good LCD)	4862
Other	Tel 20 Se	3	BHandset (Power Up, Good LCD)	4863
Other	Tel 20S	1	BHandset (Power Up, Good LCD)	4864
Other	Tel 40 Se	1	BHandset (Power Up, Good LCD)	4865
Other	Tel 40R 5G	1	BHandset (Power Up, Good LCD)	4866
Other	Xiaomi Mi 11 Lite 5G Ne	1	BHandset (Power Up, Good LCD)	4867
Other	Xiaomi Mi 8	1	BHandset (Power Up, Good LCD)	4868
Other	Xiaomi Mi 8 Lite	3	BHandset (Power Up, Good LCD)	4869
Other	Xiaomi Mi Mix 2	1	BHandset (Power Up, Good LCD)	4870
Other	Xiaomi Mi Note 10	1	BHandset (Power Up, Good LCD)	4871
Other	Xiaomi Mi Note 10 Lite	1	BHandset (Power Up, Good LCD)	4872
Other	Xiaomi Poco X3 Nfc	1	BHandset (Power Up, Good LCD)	4873
Other	Xiaomi Redmi 9	3	BHandset (Power Up, Good LCD)	4874
Other	Xiaomi Redmi 9A	4	BHandset (Power Up, Good LCD)	4875
Other	Xiaomi Redmi 9C	1	BHandset (Power Up, Good LCD)	4876
Other	Xiaomi Redmi Note 10S	8	BHandset (Power Up, Good LCD)	4877
Other	Xiaomi Redmi Note 11 Pro 5G	4	BHandset (Power Up, Good LCD)	4878
Other	Xiaomi Redmi Note 12 Pro 5G	1	BHandset (Power Up, Good LCD)	4879
Other	Xiaomi Redmi Note 8T	1	BHandset (Power Up, Good LCD)	4880
Other	Xiaomi Redmi Note 9	3	BHandset (Power Up, Good LCD)	4881
Pc	A114-31	1	BHandset (Power Up, Good LCD)	4882
Zte	Axon 10 Pro 5G	3	BHandset (Power Up, Good LCD)	4883
Zte	Axon 11 5G	16	BHandset (Power Up, Good LCD)	4884
Zte	Axon 9 Pro	1	BHandset (Power Up, Good LCD)	4885
Zte	Blade V40 SMart	20	BHandset (Power Up, Good LCD)	4886
Zte	Blade V40 Vita	10	BHandset (Power Up, Good LCD)	4887
Pc	532H-2DS	1	14C	4888
Pc	5732Z	1	14C	4889
Pc	A514-52	1	14C	4890
Pc	Cb314	1	14C	4891
Pc	Cb314-1Ht	1	14C	4892
Pc	Cb514-1H	1	14C	4893
Pc	Cb515-1W	1	14C	4894
Pc	Cp513-1HI	3	14C	4895
Pc	E1-531	1	14C	4896
Pc	R752Tn	1	14C	4897
Pc	Sf114-32	1	14C	4898
Pc	Swift 1 N5100	1	14C	4899
Pc	V3-571	1	14C	4900

Pc	Apple Ibook G3	1	14C	4901
Pc	Apple Macbook	1	14C	4902
Pc	Apple Macbook Air 13 2011	1	14C	4903
Pc	Apple Macbook Pro 13 2008	1	14C	4904
Pc	Apple Macbook Pro 13 2009	1	14C	4905
Pc	Apple Macbook Pro 13 2010	1	14C	4906
Pc	Apple Macbook Pro 15 2017	1	14C	4907
Pc	Apple Macbook Pro Retina 13 2012	1	14C	4908
Pc	Apple Macbook Pro Retina 15 2012	1	14C	4909
Pc	A411U	1	14C	4910
Pc	C434T	1	14C	4911
Pc	Cx5400Fm	1	14C	4912
Pc	M413I	1	14C	4913
Pc	M509D	1	14C	4914
Pc	TP412F	1	14C	4915
Pc	Ux303L	1	14C	4916
Pc	X502C	1	14C	4917
Pc	X512D	2	14C	4918
Pc	X512F	1	14C	4919
Pc	X555L	1	14C	4920
Pc	Fujitsu A530	1	14C	4921
Pc	11-Ak0502Sa	1	14C	4922
Pc	14-Db0003Na	1	14C	4923
Pc	14Dv598Sa	1	14C	4924
Pc	17-Ca0001Na	1	14C	4925
Pc	G6-2210Sa	1	14C	4926
Pc	Mini 110	1	14C	4927
Pc	Probook 440 G3	1	14C	4928
Pc	Lenovo 310-10Icr	1	14C	4929
Pc	Lenovo T530	1	14C	4930
Pc	Samsung N150	1	14C	4931
Pc	Samsung Np345Xna	3	14C	4932
Pc	Samsung Np965Qfg	1	14C	4933
Pc	Samsung W700	2	14C	4934
Pc	Samsung W720	2	14C	4935
Pc	Samsung W727	1	14C	4936
Pc	Samsung XE315Xda	3	14C	4937
Pc	Samsung XE345Xda	68	14C	4938
Pc	Samsung XE345Xna	1	14C	4939
Pc	Samsung XE525Qea	7	14C	4940
Pc	Sony Pcg71911M	1	14C	4941
Pc	Toshiba U500	1	14C	4942
Ericsson	E5303	3	BHandset (Power Up, Bad LCD)	4943
Ericsson	E5333	1	BHandset (Power Up, Bad LCD)	4944
Ericsson	E5506	1	BHandset (Power Up, Bad LCD)	4945
Ericsson	E5533	31	BHandset (Power Up, Bad LCD)	4946
Ericsson	E5603	8	BHandset (Power Up, Bad LCD)	4947
Ericsson	E5633	4	BHandset (Power Up, Bad LCD)	4948
Ericsson	E5653	2	BHandset (Power Up, Bad LCD)	4949
Ericsson	E5823	16	BHandset (Power Up, Bad LCD)	4950
Ericsson	E6533	1	BHandset (Power Up, Bad LCD)	4951
Ericsson	E6553	1	BHandset (Power Up, Bad LCD)	4952
Ericsson	E6633	3	BHandset (Power Up, Bad LCD)	4953
Ericsson	E6653	3	BHandset (Power Up, Bad LCD)	4954
Ericsson	E6683	1	BHandset (Power Up, Bad LCD)	4955
Ericsson	E6853	10	BHandset (Power Up, Bad LCD)	4956
Ericsson	F3111	79	BHandset (Power Up, Bad LCD)	4957
Ericsson	F3112	4	BHandset (Power Up, Bad LCD)	4958
Ericsson	F3113	2	BHandset (Power Up, Bad LCD)	4959
Ericsson	F3115	9	BHandset (Power Up, Bad LCD)	4960
Ericsson	F3211	7	BHandset (Power Up, Bad LCD)	4961
Ericsson	F3212	2	BHandset (Power Up, Bad LCD)	4962
Ericsson	F3213	2	BHandset (Power Up, Bad LCD)	4963
Ericsson	F3311	18	BHandset (Power Up, Bad LCD)	4964
Ericsson	F5121	23	BHandset (Power Up, Bad LCD)	4965
Ericsson	F5122	1	BHandset (Power Up, Bad LCD)	4966
Ericsson	F5321	6	BHandset (Power Up, Bad LCD)	4967
Ericsson	F8131	3	BHandset (Power Up, Bad LCD)	4968
Ericsson	F8331	50	BHandset (Power Up, Bad LCD)	4969
Ericsson	F8341	1	BHandset (Power Up, Bad LCD)	4970
Ericsson	G3121	49	BHandset (Power Up, Bad LCD)	4971
Ericsson	G3125	2	BHandset (Power Up, Bad LCD)	4972
Ericsson	G3221	12	BHandset (Power Up, Bad LCD)	4973
Ericsson	G3311	77	BHandset (Power Up, Bad LCD)	4974
Ericsson	G3312	3	BHandset (Power Up, Bad LCD)	4975
Ericsson	G3313	1	BHandset (Power Up, Bad LCD)	4976
Ericsson	G3421	6	BHandset (Power Up, Bad LCD)	4977
Ericsson	G8141	1	BHandset (Power Up, Bad LCD)	4978
Ericsson	G8331	1	BHandset (Power Up, Bad LCD)	4979
Ericsson	H3113	3	BHandset (Power Up, Bad LCD)	4980
Ericsson	H3223	1	BHandset (Power Up, Bad LCD)	4981
Ericsson	H3311	1	BHandset (Power Up, Bad LCD)	4982
Ericsson	H4113	4	BHandset (Power Up, Bad LCD)	4983
Ericsson	H4413	4	BHandset (Power Up, Bad LCD)	4984
Ericsson	i3312	9	BHandset (Power Up, Bad LCD)	4985
Ericsson	i4312	5	BHandset (Power Up, Bad LCD)	4986

Ericsson	XQ-AD51	2	BHandset (Power Up, Bad LCD)	4987
Ericsson	XQ-BC52	1	BHandset (Power Up, Bad LCD)	4988
Ericsson	XQ-CC54	1	BHandset (Power Up, Bad LCD)	4989
Huawei	ALP-L09	1	BHandset (Power Up, Bad LCD)	4990
Huawei	COL-L29	5	BHandset (Power Up, Bad LCD)	4991
Huawei	COR-L29	3	BHandset (Power Up, Bad LCD)	4992
Huawei	HMA-L09	2	BHandset (Power Up, Bad LCD)	4993
Huawei	HMA-L29	4	BHandset (Power Up, Bad LCD)	4994
Huawei	HONOR MAGIC V3 5G	1	BHandset (Power Up, Bad LCD)	4995
Huawei	INE-LX2	8	BHandset (Power Up, Bad LCD)	4996
Huawei	P10	41	BHandset (Power Up, Bad LCD)	4997
Huawei	P10 Lite	309	BHandset (Power Up, Bad LCD)	4998
Huawei	P10 PLUS	1	BHandset (Power Up, Bad LCD)	4999
Huawei	P20	74	BHandset (Power Up, Bad LCD)	5000
Huawei	P20 Lite	287	BHandset (Power Up, Bad LCD)	5001
Huawei	P30 Lite	3	BHandset (Power Up, Bad LCD)	5002
Huawei	P30 Pro	1	BHandset (Power Up, Bad LCD)	5003
Huawei	P8 Lite	1	BHandset (Power Up, Bad LCD)	5004
Huawei	PCT-L29	1	BHandset (Power Up, Bad LCD)	5005
Huawei	SNE-LX1	1	BHandset (Power Up, Bad LCD)	5006
Huawei	YAL-L21	1	BHandset (Power Up, Bad LCD)	5007
Lg	K200QM	1	BHandset (Power Up, Bad LCD)	5008
Lg	M320	1	BHandset (Power Up, Bad LCD)	5009
Lg	M470	1	BHandset (Power Up, Bad LCD)	5010
Lg	Q710	8	BHandset (Power Up, Bad LCD)	5011
Lg	X210	2	BHandset (Power Up, Bad LCD)	5012
Lg	X320	3	BHandset (Power Up, Bad LCD)	5013
Lg	X510	9	BHandset (Power Up, Bad LCD)	5014
Motorola	XT2000	84	BHandset (Power Up, Bad LCD)	5015
Motorola	XT2010	14	BHandset (Power Up, Bad LCD)	5016
Motorola	XT2013	12	BHandset (Power Up, Bad LCD)	5017
Motorola	XT2015	7	BHandset (Power Up, Bad LCD)	5018
Motorola	XT2016	3	BHandset (Power Up, Bad LCD)	5019
Motorola	XT2025	38	BHandset (Power Up, Bad LCD)	5020
Motorola	XT2027	7	BHandset (Power Up, Bad LCD)	5021
Motorola	XT2029	16	BHandset (Power Up, Bad LCD)	5022
Motorola	XT2043	2	BHandset (Power Up, Bad LCD)	5023
Motorola	XT2045	13	BHandset (Power Up, Bad LCD)	5024
Motorola	XT2053	74	BHandset (Power Up, Bad LCD)	5025
Motorola	XT2055	10	BHandset (Power Up, Bad LCD)	5026
Motorola	XT2075	1	BHandset (Power Up, Bad LCD)	5027
Motorola	XT2083	6	BHandset (Power Up, Bad LCD)	5028
Motorola	XT2091	1	BHandset (Power Up, Bad LCD)	5029
Motorola	XT2093	1	BHandset (Power Up, Bad LCD)	5030
Motorola	XT2095	1	BHandset (Power Up, Bad LCD)	5031
Motorola	XT2097	23	BHandset (Power Up, Bad LCD)	5032
Motorola	XT2113	1	BHandset (Power Up, Bad LCD)	5033
Motorola	XT2117	1	BHandset (Power Up, Bad LCD)	5034
Motorola	XT2127	1	BHandset (Power Up, Bad LCD)	5035
Motorola	XT2131	2	BHandset (Power Up, Bad LCD)	5036
Motorola	XT2133	3	BHandset (Power Up, Bad LCD)	5037
Motorola	XT2137	1	BHandset (Power Up, Bad LCD)	5038
Motorola	XT2155	34	BHandset (Power Up, Bad LCD)	5039
Motorola	XT2159	16	BHandset (Power Up, Bad LCD)	5040
Motorola	XT2163	5	BHandset (Power Up, Bad LCD)	5041
Motorola	XT2165	2	BHandset (Power Up, Bad LCD)	5042
Motorola	XT2167	14	BHandset (Power Up, Bad LCD)	5043
Motorola	XT2173	6	BHandset (Power Up, Bad LCD)	5044
Motorola	XT2213	7	BHandset (Power Up, Bad LCD)	5045
Motorola	XT2223	2	BHandset (Power Up, Bad LCD)	5046
Motorola	XT2227	7	BHandset (Power Up, Bad LCD)	5047
Motorola	XT2231	16	BHandset (Power Up, Bad LCD)	5048
Motorola	XT2233	1	BHandset (Power Up, Bad LCD)	5049
Motorola	XT2235	3	BHandset (Power Up, Bad LCD)	5050
Motorola	XT2237	1	BHandset (Power Up, Bad LCD)	5051
Motorola	XT2239	55	BHandset (Power Up, Bad LCD)	5052
Motorola	XT2245	1	BHandset (Power Up, Bad LCD)	5053
Motorola	XT2313	1	BHandset (Power Up, Bad LCD)	5054
Motorola	XT2341	2	BHandset (Power Up, Bad LCD)	5055
Motorola	XT2343	2	BHandset (Power Up, Bad LCD)	5056
Motorola	XT2345	19	BHandset (Power Up, Bad LCD)	5057
Motorola	XT2421	2	BHandset (Power Up, Bad LCD)	5058
Motorola	XT2451	1	BHandset (Power Up, Bad LCD)	5059
Nokia	1	1	BHandset (Power Up, Bad LCD)	5060
Nokia	2.1	1	BHandset (Power Up, Bad LCD)	5061
Nokia	2.2	1	BHandset (Power Up, Bad LCD)	5062
Nokia	3	28	BHandset (Power Up, Bad LCD)	5063
Nokia	3.1	10	BHandset (Power Up, Bad LCD)	5064
Nokia	3.1 Plus	2	BHandset (Power Up, Bad LCD)	5065
Nokia	3.2	2	BHandset (Power Up, Bad LCD)	5066
Nokia	3.4	3	BHandset (Power Up, Bad LCD)	5067
Nokia	4.2	13	BHandset (Power Up, Bad LCD)	5068
Nokia	5	14	BHandset (Power Up, Bad LCD)	5069
Nokia	5.1	10	BHandset (Power Up, Bad LCD)	5070
Nokia	5.1 Plus	1	BHandset (Power Up, Bad LCD)	5071
Nokia	6	11	BHandset (Power Up, Bad LCD)	5072

Nokia	6.1	17	BHandset (Power Up, Bad LCD)	5073
Nokia	6.2	1	BHandset (Power Up, Bad LCD)	5074
Nokia	7 Plus	10	BHandset (Power Up, Bad LCD)	5075
Nokia	7.1	3	BHandset (Power Up, Bad LCD)	5076
Nokia	8.1	3	BHandset (Power Up, Bad LCD)	5077
Nokia	C1 Plus	1	BHandset (Power Up, Bad LCD)	5078
Nokia	C2	1	BHandset (Power Up, Bad LCD)	5079
Nokia	C21	2	BHandset (Power Up, Bad LCD)	5080
Nokia	C21 Plus	1	BHandset (Power Up, Bad LCD)	5081
Nokia	G10	2	BHandset (Power Up, Bad LCD)	5082
Nokia	G11	1	BHandset (Power Up, Bad LCD)	5083
Nokia	G20	2	BHandset (Power Up, Bad LCD)	5084
Nokia	G21	1	BHandset (Power Up, Bad LCD)	5085
Nokia	G42 5G	1	BHandset (Power Up, Bad LCD)	5086
Nokia	G50	3	BHandset (Power Up, Bad LCD)	5087
Nokia	T20	1	BHandset (Power Up, Bad LCD)	5088
Other	Google G011C	3	BHandset (Power Up, Bad LCD)	5089
Other	Google G020F	4	BHandset (Power Up, Bad LCD)	5090
Other	Google G025J	2	BHandset (Power Up, Bad LCD)	5091
Other	Google G025N	1	BHandset (Power Up, Bad LCD)	5092
Other	Google G1AZg	1	BHandset (Power Up, Bad LCD)	5093
Other	Google GB7N6	4	BHandset (Power Up, Bad LCD)	5094
Other	Google Gc3Ve	13	BHandset (Power Up, Bad LCD)	5095
Other	Google Ggh2X	5	BHandset (Power Up, Bad LCD)	5096
Other	Google Gh11X	5	BHandset (Power Up, Bad LCD)	5097
Other	Google Glu0G	8	BHandset (Power Up, Bad LCD)	5098
Other	Google Gp4Bc	15	BHandset (Power Up, Bad LCD)	5099
Other	Google Gpj41	12	BHandset (Power Up, Bad LCD)	5100
Other	Google Gtt9Q	8	BHandset (Power Up, Bad LCD)	5101
Other	Google Gvu6C	9	BHandset (Power Up, Bad LCD)	5102
Other	Google Gwkk3	1	BHandset (Power Up, Bad LCD)	5103
Other	Google Gzc4K	1	BHandset (Power Up, Bad LCD)	5104
Other	Lenovo Tb300Xu	1	BHandset (Power Up, Bad LCD)	5105
Other	Lenovo Tb-8505	1	BHandset (Power Up, Bad LCD)	5106
Other	Lenovo Tb-X306X	1	BHandset (Power Up, Bad LCD)	5107
Other	Lenovo Tb-X606F	1	BHandset (Power Up, Bad LCD)	5108
Other	Lenovo Tb-X606X	2	BHandset (Power Up, Bad LCD)	5109
Other	One Plus	14	BHandset (Power Up, Bad LCD)	5110
Other	One Plus 2	4	BHandset (Power Up, Bad LCD)	5111
Other	One Plus 3	18	BHandset (Power Up, Bad LCD)	5112
Other	One Plus 5	11	BHandset (Power Up, Bad LCD)	5113
Other	One Plus 5T	6	BHandset (Power Up, Bad LCD)	5114
Other	One Plus 6	16	BHandset (Power Up, Bad LCD)	5115
Other	One Plus 7 Pro 5G	1	BHandset (Power Up, Bad LCD)	5116
Other	One Plus Nord N100	1	BHandset (Power Up, Bad LCD)	5117
Other	One Plus X	8	BHandset (Power Up, Bad LCD)	5118
Other	Oppo A15	1	BHandset (Power Up, Bad LCD)	5119
Other	Oppo A16s	4	BHandset (Power Up, Bad LCD)	5120
Other	Oppo A38	1	BHandset (Power Up, Bad LCD)	5121
Other	Oppo A5(2020)	4	BHandset (Power Up, Bad LCD)	5122
Other	Oppo A53	4	BHandset (Power Up, Bad LCD)	5123
Other	Oppo A54 5G	5	BHandset (Power Up, Bad LCD)	5124
Other	Oppo A54s	3	BHandset (Power Up, Bad LCD)	5125
Other	Oppo A58	4	BHandset (Power Up, Bad LCD)	5126
Other	Oppo A72	1	BHandset (Power Up, Bad LCD)	5127
Other	Oppo A74	1	BHandset (Power Up, Bad LCD)	5128
Other	Oppo A74 5G	6	BHandset (Power Up, Bad LCD)	5129
Other	Oppo A77	4	BHandset (Power Up, Bad LCD)	5130
Other	Oppo A77 5G	7	BHandset (Power Up, Bad LCD)	5131
Other	Oppo A78 5G	2	BHandset (Power Up, Bad LCD)	5132
Other	Oppo A9(2020)	2	BHandset (Power Up, Bad LCD)	5133
Other	Oppo A91	3	BHandset (Power Up, Bad LCD)	5134
Other	Oppo A92	2	BHandset (Power Up, Bad LCD)	5135
Other	Oppo A93	7	BHandset (Power Up, Bad LCD)	5136
Other	Oppo A94 5G	12	BHandset (Power Up, Bad LCD)	5137
Other	Oppo A95	4	BHandset (Power Up, Bad LCD)	5138
Other	Oppo A96	1	BHandset (Power Up, Bad LCD)	5139
Other	Oppo Find N2 Flip	10	BHandset (Power Up, Bad LCD)	5140
Other	Oppo Find X	3	BHandset (Power Up, Bad LCD)	5141
Other	Oppo Find X2 5G	1	BHandset (Power Up, Bad LCD)	5142
Other	Oppo Find X2 Lite 5G	3	BHandset (Power Up, Bad LCD)	5143
Other	Oppo Find X2 Pro 5G	1	BHandset (Power Up, Bad LCD)	5144
Other	Oppo Find X3 Neo 5G	1	BHandset (Power Up, Bad LCD)	5145
Other	Oppo Find X5 5G	1	BHandset (Power Up, Bad LCD)	5146
Other	Oppo Find X5 Lite 5G	2	BHandset (Power Up, Bad LCD)	5147
Other	Oppo Reno 10	1	BHandset (Power Up, Bad LCD)	5148
Other	Oppo Reno 2	7	BHandset (Power Up, Bad LCD)	5149
Other	Oppo Reno 2 Z	3	BHandset (Power Up, Bad LCD)	5150
Other	Oppo Reno 3 Pro	4	BHandset (Power Up, Bad LCD)	5151
Other	Oppo Reno 4	3	BHandset (Power Up, Bad LCD)	5152
Other	Oppo Reno 4 Z 5G	3	BHandset (Power Up, Bad LCD)	5153
Other	Oppo Reno 5 5G	1	BHandset (Power Up, Bad LCD)	5154
Other	Oppo Reno 5 Z 5G	2	BHandset (Power Up, Bad LCD)	5155
Other	Oppo Reno 5F	8	BHandset (Power Up, Bad LCD)	5156
Other	Oppo Reno 5G	1	BHandset (Power Up, Bad LCD)	5157
Other	Oppo Reno 6 5G	1	BHandset (Power Up, Bad LCD)	5158

Other	Oppo Reno 6 Z 5G	4	BHandset (Power Up, Bad LCD)	5159
Other	Oppo Reno 7 5G	1	BHandset (Power Up, Bad LCD)	5160
Other	Oppo Reno 7 Z 5G	1	BHandset (Power Up, Bad LCD)	5161
Other	Oppo Reno 8 5G	1	BHandset (Power Up, Bad LCD)	5162
Other	Oppo Reno 8 Lite 5G	17	BHandset (Power Up, Bad LCD)	5163
Other	Oppo Reno 8T 5G	5	BHandset (Power Up, Bad LCD)	5164
Other	Oppo Reno Z	1	BHandset (Power Up, Bad LCD)	5165
Other	Razer Phone 2	2	BHandset (Power Up, Bad LCD)	5166
Other	Razer Rz35-0215	7	BHandset (Power Up, Bad LCD)	5167
Other	Realme C21	1	BHandset (Power Up, Bad LCD)	5168
Other	Realme Pad	1	BHandset (Power Up, Bad LCD)	5169
Other	Realme X50	1	BHandset (Power Up, Bad LCD)	5170
Other	Tcl 20L	1	BHandset (Power Up, Bad LCD)	5171
Other	Tcl 40R 5G	1	BHandset (Power Up, Bad LCD)	5172
Other	Tcl Plex	1	BHandset (Power Up, Bad LCD)	5173
Other	Vivo Y52 5G	1	BHandset (Power Up, Bad LCD)	5174
Other	Windows Surface 1514	1	BHandset (Power Up, Bad LCD)	5175
Other	Windows Surface 1516	4	BHandset (Power Up, Bad LCD)	5176
Other	Windows Surface 1631	1	BHandset (Power Up, Bad LCD)	5177
Other	Windows Surface 1645	1	BHandset (Power Up, Bad LCD)	5178
Other	Windows Surface 1724	2	BHandset (Power Up, Bad LCD)	5179
Other	Xiaomi Mi 10T Lite 5G	11	BHandset (Power Up, Bad LCD)	5180
Other	Xiaomi Mi 11 Lite	2	BHandset (Power Up, Bad LCD)	5181
Other	Xiaomi Mi 11 Lite 5G	13	BHandset (Power Up, Bad LCD)	5182
Other	Xiaomi Mi 11 Lite 5G Ne	7	BHandset (Power Up, Bad LCD)	5183
Other	Xiaomi Mi 12 5G	1	BHandset (Power Up, Bad LCD)	5184
Other	Xiaomi Mi 8	2	BHandset (Power Up, Bad LCD)	5185
Other	Xiaomi Mi 8 Lite	9	BHandset (Power Up, Bad LCD)	5186
Other	Xiaomi Mi 9	11	BHandset (Power Up, Bad LCD)	5187
Other	Xiaomi Mi 9 Lite	5	BHandset (Power Up, Bad LCD)	5188
Other	Xiaomi Mi 9 Se	9	BHandset (Power Up, Bad LCD)	5189
Other	Xiaomi Mi 9T Pro	22	BHandset (Power Up, Bad LCD)	5190
Other	Xiaomi Mi Note 10 Lite	3	BHandset (Power Up, Bad LCD)	5191
Other	Xiaomi Redmi 10A	1	BHandset (Power Up, Bad LCD)	5192
Other	Xiaomi Redmi 8	2	BHandset (Power Up, Bad LCD)	5193
Other	Xiaomi Redmi 9A	5	BHandset (Power Up, Bad LCD)	5194
Other	Xiaomi Redmi 9T	10	BHandset (Power Up, Bad LCD)	5195
Other	Xiaomi Redmi Note 12 5G	1	BHandset (Power Up, Bad LCD)	5196
Other	Xiaomi Redmi Note 8 Pro	32	BHandset (Power Up, Bad LCD)	5197
Other	Xiaomi Redmi Note 8T	21	BHandset (Power Up, Bad LCD)	5198
Other	Xiaomi Redmi Note 9	3	BHandset (Power Up, Bad LCD)	5199
Zte	Axon 10 Pro 5G	15	BHandset (Power Up, Bad LCD)	5200
Zte	Axon 11 5G	10	BHandset (Power Up, Bad LCD)	5201
Zte	Axon 20 5G	3	BHandset (Power Up, Bad LCD)	5202
Zte	Axon 9 Pro	2	BHandset (Power Up, Bad LCD)	5203
Zte	Blade V10 Vita	5	BHandset (Power Up, Bad LCD)	5204
Zte	Blade V2020 SMart	2	BHandset (Power Up, Bad LCD)	5205
Zte	Blade V2020 Vita	9	BHandset (Power Up, Bad LCD)	5206
Zte	Blade V30	3	BHandset (Power Up, Bad LCD)	5207
Zte	Blade V30 Vita	2	BHandset (Power Up, Bad LCD)	5208
Zte	Blade V40 Design	7	BHandset (Power Up, Bad LCD)	5209
Zte	Blade V40 Pro	1	BHandset (Power Up, Bad LCD)	5210
Zte	Blade V40 SMart	18	BHandset (Power Up, Bad LCD)	5211
Zte	Blade V40 Vita	40	BHandset (Power Up, Bad LCD)	5212
Ericsson	E5533	5	BHandset (No Power)	5213
Ericsson	E5603	1	BHandset (No Power)	5214
Ericsson	E5606	1	BHandset (No Power)	5215
Ericsson	E5633	1	BHandset (No Power)	5216
Ericsson	E5823	5	BHandset (No Power)	5217
Ericsson	E6553	1	BHandset (No Power)	5218
Ericsson	E6633	3	BHandset (No Power)	5219
Ericsson	E6653	5	BHandset (No Power)	5220
Ericsson	E6853	5	BHandset (No Power)	5221
Ericsson	F3111	6	BHandset (No Power)	5222
Ericsson	F3112	2	BHandset (No Power)	5223
Ericsson	F3115	1	BHandset (No Power)	5224
Ericsson	F3211	2	BHandset (No Power)	5225
Ericsson	F3311	1	BHandset (No Power)	5226
Ericsson	F5121	6	BHandset (No Power)	5227
Ericsson	F5321	11	BHandset (No Power)	5228
Ericsson	F8331	17	BHandset (No Power)	5229
Ericsson	G3121	40	BHandset (No Power)	5230
Ericsson	G3125	3	BHandset (No Power)	5231
Ericsson	G3221	3	BHandset (No Power)	5232
Ericsson	G3311	11	BHandset (No Power)	5233
Ericsson	G3313	1	BHandset (No Power)	5234
Ericsson	G3421	1	BHandset (No Power)	5235
Ericsson	G8141	1	BHandset (No Power)	5236
Ericsson	H3113	10	BHandset (No Power)	5237
Ericsson	H3213	2	BHandset (No Power)	5238
Ericsson	H4113	1	BHandset (No Power)	5239
Ericsson	H4413	3	BHandset (No Power)	5240
Ericsson	H8314	2	BHandset (No Power)	5241
Ericsson	i3312	1	BHandset (No Power)	5242
Ericsson	i4312	2	BHandset (No Power)	5243
Ericsson	i4332	1	BHandset (No Power)	5244

Huawei	ALP-L09	1	BHandset (No Power)	5245
Huawei	ALP-L29	1	BHandset (No Power)	5246
Huawei	BLA-L09	1	BHandset (No Power)	5247
Huawei	FRL-L23	1	BHandset (No Power)	5248
Huawei	HMA-L29	2	BHandset (No Power)	5249
Huawei	LYA-L29	15	BHandset (No Power)	5250
Huawei	P10	1	BHandset (No Power)	5251
Huawei	P10 Lite	1	BHandset (No Power)	5252
Huawei	P10 PLUS	1	BHandset (No Power)	5253
Huawei	P20	5	BHandset (No Power)	5254
Huawei	P20 Lite	8	BHandset (No Power)	5255
Huawei	P20 Pro	4	BHandset (No Power)	5256
Huawei	P30 Lite	1	BHandset (No Power)	5257
Huawei	P7	1	BHandset (No Power)	5258
Huawei	SNE-LX1	9	BHandset (No Power)	5259
Lg	Q710	1	BHandset (No Power)	5260
Motorola	XT2010	4	BHandset (No Power)	5261
Motorola	XT2013	2	BHandset (No Power)	5262
Motorola	XT2015	5	BHandset (No Power)	5263
Motorola	XT2016	2	BHandset (No Power)	5264
Motorola	XT2019	8	BHandset (No Power)	5265
Motorola	XT2025	34	BHandset (No Power)	5266
Motorola	XT2027	6	BHandset (No Power)	5267
Motorola	XT2029	6	BHandset (No Power)	5268
Motorola	XT2041	6	BHandset (No Power)	5269
Motorola	XT2045	3	BHandset (No Power)	5270
Motorola	XT2053	4	BHandset (No Power)	5271
Motorola	XT2055	5	BHandset (No Power)	5272
Motorola	XT2095	2	BHandset (No Power)	5273
Motorola	XT2097	3	BHandset (No Power)	5274
Motorola	XT2127	3	BHandset (No Power)	5275
Motorola	XT2128	2	BHandset (No Power)	5276
Motorola	XT2137	1	BHandset (No Power)	5277
Motorola	XT2149	1	BHandset (No Power)	5278
Motorola	XT2159	4	BHandset (No Power)	5279
Motorola	XT2231	3	BHandset (No Power)	5280
Motorola	XT2239	3	BHandset (No Power)	5281
Motorola	XT2331	2	BHandset (No Power)	5282
Motorola	XT2421	3	BHandset (No Power)	5283
Nokia	2.2	1	BHandset (No Power)	5284
Nokia	3	8	BHandset (No Power)	5285
Nokia	3.1	2	BHandset (No Power)	5286
Nokia	3.1 Plus	2	BHandset (No Power)	5287
Nokia	3.1(2018)	1	BHandset (No Power)	5288
Nokia	3.2	1	BHandset (No Power)	5289
Nokia	4.2	2	BHandset (No Power)	5290
Nokia	5	7	BHandset (No Power)	5291
Nokia	5.1	11	BHandset (No Power)	5292
Nokia	5.1 Plus	12	BHandset (No Power)	5293
Nokia	5.4	1	BHandset (No Power)	5294
Nokia	6	10	BHandset (No Power)	5295
Nokia	6.1	9	BHandset (No Power)	5296
Nokia	6.1 Plus	1	BHandset (No Power)	5297
Nokia	6.2	1	BHandset (No Power)	5298
Nokia	7 Plus	4	BHandset (No Power)	5299
Nokia	7.1	12	BHandset (No Power)	5300
Nokia	8	1	BHandset (No Power)	5301
Nokia	8.1	2	BHandset (No Power)	5302
Nokia	C2	1	BHandset (No Power)	5303
Nokia	G10	1	BHandset (No Power)	5304
Other	Google G011C	2	BHandset (No Power)	5305
Other	Google G020F	1	BHandset (No Power)	5306
Other	Google G020P	2	BHandset (No Power)	5307
Other	Google G025I	4	BHandset (No Power)	5308
Other	Google G025N	2	BHandset (No Power)	5309
Other	Google G1AZg	3	BHandset (No Power)	5310
Other	Google G9Fpl	1	BHandset (No Power)	5311
Other	Google GB7N6	12	BHandset (No Power)	5312
Other	Google Gh11X	2	BHandset (No Power)	5313
Other	Google Glu0G	2	BHandset (No Power)	5314
Other	Google Gp4Bc	10	BHandset (No Power)	5315
Other	Google Gpj41	3	BHandset (No Power)	5316
Other	Google Gvu6C	16	BHandset (No Power)	5317
Other	One Plus	1	BHandset (No Power)	5318
Other	One Plus 3	4	BHandset (No Power)	5319
Other	One Plus 5T	3	BHandset (No Power)	5320
Other	One Plus 6	2	BHandset (No Power)	5321
Other	Oppo A17	2	BHandset (No Power)	5322
Other	Oppo A54 5G	2	BHandset (No Power)	5323
Other	Oppo A76	1	BHandset (No Power)	5324
Other	Oppo A78 5G	5	BHandset (No Power)	5325
Other	Oppo A9(2020)	1	BHandset (No Power)	5326
Other	Oppo Find N2 Flip	1	BHandset (No Power)	5327
Other	Oppo Find X3 Lite 5G	1	BHandset (No Power)	5328
Other	Oppo Reno 5 5G	1	BHandset (No Power)	5329
Other	Razer Rz35-0215	6	BHandset (No Power)	5330

Other	Realme C3	2	BHandset (No Power)	5331
Other	Tcl 10 Se	1	BHandset (No Power)	5332
Other	Tcl 10L	1	BHandset (No Power)	5333
Other	Tcl 30 Se	1	BHandset (No Power)	5334
Other	Tcl 40 Se	2	BHandset (No Power)	5335
Other	Tcl 40R 5G	1	BHandset (No Power)	5336
Other	Vivo Y02	1	BHandset (No Power)	5337
Other	Vivo Y02S	1	BHandset (No Power)	5338
Other	Vivo Y16	2	BHandset (No Power)	5339
Other	Vivo Y20	1	BHandset (No Power)	5340
Other	Vivo Y21	1	BHandset (No Power)	5341
Other	Vivo Y21S	1	BHandset (No Power)	5342
Other	Vivo Y22S	5	BHandset (No Power)	5343
Other	Xiaomi Mi 11 Lite	1	BHandset (No Power)	5344
Other	Xiaomi Mi 11T 5G	2	BHandset (No Power)	5345
Other	Xiaomi Mi 11T Pro 5G	1	BHandset (No Power)	5346
Other	Xiaomi Mi 9	2	BHandset (No Power)	5347
Other	Xiaomi Mi 9 Lite	1	BHandset (No Power)	5348
Other	Xiaomi Mi 9T	1	BHandset (No Power)	5349
Other	Xiaomi Mi Note 10 Lite	1	BHandset (No Power)	5350
Other	Xiaomi Poco X3 Pro	9	BHandset (No Power)	5351
Other	Xiaomi Redmi 10	1	BHandset (No Power)	5352
Other	Xiaomi Redmi 10 5G	2	BHandset (No Power)	5353
Other	Xiaomi Redmi 10C	2	BHandset (No Power)	5354
Other	Xiaomi Redmi 12 5G	1	BHandset (No Power)	5355
Other	Xiaomi Redmi 12C	2	BHandset (No Power)	5356
Other	Xiaomi Redmi 9	1	BHandset (No Power)	5357
Other	Xiaomi Redmi 9A	7	BHandset (No Power)	5358
Other	Xiaomi Redmi 9C	7	BHandset (No Power)	5359
Other	Xiaomi Redmi 9T	3	BHandset (No Power)	5360
Other	Xiaomi Redmi Note 10 5G	2	BHandset (No Power)	5361
Other	Xiaomi Redmi Note 10 Pro	1	BHandset (No Power)	5362
Other	Xiaomi Redmi Note 10S	3	BHandset (No Power)	5363
Other	Xiaomi Redmi Note 11	3	BHandset (No Power)	5364
Other	Xiaomi Redmi Note 12	3	BHandset (No Power)	5365
Other	Xiaomi Redmi Note 12 Pro 5G	2	BHandset (No Power)	5366
Other	Xiaomi Redmi Note 12 Pro+ 5G	3	BHandset (No Power)	5367
Other	Xiaomi Redmi Note 8T	6	BHandset (No Power)	5368
Other	Xiaomi Redmi Note 9	5	BHandset (No Power)	5369
Other	Xiaomi Redmi Note 9 Pro	1	BHandset (No Power)	5370
Zte	Axon 50 Lite	1	BHandset (No Power)	5371
Zte	Blade 20	2	BHandset (No Power)	5372
Zte	Blade V30 Vita	1	BHandset (No Power)	5373
Zte	Blade V40 SMart	2	BHandset (No Power)	5374
Zte	Blade V40 Vita	2	BHandset (No Power)	5375
Acer	A3-A20	1	BHandset	5376
Acer	A60	3	BHandset	5377
Acer	A7001	1	BHandset	5378
Acer	A8003	1	BHandset	5379
Acer	Actab1021	2	BHandset	5380
Acer	Actab1022	4	BHandset	5381
Acer	Actab1024	3	BHandset	5382
Acer	Actab10Kb24	4	BHandset	5383
Acer	Actab1123	1	BHandset	5384
Acer	Actab1422	3	BHandset	5385
Acer	Actab721	2	BHandset	5386
Acer	B1-850	3	BHandset	5387
Acer	B3-A20	3	BHandset	5388
Acer	B3-A30	5	BHandset	5389
Acer	B3-A40	1	BHandset	5390
Acer	E380	1	BHandset	5391
Acer	N18Q1	1	BHandset	5392
Acer	Sospiro Ax64	1	BHandset	5393
Acer	T06	1	BHandset	5394
Acer	W510	1	BHandset	5395
Acer	Z520	1	BHandset	5396
Alcatel	OT1013	3	BHandset	5397
Alcatel	OT1016	2	BHandset	5398
Alcatel	OT1030	2	BHandset	5399
Alcatel	OT1052	1	BHandset	5400
Alcatel	OT1054	5	BHandset	5401
Alcatel	OT1066	25	BHandset	5402
Alcatel	OT1067	1	BHandset	5403
Alcatel	OT1068	17	BHandset	5404
Alcatel	OT2000	8	BHandset	5405
Alcatel	OT2001	1	BHandset	5406
Alcatel	OT2003	6	BHandset	5407
Alcatel	OT2004	157	BHandset	5408
Alcatel	OT2007	5	BHandset	5409
Alcatel	OT2010	1	BHandset	5410
Alcatel	OT2012	1	BHandset	5411
Alcatel	OT2020	5	BHandset	5412
Alcatel	OT2036	53	BHandset	5413
Alcatel	OT2038	40	BHandset	5414
Alcatel	OT2045	46	BHandset	5415
Alcatel	OT2051	470	BHandset	5416

Alcatel	OT2052	47	BHandset	5417
Alcatel	OT2053	11	BHandset	5418
Alcatel	OT2057	6	BHandset	5419
Alcatel	OT2067	14	BHandset	5420
Alcatel	OT3025	2	BHandset	5421
Alcatel	OT3026	49	BHandset	5422
Alcatel	OT3082	214	BHandset	5423
Alcatel	OT4003	165	BHandset	5424
Alcatel	OT4009	11	BHandset	5425
Alcatel	OT4010	18	BHandset	5426
Alcatel	OT4013	117	BHandset	5427
Alcatel	OT4015	2	BHandset	5428
Alcatel	OT4018	55	BHandset	5429
Alcatel	OT4022	1	BHandset	5430
Alcatel	OT4024	56	BHandset	5431
Alcatel	OT4027	41	BHandset	5432
Alcatel	OT4030	50	BHandset	5433
Alcatel	OT4031	1	BHandset	5434
Alcatel	OT4032	1	BHandset	5435
Alcatel	OT4033	45	BHandset	5436
Alcatel	OT4034	228	BHandset	5437
Alcatel	OT4035	7	BHandset	5438
Alcatel	OT4037	7	BHandset	5439
Alcatel	OT4044	10	BHandset	5440
Alcatel	OT4047	16	BHandset	5441
Alcatel	OT4052	55	BHandset	5442
Alcatel	OT4055	2	BHandset	5443
Alcatel	OT4056	3	BHandset	5444
Alcatel	OT4060	6	BHandset	5445
Alcatel	OT4087	3	BHandset	5446
Alcatel	OT5001	5	BHandset	5447
Alcatel	OT5002	73	BHandset	5448
Alcatel	OT5003	44	BHandset	5449
Alcatel	OT5006	1	BHandset	5450
Alcatel	OT5007	2	BHandset	5451
Alcatel	OT5008	16	BHandset	5452
Alcatel	OT5009	9	BHandset	5453
Alcatel	OT5010	39	BHandset	5454
Alcatel	OT5015	10	BHandset	5455
Alcatel	OT5017	24	BHandset	5456
Alcatel	OT5020	43	BHandset	5457
Alcatel	OT5022	12	BHandset	5458
Alcatel	OT5024	8	BHandset	5459
Alcatel	OT5025	1	BHandset	5460
Alcatel	OT5026	5	BHandset	5461
Alcatel	OT5030	22	BHandset	5462
Alcatel	OT5036	29	BHandset	5463
Alcatel	OT5037	1	BHandset	5464
Alcatel	OT5038	1	BHandset	5465
Alcatel	OT5039	7	BHandset	5466
Alcatel	OT5041	1	BHandset	5467
Alcatel	OT5042	27	BHandset	5468
Alcatel	OT5044	35	BHandset	5469
Alcatel	OT5045	42	BHandset	5470
Alcatel	OT5046	8	BHandset	5471
Alcatel	OT5047	7	BHandset	5472
Alcatel	OT5048	3	BHandset	5473
Alcatel	OT5049	1	BHandset	5474
Alcatel	OT5050	4	BHandset	5475
Alcatel	OT5051	34	BHandset	5476
Alcatel	OT5052	4	BHandset	5477
Alcatel	OT5053	1	BHandset	5478
Alcatel	OT5054	2	BHandset	5479
Alcatel	OT5056	15	BHandset	5480
Alcatel	OT5059	57	BHandset	5481
Alcatel	OT5060	1	BHandset	5482
Alcatel	OT5065	1	BHandset	5483
Alcatel	OT5080	2	BHandset	5484
Alcatel	OT5095	1	BHandset	5485
Alcatel	OT5099	1	BHandset	5486
Alcatel	OT6010	5	BHandset	5487
Alcatel	OT6012	5	BHandset	5488
Alcatel	OT6016	2	BHandset	5489
Alcatel	OT6025	1	BHandset	5490
Alcatel	OT6030	7	BHandset	5491
Alcatel	OT6034	1	BHandset	5492
Alcatel	OT6036	13	BHandset	5493
Alcatel	OT6039	10	BHandset	5494
Alcatel	OT6040	1	BHandset	5495
Alcatel	OT6044	1	BHandset	5496
Alcatel	OT6050	3	BHandset	5497
Alcatel	OT6055	3	BHandset	5498
Alcatel	OT606	3	BHandset	5499
Alcatel	OT6233	2	BHandset	5500
Alcatel	OT7040	6	BHandset	5501
Alcatel	OT7041	5	BHandset	5502

Alcatel	OT7047	5	BHandset	5503
Alcatel	OT7048	7	BHandset	5504
Alcatel	OT8000	2	BHandset	5505
Alcatel	OT8008	1	BHandset	5506
Alcatel	OT8050	7	BHandset	5507
Alcatel	OT8055	1	BHandset	5508
Alcatel	OT8063	3	BHandset	5509
Alcatel	OT8068	1	BHandset	5510
Alcatel	OT8079	1	BHandset	5511
Alcatel	OT8092	1	BHandset	5512
Alcatel	OT815	11	BHandset	5513
Alcatel	OT9001	18	BHandset	5514
Alcatel	OT9007	1	BHandset	5515
Alcatel	OT9008	9	BHandset	5516
Alcatel	OT9010	1	BHandset	5517
Alcatel	OT9022	3	BHandset	5518
Alcatel	OT9026	2	BHandset	5519
Alcatel	OT9027	9	BHandset	5520
Alcatel	OT903	27	BHandset	5521
Alcatel	OT9032	8	BHandset	5522
Alcatel	OT918	3	BHandset	5523
Alcatel	OT922	17	BHandset	5524
Alcatel	OT983	1	BHandset	5525
Alcatel	OT991	2	BHandset	5526
Alcatel	OT993	5	BHandset	5527
Alcatel	OT995	5	BHandset	5528
Alcatel	OT997	12	BHandset	5529
Alcatel	OT-A571	1	BHandset	5530
Alcatel	OT-P310	1	BHandset	5531
Alcatel	OT-P330	2	BHandset	5532
Asus	A001	1	BHandset	5533
Asus	A002	1	BHandset	5534
Asus	A007	3	BHandset	5535
Asus	K004	3	BHandset	5536
Asus	K00B	2	BHandset	5537
Asus	K00E	3	BHandset	5538
Asus	K00F	2	BHandset	5539
Asus	K013	1	BHandset	5540
Asus	K017	1	BHandset	5541
Asus	Me370T	4	BHandset	5542
Asus	Nexus 7	17	BHandset	5543
Asus	Nexus 7 K008	12	BHandset	5544
Asus	P00A	6	BHandset	5545
Asus	P00C	6	BHandset	5546
Asus	P01M	1	BHandset	5547
Asus	P024	1	BHandset	5548
Asus	P028	2	BHandset	5549
Asus	T00F	1	BHandset	5550
Asus	T00G	1	BHandset	5551
Asus	T00J	7	BHandset	5552
Asus	T00P	3	BHandset	5553
Asus	Tf700	1	BHandset	5554
Asus	X007D	1	BHandset	5555
Asus	X00Dd	3	BHandset	5556
Asus	X018D	1	BHandset	5557
Asus	X01Ad	1	BHandset	5558
Asus	Z002	1	BHandset	5559
Asus	Z00Ad	5	BHandset	5560
Asus	Z00D	1	BHandset	5561
Asus	Z00Ed	3	BHandset	5562
Asus	Z00Ld	2	BHandset	5563
Asus	Z00Ud	3	BHandset	5564
Asus	Z00Vd	1	BHandset	5565
Asus	Z010D	1	BHandset	5566
Asus	Z011D	2	BHandset	5567
Asus	Z017D	4	BHandset	5568
Asus	Z01Bd	1	BHandset	5569
Blackberry	BB9000	56	BHandset	5570
Blackberry	BB9100	3	BHandset	5571
Blackberry	BB9105	13	BHandset	5572
Blackberry	BB9220	5	BHandset	5573
Blackberry	BB9300	1	BHandset	5574
Blackberry	BB9320	164	BHandset	5575
Blackberry	BB9360	94	BHandset	5576
Blackberry	BB9380	5	BHandset	5577
Blackberry	BB9520	1	BHandset	5578
Blackberry	BB9700	56	BHandset	5579
Blackberry	BB9720	67	BHandset	5580
Blackberry	BB9780	10	BHandset	5581
Blackberry	BB9790	20	BHandset	5582
Blackberry	BB9800	7	BHandset	5583
Blackberry	BB9800 (倒键)	27	BHandset	5584
Blackberry	BB9860	4	BHandset	5585
Blackberry	BB9900	15	BHandset	5586
Blackberry	BB9900 (倒键)	6	BHandset	5587
Blackberry	BB9930	1	BHandset	5588

Blackberry	DTEK50	17	BHandset	5589
Blackberry	DTEK60	1	BHandset	5590
Blackberry	Playbook (16GB)	2	BHandset	5591
Blackberry	Playbook (32GB)	2	BHandset	5592
Blackberry	Priv	1	BHandset	5593
Blackberry	Q10	1	BHandset	5594
Blackberry	Q20 (倒键)	1	BHandset	5595
Blackberry	Q5	1	BHandset	5596
Blackberry	Z10	13	BHandset	5597
Blackberry	Z10 4G	103	BHandset	5598
Blackberry	Z3	7	BHandset	5599
Blackberry	Z30	3	BHandset	5600
Blackberry	Z30 4G	9	BHandset	5601
Dell	T02D	7	BHandset	5602
Dell	Venue 8 Pro	17	BHandset	5603
Ericsson	C1505	11	BHandset	5604
Ericsson	C1904	14	BHandset	5605
Ericsson	C1905	17	BHandset	5606
Ericsson	C2104	2	BHandset	5607
Ericsson	C2105	31	BHandset	5608
Ericsson	C2305	1	BHandset	5609
Ericsson	C5302	1	BHandset	5610
Ericsson	C5303	25	BHandset	5611
Ericsson	C6833	12	BHandset	5612
Ericsson	C6903	33	BHandset	5613
Ericsson	C6906	7	BHandset	5614
Ericsson	C702	1	BHandset	5615
Ericsson	D2004	39	BHandset	5616
Ericsson	D2005	13	BHandset	5617
Ericsson	D2203	9	BHandset	5618
Ericsson	D2303	144	BHandset	5619
Ericsson	D2306	35	BHandset	5620
Ericsson	D2403	10	BHandset	5621
Ericsson	D2533	4	BHandset	5622
Ericsson	D5103	14	BHandset	5623
Ericsson	D5106	2	BHandset	5624
Ericsson	D5322	1	BHandset	5625
Ericsson	D5503	55	BHandset	5626
Ericsson	D5803	59	BHandset	5627
Ericsson	D5833	15	BHandset	5628
Ericsson	D6503	33	BHandset	5629
Ericsson	D6603	54	BHandset	5630
Ericsson	D6653	12	BHandset	5631
Ericsson	E2003	18	BHandset	5632
Ericsson	E2053	31	BHandset	5633
Ericsson	E2104	47	BHandset	5634
Ericsson	E2105	13	BHandset	5635
Ericsson	E2115	3	BHandset	5636
Ericsson	E2303	88	BHandset	5637
Ericsson	E2306	10	BHandset	5638
Ericsson	E2353	31	BHandset	5639
Ericsson	E2363	1	BHandset	5640
Ericsson	E5353	26	BHandset	5641
Ericsson	E6553	1	BHandset	5642
Ericsson	J108	6	BHandset	5643
Ericsson	K800	25	BHandset	5644
Ericsson	K810	1	BHandset	5645
Ericsson	LT18i	184	BHandset	5646
Ericsson	LT22i	1	BHandset	5647
Ericsson	LT25i	2	BHandset	5648
Ericsson	LT26i	38	BHandset	5649
Ericsson	LT26W	11	BHandset	5650
Ericsson	LT28i	1	BHandset	5651
Ericsson	LT30p	8	BHandset	5652
Ericsson	LT36	74	BHandset	5653
Ericsson	MK16i	13	BHandset	5654
Ericsson	MT11i	30	BHandset	5655
Ericsson	MT15i	9	BHandset	5656
Ericsson	S500i	5	BHandset	5657
Ericsson	SGPT311	2	BHandset	5658
Ericsson	SGPT521	8	BHandset	5659
Ericsson	SGPT771	1	BHandset	5660
Ericsson	SK17i	23	BHandset	5661
Ericsson	SO-04G	3	BHandset	5662
Ericsson	ST15i	18	BHandset	5663
Ericsson	ST18i	6	BHandset	5664
Ericsson	ST21i	55	BHandset	5665
Ericsson	ST23i	3	BHandset	5666
Ericsson	ST25i	14	BHandset	5667
Ericsson	ST26i	31	BHandset	5668
Ericsson	ST27i	11	BHandset	5669
Ericsson	W200i	1	BHandset	5670
Ericsson	W20i	24	BHandset	5671
Ericsson	W350	3	BHandset	5672
Ericsson	W508	10	BHandset	5673
Ericsson	W580	13	BHandset	5674

Ericsson	W595	2	BHandset	5675
Ericsson	W715	1	BHandset	5676
Ericsson	W910	1	BHandset	5677
Ericsson	WT19i	1	BHandset	5678
Ericsson	X12	17	BHandset	5679
Ericsson	X8	6	BHandset	5680
Ericsson	Z750	7	BHandset	5681
Htc	10	139	BHandset	5682
Htc	10 EVO	7	BHandset	5683
Htc	7 Mozart	4	BHandset	5684
Htc	7 Trophy	8	BHandset	5685
Htc	8S	59	BHandset	5686
Htc	8X	3	BHandset	5687
Htc	ChaCha	6	BHandset	5688
Htc	Desire	46	BHandset	5689
Htc	Desire 10 Lifestyle	2	BHandset	5690
Htc	Desire 10 Pro	3	BHandset	5691
Htc	Desire 12 Plus	1	BHandset	5692
Htc	Desire 12+	1	BHandset	5693
Htc	Desire 20 Pro	1	BHandset	5694
Htc	Desire 200	2	BHandset	5695
Htc	Desire 300	15	BHandset	5696
Htc	Desire 310	48	BHandset	5697
Htc	Desire 320	4	BHandset	5698
Htc	Desire 500	19	BHandset	5699
Htc	Desire 510	55	BHandset	5700
Htc	Desire 520	2	BHandset	5701
Htc	Desire 526	4	BHandset	5702
Htc	Desire 530	23	BHandset	5703
Htc	Desire 601	2	BHandset	5704
Htc	Desire 610	17	BHandset	5705
Htc	Desire 620	5	BHandset	5706
Htc	Desire 626	32	BHandset	5707
Htc	Desire 626s	24	BHandset	5708
Htc	Desire 628	1	BHandset	5709
Htc	Desire 650	61	BHandset	5710
Htc	Desire 816	6	BHandset	5711
Htc	Desire 820	4	BHandset	5712
Htc	Desire 825	6	BHandset	5713
Htc	Desire 826	1	BHandset	5714
Htc	Desire C	45	BHandset	5715
Htc	Desire Eye	5	BHandset	5716
Htc	Desire HD	4	BHandset	5717
Htc	Desire S	25	BHandset	5718
Htc	Desire X	52	BHandset	5719
Htc	Desire Z	3	BHandset	5720
Htc	Explorer	5	BHandset	5721
Htc	HD II	3	BHandset	5722
Htc	Incredible S	12	BHandset	5723
Htc	Nexus 9	6	BHandset	5724
Htc	One	40	BHandset	5725
Htc	One A9	1	BHandset	5726
Htc	One A9S	6	BHandset	5727
Htc	One E9	1	BHandset	5728
Htc	One M8	12	BHandset	5729
Htc	One M8S	9	BHandset	5730
Htc	One M9	16	BHandset	5731
Htc	One Max	2	BHandset	5732
Htc	One Mini	19	BHandset	5733
Htc	One Mini II	7	BHandset	5734
Htc	One S	5	BHandset	5735
Htc	One SV	4	BHandset	5736
Htc	One SV 4G	6	BHandset	5737
Htc	One V	21	BHandset	5738
Htc	One X	40	BHandset	5739
Htc	One X+	3	BHandset	5740
Htc	One X9	2	BHandset	5741
Htc	One XL	4	BHandset	5742
Htc	Radar	3	BHandset	5743
Htc	Rhyme	1	BHandset	5744
Htc	Sensation	46	BHandset	5745
Htc	Sensation XE	6	BHandset	5746
Htc	Sensation XL	9	BHandset	5747
Htc	U Play	14	BHandset	5748
Htc	U Ultra	21	BHandset	5749
Htc	U11	59	BHandset	5750
Htc	U11 Life	40	BHandset	5751
Htc	U11 Plus	2	BHandset	5752
Htc	U12 Life	2	BHandset	5753
Htc	U12 Plus	13	BHandset	5754
Htc	U20	4	BHandset	5755
Htc	Wildfire	14	BHandset	5756
Htc	Wildfire S	70	BHandset	5757
Huawei	AGR-K-L09	2	BHandset	5758
Huawei	AGR-L09	1	BHandset	5759
Huawei	AGR-W09	4	BHandset	5760

Huawei	AGS2-L09	1	BHandset	5761
Huawei	AGS2-W09	7	BHandset	5762
Huawei	AGS3-W09	1	BHandset	5763
Huawei	AGS-L09	6	BHandset	5764
Huawei	AGS-W09	7	BHandset	5765
Huawei	AMN-LX2	24	BHandset	5766
Huawei	AMN-LX9	3	BHandset	5767
Huawei	ART-L28	1	BHandset	5768
Huawei	ART-L29	2	BHandset	5769
Huawei	ATU-AL10	1	BHandset	5770
Huawei	ATU-L11	37	BHandset	5771
Huawei	ATU-L21	60	BHandset	5772
Huawei	ATU-L22	52	BHandset	5773
Huawei	ATU-L31	96	BHandset	5774
Huawei	ATU-LX3	60	BHandset	5775
Huawei	AUM-L29	7	BHandset	5776
Huawei	BAC-L23	1	BHandset	5777
Huawei	BAH2-W19	6	BHandset	5778
Huawei	BAH-W09	3	BHandset	5779
Huawei	BG2-U01	1	BHandset	5780
Huawei	BG2-W09	5	BHandset	5781
Huawei	BGO-DL09	1	BHandset	5782
Huawei	BLL-L22	2	BHandset	5783
Huawei	BLL-L23	10	BHandset	5784
Huawei	BLN-L21	6	BHandset	5785
Huawei	BND-L21	1	BHandset	5786
Huawei	BND-TL10	1	BHandset	5787
Huawei	BTW-W09	1	BHandset	5788
Huawei	CAG-L03	91	BHandset	5789
Huawei	CAM-L03	17	BHandset	5790
Huawei	CAM-L21	20	BHandset	5791
Huawei	CAM-L29	1	BHandset	5792
Huawei	CAN-L01	1	BHandset	5793
Huawei	CAN-L11	45	BHandset	5794
Huawei	CAN-L12	1	BHandset	5795
Huawei	CHC-U01	5	BHandset	5796
Huawei	CHC-U03	1	BHandset	5797
Huawei	Che2-L11	3	BHandset	5798
Huawei	CHM-U01	2	BHandset	5799
Huawei	CRO-L03	1	BHandset	5800
Huawei	CRO-L23	1	BHandset	5801
Huawei	CRR-L09	6	BHandset	5802
Huawei	CUN-L01	3	BHandset	5803
Huawei	CUN-L02	8	BHandset	5804
Huawei	CUN-L21	1	BHandset	5805
Huawei	DAV-703L	1	BHandset	5806
Huawei	DIG-L03	2	BHandset	5807
Huawei	DIG-L21	1	BHandset	5808
Huawei	DIG-LX3	2	BHandset	5809
Huawei	DLI-L22	9	BHandset	5810
Huawei	DRA-L01	10	BHandset	5811
Huawei	DRA-L21	12	BHandset	5812
Huawei	DRA-LX1	1	BHandset	5813
Huawei	DRA-LX2	2	BHandset	5814
Huawei	DRA-LX3	41	BHandset	5815
Huawei	DRA-LX9	24	BHandset	5816
Huawei	DUA-L22	14	BHandset	5817
Huawei	DUB-LX1	2	BHandset	5818
Huawei	DUB-LX3	23	BHandset	5819
Huawei	DUK-L09	2	BHandset	5820
Huawei	EDI-AL10	1	BHandset	5821
Huawei	FDR-A01L	1	BHandset	5822
Huawei	FIG-LX1	34	BHandset	5823
Huawei	FIG-LX3	7	BHandset	5824
Huawei	FLA-LX3	1	BHandset	5825
Huawei	FRD-AL10	2	BHandset	5826
Huawei	FRD-L09	8	BHandset	5827
Huawei	G510	43	BHandset	5828
Huawei	G526	6	BHandset	5829
Huawei	G535	45	BHandset	5830
Huawei	G6	14	BHandset	5831
Huawei	G610	4	BHandset	5832
Huawei	G620	4	BHandset	5833
Huawei	G630	15	BHandset	5834
Huawei	G6600	5	BHandset	5835
Huawei	G7	4	BHandset	5836
Huawei	G7010	1	BHandset	5837
Huawei	G730	23	BHandset	5838
Huawei	G735	1	BHandset	5839
Huawei	G750	1	BHandset	5840
Huawei	G8	15	BHandset	5841
Huawei	H1512	35	BHandset	5842
Huawei	H1515	1	BHandset	5843
Huawei	H30-U10	4	BHandset	5844
Huawei	H60-L04	1	BHandset	5845
Huawei	Hol-U19	1	BHandset	5846

Huawei	HONOR 8A	1	BHandset	5847
Huawei	HONOR 8X	4	BHandset	5848
Huawei	HRY-LX1	5	BHandset	5849
Huawei	INE-LX2	19	BHandset	5850
Huawei	JAT-L29	1	BHandset	5851
Huawei	JAT-LX3	2	BHandset	5852
Huawei	JMM-L22	1	BHandset	5853
Huawei	JNY-LX2	1	BHandset	5854
Huawei	KII-L22	5	BHandset	5855
Huawei	KII-L23	4	BHandset	5856
Huawei	KIW-L21	7	BHandset	5857
Huawei	KOB-L09	10	BHandset	5858
Huawei	KOB-W09	1	BHandset	5859
Huawei	KSA-LX9	7	BHandset	5860
Huawei	LDN-L01	7	BHandset	5861
Huawei	LDN-L21	2	BHandset	5862
Huawei	LDN-LX3	74	BHandset	5863
Huawei	LLD-AL10	1	BHandset	5864
Huawei	LLD-L31	5	BHandset	5865
Huawei	LON-L29	4	BHandset	5866
Huawei	LUA-L01	2	BHandset	5867
Huawei	LUA-L02	13	BHandset	5868
Huawei	LUA-L03	6	BHandset	5869
Huawei	LUA-L21	1	BHandset	5870
Huawei	LYO-L01	6	BHandset	5871
Huawei	LYO-L02	22	BHandset	5872
Huawei	LYO-L21	1	BHandset	5873
Huawei	MED-LX9N	1	BHandset	5874
Huawei	MHA-L09	2	BHandset	5875
Huawei	MHA-L29	10	BHandset	5876
Huawei	MT2-L03	2	BHandset	5877
Huawei	MT7-L09	4	BHandset	5878
Huawei	MT7-TL10	2	BHandset	5879
Huawei	MYA-L02	30	BHandset	5880
Huawei	MYA-L11	22	BHandset	5881
Huawei	MYA-L22	1	BHandset	5882
Huawei	MYA-L41	26	BHandset	5883
Huawei	NEM-L21	4	BHandset	5884
Huawei	NEM-L51	12	BHandset	5885
Huawei	NMO-L22	15	BHandset	5886
Huawei	NXT-L09	1	BHandset	5887
Huawei	NXT-L29	2	BHandset	5888
Huawei	P2	9	BHandset	5889
Huawei	P6	10	BHandset	5890
Huawei	P7	14	BHandset	5891
Huawei	P8	13	BHandset	5892
Huawei	P8 Lite	13	BHandset	5893
Huawei	P8 Lite 2017	7	BHandset	5894
Huawei	P9	2	BHandset	5895
Huawei	P9 Lite	5	BHandset	5896
Huawei	P9 PLUS	1	BHandset	5897
Huawei	PAR-LX9	1	BHandset	5898
Huawei	PE-TL10	1	BHandset	5899
Huawei	PIC-AL00	1	BHandset	5900
Huawei	PIC-LX9	4	BHandset	5901
Huawei	PLK-L01	3	BHandset	5902
Huawei	POT-LX1	416	BHandset	5903
Huawei	POT-LX3	32	BHandset	5904
Huawei	RNE-L02	1	BHandset	5905
Huawei	RNE-L22	17	BHandset	5906
Huawei	S10-231	2	BHandset	5907
Huawei	S7-301	1	BHandset	5908
Huawei	S7-721	5	BHandset	5909
Huawei	S8-301	11	BHandset	5910
Huawei	SCL-L01	8	BHandset	5911
Huawei	SCL-L02	6	BHandset	5912
Huawei	SCL-L21	1	BHandset	5913
Huawei	SCL-U31	3	BHandset	5914
Huawei	STF-L09	3	BHandset	5915
Huawei	T1-701	2	BHandset	5916
Huawei	T1-821	4	BHandset	5917
Huawei	T1-821L	1	BHandset	5918
Huawei	T1-A21	2	BHandset	5919
Huawei	TAG-AL00	1	BHandset	5920
Huawei	TAG-L21	1	BHandset	5921
Huawei	TAG-L22	1	BHandset	5922
Huawei	TAG-L23	2	BHandset	5923
Huawei	TRT-L53	1	BHandset	5924
Huawei	TRT-LX1	33	BHandset	5925
Huawei	TRT-LX2	6	BHandset	5926
Huawei	TRT-LX3	4	BHandset	5927
Huawei	TRT-TL10	1	BHandset	5928
Huawei	U2900	3	BHandset	5929
Huawei	U8150	97	BHandset	5930
Huawei	U8180	68	BHandset	5931
Huawei	U8186	15	BHandset	5932

Huawei	U8510	28	BHandset	5933
Huawei	U8650	4	BHandset	5934
Huawei	U8655	36	BHandset	5935
Huawei	U8666	23	BHandset	5936
Huawei	U8685	87	BHandset	5937
Huawei	U8800	17	BHandset	5938
Huawei	U8815	15	BHandset	5939
Huawei	U8833	156	BHandset	5940
Huawei	U8855	1	BHandset	5941
Huawei	U8950	15	BHandset	5942
Huawei	U9200	4	BHandset	5943
Huawei	U9202	13	BHandset	5944
Huawei	Y210	5	BHandset	5945
Huawei	Y221	16	BHandset	5946
Huawei	Y320	249	BHandset	5947
Huawei	Y330	64	BHandset	5948
Huawei	Y360	151	BHandset	5949
Huawei	Y520	100	BHandset	5950
Huawei	Y530	52	BHandset	5951
Huawei	Y540	1	BHandset	5952
Huawei	Y550	15	BHandset	5953
Huawei	Y560	6	BHandset	5954
Huawei	Y600	19	BHandset	5955
Huawei	Y625	29	BHandset	5956
Huawei	Y635	38	BHandset	5957
Lg	C365	1	BHandset	5958
Lg	D150	1	BHandset	5959
Lg	D160	4	BHandset	5960
Lg	D165	1	BHandset	5961
Lg	D288	1	BHandset	5962
Lg	D290	18	BHandset	5963
Lg	D295	1	BHandset	5964
Lg	D315	14	BHandset	5965
Lg	D320	125	BHandset	5966
Lg	D321	1	BHandset	5967
Lg	D325	30	BHandset	5968
Lg	D331	4	BHandset	5969
Lg	D335	2	BHandset	5970
Lg	D337	60	BHandset	5971
Lg	D373	1	BHandset	5972
Lg	D380	2	BHandset	5973
Lg	D390	7	BHandset	5974
Lg	D405	12	BHandset	5975
Lg	D410	17	BHandset	5976
Lg	D415	2	BHandset	5977
Lg	D505	5	BHandset	5978
Lg	D605	3	BHandset	5979
Lg	D620	25	BHandset	5980
Lg	D631	1	BHandset	5981
Lg	D682	4	BHandset	5982
Lg	D685	2	BHandset	5983
Lg	D686	4	BHandset	5984
Lg	D690	2	BHandset	5985
Lg	D722	34	BHandset	5986
Lg	D725	6	BHandset	5987
Lg	D800	1	BHandset	5988
Lg	D801	1	BHandset	5989
Lg	D802	34	BHandset	5990
Lg	D805	1	BHandset	5991
Lg	D820	2	BHandset	5992
Lg	D821	26	BHandset	5993
Lg	D850	3	BHandset	5994
Lg	D855	36	BHandset	5995
Lg	D858	2	BHandset	5996
Lg	D950	1	BHandset	5997
Lg	D955	1	BHandset	5998
Lg	D959	1	BHandset	5999
Lg	E160	1	BHandset	6000
Lg	E400	46	BHandset	6001
Lg	E425	56	BHandset	6002
Lg	E430	24	BHandset	6003
Lg	E450	4	BHandset	6004
Lg	E455	4	BHandset	6005
Lg	E460	58	BHandset	6006
Lg	E465	1	BHandset	6007
Lg	E510	3	BHandset	6008
Lg	E610	4	BHandset	6009
Lg	E612	43	BHandset	6010
Lg	E900	2	BHandset	6011
Lg	E960	97	BHandset	6012
Lg	E975	38	BHandset	6013
Lg	E986	1	BHandset	6014
Lg	E988	1	BHandset	6015
Lg	F310	1	BHandset	6016
Lg	F320	1	BHandset	6017
Lg	F350	1	BHandset	6018

Lg	G710	1	BHandset	6019
Lg	GS101	1	BHandset	6020
Lg	H220	5	BHandset	6021
Lg	H320	7	BHandset	6022
Lg	H340	20	BHandset	6023
Lg	H420	2	BHandset	6024
Lg	H440	27	BHandset	6025
Lg	H500	9	BHandset	6026
Lg	H502	3	BHandset	6027
Lg	H520	2	BHandset	6028
Lg	H525	10	BHandset	6029
Lg	H540	1	BHandset	6030
Lg	H630	1	BHandset	6031
Lg	H631	4	BHandset	6032
Lg	H634	1	BHandset	6033
Lg	H635	2	BHandset	6034
Lg	H650	1	BHandset	6035
Lg	H791	176	BHandset	6036
Lg	H798	1	BHandset	6037
Lg	H810	3	BHandset	6038
Lg	H811	5	BHandset	6039
Lg	H812	1	BHandset	6040
Lg	H815	28	BHandset	6041
Lg	H818	2	BHandset	6042
Lg	H820	1	BHandset	6043
Lg	H830	5	BHandset	6044
Lg	H840	9	BHandset	6045
Lg	H850	16	BHandset	6046
Lg	H855	1	BHandset	6047
Lg	H870	5	BHandset	6048
Lg	H900	2	BHandset	6049
Lg	H901	2	BHandset	6050
Lg	H930	2	BHandset	6051
Lg	H932	1	BHandset	6052
Lg	H955	5	BHandset	6053
Lg	H960	1	BHandset	6054
Lg	H961	1	BHandset	6055
Lg	H990	1	BHandset	6056
Lg	K100	9	BHandset	6057
Lg	K120	18	BHandset	6058
Lg	K121	1	BHandset	6059
Lg	K130	28	BHandset	6060
Lg	K200	17	BHandset	6061
Lg	K220	10	BHandset	6062
Lg	K330	3	BHandset	6063
Lg	K350	2	BHandset	6064
Lg	K350N	28	BHandset	6065
Lg	K420	71	BHandset	6066
Lg	K420N	2	BHandset	6067
Lg	K428	6	BHandset	6068
Lg	K430	152	BHandset	6069
Lg	K500	28	BHandset	6070
Lg	K500N	8	BHandset	6071
Lg	K520	7	BHandset	6072
Lg	K530	1	BHandset	6073
Lg	K550	1	BHandset	6074
Lg	K580	6	BHandset	6075
Lg	KP500	15	BHandset	6076
Lg	LMK120	1	BHandset	6077
Lg	LMK200	35	BHandset	6078
Lg	LMK300	6	BHandset	6079
Lg	LML212	4	BHandset	6080
Lg	LMQ610	91	BHandset	6081
Lg	LMQ710	3	BHandset	6082
Lg	LMX120	55	BHandset	6083
Lg	LMX210	83	BHandset	6084
Lg	LMX320	16	BHandset	6085
Lg	LMX410	68	BHandset	6086
Lg	LS450	4	BHandset	6087
Lg	LS676	1	BHandset	6088
Lg	LS980	1	BHandset	6089
Lg	LS991	3	BHandset	6090
Lg	LS997	1	BHandset	6091
Lg	LS998	1	BHandset	6092
Lg	M150	2	BHandset	6093
Lg	M151	1	BHandset	6094
Lg	M153	2	BHandset	6095
Lg	M160	126	BHandset	6096
Lg	M200	165	BHandset	6097
Lg	M210	12	BHandset	6098
Lg	M250	60	BHandset	6099
Lg	M250N	4	BHandset	6100
Lg	M320	11	BHandset	6101
Lg	M327	3	BHandset	6102
Lg	M400	44	BHandset	6103
Lg	M430	2	BHandset	6104

Lg	M470	8	BHandset	6105
Lg	M700	139	BHandset	6106
Lg	MP260	5	BHandset	6107
Lg	MS330	4	BHandset	6108
Lg	MS550	8	BHandset	6109
Lg	MS631	1	BHandset	6110
Lg	P350	65	BHandset	6111
Lg	P500	41	BHandset	6112
Lg	P700	30	BHandset	6113
Lg	P705	9	BHandset	6114
Lg	P708	7	BHandset	6115
Lg	P710	13	BHandset	6116
Lg	P715	2	BHandset	6117
Lg	P760	20	BHandset	6118
Lg	P768	21	BHandset	6119
Lg	P880	6	BHandset	6120
Lg	P920	3	BHandset	6121
Lg	P970	10	BHandset	6122
Lg	P990	13	BHandset	6123
Lg	Q610	4	BHandset	6124
Lg	T385	5	BHandset	6125
Lg	T505	1	BHandset	6126
Lg	V400	1	BHandset	6127
Lg	V410	1	BHandset	6128
Lg	V490	1	BHandset	6129
Lg	V500(PAD)	2	BHandset	6130
Lg	V930	1	BHandset	6131
Lg	VK810	1	BHandset	6132
Lg	VS425	1	BHandset	6133
Lg	VS500	1	BHandset	6134
Lg	VS501	1	BHandset	6135
Lg	VS810	1	BHandset	6136
Lg	VS835	3	BHandset	6137
Lg	VS985	2	BHandset	6138
Lg	VS986	3	BHandset	6139
Lg	VS990	4	BHandset	6140
Lg	X120	2	BHandset	6141
Lg	X130	1	BHandset	6142
Lg	X150	9	BHandset	6143
Lg	X210	6	BHandset	6144
Lg	X220	8	BHandset	6145
Lg	X230	40	BHandset	6146
Lg	X240	3	BHandset	6147
Lg	X320	1	BHandset	6148
Lg	X410	7	BHandset	6149
Lg	X520	1	BHandset	6150
Lg	X525	7	BHandset	6151
Lg	X600	1	BHandset	6152
Motorola	LEX L10	2	BHandset	6153
Motorola	MB511	4	BHandset	6154
Motorola	MB525	18	BHandset	6155
Motorola	MB860	3	BHandset	6156
Motorola	MB865	65	BHandset	6157
Motorola	MB886	1	BHandset	6158
Motorola	MZ616	1	BHandset	6159
Motorola	U9	117	BHandset	6160
Motorola	V3	2	BHandset	6161
Motorola	V8	2	BHandset	6162
Motorola	XT1021	51	BHandset	6163
Motorola	XT1022	21	BHandset	6164
Motorola	XT1031	1	BHandset	6165
Motorola	XT1032	113	BHandset	6166
Motorola	XT1033	20	BHandset	6167
Motorola	XT1034	1	BHandset	6168
Motorola	XT1039	43	BHandset	6169
Motorola	XT1040	10	BHandset	6170
Motorola	XT1052	10	BHandset	6171
Motorola	XT1053	3	BHandset	6172
Motorola	XT1058	6	BHandset	6173
Motorola	XT1063	2	BHandset	6174
Motorola	XT1068	61	BHandset	6175
Motorola	XT1069	1	BHandset	6176
Motorola	XT1072	47	BHandset	6177
Motorola	XT1080	6	BHandset	6178
Motorola	XT1092	4	BHandset	6179
Motorola	XT1095	3	BHandset	6180
Motorola	XT1097	6	BHandset	6181
Motorola	XT1100	8	BHandset	6182
Motorola	XT1103	3	BHandset	6183
Motorola	XT1254	1	BHandset	6184
Motorola	XT1505	1	BHandset	6185
Motorola	XT1506	2	BHandset	6186
Motorola	XT1521	14	BHandset	6187
Motorola	XT1524	45	BHandset	6188
Motorola	XT1527	5	BHandset	6189
Motorola	XT1528	1	BHandset	6190

Motorola	XT1540	2	BHandset	6191
Motorola	XT1541	140	BHandset	6192
Motorola	XT1542	2	BHandset	6193
Motorola	XT1550	17	BHandset	6194
Motorola	XT1557	2	BHandset	6195
Motorola	XT1562	12	BHandset	6196
Motorola	XT1563	17	BHandset	6197
Motorola	XT1565	1	BHandset	6198
Motorola	XT1572	14	BHandset	6199
Motorola	XT1575	8	BHandset	6200
Motorola	XT1580	2	BHandset	6201
Motorola	XT1585	9	BHandset	6202
Motorola	XT1601	4	BHandset	6203
Motorola	XT1602	9	BHandset	6204
Motorola	XT1603	6	BHandset	6205
Motorola	XT1604	45	BHandset	6206
Motorola	XT1607	4	BHandset	6207
Motorola	XT1609	3	BHandset	6208
Motorola	XT1621	6	BHandset	6209
Motorola	XT1622	139	BHandset	6210
Motorola	XT1625	2	BHandset	6211
Motorola	XT1635	35	BHandset	6212
Motorola	XT1640	57	BHandset	6213
Motorola	XT1641	2	BHandset	6214
Motorola	XT1642	19	BHandset	6215
Motorola	XT1643	4	BHandset	6216
Motorola	XT1650	34	BHandset	6217
Motorola	XT1670	9	BHandset	6218
Motorola	XT1671	1	BHandset	6219
Motorola	XT1672	61	BHandset	6220
Motorola	XT1675	117	BHandset	6221
Motorola	XT1676	142	BHandset	6222
Motorola	XT1677	2	BHandset	6223
Motorola	XT1680	11	BHandset	6224
Motorola	XT1681	1	BHandset	6225
Motorola	XT1684	6	BHandset	6226
Motorola	XT1685	54	BHandset	6227
Motorola	XT1686	3	BHandset	6228
Motorola	XT1687	2	BHandset	6229
Motorola	XT1700	53	BHandset	6230
Motorola	XT1710	21	BHandset	6231
Motorola	XT1723	8	BHandset	6232
Motorola	XT1725	1	BHandset	6233
Motorola	XT1754	54	BHandset	6234
Motorola	XT1756	7	BHandset	6235
Motorola	XT1757	1	BHandset	6236
Motorola	XT1758	7	BHandset	6237
Motorola	XT1761	12	BHandset	6238
Motorola	XT1762	6	BHandset	6239
Motorola	XT1763	3	BHandset	6240
Motorola	XT1764	1	BHandset	6241
Motorola	XT1769	8	BHandset	6242
Motorola	XT1770	4	BHandset	6243
Motorola	XT1771	18	BHandset	6244
Motorola	XT1772	4	BHandset	6245
Motorola	XT1789	21	BHandset	6246
Motorola	XT1790	5	BHandset	6247
Motorola	XT1792	21	BHandset	6248
Motorola	XT1793	29	BHandset	6249
Motorola	XT1794	51	BHandset	6250
Motorola	XT1797	10	BHandset	6251
Motorola	XT1802	2	BHandset	6252
Motorola	XT1803	4	BHandset	6253
Motorola	XT1804	2	BHandset	6254
Motorola	XT1805	8	BHandset	6255
Motorola	XT1900	34	BHandset	6256
Motorola	XT1910	1	BHandset	6257
Motorola	XT1920	59	BHandset	6258
Motorola	XT1921	16	BHandset	6259
Motorola	XT1922	130	BHandset	6260
Motorola	XT1924	4	BHandset	6261
Motorola	XT1925	358	BHandset	6262
Motorola	XT1926	35	BHandset	6263
Motorola	XT1929	10	BHandset	6264
Motorola	XT1941	42	BHandset	6265
Motorola	XT1942	1	BHandset	6266
Motorola	XT1944	69	BHandset	6267
Motorola	XT1952	48	BHandset	6268
Motorola	XT1955	2	BHandset	6269
Motorola	XT1965	5	BHandset	6270
Motorola	XT1970	1	BHandset	6271
Motorola	XT1976	1	BHandset	6272
Motorola	XT300	38	BHandset	6273
Motorola	XT316	3	BHandset	6274
Motorola	XT320	67	BHandset	6275
Motorola	XT531	1	BHandset	6276

Motorola	XT535	10	BHandset	6277
Motorola	XT890	21	BHandset	6278
Motorola	XT905	3	BHandset	6279
Motorola	XT910	6	BHandset	6280
Motorola	XT912	2	BHandset	6281
Motorola	XT915	6	BHandset	6282
Motorola	XT919	22	BHandset	6283
Motorola	XT925	14	BHandset	6284
Nokia	100	107	BHandset	6285
Nokia	103	1	BHandset	6286
Nokia	105	19	BHandset	6287
Nokia	106	4	BHandset	6288
Nokia	108	8	BHandset	6289
Nokia	110	2	BHandset	6290
Nokia	111	181	BHandset	6291
Nokia	112	1	BHandset	6292
Nokia	113	3	BHandset	6293
Nokia	130	72	BHandset	6294
Nokia	201	2	BHandset	6295
Nokia	203	2	BHandset	6296
Nokia	206	3	BHandset	6297
Nokia	207	6	BHandset	6298
Nokia	208	30	BHandset	6299
Nokia	215	1	BHandset	6300
Nokia	220	2	BHandset	6301
Nokia	225	2	BHandset	6302
Nokia	301	55	BHandset	6303
Nokia	302	4	BHandset	6304
Nokia	306	2	BHandset	6305
Nokia	308	1	BHandset	6306
Nokia	435	50	BHandset	6307
Nokia	501	2	BHandset	6308
Nokia	505	1	BHandset	6309
Nokia	520	67	BHandset	6310
Nokia	530	6	BHandset	6311
Nokia	532	2	BHandset	6312
Nokia	535	204	BHandset	6313
Nokia	540	2	BHandset	6314
Nokia	550	180	BHandset	6315
Nokia	610	3	BHandset	6316
Nokia	620	74	BHandset	6317
Nokia	625	37	BHandset	6318
Nokia	630	272	BHandset	6319
Nokia	635	417	BHandset	6320
Nokia	638	1	BHandset	6321
Nokia	640	560	BHandset	6322
Nokia	650	125	BHandset	6323
Nokia	700	7	BHandset	6324
Nokia	710	14	BHandset	6325
Nokia	720	5	BHandset	6326
Nokia	730	1	BHandset	6327
Nokia	735	2	BHandset	6328
Nokia	800	102	BHandset	6329
Nokia	810	1	BHandset	6330
Nokia	820	49	BHandset	6331
Nokia	830	6	BHandset	6332
Nokia	900	4	BHandset	6333
Nokia	920	10	BHandset	6334
Nokia	925	10	BHandset	6335
Nokia	1100	73	BHandset	6336
Nokia	1110	1	BHandset	6337
Nokia	1112	5	BHandset	6338
Nokia	1200	5	BHandset	6339
Nokia	1202	9	BHandset	6340
Nokia	1208	25	BHandset	6341
Nokia	1209	1	BHandset	6342
Nokia	1280	14	BHandset	6343
Nokia	1282	1	BHandset	6344
Nokia	1320	13	BHandset	6345
Nokia	1600	13	BHandset	6346
Nokia	1650	8	BHandset	6347
Nokia	1661	1	BHandset	6348
Nokia	2112	14	BHandset	6349
Nokia	2310	11	BHandset	6350
Nokia	2505	2	BHandset	6351
Nokia	2610	28	BHandset	6352
Nokia	2626	11	BHandset	6353
Nokia	2630	22	BHandset	6354
Nokia	2690	10	BHandset	6355
Nokia	2760	11	BHandset	6356
Nokia	3100	7	BHandset	6357
Nokia	3120	22	BHandset	6358
Nokia	3310	18	BHandset	6359
Nokia	5000	3	BHandset	6360
Nokia	5230	49	BHandset	6361
Nokia	5233	1	BHandset	6362

Nokia	5310	3	BHandset	6363
Nokia	5610	1	BHandset	6364
Nokia	5800	40	BHandset	6365
Nokia	6015	13	BHandset	6366
Nokia	6020	8	BHandset	6367
Nokia	6030	5	BHandset	6368
Nokia	6070	10	BHandset	6369
Nokia	6085	125	BHandset	6370
Nokia	6100	15	BHandset	6371
Nokia	6210	14	BHandset	6372
Nokia	6233	1	BHandset	6373
Nokia	6234	23	BHandset	6374
Nokia	6235	32	BHandset	6375
Nokia	6300	28	BHandset	6376
Nokia	6555	7	BHandset	6377
Nokia	6630	2	BHandset	6378
Nokia	7370	1	BHandset	6379
Nokia	7373	1	BHandset	6380
Nokia	105(2017)	12	BHandset	6381
Nokia	105(2019)	30	BHandset	6382
Nokia	105(2021)	2	BHandset	6383
Nokia	105(2023)	1	BHandset	6384
Nokia	106(2018)	1	BHandset	6385
Nokia	1110i	26	BHandset	6386
Nokia	130(2017)	1	BHandset	6387
Nokia	1680C	5	BHandset	6388
Nokia	2220S	18	BHandset	6389
Nokia	2323C	4	BHandset	6390
Nokia	2330C	18	BHandset	6391
Nokia	2600C	1	BHandset	6392
Nokia	2700C	6	BHandset	6393
Nokia	2720 Flip	1	BHandset	6394
Nokia	2720A	28	BHandset	6395
Nokia	2730C	103	BHandset	6396
Nokia	2760 Flip	1	BHandset	6397
Nokia	3109C	9	BHandset	6398
Nokia	3110C	13	BHandset	6399
Nokia	3120C	33	BHandset	6400
Nokia	3120C-1C	10	BHandset	6401
Nokia	3310(2017)	2	BHandset	6402
Nokia	3600S	1	BHandset	6403
Nokia	3610A	5	BHandset	6404
Nokia	3710A-1C	7	BHandset	6405
Nokia	3720C	8	BHandset	6406
Nokia	5030C	1	BHandset	6407
Nokia	5130C	14	BHandset	6408
Nokia	5130C-2	1	BHandset	6409
Nokia	6210S	6	BHandset	6410
Nokia	6303C	24	BHandset	6411
Nokia	640XL	42	BHandset	6412
Nokia	6500C	6	BHandset	6413
Nokia	6600F	4	BHandset	6414
Nokia	6600S	5	BHandset	6415
Nokia	6600S-1C	1	BHandset	6416
Nokia	6700C	2	BHandset	6417
Nokia	6700S	2	BHandset	6418
Nokia	6720C	1	BHandset	6419
Nokia	6730C	1	BHandset	6420
Nokia	7230S	16	BHandset	6421
Nokia	C1-01	28	BHandset	6422
Nokia	C1-02	1	BHandset	6423
Nokia	C2	2	BHandset	6424
Nokia	C2-02	8	BHandset	6425
Nokia	C3	12	BHandset	6426
Nokia	C3-01	25	BHandset	6427
Nokia	C5	38	BHandset	6428
Nokia	C5-03	46	BHandset	6429
Nokia	C6	4	BHandset	6430
Nokia	C6-01	12	BHandset	6431
Nokia	C7	9	BHandset	6432
Nokia	E5	1	BHandset	6433
Nokia	E50-2	1	BHandset	6434
Nokia	E51	2	BHandset	6435
Nokia	E61-1	1	BHandset	6436
Nokia	E63	4	BHandset	6437
Nokia	E65	2	BHandset	6438
Nokia	E66	2	BHandset	6439
Nokia	E71-1	1	BHandset	6440
Nokia	N70	2	BHandset	6441
Nokia	N73	2	BHandset	6442
Nokia	N82	1	BHandset	6443
Nokia	N9	4	BHandset	6444
Nokia	N900	2	BHandset	6445
Nokia	N95	1	BHandset	6446
Nokia	N96	1	BHandset	6447
Nokia	N97	1	BHandset	6448

Nokia	N97 Mini	6	BHandset	6449
Nokia	1	15	BHandset	6450
Nokia	1 Plus	20	BHandset	6451
Nokia	1.3	15	BHandset	6452
Nokia	1.4	5	BHandset	6453
Nokia	2	24	BHandset	6454
Nokia	2.1	17	BHandset	6455
Nokia	2.2	10	BHandset	6456
Nokia	2.3	7	BHandset	6457
Nokia	2.4	2	BHandset	6458
Nokia	C01 Plus	8	BHandset	6459
Nokia	C02	10	BHandset	6460
Nokia	C1	4	BHandset	6461
Nokia	C1 Plus	9	BHandset	6462
Nokia	C110	1	BHandset	6463
Nokia	C12	2	BHandset	6464
Nokia	C2	3	BHandset	6465
Nokia	X	1	BHandset	6466
Nokia	X1	3	BHandset	6467
Nokia	X1-01	2	BHandset	6468
Nokia	X2	1	BHandset	6469
Nokia	X3	1	BHandset	6470
Nokia	X3-02	38	BHandset	6471
Nokia	X6	6	BHandset	6472
Nokia	X7	1	BHandset	6473
Other	2Hix Wee Pad	1	BHandset	6474
Other	A1 Alpha 2+	1	BHandset	6475
Other	A1 Alpha 20	1	BHandset	6476
Other	A1 Alpha 21	1	BHandset	6477
Other	Alba Ac40 As3G	1	BHandset	6478
Other	Alba Ac57	1	BHandset	6479
Other	Alba Ac57As	1	BHandset	6480
Other	Alba Ac80Cplv2	1	BHandset	6481
Other	Altice E54	2	BHandset	6482
Other	Altice S11	1	BHandset	6483
Other	Altice S31	16	BHandset	6484
Other	Altice S32	4	BHandset	6485
Other	Altice S33	2	BHandset	6486
Other	Altice S34	1	BHandset	6487
Other	Altice S41	2	BHandset	6488
Other	Altice S60	2	BHandset	6489
Other	Altice S61	1	BHandset	6490
Other	Altice S62	1	BHandset	6491
Other	Altice Sx41	1	BHandset	6492
Other	Amazon Fire 7	12	BHandset	6493
Other	Amazon Fire HD 10	3	BHandset	6494
Other	Amazon Fire HD 10 Plus	1	BHandset	6495
Other	Amazon Fire HD 10(2021)	1	BHandset	6496
Other	Amazon Fire HD 7	3	BHandset	6497
Other	Amazon Fire HD 7(2017)	3	BHandset	6498
Other	Amazon Fire HD 8	19	BHandset	6499
Other	Amazon Firephone	7	BHandset	6500
Other	Amazon Kindle 4	1	BHandset	6501
Other	Amazon Kindle Fire	1	BHandset	6502
Other	Amazon Kindle Fire 7	128	BHandset	6503
Other	Amazon Kindle Fire HD 7	1	BHandset	6504
Other	Amazon Kindle Fire HD 8.9	1	BHandset	6505
Other	Amgoo Am530	4	BHandset	6506
Other	ARCHOS 50 Diamond	1	BHandset	6507
Other	ARCHOS 50C Neon	1	BHandset	6508
Other	ARCHOS 50E Helium 4G	1	BHandset	6509
Other	ARCHOS 53 Platinum	1	BHandset	6510
Other	ARCHOS Ac50	1	BHandset	6511
Other	ARCHOS Ac50Fne V2	1	BHandset	6512
Other	AZumi A5	101	BHandset	6513
Other	AZumi A50C+	46	BHandset	6514
Other	AZumi A55Q Pro	39	BHandset	6515
Other	AZumi A55T	66	BHandset	6516
Other	AZumi A5D	142	BHandset	6517
Other	AZumi A5Q	15	BHandset	6518
Other	AZumi Q10	61	BHandset	6519
Other	AZumi Speed 5.5	10	BHandset	6520
Other	AZumi V5	417	BHandset	6521
Other	Blackview A53	2	BHandset	6522
Other	Blackview A60	1	BHandset	6523
Other	Blackview A7	2	BHandset	6524
Other	Blackview A8 Max	1	BHandset	6525
Other	Blackview A80 Pro	7	BHandset	6526
Other	Blackview Bv2000	12	BHandset	6527
Other	Blackview Bv4000 Pro	1	BHandset	6528
Other	Blackview Bv4900	2	BHandset	6529
Other	Blackview Bv4900 Pro	1	BHandset	6530
Other	Blackview Bv5200	1	BHandset	6531
Other	Blackview Bv5500	1	BHandset	6532
Other	Blackview Bv6000S	1	BHandset	6533
Other	Blackview P2	1	BHandset	6534

Other	Blaupunkt Bs04	1	BHandset	6535
Other	Blaupunkt Bs04I	1	BHandset	6536
Other	Blaupunkt FI02	4	BHandset	6537
Other	Blaupunkt FI07	1	BHandset	6538
Other	Blaupunkt FI08	3	BHandset	6539
Other	Blaupunkt Fm02	1	BHandset	6540
Other	Blaupunkt Fm03	10	BHandset	6541
Other	Blaupunkt Fm03I	2	BHandset	6542
Other	Blaupunkt OT16	1	BHandset	6543
Other	Blaupunkt Sf01	19	BHandset	6544
Other	Blaupunkt Sf04	10	BHandset	6545
Other	Blaupunkt Sf04 4G	18	BHandset	6546
Other	Blaupunkt SI04	7	BHandset	6547
Other	Blaupunkt SM02	202	BHandset	6548
Other	Blaupunkt SM05	2	BHandset	6549
Other	Blu G90	1	BHandset	6550
Other	Blu Life Play	29	BHandset	6551
Other	Blu R2 Plus	1	BHandset	6552
Other	Blu X130E	1	BHandset	6553
Other	BQ Aquaris A4.5	1	BHandset	6554
Other	BQ Aquaris C	1	BHandset	6555
Other	BQ Aquaris E4.5	2	BHandset	6556
Other	BQ Aquaris E5	8	BHandset	6557
Other	BQ Aquaris E5s	2	BHandset	6558
Other	BQ Aquaris E6	1	BHandset	6559
Other	BQ Aquaris M4.5	1	BHandset	6560
Other	BQ Aquaris M5	4	BHandset	6561
Other	BQ Aquaris M5.5	5	BHandset	6562
Other	BQ Aquaris U	5	BHandset	6563
Other	BQ Aquaris X	8	BHandset	6564
Other	BQ Aquaris X2	4	BHandset	6565
Other	BQ Aquaris X2 Pro	3	BHandset	6566
Other	Cat B15	191	BHandset	6567
Other	Cat B25	1	BHandset	6568
Other	Cat B30	16	BHandset	6569
Other	Cat B35	12	BHandset	6570
Other	Cat B40	12	BHandset	6571
Other	Cat S30	13	BHandset	6572
Other	Cat S31	1	BHandset	6573
Other	Cat S40	1	BHandset	6574
Other	Cat S42	1	BHandset	6575
Other	Cat S60	1	BHandset	6576
Other	Cat S61	1	BHandset	6577
Other	Crosscall Action X3	2	BHandset	6578
Other	Crosscall Core M4	39	BHandset	6579
Other	Crosscall Core X4	2	BHandset	6580
Other	Crosscall Trekker M1 Core	14	BHandset	6581
Other	Crosscall Trekker X3	3	BHandset	6582
Other	Crosscall Trekker X4	3	BHandset	6583
Other	Cryptodata Impulse K1	1	BHandset	6584
Other	Cubot Cheetah 2	2	BHandset	6585
Other	Cubot K30 Pro	1	BHandset	6586
Other	Cubot Max	3	BHandset	6587
Other	Cubot Max 3	1	BHandset	6588
Other	Cubot Note 20	2	BHandset	6589
Other	Cubot Note 7	1	BHandset	6590
Other	Cubot Note 9	1	BHandset	6591
Other	Cubot P40	2	BHandset	6592
Other	Cubot X18 Plus	1	BHandset	6593
Other	Cubot X19	4	BHandset	6594
Other	Cubot X20 Pro	7	BHandset	6595
Other	Cyrus Cs22	1	BHandset	6596
Other	Cyrus Cs24	1	BHandset	6597
Other	Cyrus Cs28	3	BHandset	6598
Other	Doogee F5	1	BHandset	6599
Other	Doogee Mix Lite	1	BHandset	6600
Other	Doogee S35	2	BHandset	6601
Other	Doogee S35T	1	BHandset	6602
Other	Doogee X10	2	BHandset	6603
Other	Doogee X10S	1	BHandset	6604
Other	Doogee X20L	2	BHandset	6605
Other	Doogee X30	1	BHandset	6606
Other	Doogee X5	2	BHandset	6607
Other	Doogee X50	2	BHandset	6608
Other	Doogee X95	1	BHandset	6609
Other	Doro 1360	7	BHandset	6610
Other	Doro 1370	31	BHandset	6611
Other	Doro 1380	3	BHandset	6612
Other	Doro 2404	7	BHandset	6613
Other	Doro 5030	12	BHandset	6614
Other	Doro 5516	14	BHandset	6615
Other	Doro 5517	5	BHandset	6616
Other	Doro 6030	14	BHandset	6617
Other	Doro 6050	10	BHandset	6618
Other	Doro 6060	1	BHandset	6619
Other	Doro 6520	75	BHandset	6620

Other	Doro 6530	1	BHandset	6621
Other	Doro 6620	33	BHandset	6622
Other	Doro 6880	4	BHandset	6623
Other	Doro 7010	6	BHandset	6624
Other	Doro 7030	67	BHandset	6625
Other	Doro 7060	16	BHandset	6626
Other	Doro 7070	8	BHandset	6627
Other	Doro 7080	5	BHandset	6628
Other	Doro 8030	5	BHandset	6629
Other	Doro 8031	3	BHandset	6630
Other	Doro 8035	20	BHandset	6631
Other	Doro 8040	8	BHandset	6632
Other	Doro 8050	13	BHandset	6633
Other	Doro 8080	2	BHandset	6634
Other	Doro 8100	4	BHandset	6635
Other	Doro 8200	1	BHandset	6636
Other	Doro PE508	7	BHandset	6637
Other	Doro PE612	6	BHandset	6638
Other	Doro PE621	2	BHandset	6639
Other	Doro PE631	186	BHandset	6640
Other	Doro PE632	17	BHandset	6641
Other	Doro PE820	1	BHandset	6642
Other	Elephone C1 Max	1	BHandset	6643
Other	Elephone M2	1	BHandset	6644
Other	Elephone S7	1	BHandset	6645
Other	Emporia S5	10	BHandset	6646
Other	Emporia SMart 2	4	BHandset	6647
Other	Emporia SMart 3	19	BHandset	6648
Other	Emporia SMart 3 Mini	2	BHandset	6649
Other	Emporia SMart 4	1	BHandset	6650
Other	Emporia SMart 5	1	BHandset	6651
Other	Energizer S550	2	BHandset	6652
Other	Enspire C8660	56	BHandset	6653
Other	Fnac 2 4.5	1	BHandset	6654
Other	General Mobile Gm 8 Go	1	BHandset	6655
Other	Gigabyte Gsmart Classic Lite	1	BHandset	6656
Other	Gigaset Gs110	2	BHandset	6657
Other	Gigaset Gs4	1	BHandset	6658
Other	Gigaset Gs5 Lite	1	BHandset	6659
Other	Google G-2PW2100	3	BHandset	6660
Other	Google G-2PW2200	8	BHandset	6661
Other	Google G-2PW4100	7	BHandset	6662
Other	Google G-2PW4200	12	BHandset	6663
Other	Hafury K30 Pro	1	BHandset	6664
Other	Hafury Note 10	1	BHandset	6665
Other	Hammer Energy	1	BHandset	6666
Other	Hammer Energy 2	4	BHandset	6667
Other	Harrier Mini	32	BHandset	6668
Other	Harrier Rook	28	BHandset	6669
Other	Harrier TAB	6	BHandset	6670
Other	Hawk	10	BHandset	6671
Other	Hisense C20	4	BHandset	6672
Other	Homtom Ht70	1	BHandset	6673
Other	Homtom S9 Plus	1	BHandset	6674
Other	Ihunt Like 12 Pro	1	BHandset	6675
Other	Imo Dash	11	BHandset	6676
Other	Imo Dash 4G	15	BHandset	6677
Other	Imo Dash Plus	1	BHandset	6678
Other	Imo Q2	7	BHandset	6679
Other	Imo Q2 Plus	44	BHandset	6680
Other	Imo Q2 Pro	21	BHandset	6681
Other	Imo Q3 Plus	2	BHandset	6682
Other	Imo Q4 Pro	9	BHandset	6683
Other	Imo Q4 Pro(2021)	4	BHandset	6684
Other	Imo Q5	4	BHandset	6685
Other	Impulse K1	1	BHandset	6686
Other	Insys Ih9-L614	1	BHandset	6687
Other	Itravl X1	1	BHandset	6688
Other	Kazam Life B5	1	BHandset	6689
Other	Kazam Trooper 2 6.0	1	BHandset	6690
Other	Kazam Trooper 540	3	BHandset	6691
Other	Kazam Trooper 551	1	BHandset	6692
Other	Kicka 5 Plus 4G	1	BHandset	6693
Other	Kogan Agora 4G	1	BHandset	6694
Other	Kogan Agora 6	1	BHandset	6695
Other	Kogan Agora Lite	1	BHandset	6696
Other	Kyocera C6530N	2	BHandset	6697
Other	Kyocera E4750	1	BHandset	6698
Other	Kyocera E6910	1	BHandset	6699
Other	Laiq Glow	1	BHandset	6700
Other	Leagoo T5	1	BHandset	6701
Other	Leeco Lex653	1	BHandset	6702
Other	Lenovo 10E	3	BHandset	6703
Other	Lenovo A1000	3	BHandset	6704
Other	Lenovo A1010A20	1	BHandset	6705
Other	Lenovo A2010	4	BHandset	6706

Other	Lenovo A2016	1	BHandset	6707
Other	Lenovo A319	1	BHandset	6708
Other	Lenovo A6000	2	BHandset	6709
Other	Lenovo A6020	12	BHandset	6710
Other	Lenovo A606	1	BHandset	6711
Other	Lenovo A7000	1	BHandset	6712
Other	Lenovo A7010A48	5	BHandset	6713
Other	Lenovo A7600	4	BHandset	6714
Other	Lenovo A806	1	BHandset	6715
Other	Lenovo A816	1	BHandset	6716
Other	Lenovo A916	2	BHandset	6717
Other	Lenovo B6000	1	BHandset	6718
Other	Lenovo B8000	2	BHandset	6719
Other	Lenovo K10A40	18	BHandset	6720
Other	Lenovo K320T	1	BHandset	6721
Other	Lenovo K33B36	8	BHandset	6722
Other	Lenovo K50	2	BHandset	6723
Other	Lenovo Miix 2 8	1	BHandset	6724
Other	Lenovo Pb2-690	1	BHandset	6725
Other	Lenovo S1La40	1	BHandset	6726
Other	Lenovo S6000	1	BHandset	6727
Other	Lenovo S750	1	BHandset	6728
Other	Lenovo S856	2	BHandset	6729
Other	Lenovo TAB 2 A10-70	2	BHandset	6730
Other	Lenovo TAB 2 A7-30	2	BHandset	6731
Other	Lenovo TAB 2 A8-50	1	BHandset	6732
Other	Lenovo TAB 2 X30	8	BHandset	6733
Other	Lenovo TAB 3-710F	2	BHandset	6734
Other	Lenovo TAB E10	1	BHandset	6735
Other	Lenovo TABLET 2-1050L	1	BHandset	6736
Other	Lenovo Tb125Fu	1	BHandset	6737
Other	Lenovo Tb128Xu	19	BHandset	6738
Other	Lenovo Tb300Xu	1	BHandset	6739
Other	Lenovo Tb301Xu	13	BHandset	6740
Other	Lenovo Tb328Xu	2	BHandset	6741
Other	Lenovo Tb330Xu	1	BHandset	6742
Other	Lenovo Tb360Zu	2	BHandset	6743
Other	Lenovo Tb3-730X	1	BHandset	6744
Other	Lenovo Tb3-850F	1	BHandset	6745
Other	Lenovo Tb3-X70	1	BHandset	6746
Other	Lenovo Tb-7104F	3	BHandset	6747
Other	Lenovo Tb-7305	3	BHandset	6748
Other	Lenovo Tb-8304	3	BHandset	6749
Other	Lenovo Tb-8504	1	BHandset	6750
Other	Lenovo Tb-8505	4	BHandset	6751
Other	Lenovo Tb-J616F	1	BHandset	6752
Other	Lenovo Tb-X103	1	BHandset	6753
Other	Lenovo Tb-X103F	13	BHandset	6754
Other	Lenovo Tb-X104F	20	BHandset	6755
Other	Lenovo Tb-X304	2	BHandset	6756
Other	Lenovo Tb-X304F	2	BHandset	6757
Other	Lenovo Tb-X306X	4	BHandset	6758
Other	Lenovo Tb-X505	3	BHandset	6759
Other	Lenovo Tb-X505F	6	BHandset	6760
Other	Lenovo Tb-X605F	2	BHandset	6761
Other	Lenovo Tb-X606X	5	BHandset	6762
Other	Lenovo Tb-X636	1	BHandset	6763
Other	Lenovo Tb-X704	1	BHandset	6764
Other	Lenovo Tb-X705	1	BHandset	6765
Other	Lenovo YOGA TAB 2-1050F	1	BHandset	6766
Other	Lenovo YT3-850	3	BHandset	6767
Other	Lenovo YT3-X50F	4	BHandset	6768
Other	Lenovo YT-X705F	1	BHandset	6769
Other	Letv Lex651	1	BHandset	6770
Other	Letv Lex820	1	BHandset	6771
Other	Letv X526	1	BHandset	6772
Other	Logicom Flow	1	BHandset	6773
Other	Maxfone Max 70 Plus	1	BHandset	6774
Other	Meizu 16Th	1	BHandset	6775
Other	Meizu M3 Note	1	BHandset	6776
Other	Meizu M3S	2	BHandset	6777
Other	Meizu M5s	1	BHandset	6778
Other	Meizu Pro 5	1	BHandset	6779
Other	Mobicel R1 Plus	1	BHandset	6780
Other	Mobile Ax1082	9	BHandset	6781
Other	Mobile Ax810	2	BHandset	6782
Other	Mobile Ax820	1	BHandset	6783
Other	Mobiphone 3G	139	BHandset	6784
Other	Mobiwire Dakota	90	BHandset	6785
Other	Mobiwire Hakan	35	BHandset	6786
Other	Mobiwire Hinto	61	BHandset	6787
Other	Mobiwire Hinto 4G	119	BHandset	6788
Other	Mobiwire Hotah	1	BHandset	6789
Other	Mobiwire Kanuna	18	BHandset	6790
Other	Mobiwire Kosumi	4	BHandset	6791
Other	Mobiwire Nokosi	6	BHandset	6792

Other	Mobiwire Ogima	32	BHandset	6793
Other	Mobiwire Oneida	2	BHandset	6794
Other	Mobiwire Sakari	135	BHandset	6795
Other	Mtt M14D	52	BHandset	6796
Other	Navon Spt1100	8	BHandset	6797
Other	Navon T310	1	BHandset	6798
Other	Neffos C5 Plus	1	BHandset	6799
Other	Neffos X1	1	BHandset	6800
Other	Neffos X20	1	BHandset	6801
Other	Nuu A4L	1	BHandset	6802
Other	Nuu A5L	1	BHandset	6803
Other	Nuu G2	1	BHandset	6804
Other	Nuu G3	1	BHandset	6805
Other	Nuu M3	1	BHandset	6806
Other	Nuu N5004L	1	BHandset	6807
Other	Nuu X6 Mini	1	BHandset	6808
Other	Oppo A57(2016)	1	BHandset	6809
Other	Optus P600	5	BHandset	6810
Other	Optus P650	1	BHandset	6811
Other	Optus P652	3	BHandset	6812
Other	Orange Neva Start	9	BHandset	6813
Other	Oukitel C15 Pro	1	BHandset	6814
Other	Oukitel C21 Pro	1	BHandset	6815
Other	Oukitel K15 Plus	1	BHandset	6816
Other	Oukitel U7 Plus	1	BHandset	6817
Other	Own F1023	43	BHandset	6818
Other	Own F1024	393	BHandset	6819
Other	Own Fun 6	16	BHandset	6820
Other	Own Fun 7	8	BHandset	6821
Other	Own Fun Plus	2	BHandset	6822
Other	Own Fun+	6	BHandset	6823
Other	Own One Plus	1	BHandset	6824
Other	Own S3020	1	BHandset	6825
Other	Own SMart 8	5	BHandset	6826
Other	Own SMart 9	8	BHandset	6827
Other	Polaroid P4526A	3	BHandset	6828
Other	Polaroid P5526A	15	BHandset	6829
Other	Sharp Aquos D10	1	BHandset	6830
Other	Sky 55M	4	BHandset	6831
Other	Sonim XP5800	8	BHandset	6832
Other	Spark Plus 3	140	BHandset	6833
Other	Spark Pocket 2	273	BHandset	6834
Other	Spc Gen Max	1	BHandset	6835
Other	Spc SMart Plus	1	BHandset	6836
Other	Spc SMart Ultimate	1	BHandset	6837
Other	Stk Ace	1	BHandset	6838
Other	Tcl 306	6	BHandset	6839
Other	Tcl 403	4	BHandset	6840
Other	Tcl 405	1	BHandset	6841
Other	Tcl 4058	25	BHandset	6842
Other	Tcl 406	3	BHandset	6843
Other	Tcl 4061	1	BHandset	6844
Other	Tcl 501	2	BHandset	6845
Other	Tcl T301	3	BHandset	6846
Other	Tcl T302	1	BHandset	6847
Other	Tcl T312	13	BHandset	6848
Other	Tcl T433	4	BHandset	6849
Other	Tcl TAB 10 4G	1	BHandset	6850
Other	Tcl TAB 8 4G	1	BHandset	6851
Other	Tesco K15	1	BHandset	6852
Other	T-Mobile Revvlry	1	BHandset	6853
Other	T-Mobile T Phone	4	BHandset	6854
Other	T-Mobile T Phone Pro	3	BHandset	6855
Other	Ulefone Armor 2	1	BHandset	6856
Other	Ulefone Armor 2S	1	BHandset	6857
Other	Ulefone Armor X	2	BHandset	6858
Other	Ulefone Armor X5	2	BHandset	6859
Other	Ulefone Note 6	1	BHandset	6860
Other	Ulefone Note 7	2	BHandset	6861
Other	Ulefone T1	1	BHandset	6862
Other	Umidigi Crystal	1	BHandset	6863
Other	Umidigi A7S	1	BHandset	6864
Other	Umidigi F1	1	BHandset	6865
Other	Umidigi F2	1	BHandset	6866
Other	Umidigi One	1	BHandset	6867
Other	Umidigi S2 Lite	1	BHandset	6868
Other	Umidigi Z2	1	BHandset	6869
Other	Vivo Y12S	2	BHandset	6870
Other	Wiko BLOOM	1	BHandset	6871
Other	Wiko HARRY 2	20	BHandset	6872
Other	Wiko JERRY	6	BHandset	6873
Other	Wiko JERRY 2	4	BHandset	6874
Other	Wiko LENNY	1	BHandset	6875
Other	Wiko LENNY 2	5	BHandset	6876
Other	Wiko LENNY 3	5	BHandset	6877
Other	Wiko LENNY 4	3	BHandset	6878

Other	Wiko LENNY 4 PLUS	1	BHandset	6879
Other	Wiko LENNY 5	2	BHandset	6880
Other	Wiko POWER U10	1	BHandset	6881
Other	Wiko POWER U20	1	BHandset	6882
Other	Wiko PULP 4G	2	BHandset	6883
Other	Wiko RAINBOW	1	BHandset	6884
Other	Wiko RAINBOW UP 4G	1	BHandset	6885
Other	Wiko ROBBY	1	BHandset	6886
Other	Wiko SAS	1	BHandset	6887
Other	Wiko SUNNY 2	2	BHandset	6888
Other	Wiko TOMMY 2	2	BHandset	6889
Other	Wiko VIEW	1	BHandset	6890
Other	Wiko VIEW 2	2	BHandset	6891
Other	Wiko VIEW 3	1	BHandset	6892
Other	Wiko VIEW 4	1	BHandset	6893
Other	Wiko VIEW GO	1	BHandset	6894
Other	Wiko VIEW PRIME	1	BHandset	6895
Other	Wiko WIM	1	BHandset	6896
Other	Wiko WIM Lite	1	BHandset	6897
Other	Wiko Y50	1	BHandset	6898
Other	Wiko Y51	2	BHandset	6899
Other	Wiko Y60	2	BHandset	6900
Other	Wiko Y80	1	BHandset	6901
Other	Wiko Y81	1	BHandset	6902
Other	Wiko Y82	1	BHandset	6903
Other	Wilefox Swift	1	BHandset	6904
Other	Wileyfox Pro	1	BHandset	6905
Other	Wileyfox Spark	1	BHandset	6906
Other	Wileyfox Spark X	7	BHandset	6907
Other	Wileyfox Spark+	2	BHandset	6908
Other	Wileyfox Storm	3	BHandset	6909
Other	Wileyfox Swift	8	BHandset	6910
Other	Wileyfox Swift 2	12	BHandset	6911
Other	Wileyfox Swift 2 Plus	2	BHandset	6912
Other	Wileyfox Swift 2X	14	BHandset	6913
Other	Xgody K40 Pro	1	BHandset	6914
Other	Xgody P30	1	BHandset	6915
Other	Xgody S14	1	BHandset	6916
Other	Xgody X18	1	BHandset	6917
Other	Xgody Y13	1	BHandset	6918
Other	Xiaomi Mi 4C	1	BHandset	6919
Other	Xiaomi Mi 5	1	BHandset	6920
Other	Xiaomi Mi A1	2	BHandset	6921
Other	Xiaomi Mi A2	1	BHandset	6922
Other	Xiaomi Mi A2 Lite	1	BHandset	6923
Other	Xiaomi Mi Max 3	1	BHandset	6924
Other	Xiaomi Mi Mix 2S	5	BHandset	6925
Other	Xiaomi Mi Mix 3	2	BHandset	6926
Other	Xiaomi Mi Play	1	BHandset	6927
Other	Xiaomi Redmi 1S	2	BHandset	6928
Other	Xiaomi Redmi 4X	1	BHandset	6929
Other	Xiaomi Redmi 5 Plus	1	BHandset	6930
Other	Xiaomi Redmi 5A	1	BHandset	6931
Other	Xiaomi Redmi 6	2	BHandset	6932
Other	Xiaomi Redmi 6A	6	BHandset	6933
Other	Xiaomi Redmi 7	1	BHandset	6934
Other	Xiaomi Redmi A1	2	BHandset	6935
Other	Xiaomi Redmi Note	1	BHandset	6936
Other	Xiaomi Redmi Note 3	1	BHandset	6937
Other	Xiaomi Redmi Note 4X	2	BHandset	6938
Other	Xiaomi Redmi Note 5A	1	BHandset	6939
Other	Xiaomi Redmi Note 7	2	BHandset	6940
Other	Yezz Andy 5Ei3	2	BHandset	6941
Other	Zonda Zmck870	18	BHandset	6942
Other	Mixed Tablets	92	BHandset	6943
Samsung	A300	4	BHandset	6944
Samsung	A310	3	BHandset	6945
Samsung	A310 (Demo)	1	BHandset	6946
Samsung	A310F	5	BHandset	6947
Samsung	A320	2	BHandset	6948
Samsung	A320F	5	BHandset	6949
Samsung	A908B	1	BHandset	6950
Samsung	B2100	2	BHandset	6951
Samsung	B270	20	BHandset	6952
Samsung	B2700	2	BHandset	6953
Samsung	B300	5	BHandset	6954
Samsung	B3210	1	BHandset	6955
Samsung	B3410	1	BHandset	6956
Samsung	B5510	2	BHandset	6957
Samsung	B5512	1	BHandset	6958
Samsung	B7510	1	BHandset	6959
Samsung	C260	6	BHandset	6960
Samsung	C270	2	BHandset	6961
Samsung	C3050	28	BHandset	6962
Samsung	C3262	2	BHandset	6963
Samsung	C3300	10	BHandset	6964

Samsung	C3350	2	BHandset	6965
Samsung	C3520	12	BHandset	6966
Samsung	C3590	1	BHandset	6967
Samsung	C5000	1	BHandset	6968
Samsung	C5010	3	BHandset	6969
Samsung	C5130	3	BHandset	6970
Samsung	C5220	49	BHandset	6971
Samsung	C5510	1	BHandset	6972
Samsung	C7010	2	BHandset	6973
Samsung	E1050	3	BHandset	6974
Samsung	E1080	5	BHandset	6975
Samsung	E1120	4	BHandset	6976
Samsung	E1150	4	BHandset	6977
Samsung	E1170	10	BHandset	6978
Samsung	E1270	6	BHandset	6979
Samsung	E1310	14	BHandset	6980
Samsung	E1360	1	BHandset	6981
Samsung	E2100	1	BHandset	6982
Samsung	E2121	3	BHandset	6983
Samsung	E2210	1	BHandset	6984
Samsung	E2230	5	BHandset	6985
Samsung	E2370	18	BHandset	6986
Samsung	E2530	7	BHandset	6987
Samsung	E2550	27	BHandset	6988
Samsung	E2600	16	BHandset	6989
Samsung	E3300	30	BHandset	6990
Samsung	E3309	27	BHandset	6991
Samsung	E500	4	BHandset	6992
Samsung	E700	1	BHandset	6993
Samsung	F480	30	BHandset	6994
Samsung	F488	1	BHandset	6995
Samsung	G110	4	BHandset	6996
Samsung	G130	24	BHandset	6997
Samsung	G310	24	BHandset	6998
Samsung	G313	63	BHandset	6999
Samsung	G316	27	BHandset	7000
Samsung	G318	140	BHandset	7001
Samsung	G350	11	BHandset	7002
Samsung	G355	24	BHandset	7003
Samsung	G357F	118	BHandset	7004
Samsung	G360	292	BHandset	7005
Samsung	G360F	49	BHandset	7006
Samsung	G361	1	BHandset	7007
Samsung	G361F	157	BHandset	7008
Samsung	G3815	11	BHandset	7009
Samsung	G386	3	BHandset	7010
Samsung	G386F	25	BHandset	7011
Samsung	G388F	414	BHandset	7012
Samsung	G389	5	BHandset	7013
Samsung	G389F	7	BHandset	7014
Samsung	G390	442	BHandset	7015
Samsung	G390F	610	BHandset	7016
Samsung	G398	7	BHandset	7017
Samsung	G398F	591	BHandset	7018
Samsung	G398F (IMEI Cut)	3	BHandset	7019
Samsung	G525F	1	BHandset	7020
Samsung	G530	63	BHandset	7021
Samsung	G5308	1	BHandset	7022
Samsung	G530F	14	BHandset	7023
Samsung	G531	8	BHandset	7024
Samsung	G531F	13	BHandset	7025
Samsung	G532	147	BHandset	7026
Samsung	G532F	1	BHandset	7027
Samsung	G550	7	BHandset	7028
Samsung	G570	9	BHandset	7029
Samsung	G570F	1	BHandset	7030
Samsung	G600F	2	BHandset	7031
Samsung	G7102	4	BHandset	7032
Samsung	G7105	10	BHandset	7033
Samsung	G7106	1	BHandset	7034
Samsung	G720	1	BHandset	7035
Samsung	G730	2	BHandset	7036
Samsung	G750	3	BHandset	7037
Samsung	G800	2	BHandset	7038
Samsung	G800 (Demo)	1	BHandset	7039
Samsung	G800F	95	BHandset	7040
Samsung	G850	3	BHandset	7041
Samsung	G850F	17	BHandset	7042
Samsung	G870	6	BHandset	7043
Samsung	G870F	2	BHandset	7044
Samsung	G900	37	BHandset	7045
Samsung	G900 (Demo)	3	BHandset	7046
Samsung	G901F	1	BHandset	7047
Samsung	G903	1	BHandset	7048
Samsung	G920F	23	BHandset	7049
Samsung	i257	1	BHandset	7050

Samsung	i317	3	BHandset	7051
Samsung	i337	4	BHandset	7052
Samsung	i437	1	BHandset	7053
Samsung	i497	1	BHandset	7054
Samsung	i535	3	BHandset	7055
Samsung	i537	2	BHandset	7056
Samsung	i545	9	BHandset	7057
Samsung	i5500	11	BHandset	7058
Samsung	i5503	19	BHandset	7059
Samsung	i5700	2	BHandset	7060
Samsung	i5800	2	BHandset	7061
Samsung	i605	5	BHandset	7062
Samsung	i705	3	BHandset	7063
Samsung	i727	1	BHandset	7064
Samsung	i747	5	BHandset	7065
Samsung	i757	1	BHandset	7066
Samsung	i777	1	BHandset	7067
Samsung	i8000	1	BHandset	7068
Samsung	i8150	13	BHandset	7069
Samsung	i8160	159	BHandset	7070
Samsung	i8190	535	BHandset	7071
Samsung	i8200	216	BHandset	7072
Samsung	i8260	16	BHandset	7073
Samsung	i8262	4	BHandset	7074
Samsung	i8350	1	BHandset	7075
Samsung	i8552	8	BHandset	7076
Samsung	i8700	5	BHandset	7077
Samsung	i8730	12	BHandset	7078
Samsung	i8750	24	BHandset	7079
Samsung	i897	2	BHandset	7080
Samsung	i9000	135	BHandset	7081
Samsung	i9001	18	BHandset	7082
Samsung	i9003	12	BHandset	7083
Samsung	i9020	10	BHandset	7084
Samsung	i9023	15	BHandset	7085
Samsung	i905	4	BHandset	7086
Samsung	i9060	145	BHandset	7087
Samsung	i9070	11	BHandset	7088
Samsung	i9080	1	BHandset	7089
Samsung	i9082	4	BHandset	7090
Samsung	i9100	409	BHandset	7091
Samsung	i9103	1	BHandset	7092
Samsung	i9105	45	BHandset	7093
Samsung	i9150	2	BHandset	7094
Samsung	i9152	3	BHandset	7095
Samsung	i918	1	BHandset	7096
Samsung	i9190	2	BHandset	7097
Samsung	i9192	13	BHandset	7098
Samsung	i9195	552	BHandset	7099
Samsung	i9195 (Demo)	1	BHandset	7100
Samsung	i9197	1	BHandset	7101
Samsung	i9200	1	BHandset	7102
Samsung	i9205	5	BHandset	7103
Samsung	i9210	4	BHandset	7104
Samsung	i9250	7	BHandset	7105
Samsung	i9295	25	BHandset	7106
Samsung	i9300	610	BHandset	7107
Samsung	i9300 (Demo)	5	BHandset	7108
Samsung	i9301	139	BHandset	7109
Samsung	i9305	52	BHandset	7110
Samsung	i9500	7	BHandset	7111
Samsung	i9505	14	BHandset	7112
Samsung	i9505 (Demo)	2	BHandset	7113
Samsung	i9506	1	BHandset	7114
Samsung	i9515	8	BHandset	7115
Samsung	i997	2	BHandset	7116
Samsung	J100	117	BHandset	7117
Samsung	J105	9	BHandset	7118
Samsung	J105F	2	BHandset	7119
Samsung	J106	3	BHandset	7120
Samsung	J106F	1	BHandset	7121
Samsung	J110	90	BHandset	7122
Samsung	J200	12	BHandset	7123
Samsung	J250	28	BHandset	7124
Samsung	J260	15	BHandset	7125
Samsung	J320	10	BHandset	7126
Samsung	J320F	11	BHandset	7127
Samsung	J327	1	BHandset	7128
Samsung	J330	7	BHandset	7129
Samsung	J330F	12	BHandset	7130
Samsung	J337	2	BHandset	7131
Samsung	J410	3	BHandset	7132
Samsung	J410F	2	BHandset	7133
Samsung	J415F	1	BHandset	7134
Samsung	J500F	7	BHandset	7135
Samsung	J530F	1	BHandset	7136

Samsung	J600	4	BHandset	7137
Samsung	J600F	5	BHandset	7138
Samsung	J610	4	BHandset	7139
Samsung	J610F	3	BHandset	7140
Samsung	J700F	1	BHandset	7141
Samsung	J710F	3	BHandset	7142
Samsung	J720F	1	BHandset	7143
Samsung	J727	4	BHandset	7144
Samsung	J810	3	BHandset	7145
Samsung	L720	2	BHandset	7146
Samsung	L900	5	BHandset	7147
Samsung	M150	1	BHandset	7148
Samsung	M919	2	BHandset	7149
Samsung	N5110	6	BHandset	7150
Samsung	N7000	17	BHandset	7151
Samsung	N7100	47	BHandset	7152
Samsung	N7100 (Demo)	1	BHandset	7153
Samsung	N7105	13	BHandset	7154
Samsung	N7505	3	BHandset	7155
Samsung	N8000	1	BHandset	7156
Samsung	N8010	21	BHandset	7157
Samsung	N8020	2	BHandset	7158
Samsung	N900	3	BHandset	7159
Samsung	N900 (Demo)	4	BHandset	7160
Samsung	N9005	67	BHandset	7161
Samsung	N9007	2	BHandset	7162
Samsung	N910	33	BHandset	7163
Samsung	N910 (Demo)	8	BHandset	7164
Samsung	N9100	3	BHandset	7165
Samsung	N910F	4	BHandset	7166
Samsung	N910S	1	BHandset	7167
Samsung	N915	1	BHandset	7168
Samsung	N915F	7	BHandset	7169
Samsung	N9208	1	BHandset	7170
Samsung	P1000	1	BHandset	7171
Samsung	P3100	3	BHandset	7172
Samsung	P3110	42	BHandset	7173
Samsung	P3113	4	BHandset	7174
Samsung	P355	4	BHandset	7175
Samsung	P5100	6	BHandset	7176
Samsung	P5110	34	BHandset	7177
Samsung	P5113	3	BHandset	7178
Samsung	P5200	6	BHandset	7179
Samsung	P5210	23	BHandset	7180
Samsung	P550	7	BHandset	7181
Samsung	P580	2	BHandset	7182
Samsung	P600	3	BHandset	7183
Samsung	P601	1	BHandset	7184
Samsung	P605	2	BHandset	7185
Samsung	P7310	1	BHandset	7186
Samsung	P7500	1	BHandset	7187
Samsung	P7510	4	BHandset	7188
Samsung	P8110	9	BHandset	7189
Samsung	P900	1	BHandset	7190
Samsung	P900(Pad)	4	BHandset	7191
Samsung	P905	1	BHandset	7192
Samsung	R530	3	BHandset	7193
Samsung	R970	2	BHandset	7194
Samsung	S111	2	BHandset	7195
Samsung	S205	1	BHandset	7196
Samsung	S260	46	BHandset	7197
Samsung	S3100	1	BHandset	7198
Samsung	S3350	2	BHandset	7199
Samsung	S3370	55	BHandset	7200
Samsung	S3560	1	BHandset	7201
Samsung	S3570	1	BHandset	7202
Samsung	S3650	35	BHandset	7203
Samsung	S367	1	BHandset	7204
Samsung	S5220	12	BHandset	7205
Samsung	S5230	3	BHandset	7206
Samsung	S5250	1	BHandset	7207
Samsung	S5260	19	BHandset	7208
Samsung	S5280	4	BHandset	7209
Samsung	S5300	53	BHandset	7210
Samsung	S5310	19	BHandset	7211
Samsung	S5360	71	BHandset	7212
Samsung	S5360T	104	BHandset	7213
Samsung	S5363	6	BHandset	7214
Samsung	S5380	7	BHandset	7215
Samsung	S550	5	BHandset	7216
Samsung	S5560	1	BHandset	7217
Samsung	S5570	200	BHandset	7218
Samsung	S5600	61	BHandset	7219
Samsung	S5610	15	BHandset	7220
Samsung	S5620	81	BHandset	7221
Samsung	S5660	30	BHandset	7222

Samsung	S5670	48	BHandset	7223
Samsung	S5690	93	BHandset	7224
Samsung	S5780	1	BHandset	7225
Samsung	S5830	362	BHandset	7226
Samsung	S6310	82	BHandset	7227
Samsung	S6500	67	BHandset	7228
Samsung	S6790	4	BHandset	7229
Samsung	S6802	6	BHandset	7230
Samsung	S6810	115	BHandset	7231
Samsung	S7230	6	BHandset	7232
Samsung	S7275	269	BHandset	7233
Samsung	S737	2	BHandset	7234
Samsung	S7390	61	BHandset	7235
Samsung	S7392	4	BHandset	7236
Samsung	S7500	72	BHandset	7237
Samsung	S7530	2	BHandset	7238
Samsung	S7560	30	BHandset	7239
Samsung	S7562	45	BHandset	7240
Samsung	S7580	73	BHandset	7241
Samsung	S7582	6	BHandset	7242
Samsung	S7583	1	BHandset	7243
Samsung	S767	1	BHandset	7244
Samsung	S7710	62	BHandset	7245
Samsung	S8000	2	BHandset	7246
Samsung	S820	3	BHandset	7247
Samsung	S8300	11	BHandset	7248
Samsung	S8500	4	BHandset	7249
Samsung	S8530	4	BHandset	7250
Samsung	S8600	5	BHandset	7251
Samsung	S907	3	BHandset	7252
Samsung	S978	1	BHandset	7253
Samsung	SC-56B	1	BHandset	7254
Samsung	T110	2	BHandset	7255
Samsung	T113	4	BHandset	7256
Samsung	T116	1	BHandset	7257
Samsung	T210	19	BHandset	7258
Samsung	T2105	1	BHandset	7259
Samsung	T211	2	BHandset	7260
Samsung	T220	15	BHandset	7261
Samsung	T220(IMEI Cut)	4	BHandset	7262
Samsung	T225	2	BHandset	7263
Samsung	T230	14	BHandset	7264
Samsung	T280	3	BHandset	7265
Samsung	T285	1	BHandset	7266
Samsung	T290	5	BHandset	7267
Samsung	T295	7	BHandset	7268
Samsung	T307	19	BHandset	7269
Samsung	T310	12	BHandset	7270
Samsung	T320	1	BHandset	7271
Samsung	T330	4	BHandset	7272
Samsung	T335	5	BHandset	7273
Samsung	T337	1	BHandset	7274
Samsung	T350	1	BHandset	7275
Samsung	T365	32	BHandset	7276
Samsung	T377	2	BHandset	7277
Samsung	T385	2	BHandset	7278
Samsung	T387	13	BHandset	7279
Samsung	T390	2	BHandset	7280
Samsung	T395	29	BHandset	7281
Samsung	T397	1	BHandset	7282
Samsung	T399	1	BHandset	7283
Samsung	T505	1	BHandset	7284
Samsung	T520	4	BHandset	7285
Samsung	T530	8	BHandset	7286
Samsung	T533	1	BHandset	7287
Samsung	T535	1	BHandset	7288
Samsung	T550	9	BHandset	7289
Samsung	T555	2	BHandset	7290
Samsung	T560	8	BHandset	7291
Samsung	T575	3	BHandset	7292
Samsung	T580	90	BHandset	7293
Samsung	T590	2	BHandset	7294
Samsung	T679	1	BHandset	7295
Samsung	T700	2	BHandset	7296
Samsung	T705	7	BHandset	7297
Samsung	T710	4	BHandset	7298
Samsung	T713	1	BHandset	7299
Samsung	T715	1	BHandset	7300
Samsung	T719	1	BHandset	7301
Samsung	T800	8	BHandset	7302
Samsung	T805	19	BHandset	7303
Samsung	T810	1	BHandset	7304
Samsung	T813	2	BHandset	7305
Samsung	T815	4	BHandset	7306
Samsung	T817	1	BHandset	7307
Samsung	T819	4	BHandset	7308

Samsung	T900	2	BHandset	7309
Samsung	T959	9	BHandset	7310
Samsung	T991	1	BHandset	7311
Samsung	T999	2	BHandset	7312
Sfr	STARNAUTE IV	3	BHandset	7313
Sfr	STARSHINE IV	1	BHandset	7314
Sfr	STARTRAIL 8	28	BHandset	7315
Sfr	STARXTREM 5	1	BHandset	7316
Sfr	STARXTREM 6	15	BHandset	7317
Vodafone	SMart C11	13	BHandset	7318
Vodafone	SMart E10	44	BHandset	7319
Vodafone	SMart E11	19	BHandset	7320
Vodafone	SMart Green	13	BHandset	7321
Vodafone	SMart M23	16	BHandset	7322
Vodafone	SMart N10	1	BHandset	7323
Vodafone	SMart V22	27	BHandset	7324
Vodafone	V1397	2	BHandset	7325
Vodafone	V155	29	BHandset	7326
Vodafone	V500	2	BHandset	7327
Vodafone	V555	5	BHandset	7328
Vodafone	V655	2	BHandset	7329
Vodafone	V685	167	BHandset	7330
Vodafone	V695	2	BHandset	7331
Vodafone	V785	133	BHandset	7332
Vodafone	V795	58	BHandset	7333
Vodafone	V858	79	BHandset	7334
Vodafone	V860	15	BHandset	7335
Vodafone	V875	35	BHandset	7336
Vodafone	V888	14	BHandset	7337
Vodafone	V890	50	BHandset	7338
Vodafone	V895	74	BHandset	7339
Vodafone	V985	47	BHandset	7340
Vodafone	V995	19	BHandset	7341
Vodafone	VFD 120	180	BHandset	7342
Vodafone	VFD 1300	15	BHandset	7343
Vodafone	VFD 200	67	BHandset	7344
Vodafone	VFD 300	199	BHandset	7345
Vodafone	VFD 320	184	BHandset	7346
Vodafone	VFD 500	3	BHandset	7347
Vodafone	VFD 501	18	BHandset	7348
Vodafone	VFD 510	16	BHandset	7349
Vodafone	VFD 511	2	BHandset	7350
Vodafone	VFD 513	93	BHandset	7351
Vodafone	VFD 527	2	BHandset	7352
Vodafone	VFD 600	62	BHandset	7353
Vodafone	VFD 610	146	BHandset	7354
Vodafone	VFD 620	109	BHandset	7355
Vodafone	VFD 630	22	BHandset	7356
Vodafone	VFD 700	84	BHandset	7357
Vodafone	VFD 710	106	BHandset	7358
Vodafone	VFD 720	148	BHandset	7359
Vodafone	VFD 730	6	BHandset	7360
Vodafone	VFD 820	1	BHandset	7361
Vodafone	VFD 822	7	BHandset	7362
Vodafone	VFD 900	3	BHandset	7363
Zte	Axon 7 Mini	1	BHandset	7364
Zte	B2017G	1	BHandset	7365
Zte	Blade 10 SMart	1	BHandset	7366
Zte	Blade 10 Vita	1	BHandset	7367
Zte	Blade A110	205	BHandset	7368
Zte	Blade A112	2	BHandset	7369
Zte	Blade A3 Lite	542	BHandset	7370
Zte	Blade A3(2019)	6	BHandset	7371
Zte	Blade A31 Plus	1	BHandset	7372
Zte	Blade A321	2	BHandset	7373
Zte	Blade A33	6	BHandset	7374
Zte	Blade A330	102	BHandset	7375
Zte	Blade A33S	1	BHandset	7376
Zte	Blade A410	1	BHandset	7377
Zte	Blade A452	1	BHandset	7378
Zte	Blade A460	29	BHandset	7379
Zte	Blade A462	284	BHandset	7380
Zte	Blade A5(2019)	12	BHandset	7381
Zte	Blade A5(2020)	34	BHandset	7382
Zte	Blade A506	2	BHandset	7383
Zte	Blade A51	3	BHandset	7384
Zte	Blade A510	4	BHandset	7385
Zte	Blade A512	9	BHandset	7386
Zte	Blade A521	11	BHandset	7387
Zte	Blade A6	13	BHandset	7388
Zte	Blade A602	6	BHandset	7389
Zte	Blade A610	21	BHandset	7390
Zte	Blade A612	1	BHandset	7391
Zte	Blade A71	1	BHandset	7392
Zte	Blade A910	2	BHandset	7393
Zte	Blade Apex	1	BHandset	7394

Zte	Blade Apex II	2	BHandset	7395
Zte	Blade Apex III	1	BHandset	7396
Zte	Blade C2 Plus	3	BHandset	7397
Zte	Blade G	2	BHandset	7398
Zte	Blade III	3	BHandset	7399
Zte	Blade L110	122	BHandset	7400
Zte	Blade L2	38	BHandset	7401
Zte	Blade L210	1	BHandset	7402
Zte	Blade L3	13	BHandset	7403
Zte	Blade L5	1	BHandset	7404
Zte	Blade L5 Plus	40	BHandset	7405
Zte	Blade L7	15	BHandset	7406
Zte	Blade L8	2	BHandset	7407
Zte	Blade L9	1	BHandset	7408
Zte	Blade Q	2	BHandset	7409
Zte	Blade Q Lux	3	BHandset	7410
Zte	Blade V	1	BHandset	7411
Zte	Blade V1000	4	BHandset	7412
Zte	Blade V3(2019)	1	BHandset	7413
Zte	Blade V30 Vita	1	BHandset	7414
Zte	Blade V40 Vita	1	BHandset	7415
Zte	Blade V6	1	BHandset	7416
Zte	Blade V6 Plus	8	BHandset	7417
Zte	Blade V7	16	BHandset	7418
Zte	Blade V7 Lite	2	BHandset	7419
Zte	Blade V9 Vita	17	BHandset	7420
Zte	Blade Vec	3	BHandset	7421
Zte	E8QP	2	BHandset	7422
Zte	F102 3G	146	BHandset	7423
Zte	F320	271	BHandset	7424
Zte	F327	16	BHandset	7425
Zte	F328	27	BHandset	7426
Zte	Grand S Flex	1	BHandset	7427
Zte	K88	1	BHandset	7428
Zte	N9520	1	BHandset	7429
Zte	Nubia M2 Lite	2	BHandset	7430
Zte	P743	2	BHandset	7431
Zte	R101	4	BHandset	7432
Zte	R109	81	BHandset	7433
Zte	R22	18	BHandset	7434
Zte	R286	50	BHandset	7435
Zte	R350	212	BHandset	7436
Zte	R55	149	BHandset	7437
Zte	R83	16	BHandset	7438
Zte	R84	22	BHandset	7439
Zte	T126	1	BHandset	7440
Zte	T21	1	BHandset	7441
Zte	T57	1	BHandset	7442
Zte	T610	1	BHandset	7443
Zte	T815	5	BHandset	7444
Zte	T83	47	BHandset	7445
Zte	T84	61	BHandset	7446
Zte	T85	9	BHandset	7447
Zte	T95	2	BHandset	7448
Zte	V795	52	BHandset	7449
Zte	V811	1	BHandset	7450
Zte	V812	3	BHandset	7451
Zte	Z831	2	BHandset	7452
Zte	Z835	2	BHandset	7453
Zte	Z970	2	BHandset	7454
Zte	Z981	12	BHandset	7455
Zte	Z982	4	BHandset	7456
Acer	A1-830	1	BHandset (Power Up, Bad LCD) (No Power)	7457
Acer	A60	3	BHandset (Power Up, Bad LCD) (No Power)	7458
Acer	Sospiro Ax64	1	BHandset (Power Up, Bad LCD) (No Power)	7459
Alcatel	OT1016	1	BHandset (Power Up, Bad LCD) (No Power)	7460
Alcatel	OT1066	2	BHandset (Power Up, Bad LCD) (No Power)	7461
Alcatel	OT2004	1	BHandset (Power Up, Bad LCD) (No Power)	7462
Alcatel	OT2008	2	BHandset (Power Up, Bad LCD) (No Power)	7463
Alcatel	OT2020	1	BHandset (Power Up, Bad LCD) (No Power)	7464
Alcatel	OT2053	2	BHandset (Power Up, Bad LCD) (No Power)	7465
Alcatel	OT2057	33	BHandset (Power Up, Bad LCD) (No Power)	7466
Alcatel	OT3026	3	BHandset (Power Up, Bad LCD) (No Power)	7467
Alcatel	OT3082	1	BHandset (Power Up, Bad LCD) (No Power)	7468
Alcatel	OT4034	2	BHandset (Power Up, Bad LCD) (No Power)	7469
Alcatel	OT4047	7	BHandset (Power Up, Bad LCD) (No Power)	7470
Alcatel	OT5002	4	BHandset (Power Up, Bad LCD) (No Power)	7471
Alcatel	OT5006	1	BHandset (Power Up, Bad LCD) (No Power)	7472
Alcatel	OT5008	3	BHandset (Power Up, Bad LCD) (No Power)	7473
Alcatel	OT5009	2	BHandset (Power Up, Bad LCD) (No Power)	7474
Alcatel	OT5010	4	BHandset (Power Up, Bad LCD) (No Power)	7475
Alcatel	OT5015	3	BHandset (Power Up, Bad LCD) (No Power)	7476
Alcatel	OT5017	1	BHandset (Power Up, Bad LCD) (No Power)	7477
Alcatel	OT5022	2	BHandset (Power Up, Bad LCD) (No Power)	7478
Alcatel	OT5024	34	BHandset (Power Up, Bad LCD) (No Power)	7479
Alcatel	OT5025	1	BHandset (Power Up, Bad LCD) (No Power)	7480

Alcatel		OT5026	1	BHandset (Power Up, Bad LCD) (No Power)	7481
Alcatel		OT5030	41	BHandset (Power Up, Bad LCD) (No Power)	7482
Alcatel		OT5031	4	BHandset (Power Up, Bad LCD) (No Power)	7483
Alcatel		OT5033	63	BHandset (Power Up, Bad LCD) (No Power)	7484
Alcatel		OT5039	1	BHandset (Power Up, Bad LCD) (No Power)	7485
Alcatel		OT5042	1	BHandset (Power Up, Bad LCD) (No Power)	7486
Alcatel		OT5044	8	BHandset (Power Up, Bad LCD) (No Power)	7487
Alcatel		OT5045	2	BHandset (Power Up, Bad LCD) (No Power)	7488
Alcatel		OT5047	2	BHandset (Power Up, Bad LCD) (No Power)	7489
Alcatel		OT5048	6	BHandset (Power Up, Bad LCD) (No Power)	7490
Alcatel		OT5051	1	BHandset (Power Up, Bad LCD) (No Power)	7491
Alcatel		OT5054	4	BHandset (Power Up, Bad LCD) (No Power)	7492
Alcatel		OT5056	1	BHandset (Power Up, Bad LCD) (No Power)	7493
Alcatel		OT5058	2	BHandset (Power Up, Bad LCD) (No Power)	7494
Alcatel		OT5059	4	BHandset (Power Up, Bad LCD) (No Power)	7495
Alcatel		OT5061	6	BHandset (Power Up, Bad LCD) (No Power)	7496
Alcatel		OT5080	2	BHandset (Power Up, Bad LCD) (No Power)	7497
Alcatel		OT5085	1	BHandset (Power Up, Bad LCD) (No Power)	7498
Alcatel		OT5099	1	BHandset (Power Up, Bad LCD) (No Power)	7499
Alcatel		OT6012	1	BHandset (Power Up, Bad LCD) (No Power)	7500
Alcatel		OT6025	6	BHandset (Power Up, Bad LCD) (No Power)	7501
Alcatel		OT6045	1	BHandset (Power Up, Bad LCD) (No Power)	7502
Alcatel		OT6055	1	BHandset (Power Up, Bad LCD) (No Power)	7503
Alcatel		OT6056	1	BHandset (Power Up, Bad LCD) (No Power)	7504
Alcatel		OT7047	1	BHandset (Power Up, Bad LCD) (No Power)	7505
Alcatel		OT7048	1	BHandset (Power Up, Bad LCD) (No Power)	7506
Alcatel		OT8055	1	BHandset (Power Up, Bad LCD) (No Power)	7507
Alcatel		OT8063	1	BHandset (Power Up, Bad LCD) (No Power)	7508
Alcatel		OT8088	7	BHandset (Power Up, Bad LCD) (No Power)	7509
Alcatel		OT8094	1	BHandset (Power Up, Bad LCD) (No Power)	7510
Alcatel		OT9001	1	BHandset (Power Up, Bad LCD) (No Power)	7511
Alcatel		OT9007	7	BHandset (Power Up, Bad LCD) (No Power)	7512
Alcatel		OT9008	2	BHandset (Power Up, Bad LCD) (No Power)	7513
Alcatel		OT9013	1	BHandset (Power Up, Bad LCD) (No Power)	7514
Alcatel		OT9022	5	BHandset (Power Up, Bad LCD) (No Power)	7515
Alcatel		OT9027	4	BHandset (Power Up, Bad LCD) (No Power)	7516
Alcatel		OT9032	1	BHandset (Power Up, Bad LCD) (No Power)	7517
Alcatel		OT-P330	3	BHandset (Power Up, Bad LCD) (No Power)	7518
Asus		Nexus 7	1	BHandset (Power Up, Bad LCD) (No Power)	7519
Asus		Nexus 7 K008	1	BHandset (Power Up, Bad LCD) (No Power)	7520
Asus		Nexus 7 K009	1	BHandset (Power Up, Bad LCD) (No Power)	7521
Asus		Z01HD	2	BHandset (Power Up, Bad LCD) (No Power)	7522
Asus		Z01Kd	1	BHandset (Power Up, Bad LCD) (No Power)	7523
Blackberry		BB9900	9	BHandset (Power Up, Bad LCD) (No Power)	7524
Blackberry		BB9900 (倒键)	7	BHandset (Power Up, Bad LCD) (No Power)	7525
Blackberry		DTEK50	16	BHandset (Power Up, Bad LCD) (No Power)	7526
Blackberry		DTEK60	2	BHandset (Power Up, Bad LCD) (No Power)	7527
Blackberry		Playbook (64GB)	1	BHandset (Power Up, Bad LCD) (No Power)	7528
Blackberry		Priv	4	BHandset (Power Up, Bad LCD) (No Power)	7529
Blackberry		Q10	2	BHandset (Power Up, Bad LCD) (No Power)	7530
Blackberry		Q10 (倒键)	1	BHandset (Power Up, Bad LCD) (No Power)	7531
Blackberry		Q20	2	BHandset (Power Up, Bad LCD) (No Power)	7532
Blackberry		Q20 (倒键)	4	BHandset (Power Up, Bad LCD) (No Power)	7533
Blackberry		Q5	1	BHandset (Power Up, Bad LCD) (No Power)	7534
Blackberry		Q5 (倒键)	1	BHandset (Power Up, Bad LCD) (No Power)	7535
Blackberry		Z10	1	BHandset (Power Up, Bad LCD) (No Power)	7536
Blackberry		Z10 4G	10	BHandset (Power Up, Bad LCD) (No Power)	7537
Blackberry		Z3	2	BHandset (Power Up, Bad LCD) (No Power)	7538
Blackberry		Z30	2	BHandset (Power Up, Bad LCD) (No Power)	7539
Blackberry		Z30 4G	3	BHandset (Power Up, Bad LCD) (No Power)	7540
Ericsson		C1505	5	BHandset (Power Up, Bad LCD) (No Power)	7541
Ericsson		C2105	1	BHandset (Power Up, Bad LCD) (No Power)	7542
Ericsson		C5303	6	BHandset (Power Up, Bad LCD) (No Power)	7543
Ericsson		C6833	2	BHandset (Power Up, Bad LCD) (No Power)	7544
Ericsson		C6903	2	BHandset (Power Up, Bad LCD) (No Power)	7545
Ericsson		D2005	1	BHandset (Power Up, Bad LCD) (No Power)	7546
Ericsson		D2203	3	BHandset (Power Up, Bad LCD) (No Power)	7547
Ericsson		D2303	1	BHandset (Power Up, Bad LCD) (No Power)	7548
Ericsson		D2403	4	BHandset (Power Up, Bad LCD) (No Power)	7549
Ericsson		D5106	1	BHandset (Power Up, Bad LCD) (No Power)	7550
Ericsson		D5303	1	BHandset (Power Up, Bad LCD) (No Power)	7551
Ericsson		D5503	14	BHandset (Power Up, Bad LCD) (No Power)	7552
Ericsson		D5803	14	BHandset (Power Up, Bad LCD) (No Power)	7553
Ericsson		D6503	4	BHandset (Power Up, Bad LCD) (No Power)	7554
Ericsson		D6603	7	BHandset (Power Up, Bad LCD) (No Power)	7555
Ericsson		E2053	2	BHandset (Power Up, Bad LCD) (No Power)	7556
Ericsson		E2104	1	BHandset (Power Up, Bad LCD) (No Power)	7557
Ericsson		E2303	5	BHandset (Power Up, Bad LCD) (No Power)	7558
Ericsson		E2306	3	BHandset (Power Up, Bad LCD) (No Power)	7559
Ericsson		E2353	1	BHandset (Power Up, Bad LCD) (No Power)	7560
Ericsson		LT22i	1	BHandset (Power Up, Bad LCD) (No Power)	7561
Ericsson		LT26i	2	BHandset (Power Up, Bad LCD) (No Power)	7562
Ericsson		LT30p	2	BHandset (Power Up, Bad LCD) (No Power)	7563
Ericsson		LT36	5	BHandset (Power Up, Bad LCD) (No Power)	7564
Ericsson		R800	1	BHandset (Power Up, Bad LCD) (No Power)	7565
Ericsson		SGPT321	1	BHandset (Power Up, Bad LCD) (No Power)	7566

Ericsson	SGPT521	2	BHandset (Power Up, Bad LCD) (No Power)	7567
Ericsson	ST21i	3	BHandset (Power Up, Bad LCD) (No Power)	7568
Ericsson	ST26i	2	BHandset (Power Up, Bad LCD) (No Power)	7569
Ericsson	X12	2	BHandset (Power Up, Bad LCD) (No Power)	7570
Htc	10	7	BHandset (Power Up, Bad LCD) (No Power)	7571
Htc	10 EVO	5	BHandset (Power Up, Bad LCD) (No Power)	7572
Htc	8S	1	BHandset (Power Up, Bad LCD) (No Power)	7573
Htc	Desire 10 Lifestyle	3	BHandset (Power Up, Bad LCD) (No Power)	7574
Htc	Desire 12 Plus	4	BHandset (Power Up, Bad LCD) (No Power)	7575
Htc	Desire 20 Pro	1	BHandset (Power Up, Bad LCD) (No Power)	7576
Htc	Desire 510	2	BHandset (Power Up, Bad LCD) (No Power)	7577
Htc	Desire 530	4	BHandset (Power Up, Bad LCD) (No Power)	7578
Htc	Desire 610	7	BHandset (Power Up, Bad LCD) (No Power)	7579
Htc	Desire 620	1	BHandset (Power Up, Bad LCD) (No Power)	7580
Htc	Desire 626	7	BHandset (Power Up, Bad LCD) (No Power)	7581
Htc	Desire 816	4	BHandset (Power Up, Bad LCD) (No Power)	7582
Htc	Desire 820	3	BHandset (Power Up, Bad LCD) (No Power)	7583
Htc	Desire 825	2	BHandset (Power Up, Bad LCD) (No Power)	7584
Htc	Desire HD	2	BHandset (Power Up, Bad LCD) (No Power)	7585
Htc	Desire X	1	BHandset (Power Up, Bad LCD) (No Power)	7586
Htc	Nexus 9	2	BHandset (Power Up, Bad LCD) (No Power)	7587
Htc	One	4	BHandset (Power Up, Bad LCD) (No Power)	7588
Htc	One A9	5	BHandset (Power Up, Bad LCD) (No Power)	7589
Htc	One E9	1	BHandset (Power Up, Bad LCD) (No Power)	7590
Htc	One M8	3	BHandset (Power Up, Bad LCD) (No Power)	7591
Htc	One M8S	5	BHandset (Power Up, Bad LCD) (No Power)	7592
Htc	One M9	3	BHandset (Power Up, Bad LCD) (No Power)	7593
Htc	One Mini	4	BHandset (Power Up, Bad LCD) (No Power)	7594
Htc	One Mini II	9	BHandset (Power Up, Bad LCD) (No Power)	7595
Htc	One X	10	BHandset (Power Up, Bad LCD) (No Power)	7596
Htc	One X+	3	BHandset (Power Up, Bad LCD) (No Power)	7597
Htc	One XL	1	BHandset (Power Up, Bad LCD) (No Power)	7598
Htc	Sensation XE	1	BHandset (Power Up, Bad LCD) (No Power)	7599
Htc	Sensation XL	3	BHandset (Power Up, Bad LCD) (No Power)	7600
Htc	U Play	6	BHandset (Power Up, Bad LCD) (No Power)	7601
Htc	U Ultra	13	BHandset (Power Up, Bad LCD) (No Power)	7602
Htc	U11	19	BHandset (Power Up, Bad LCD) (No Power)	7603
Htc	U11 Life	9	BHandset (Power Up, Bad LCD) (No Power)	7604
Htc	U12 Plus	3	BHandset (Power Up, Bad LCD) (No Power)	7605
Htc	Wildfire	1	BHandset (Power Up, Bad LCD) (No Power)	7606
Huawei	AGRK-W09	2	BHandset (Power Up, Bad LCD) (No Power)	7607
Huawei	AGR-W09	1	BHandset (Power Up, Bad LCD) (No Power)	7608
Huawei	AGS2-L03	1	BHandset (Power Up, Bad LCD) (No Power)	7609
Huawei	AGS2-L09	2	BHandset (Power Up, Bad LCD) (No Power)	7610
Huawei	AGS3-W09	1	BHandset (Power Up, Bad LCD) (No Power)	7611
Huawei	AGS-L09	1	BHandset (Power Up, Bad LCD) (No Power)	7612
Huawei	AMN-LX2	1	BHandset (Power Up, Bad LCD) (No Power)	7613
Huawei	ATU-L11	1	BHandset (Power Up, Bad LCD) (No Power)	7614
Huawei	ATU-L21	1	BHandset (Power Up, Bad LCD) (No Power)	7615
Huawei	ATU-L22	1	BHandset (Power Up, Bad LCD) (No Power)	7616
Huawei	ATU-L31	5	BHandset (Power Up, Bad LCD) (No Power)	7617
Huawei	AUM-L29	2	BHandset (Power Up, Bad LCD) (No Power)	7618
Huawei	BAC-L03	2	BHandset (Power Up, Bad LCD) (No Power)	7619
Huawei	BAH2-L09	2	BHandset (Power Up, Bad LCD) (No Power)	7620
Huawei	BAH2-W19	4	BHandset (Power Up, Bad LCD) (No Power)	7621
Huawei	BAH-L09	1	BHandset (Power Up, Bad LCD) (No Power)	7622
Huawei	BAH-W09	1	BHandset (Power Up, Bad LCD) (No Power)	7623
Huawei	BKL-L09	3	BHandset (Power Up, Bad LCD) (No Power)	7624
Huawei	BND-L21	1	BHandset (Power Up, Bad LCD) (No Power)	7625
Huawei	BTV-DL09	1	BHandset (Power Up, Bad LCD) (No Power)	7626
Huawei	CAG-L03	8	BHandset (Power Up, Bad LCD) (No Power)	7627
Huawei	CAG-L23	1	BHandset (Power Up, Bad LCD) (No Power)	7628
Huawei	CAG-LX3	1	BHandset (Power Up, Bad LCD) (No Power)	7629
Huawei	CAM-L03	3	BHandset (Power Up, Bad LCD) (No Power)	7630
Huawei	CAM-L21	8	BHandset (Power Up, Bad LCD) (No Power)	7631
Huawei	CAM-L23	1	BHandset (Power Up, Bad LCD) (No Power)	7632
Huawei	CHC-U01	1	BHandset (Power Up, Bad LCD) (No Power)	7633
Huawei	Che2-L11	1	BHandset (Power Up, Bad LCD) (No Power)	7634
Huawei	CMR-W09	1	BHandset (Power Up, Bad LCD) (No Power)	7635
Huawei	CPN-W09	3	BHandset (Power Up, Bad LCD) (No Power)	7636
Huawei	CRO-L03	2	BHandset (Power Up, Bad LCD) (No Power)	7637
Huawei	CRR-L09	6	BHandset (Power Up, Bad LCD) (No Power)	7638
Huawei	CRR-UL00	2	BHandset (Power Up, Bad LCD) (No Power)	7639
Huawei	CUN-L03	1	BHandset (Power Up, Bad LCD) (No Power)	7640
Huawei	DIG-L03	2	BHandset (Power Up, Bad LCD) (No Power)	7641
Huawei	DIG-LX3	1	BHandset (Power Up, Bad LCD) (No Power)	7642
Huawei	DLI-L22	1	BHandset (Power Up, Bad LCD) (No Power)	7643
Huawei	DRA-L01	2	BHandset (Power Up, Bad LCD) (No Power)	7644
Huawei	DRA-L21	2	BHandset (Power Up, Bad LCD) (No Power)	7645
Huawei	DRA-LX2	1	BHandset (Power Up, Bad LCD) (No Power)	7646
Huawei	DUA-L22	3	BHandset (Power Up, Bad LCD) (No Power)	7647
Huawei	DUB-LX3	1	BHandset (Power Up, Bad LCD) (No Power)	7648
Huawei	DUK-L09	1	BHandset (Power Up, Bad LCD) (No Power)	7649
Huawei	FIG-LX1	13	BHandset (Power Up, Bad LCD) (No Power)	7650
Huawei	FLA-LX3	2	BHandset (Power Up, Bad LCD) (No Power)	7651
Huawei	FRD-L09	3	BHandset (Power Up, Bad LCD) (No Power)	7652

Huawei	G510	5	BHandset (Power Up, Bad LCD) (No Power)	7653
Huawei	G527	96	BHandset (Power Up, Bad LCD) (No Power)	7654
Huawei	G535	1	BHandset (Power Up, Bad LCD) (No Power)	7655
Huawei	G610	2	BHandset (Power Up, Bad LCD) (No Power)	7656
Huawei	G620	2	BHandset (Power Up, Bad LCD) (No Power)	7657
Huawei	G7	6	BHandset (Power Up, Bad LCD) (No Power)	7658
Huawei	G8	3	BHandset (Power Up, Bad LCD) (No Power)	7659
Huawei	H60-L04	6	BHandset (Power Up, Bad LCD) (No Power)	7660
Huawei	HONOR 8X	1	BHandset (Power Up, Bad LCD) (No Power)	7661
Huawei	HRY-LX1	1	BHandset (Power Up, Bad LCD) (No Power)	7662
Huawei	INE-LX1	3	BHandset (Power Up, Bad LCD) (No Power)	7663
Huawei	INE-LX2	8	BHandset (Power Up, Bad LCD) (No Power)	7664
Huawei	JAT-L41	2	BHandset (Power Up, Bad LCD) (No Power)	7665
Huawei	JDN2-W09	1	BHandset (Power Up, Bad LCD) (No Power)	7666
Huawei	JMM-L22	1	BHandset (Power Up, Bad LCD) (No Power)	7667
Huawei	KIW-L21	2	BHandset (Power Up, Bad LCD) (No Power)	7668
Huawei	KOB2-W09	2	BHandset (Power Up, Bad LCD) (No Power)	7669
Huawei	KOB-L09	2	BHandset (Power Up, Bad LCD) (No Power)	7670
Huawei	KOB-W09	1	BHandset (Power Up, Bad LCD) (No Power)	7671
Huawei	KSA-L09	2	BHandset (Power Up, Bad LCD) (No Power)	7672
Huawei	KSA-LX9	4	BHandset (Power Up, Bad LCD) (No Power)	7673
Huawei	LDN-L01	4	BHandset (Power Up, Bad LCD) (No Power)	7674
Huawei	LDN-L21	2	BHandset (Power Up, Bad LCD) (No Power)	7675
Huawei	LDN-LX3	10	BHandset (Power Up, Bad LCD) (No Power)	7676
Huawei	LLD-L31	3	BHandset (Power Up, Bad LCD) (No Power)	7677
Huawei	LND-L29	1	BHandset (Power Up, Bad LCD) (No Power)	7678
Huawei	MED-LX9	4	BHandset (Power Up, Bad LCD) (No Power)	7679
Huawei	MHA-L09	3	BHandset (Power Up, Bad LCD) (No Power)	7680
Huawei	MLA-L01	2	BHandset (Power Up, Bad LCD) (No Power)	7681
Huawei	MRD-LX1	1	BHandset (Power Up, Bad LCD) (No Power)	7682
Huawei	MT1-U06	1	BHandset (Power Up, Bad LCD) (No Power)	7683
Huawei	MT7-L09	3	BHandset (Power Up, Bad LCD) (No Power)	7684
Huawei	MT7-TL10	2	BHandset (Power Up, Bad LCD) (No Power)	7685
Huawei	NEM-L21	2	BHandset (Power Up, Bad LCD) (No Power)	7686
Huawei	NEM-L22	1	BHandset (Power Up, Bad LCD) (No Power)	7687
Huawei	NMO-L22	2	BHandset (Power Up, Bad LCD) (No Power)	7688
Huawei	NMO-L31	1	BHandset (Power Up, Bad LCD) (No Power)	7689
Huawei	NXT-L09	1	BHandset (Power Up, Bad LCD) (No Power)	7690
Huawei	NXT-L29	3	BHandset (Power Up, Bad LCD) (No Power)	7691
Huawei	NXT-TL00	1	BHandset (Power Up, Bad LCD) (No Power)	7692
Huawei	P6	14	BHandset (Power Up, Bad LCD) (No Power)	7693
Huawei	P7	4	BHandset (Power Up, Bad LCD) (No Power)	7694
Huawei	P8	1	BHandset (Power Up, Bad LCD) (No Power)	7695
Huawei	P8 Lite 2017	8	BHandset (Power Up, Bad LCD) (No Power)	7696
Huawei	P9 Lite	3	BHandset (Power Up, Bad LCD) (No Power)	7697
Huawei	P9 Lite MINI	6	BHandset (Power Up, Bad LCD) (No Power)	7698
Huawei	P9 PLUS	2	BHandset (Power Up, Bad LCD) (No Power)	7699
Huawei	PAR-LX1	1	BHandset (Power Up, Bad LCD) (No Power)	7700
Huawei	PAR-LX9	2	BHandset (Power Up, Bad LCD) (No Power)	7701
Huawei	PE-TL10	2	BHandset (Power Up, Bad LCD) (No Power)	7702
Huawei	PLK-L01	2	BHandset (Power Up, Bad LCD) (No Power)	7703
Huawei	POT-LX1	5	BHandset (Power Up, Bad LCD) (No Power)	7704
Huawei	S8-301	3	BHandset (Power Up, Bad LCD) (No Power)	7705
Huawei	SCL-L01	1	BHandset (Power Up, Bad LCD) (No Power)	7706
Huawei	STF-L09	5	BHandset (Power Up, Bad LCD) (No Power)	7707
Huawei	T1-701	1	BHandset (Power Up, Bad LCD) (No Power)	7708
Huawei	T1-821	3	BHandset (Power Up, Bad LCD) (No Power)	7709
Huawei	T1-A21	1	BHandset (Power Up, Bad LCD) (No Power)	7710
Huawei	TAG-AL00	1	BHandset (Power Up, Bad LCD) (No Power)	7711
Huawei	TAG-L01	1	BHandset (Power Up, Bad LCD) (No Power)	7712
Huawei	TAG-L21	1	BHandset (Power Up, Bad LCD) (No Power)	7713
Huawei	TRT-L53	2	BHandset (Power Up, Bad LCD) (No Power)	7714
Huawei	TRT-LX2	4	BHandset (Power Up, Bad LCD) (No Power)	7715
Huawei	U8833	1	BHandset (Power Up, Bad LCD) (No Power)	7716
Huawei	Y330	1	BHandset (Power Up, Bad LCD) (No Power)	7717
Huawei	Y550	5	BHandset (Power Up, Bad LCD) (No Power)	7718
Huawei	Y635	1	BHandset (Power Up, Bad LCD) (No Power)	7719
Lg	D150	1	BHandset (Power Up, Bad LCD) (No Power)	7720
Lg	D290	1	BHandset (Power Up, Bad LCD) (No Power)	7721
Lg	D315	5	BHandset (Power Up, Bad LCD) (No Power)	7722
Lg	D405	1	BHandset (Power Up, Bad LCD) (No Power)	7723
Lg	D415	1	BHandset (Power Up, Bad LCD) (No Power)	7724
Lg	D682	2	BHandset (Power Up, Bad LCD) (No Power)	7725
Lg	D802	7	BHandset (Power Up, Bad LCD) (No Power)	7726
Lg	D805	1	BHandset (Power Up, Bad LCD) (No Power)	7727
Lg	D820	1	BHandset (Power Up, Bad LCD) (No Power)	7728
Lg	D821	31	BHandset (Power Up, Bad LCD) (No Power)	7729
Lg	D855	5	BHandset (Power Up, Bad LCD) (No Power)	7730
Lg	D955	1	BHandset (Power Up, Bad LCD) (No Power)	7731
Lg	E610	2	BHandset (Power Up, Bad LCD) (No Power)	7732
Lg	E960	1	BHandset (Power Up, Bad LCD) (No Power)	7733
Lg	E975	6	BHandset (Power Up, Bad LCD) (No Power)	7734
Lg	F320	1	BHandset (Power Up, Bad LCD) (No Power)	7735
Lg	H340	3	BHandset (Power Up, Bad LCD) (No Power)	7736
Lg	H440	3	BHandset (Power Up, Bad LCD) (No Power)	7737
Lg	H522	1	BHandset (Power Up, Bad LCD) (No Power)	7738

Lg	H525	1	BHandset (Power Up, Bad LCD) (No Power)	7739
Lg	H635	1	BHandset (Power Up, Bad LCD) (No Power)	7740
Lg	H735	1	BHandset (Power Up, Bad LCD) (No Power)	7741
Lg	H791	29	BHandset (Power Up, Bad LCD) (No Power)	7742
Lg	H810	1	BHandset (Power Up, Bad LCD) (No Power)	7743
Lg	H811	2	BHandset (Power Up, Bad LCD) (No Power)	7744
Lg	H815	7	BHandset (Power Up, Bad LCD) (No Power)	7745
Lg	H840	8	BHandset (Power Up, Bad LCD) (No Power)	7746
Lg	H850	4	BHandset (Power Up, Bad LCD) (No Power)	7747
Lg	H870	25	BHandset (Power Up, Bad LCD) (No Power)	7748
Lg	H900	1	BHandset (Power Up, Bad LCD) (No Power)	7749
Lg	H930	4	BHandset (Power Up, Bad LCD) (No Power)	7750
Lg	H960	2	BHandset (Power Up, Bad LCD) (No Power)	7751
Lg	K100	1	BHandset (Power Up, Bad LCD) (No Power)	7752
Lg	K120	1	BHandset (Power Up, Bad LCD) (No Power)	7753
Lg	K130	2	BHandset (Power Up, Bad LCD) (No Power)	7754
Lg	K200	1	BHandset (Power Up, Bad LCD) (No Power)	7755
Lg	K220	6	BHandset (Power Up, Bad LCD) (No Power)	7756
Lg	K300	1	BHandset (Power Up, Bad LCD) (No Power)	7757
Lg	K350	42	BHandset (Power Up, Bad LCD) (No Power)	7758
Lg	K350N	4	BHandset (Power Up, Bad LCD) (No Power)	7759
Lg	K410	2	BHandset (Power Up, Bad LCD) (No Power)	7760
Lg	K420N	11	BHandset (Power Up, Bad LCD) (No Power)	7761
Lg	K430	1	BHandset (Power Up, Bad LCD) (No Power)	7762
Lg	K500	10	BHandset (Power Up, Bad LCD) (No Power)	7763
Lg	K500N	2	BHandset (Power Up, Bad LCD) (No Power)	7764
Lg	K580	12	BHandset (Power Up, Bad LCD) (No Power)	7765
Lg	LMQ610	4	BHandset (Power Up, Bad LCD) (No Power)	7766
Lg	LMQ630	1	BHandset (Power Up, Bad LCD) (No Power)	7767
Lg	LMX410	1	BHandset (Power Up, Bad LCD) (No Power)	7768
Lg	LMX420	2	BHandset (Power Up, Bad LCD) (No Power)	7769
Lg	LMX430	1	BHandset (Power Up, Bad LCD) (No Power)	7770
Lg	LMX525	1	BHandset (Power Up, Bad LCD) (No Power)	7771
Lg	LMX540	2	BHandset (Power Up, Bad LCD) (No Power)	7772
Lg	M160	2	BHandset (Power Up, Bad LCD) (No Power)	7773
Lg	M210	2	BHandset (Power Up, Bad LCD) (No Power)	7774
Lg	M250	1	BHandset (Power Up, Bad LCD) (No Power)	7775
Lg	M320	11	BHandset (Power Up, Bad LCD) (No Power)	7776
Lg	M700	29	BHandset (Power Up, Bad LCD) (No Power)	7777
Lg	MS550	1	BHandset (Power Up, Bad LCD) (No Power)	7778
Lg	P705	1	BHandset (Power Up, Bad LCD) (No Power)	7779
Lg	P768	1	BHandset (Power Up, Bad LCD) (No Power)	7780
Lg	P880	2	BHandset (Power Up, Bad LCD) (No Power)	7781
Lg	Q610	12	BHandset (Power Up, Bad LCD) (No Power)	7782
Lg	Q720	1	BHandset (Power Up, Bad LCD) (No Power)	7783
Lg	Q730	1	BHandset (Power Up, Bad LCD) (No Power)	7784
Lg	V350	1	BHandset (Power Up, Bad LCD) (No Power)	7785
Lg	V400	1	BHandset (Power Up, Bad LCD) (No Power)	7786
Lg	V405	1	BHandset (Power Up, Bad LCD) (No Power)	7787
Lg	V480	1	BHandset (Power Up, Bad LCD) (No Power)	7788
Lg	V495	11	BHandset (Power Up, Bad LCD) (No Power)	7789
Lg	VS986	2	BHandset (Power Up, Bad LCD) (No Power)	7790
Lg	X180	2	BHandset (Power Up, Bad LCD) (No Power)	7791
Lg	X210	1	BHandset (Power Up, Bad LCD) (No Power)	7792
Lg	X220	1	BHandset (Power Up, Bad LCD) (No Power)	7793
Lg	X230	14	BHandset (Power Up, Bad LCD) (No Power)	7794
Lg	X410	4	BHandset (Power Up, Bad LCD) (No Power)	7795
Motorola	MB865	2	BHandset (Power Up, Bad LCD) (No Power)	7796
Motorola	ME865	2	BHandset (Power Up, Bad LCD) (No Power)	7797
Motorola	XT1021	5	BHandset (Power Up, Bad LCD) (No Power)	7798
Motorola	XT1022	3	BHandset (Power Up, Bad LCD) (No Power)	7799
Motorola	XT1032	7	BHandset (Power Up, Bad LCD) (No Power)	7800
Motorola	XT1033	5	BHandset (Power Up, Bad LCD) (No Power)	7801
Motorola	XT1039	6	BHandset (Power Up, Bad LCD) (No Power)	7802
Motorola	XT1053	1	BHandset (Power Up, Bad LCD) (No Power)	7803
Motorola	XT1064	1	BHandset (Power Up, Bad LCD) (No Power)	7804
Motorola	XT1068	6	BHandset (Power Up, Bad LCD) (No Power)	7805
Motorola	XT1069	1	BHandset (Power Up, Bad LCD) (No Power)	7806
Motorola	XT1072	8	BHandset (Power Up, Bad LCD) (No Power)	7807
Motorola	XT1097	1	BHandset (Power Up, Bad LCD) (No Power)	7808
Motorola	XT1100	2	BHandset (Power Up, Bad LCD) (No Power)	7809
Motorola	XT1524	2	BHandset (Power Up, Bad LCD) (No Power)	7810
Motorola	XT1526	9	BHandset (Power Up, Bad LCD) (No Power)	7811
Motorola	XT1527	2	BHandset (Power Up, Bad LCD) (No Power)	7812
Motorola	XT1528	2	BHandset (Power Up, Bad LCD) (No Power)	7813
Motorola	XT1541	18	BHandset (Power Up, Bad LCD) (No Power)	7814
Motorola	XT1542	1	BHandset (Power Up, Bad LCD) (No Power)	7815
Motorola	XT1562	7	BHandset (Power Up, Bad LCD) (No Power)	7816
Motorola	XT1572	2	BHandset (Power Up, Bad LCD) (No Power)	7817
Motorola	XT1575	1	BHandset (Power Up, Bad LCD) (No Power)	7818
Motorola	XT1585	1	BHandset (Power Up, Bad LCD) (No Power)	7819
Motorola	XT1604	2	BHandset (Power Up, Bad LCD) (No Power)	7820
Motorola	XT1621	17	BHandset (Power Up, Bad LCD) (No Power)	7821
Motorola	XT1622	11	BHandset (Power Up, Bad LCD) (No Power)	7822
Motorola	XT1625	1	BHandset (Power Up, Bad LCD) (No Power)	7823
Motorola	XT1635	63	BHandset (Power Up, Bad LCD) (No Power)	7824

Motorola	XT1641	3	BHandset (Power Up, Bad LCD) (No Power)	7825
Motorola	XT1642	7	BHandset (Power Up, Bad LCD) (No Power)	7826
Motorola	XT1643	1	BHandset (Power Up, Bad LCD) (No Power)	7827
Motorola	XT1650	23	BHandset (Power Up, Bad LCD) (No Power)	7828
Motorola	XT1675	9	BHandset (Power Up, Bad LCD) (No Power)	7829
Motorola	XT1676	22	BHandset (Power Up, Bad LCD) (No Power)	7830
Motorola	XT1680	8	BHandset (Power Up, Bad LCD) (No Power)	7831
Motorola	XT1685	7	BHandset (Power Up, Bad LCD) (No Power)	7832
Motorola	XT1700	9	BHandset (Power Up, Bad LCD) (No Power)	7833
Motorola	XT1710	8	BHandset (Power Up, Bad LCD) (No Power)	7834
Motorola	XT1721	1	BHandset (Power Up, Bad LCD) (No Power)	7835
Motorola	XT1723	2	BHandset (Power Up, Bad LCD) (No Power)	7836
Motorola	XT1725	3	BHandset (Power Up, Bad LCD) (No Power)	7837
Motorola	XT1750	2	BHandset (Power Up, Bad LCD) (No Power)	7838
Motorola	XT1754	3	BHandset (Power Up, Bad LCD) (No Power)	7839
Motorola	XT1758	2	BHandset (Power Up, Bad LCD) (No Power)	7840
Motorola	XT1761	6	BHandset (Power Up, Bad LCD) (No Power)	7841
Motorola	XT1762	1	BHandset (Power Up, Bad LCD) (No Power)	7842
Motorola	XT1763	1	BHandset (Power Up, Bad LCD) (No Power)	7843
Motorola	XT1764	1	BHandset (Power Up, Bad LCD) (No Power)	7844
Motorola	XT1766	1	BHandset (Power Up, Bad LCD) (No Power)	7845
Motorola	XT1771	14	BHandset (Power Up, Bad LCD) (No Power)	7846
Motorola	XT1772	16	BHandset (Power Up, Bad LCD) (No Power)	7847
Motorola	XT1789	2	BHandset (Power Up, Bad LCD) (No Power)	7848
Motorola	XT1790	4	BHandset (Power Up, Bad LCD) (No Power)	7849
Motorola	XT1793	3	BHandset (Power Up, Bad LCD) (No Power)	7850
Motorola	XT1797	1	BHandset (Power Up, Bad LCD) (No Power)	7851
Motorola	XT1803	1	BHandset (Power Up, Bad LCD) (No Power)	7852
Motorola	XT1805	3	BHandset (Power Up, Bad LCD) (No Power)	7853
Motorola	XT1900	6	BHandset (Power Up, Bad LCD) (No Power)	7854
Motorola	XT1920	9	BHandset (Power Up, Bad LCD) (No Power)	7855
Motorola	XT1921	2	BHandset (Power Up, Bad LCD) (No Power)	7856
Motorola	XT1924	1	BHandset (Power Up, Bad LCD) (No Power)	7857
Motorola	XT1926	4	BHandset (Power Up, Bad LCD) (No Power)	7858
Motorola	XT1929	6	BHandset (Power Up, Bad LCD) (No Power)	7859
Motorola	XT1941	29	BHandset (Power Up, Bad LCD) (No Power)	7860
Motorola	XT1944	3	BHandset (Power Up, Bad LCD) (No Power)	7861
Motorola	XT1952	10	BHandset (Power Up, Bad LCD) (No Power)	7862
Motorola	XT1955	1	BHandset (Power Up, Bad LCD) (No Power)	7863
Motorola	XT1965	1	BHandset (Power Up, Bad LCD) (No Power)	7864
Motorola	XT1970	5	BHandset (Power Up, Bad LCD) (No Power)	7865
Motorola	XT1980	4	BHandset (Power Up, Bad LCD) (No Power)	7866
Motorola	XT2025	68	BHandset (Power Up, Bad LCD) (No Power)	7867
Motorola	XT535	2	BHandset (Power Up, Bad LCD) (No Power)	7868
Nokia	110	6	BHandset (Power Up, Bad LCD) (No Power)	7869
Nokia	206	1	BHandset (Power Up, Bad LCD) (No Power)	7870
Nokia	435	2	BHandset (Power Up, Bad LCD) (No Power)	7871
Nokia	520	5	BHandset (Power Up, Bad LCD) (No Power)	7872
Nokia	535	1	BHandset (Power Up, Bad LCD) (No Power)	7873
Nokia	550	1	BHandset (Power Up, Bad LCD) (No Power)	7874
Nokia	625	4	BHandset (Power Up, Bad LCD) (No Power)	7875
Nokia	630	1	BHandset (Power Up, Bad LCD) (No Power)	7876
Nokia	635	3	BHandset (Power Up, Bad LCD) (No Power)	7877
Nokia	640	9	BHandset (Power Up, Bad LCD) (No Power)	7878
Nokia	650	5	BHandset (Power Up, Bad LCD) (No Power)	7879
Nokia	710	2	BHandset (Power Up, Bad LCD) (No Power)	7880
Nokia	720	1	BHandset (Power Up, Bad LCD) (No Power)	7881
Nokia	735	6	BHandset (Power Up, Bad LCD) (No Power)	7882
Nokia	900	1	BHandset (Power Up, Bad LCD) (No Power)	7883
Nokia	920	18	BHandset (Power Up, Bad LCD) (No Power)	7884
Nokia	950	1	BHandset (Power Up, Bad LCD) (No Power)	7885
Nokia	1320	2	BHandset (Power Up, Bad LCD) (No Power)	7886
Nokia	105(2019)	4	BHandset (Power Up, Bad LCD) (No Power)	7887
Nokia	110(2019)	1	BHandset (Power Up, Bad LCD) (No Power)	7888
Nokia	2720 Flip	1	BHandset (Power Up, Bad LCD) (No Power)	7889
Nokia	3310(2017)	1	BHandset (Power Up, Bad LCD) (No Power)	7890
Nokia	640XL	4	BHandset (Power Up, Bad LCD) (No Power)	7891
Nokia	6500C	1	BHandset (Power Up, Bad LCD) (No Power)	7892
Nokia	1	2	BHandset (Power Up, Bad LCD) (No Power)	7893
Nokia	1 Plus	17	BHandset (Power Up, Bad LCD) (No Power)	7894
Nokia	1.3	1	BHandset (Power Up, Bad LCD) (No Power)	7895
Nokia	1.4	7	BHandset (Power Up, Bad LCD) (No Power)	7896
Nokia	2	6	BHandset (Power Up, Bad LCD) (No Power)	7897
Nokia	2.1	11	BHandset (Power Up, Bad LCD) (No Power)	7898
Nokia	2.2	14	BHandset (Power Up, Bad LCD) (No Power)	7899
Nokia	2.3	18	BHandset (Power Up, Bad LCD) (No Power)	7900
Nokia	2.4	3	BHandset (Power Up, Bad LCD) (No Power)	7901
Nokia	3	1	BHandset (Power Up, Bad LCD) (No Power)	7902
Nokia	C01 Plus	1	BHandset (Power Up, Bad LCD) (No Power)	7903
Nokia	C02	1	BHandset (Power Up, Bad LCD) (No Power)	7904
Nokia	C1	1	BHandset (Power Up, Bad LCD) (No Power)	7905
Nokia	C1 Plus	3	BHandset (Power Up, Bad LCD) (No Power)	7906
Nokia	C110	2	BHandset (Power Up, Bad LCD) (No Power)	7907
Nokia	C12	1	BHandset (Power Up, Bad LCD) (No Power)	7908
Nokia	C20	1	BHandset (Power Up, Bad LCD) (No Power)	7909
Nokia	C200	1	BHandset (Power Up, Bad LCD) (No Power)	7910

Nokia	C21 Plus	3	BHandset (Power Up, Bad LCD) (No Power)	7911
Nokia	C2-2E	2	BHandset (Power Up, Bad LCD) (No Power)	7912
Nokia	C32	2	BHandset (Power Up, Bad LCD) (No Power)	7913
Nokia	G100	1	BHandset (Power Up, Bad LCD) (No Power)	7914
Nokia	T10	2	BHandset (Power Up, Bad LCD) (No Power)	7915
Nokia	T20	2	BHandset (Power Up, Bad LCD) (No Power)	7916
Other	Altice S31	10	BHandset (Power Up, Bad LCD) (No Power)	7917
Other	Amazon Fire HD 10(2021)	2	BHandset (Power Up, Bad LCD) (No Power)	7918
Other	Amazon Fire HD 8(2020)	1	BHandset (Power Up, Bad LCD) (No Power)	7919
Other	Amazon Firephone	4	BHandset (Power Up, Bad LCD) (No Power)	7920
Other	Amazon Kindle Fire 7	75	BHandset (Power Up, Bad LCD) (No Power)	7921
Other	Blackview A30	1	BHandset (Power Up, Bad LCD) (No Power)	7922
Other	Blaupunkt Sf01	26	BHandset (Power Up, Bad LCD) (No Power)	7923
Other	Cat B35	3	BHandset (Power Up, Bad LCD) (No Power)	7924
Other	Cat S41	4	BHandset (Power Up, Bad LCD) (No Power)	7925
Other	Cat S52	1	BHandset (Power Up, Bad LCD) (No Power)	7926
Other	Cat S60	5	BHandset (Power Up, Bad LCD) (No Power)	7927
Other	Doro 1370	5	BHandset (Power Up, Bad LCD) (No Power)	7928
Other	Doro 6520	3	BHandset (Power Up, Bad LCD) (No Power)	7929
Other	Doro 6620	1	BHandset (Power Up, Bad LCD) (No Power)	7930
Other	Doro 7030	40	BHandset (Power Up, Bad LCD) (No Power)	7931
Other	Doro 7060	3	BHandset (Power Up, Bad LCD) (No Power)	7932
Other	Doro 8030	4	BHandset (Power Up, Bad LCD) (No Power)	7933
Other	Doro 8035	6	BHandset (Power Up, Bad LCD) (No Power)	7934
Other	Doro 8050	3	BHandset (Power Up, Bad LCD) (No Power)	7935
Other	Doro PE631	1	BHandset (Power Up, Bad LCD) (No Power)	7936
Other	Fairphone 3	1	BHandset (Power Up, Bad LCD) (No Power)	7937
Other	Google G-2PW2100	1	BHandset (Power Up, Bad LCD) (No Power)	7938
Other	Google G-2PW2200	2	BHandset (Power Up, Bad LCD) (No Power)	7939
Other	Google G-2PW4100	2	BHandset (Power Up, Bad LCD) (No Power)	7940
Other	Google G-2PW4200	3	BHandset (Power Up, Bad LCD) (No Power)	7941
Other	Harrier Mini	1	BHandset (Power Up, Bad LCD) (No Power)	7942
Other	Harrier TAB	3	BHandset (Power Up, Bad LCD) (No Power)	7943
Other	Imo Q2 Pro	15	BHandset (Power Up, Bad LCD) (No Power)	7944
Other	Land Rover Explore	2	BHandset (Power Up, Bad LCD) (No Power)	7945
Other	Lenovo A616	1	BHandset (Power Up, Bad LCD) (No Power)	7946
Other	Lenovo Ct-X636F	1	BHandset (Power Up, Bad LCD) (No Power)	7947
Other	Lenovo TAB 2 X30	1	BHandset (Power Up, Bad LCD) (No Power)	7948
Other	Lenovo TAB S8-50F	1	BHandset (Power Up, Bad LCD) (No Power)	7949
Other	Lenovo Tb128Xu	11	BHandset (Power Up, Bad LCD) (No Power)	7950
Other	Lenovo Tb301Xu	12	BHandset (Power Up, Bad LCD) (No Power)	7951
Other	Lenovo Tb-7306	1	BHandset (Power Up, Bad LCD) (No Power)	7952
Other	Lenovo Tb-8505	6	BHandset (Power Up, Bad LCD) (No Power)	7953
Other	Lenovo Tb-X104F	1	BHandset (Power Up, Bad LCD) (No Power)	7954
Other	Lenovo Tb-X605	8	BHandset (Power Up, Bad LCD) (No Power)	7955
Other	Lenovo Tb-X605F	3	BHandset (Power Up, Bad LCD) (No Power)	7956
Other	Lenovo Tb-X704	1	BHandset (Power Up, Bad LCD) (No Power)	7957
Other	Lenovo YT-J706	3	BHandset (Power Up, Bad LCD) (No Power)	7958
Other	Lenovo YT-X703F	1	BHandset (Power Up, Bad LCD) (No Power)	7959
Other	Lenovo YT-X705F	1	BHandset (Power Up, Bad LCD) (No Power)	7960
Other	Navon T400	1	BHandset (Power Up, Bad LCD) (No Power)	7961
Other	Oppo A12	6	BHandset (Power Up, Bad LCD) (No Power)	7962
Other	Oppo A31	7	BHandset (Power Up, Bad LCD) (No Power)	7963
Other	Oppo A37	1	BHandset (Power Up, Bad LCD) (No Power)	7964
Other	Oppo A3S	3	BHandset (Power Up, Bad LCD) (No Power)	7965
Other	Oppo A5s	1	BHandset (Power Up, Bad LCD) (No Power)	7966
Other	Oppo A7	2	BHandset (Power Up, Bad LCD) (No Power)	7967
Other	Oppo A77(2017)	2	BHandset (Power Up, Bad LCD) (No Power)	7968
Other	Oppo Ax5	2	BHandset (Power Up, Bad LCD) (No Power)	7969
Other	Oppo F9 Pro	3	BHandset (Power Up, Bad LCD) (No Power)	7970
Other	Oppo R11	1	BHandset (Power Up, Bad LCD) (No Power)	7971
Other	Oppo F1026	3	BHandset (Power Up, Bad LCD) (No Power)	7972
Other	Oppo Fun 5	1	BHandset (Power Up, Bad LCD) (No Power)	7973
Other	Oppo Fun 6	2	BHandset (Power Up, Bad LCD) (No Power)	7974
Other	Oppo S1	14	BHandset (Power Up, Bad LCD) (No Power)	7975
Other	Tcl 205	7	BHandset (Power Up, Bad LCD) (No Power)	7976
Other	Tcl 305	5	BHandset (Power Up, Bad LCD) (No Power)	7977
Other	Tcl 306	7	BHandset (Power Up, Bad LCD) (No Power)	7978
Other	Tcl 406	1	BHandset (Power Up, Bad LCD) (No Power)	7979
Other	Tcl 501	1	BHandset (Power Up, Bad LCD) (No Power)	7980
Other	Tcl T431	3	BHandset (Power Up, Bad LCD) (No Power)	7981
Other	Tcl TAB 10 4G	2	BHandset (Power Up, Bad LCD) (No Power)	7982
Other	Tcl Tkee Mid 2	1	BHandset (Power Up, Bad LCD) (No Power)	7983
Other	Vivo V12	1	BHandset (Power Up, Bad LCD) (No Power)	7984
Other	Vivo Y12S	1	BHandset (Power Up, Bad LCD) (No Power)	7985
Other	Vivo Y9S	1	BHandset (Power Up, Bad LCD) (No Power)	7986
Other	Xiaomi Mi 4	1	BHandset (Power Up, Bad LCD) (No Power)	7987
Other	Xiaomi Mi 5s Plus	1	BHandset (Power Up, Bad LCD) (No Power)	7988
Other	Xiaomi Mi 6	3	BHandset (Power Up, Bad LCD) (No Power)	7989
Other	Xiaomi Mi A2 Lite	3	BHandset (Power Up, Bad LCD) (No Power)	7990
Other	Xiaomi Mi A3	9	BHandset (Power Up, Bad LCD) (No Power)	7991
Other	Xiaomi Mi Mix	2	BHandset (Power Up, Bad LCD) (No Power)	7992
Other	Xiaomi Mi Mix 2	1	BHandset (Power Up, Bad LCD) (No Power)	7993
Other	Xiaomi Mi Mix 2S	1	BHandset (Power Up, Bad LCD) (No Power)	7994
Other	Xiaomi Mi Mix 3	7	BHandset (Power Up, Bad LCD) (No Power)	7995
Other	Xiaomi Redmi 3S	3	BHandset (Power Up, Bad LCD) (No Power)	7996

Other	Xiaomi Redmi 4	2	BHandset (Power Up, Bad LCD) (No Power)	7997
Other	Xiaomi Redmi 4A	3	BHandset (Power Up, Bad LCD) (No Power)	7998
Other	Xiaomi Redmi 4X	3	BHandset (Power Up, Bad LCD) (No Power)	7999
Other	Xiaomi Redmi 6	2	BHandset (Power Up, Bad LCD) (No Power)	8000
Other	Xiaomi Redmi 6A	3	BHandset (Power Up, Bad LCD) (No Power)	8001
Other	Xiaomi Redmi 7	2	BHandset (Power Up, Bad LCD) (No Power)	8002
Other	Xiaomi Redmi 7A	2	BHandset (Power Up, Bad LCD) (No Power)	8003
Other	Xiaomi Redmi Note 3	2	BHandset (Power Up, Bad LCD) (No Power)	8004
Other	Xiaomi Redmi S2	1	BHandset (Power Up, Bad LCD) (No Power)	8005
Other	Mixed Tablets	9	BHandset (Power Up, Bad LCD) (No Power)	8006
Other	雜電子書	1	BHandset (Power Up, Bad LCD) (No Power)	8007
Samsung	A300	1	BHandset (Power Up, Bad LCD) (No Power)	8008
Samsung	A300F	18	BHandset (Power Up, Bad LCD) (No Power)	8009
Samsung	A310	12	BHandset (Power Up, Bad LCD) (No Power)	8010
Samsung	A310 (Demo)	6	BHandset (Power Up, Bad LCD) (No Power)	8011
Samsung	A320	5	BHandset (Power Up, Bad LCD) (No Power)	8012
Samsung	A320 (Demo)	1	BHandset (Power Up, Bad LCD) (No Power)	8013
Samsung	A320F	2	BHandset (Power Up, Bad LCD) (No Power)	8014
Samsung	B550	2	BHandset (Power Up, Bad LCD) (No Power)	8015
Samsung	E1190	1	BHandset (Power Up, Bad LCD) (No Power)	8016
Samsung	E500	2	BHandset (Power Up, Bad LCD) (No Power)	8017
Samsung	E700	1	BHandset (Power Up, Bad LCD) (No Power)	8018
Samsung	G130	1	BHandset (Power Up, Bad LCD) (No Power)	8019
Samsung	G316	2	BHandset (Power Up, Bad LCD) (No Power)	8020
Samsung	G357	1	BHandset (Power Up, Bad LCD) (No Power)	8021
Samsung	G357F	8	BHandset (Power Up, Bad LCD) (No Power)	8022
Samsung	G360F	3	BHandset (Power Up, Bad LCD) (No Power)	8023
Samsung	G361F	5	BHandset (Power Up, Bad LCD) (No Power)	8024
Samsung	G3812	1	BHandset (Power Up, Bad LCD) (No Power)	8025
Samsung	G3815	1	BHandset (Power Up, Bad LCD) (No Power)	8026
Samsung	G386	2	BHandset (Power Up, Bad LCD) (No Power)	8027
Samsung	G388F	7	BHandset (Power Up, Bad LCD) (No Power)	8028
Samsung	G389F	4	BHandset (Power Up, Bad LCD) (No Power)	8029
Samsung	G390	5	BHandset (Power Up, Bad LCD) (No Power)	8030
Samsung	G390F	66	BHandset (Power Up, Bad LCD) (No Power)	8031
Samsung	G398F	75	BHandset (Power Up, Bad LCD) (No Power)	8032
Samsung	G525F	1	BHandset (Power Up, Bad LCD) (No Power)	8033
Samsung	G530	2	BHandset (Power Up, Bad LCD) (No Power)	8034
Samsung	G530F	6	BHandset (Power Up, Bad LCD) (No Power)	8035
Samsung	G531	1	BHandset (Power Up, Bad LCD) (No Power)	8036
Samsung	G531F	2	BHandset (Power Up, Bad LCD) (No Power)	8037
Samsung	G532	7	BHandset (Power Up, Bad LCD) (No Power)	8038
Samsung	G532F	5	BHandset (Power Up, Bad LCD) (No Power)	8039
Samsung	G550	2	BHandset (Power Up, Bad LCD) (No Power)	8040
Samsung	G570	26	BHandset (Power Up, Bad LCD) (No Power)	8041
Samsung	G570F	3	BHandset (Power Up, Bad LCD) (No Power)	8042
Samsung	G575	1	BHandset (Power Up, Bad LCD) (No Power)	8043
Samsung	G610	8	BHandset (Power Up, Bad LCD) (No Power)	8044
Samsung	G610F	1	BHandset (Power Up, Bad LCD) (No Power)	8045
Samsung	G611F	2	BHandset (Power Up, Bad LCD) (No Power)	8046
Samsung	G7508	1	BHandset (Power Up, Bad LCD) (No Power)	8047
Samsung	G800F	73	BHandset (Power Up, Bad LCD) (No Power)	8048
Samsung	G850F	2	BHandset (Power Up, Bad LCD) (No Power)	8049
Samsung	G890	1	BHandset (Power Up, Bad LCD) (No Power)	8050
Samsung	G891	1	BHandset (Power Up, Bad LCD) (No Power)	8051
Samsung	G900	2	BHandset (Power Up, Bad LCD) (No Power)	8052
Samsung	G900F	12	BHandset (Power Up, Bad LCD) (No Power)	8053
Samsung	G901F	4	BHandset (Power Up, Bad LCD) (No Power)	8054
Samsung	G903F	6	BHandset (Power Up, Bad LCD) (No Power)	8055
Samsung	G920F	12	BHandset (Power Up, Bad LCD) (No Power)	8056
Samsung	G925F	1	BHandset (Power Up, Bad LCD) (No Power)	8057
Samsung	i257	1	BHandset (Power Up, Bad LCD) (No Power)	8058
Samsung	i337	9	BHandset (Power Up, Bad LCD) (No Power)	8059
Samsung	i545	1	BHandset (Power Up, Bad LCD) (No Power)	8060
Samsung	i5500	1	BHandset (Power Up, Bad LCD) (No Power)	8061
Samsung	i5800	1	BHandset (Power Up, Bad LCD) (No Power)	8062
Samsung	i705	2	BHandset (Power Up, Bad LCD) (No Power)	8063
Samsung	i747	15	BHandset (Power Up, Bad LCD) (No Power)	8064
Samsung	i8160	2	BHandset (Power Up, Bad LCD) (No Power)	8065
Samsung	i8190	10	BHandset (Power Up, Bad LCD) (No Power)	8066
Samsung	i8200	2	BHandset (Power Up, Bad LCD) (No Power)	8067
Samsung	i8260	2	BHandset (Power Up, Bad LCD) (No Power)	8068
Samsung	i8552	2	BHandset (Power Up, Bad LCD) (No Power)	8069
Samsung	i9000	2	BHandset (Power Up, Bad LCD) (No Power)	8070
Samsung	i9060	4	BHandset (Power Up, Bad LCD) (No Power)	8071
Samsung	i9070	1	BHandset (Power Up, Bad LCD) (No Power)	8072
Samsung	i9082	6	BHandset (Power Up, Bad LCD) (No Power)	8073
Samsung	i9100	28	BHandset (Power Up, Bad LCD) (No Power)	8074
Samsung	i9105	82	BHandset (Power Up, Bad LCD) (No Power)	8075
Samsung	i9152	1	BHandset (Power Up, Bad LCD) (No Power)	8076
Samsung	i9190	1	BHandset (Power Up, Bad LCD) (No Power)	8077
Samsung	i9195	16	BHandset (Power Up, Bad LCD) (No Power)	8078
Samsung	i9200	1	BHandset (Power Up, Bad LCD) (No Power)	8079
Samsung	i9205	6	BHandset (Power Up, Bad LCD) (No Power)	8080
Samsung	i9295	1	BHandset (Power Up, Bad LCD) (No Power)	8081
Samsung	i9300	463	BHandset (Power Up, Bad LCD) (No Power)	8082

Samsung	i9301	159	BHandset (Power Up, Bad LCD) (No Power)	8083
Samsung	i9305	6	BHandset (Power Up, Bad LCD) (No Power)	8084
Samsung	i9505	166	BHandset (Power Up, Bad LCD) (No Power)	8085
Samsung	i9506	87	BHandset (Power Up, Bad LCD) (No Power)	8086
Samsung	i9515	33	BHandset (Power Up, Bad LCD) (No Power)	8087
Samsung	J100	8	BHandset (Power Up, Bad LCD) (No Power)	8088
Samsung	J105	1	BHandset (Power Up, Bad LCD) (No Power)	8089
Samsung	J110	111	BHandset (Power Up, Bad LCD) (No Power)	8090
Samsung	J110F	2	BHandset (Power Up, Bad LCD) (No Power)	8091
Samsung	J111	3	BHandset (Power Up, Bad LCD) (No Power)	8092
Samsung	J120	67	BHandset (Power Up, Bad LCD) (No Power)	8093
Samsung	J120F	5	BHandset (Power Up, Bad LCD) (No Power)	8094
Samsung	J200	1	BHandset (Power Up, Bad LCD) (No Power)	8095
Samsung	J250	35	BHandset (Power Up, Bad LCD) (No Power)	8096
Samsung	J250F	2	BHandset (Power Up, Bad LCD) (No Power)	8097
Samsung	J260	2	BHandset (Power Up, Bad LCD) (No Power)	8098
Samsung	J260F	2	BHandset (Power Up, Bad LCD) (No Power)	8099
Samsung	J3110	1	BHandset (Power Up, Bad LCD) (No Power)	8100
Samsung	J320	32	BHandset (Power Up, Bad LCD) (No Power)	8101
Samsung	J320F	195	BHandset (Power Up, Bad LCD) (No Power)	8102
Samsung	J330	4	BHandset (Power Up, Bad LCD) (No Power)	8103
Samsung	J330F	60	BHandset (Power Up, Bad LCD) (No Power)	8104
Samsung	J337	1	BHandset (Power Up, Bad LCD) (No Power)	8105
Samsung	J400	95	BHandset (Power Up, Bad LCD) (No Power)	8106
Samsung	J400F	1	BHandset (Power Up, Bad LCD) (No Power)	8107
Samsung	J415F	3	BHandset (Power Up, Bad LCD) (No Power)	8108
Samsung	J500	198	BHandset (Power Up, Bad LCD) (No Power)	8109
Samsung	J500F	51	BHandset (Power Up, Bad LCD) (No Power)	8110
Samsung	J510	52	BHandset (Power Up, Bad LCD) (No Power)	8111
Samsung	J510F	9	BHandset (Power Up, Bad LCD) (No Power)	8112
Samsung	J530F	1	BHandset (Power Up, Bad LCD) (No Power)	8113
Samsung	J600F	4	BHandset (Power Up, Bad LCD) (No Power)	8114
Samsung	J610F	2	BHandset (Power Up, Bad LCD) (No Power)	8115
Samsung	J700	4	BHandset (Power Up, Bad LCD) (No Power)	8116
Samsung	J700F	2	BHandset (Power Up, Bad LCD) (No Power)	8117
Samsung	J701	22	BHandset (Power Up, Bad LCD) (No Power)	8118
Samsung	J701F	4	BHandset (Power Up, Bad LCD) (No Power)	8119
Samsung	J710	19	BHandset (Power Up, Bad LCD) (No Power)	8120
Samsung	J710F	1	BHandset (Power Up, Bad LCD) (No Power)	8121
Samsung	J737	4	BHandset (Power Up, Bad LCD) (No Power)	8122
Samsung	J810F	1	BHandset (Power Up, Bad LCD) (No Power)	8123
Samsung	L720	1	BHandset (Power Up, Bad LCD) (No Power)	8124
Samsung	M919	2	BHandset (Power Up, Bad LCD) (No Power)	8125
Samsung	N5100	1	BHandset (Power Up, Bad LCD) (No Power)	8126
Samsung	N5110	3	BHandset (Power Up, Bad LCD) (No Power)	8127
Samsung	N5120	1	BHandset (Power Up, Bad LCD) (No Power)	8128
Samsung	N7000	5	BHandset (Power Up, Bad LCD) (No Power)	8129
Samsung	N7100	5	BHandset (Power Up, Bad LCD) (No Power)	8130
Samsung	N7105	4	BHandset (Power Up, Bad LCD) (No Power)	8131
Samsung	N8010	13	BHandset (Power Up, Bad LCD) (No Power)	8132
Samsung	N8020	1	BHandset (Power Up, Bad LCD) (No Power)	8133
Samsung	N900	6	BHandset (Power Up, Bad LCD) (No Power)	8134
Samsung	N9005	4	BHandset (Power Up, Bad LCD) (No Power)	8135
Samsung	N910	3	BHandset (Power Up, Bad LCD) (No Power)	8136
Samsung	N910F	8	BHandset (Power Up, Bad LCD) (No Power)	8137
Samsung	N915	1	BHandset (Power Up, Bad LCD) (No Power)	8138
Samsung	N920	1	BHandset (Power Up, Bad LCD) (No Power)	8139
Samsung	N9208	1	BHandset (Power Up, Bad LCD) (No Power)	8140
Samsung	N920F	1	BHandset (Power Up, Bad LCD) (No Power)	8141
Samsung	P1000	2	BHandset (Power Up, Bad LCD) (No Power)	8142
Samsung	P205	1	BHandset (Power Up, Bad LCD) (No Power)	8143
Samsung	P3100	1	BHandset (Power Up, Bad LCD) (No Power)	8144
Samsung	P3110	9	BHandset (Power Up, Bad LCD) (No Power)	8145
Samsung	P3113	11	BHandset (Power Up, Bad LCD) (No Power)	8146
Samsung	P5100	4	BHandset (Power Up, Bad LCD) (No Power)	8147
Samsung	P5110	3	BHandset (Power Up, Bad LCD) (No Power)	8148
Samsung	P5113	4	BHandset (Power Up, Bad LCD) (No Power)	8149
Samsung	P5210	7	BHandset (Power Up, Bad LCD) (No Power)	8150
Samsung	P5220	3	BHandset (Power Up, Bad LCD) (No Power)	8151
Samsung	P550	2	BHandset (Power Up, Bad LCD) (No Power)	8152
Samsung	P580	2	BHandset (Power Up, Bad LCD) (No Power)	8153
Samsung	P600	3	BHandset (Power Up, Bad LCD) (No Power)	8154
Samsung	P605	1	BHandset (Power Up, Bad LCD) (No Power)	8155
Samsung	P6800	1	BHandset (Power Up, Bad LCD) (No Power)	8156
Samsung	P7300	1	BHandset (Power Up, Bad LCD) (No Power)	8157
Samsung	P7310	2	BHandset (Power Up, Bad LCD) (No Power)	8158
Samsung	P7500	4	BHandset (Power Up, Bad LCD) (No Power)	8159
Samsung	P7510	4	BHandset (Power Up, Bad LCD) (No Power)	8160
Samsung	P8110	4	BHandset (Power Up, Bad LCD) (No Power)	8161
Samsung	S134	3	BHandset (Power Up, Bad LCD) (No Power)	8162
Samsung	S260	27	BHandset (Power Up, Bad LCD) (No Power)	8163
Samsung	S357	1	BHandset (Power Up, Bad LCD) (No Power)	8164
Samsung	S5310	1	BHandset (Power Up, Bad LCD) (No Power)	8165
Samsung	S5830	5	BHandset (Power Up, Bad LCD) (No Power)	8166
Samsung	S5839	1	BHandset (Power Up, Bad LCD) (No Power)	8167
Samsung	S6802	1	BHandset (Power Up, Bad LCD) (No Power)	8168

Samsung	S7275	1	BHandset (Power Up, Bad LCD) (No Power)	8169
Samsung	S737	2	BHandset (Power Up, Bad LCD) (No Power)	8170
Samsung	S7580	1	BHandset (Power Up, Bad LCD) (No Power)	8171
Samsung	S7710	1	BHandset (Power Up, Bad LCD) (No Power)	8172
Samsung	S968	2	BHandset (Power Up, Bad LCD) (No Power)	8173
Samsung	T110	5	BHandset (Power Up, Bad LCD) (No Power)	8174
Samsung	T113	4	BHandset (Power Up, Bad LCD) (No Power)	8175
Samsung	T210	16	BHandset (Power Up, Bad LCD) (No Power)	8176
Samsung	T2105	1	BHandset (Power Up, Bad LCD) (No Power)	8177
Samsung	T211	1	BHandset (Power Up, Bad LCD) (No Power)	8178
Samsung	T217	2	BHandset (Power Up, Bad LCD) (No Power)	8179
Samsung	T220	9	BHandset (Power Up, Bad LCD) (No Power)	8180
Samsung	T225	28	BHandset (Power Up, Bad LCD) (No Power)	8181
Samsung	T230	3	BHandset (Power Up, Bad LCD) (No Power)	8182
Samsung	T231	1	BHandset (Power Up, Bad LCD) (No Power)	8183
Samsung	T280	11	BHandset (Power Up, Bad LCD) (No Power)	8184
Samsung	T285	1	BHandset (Power Up, Bad LCD) (No Power)	8185
Samsung	T290	2	BHandset (Power Up, Bad LCD) (No Power)	8186
Samsung	T295	1	BHandset (Power Up, Bad LCD) (No Power)	8187
Samsung	T300	1	BHandset (Power Up, Bad LCD) (No Power)	8188
Samsung	T307	30	BHandset (Power Up, Bad LCD) (No Power)	8189
Samsung	T310	11	BHandset (Power Up, Bad LCD) (No Power)	8190
Samsung	T315	3	BHandset (Power Up, Bad LCD) (No Power)	8191
Samsung	T330	3	BHandset (Power Up, Bad LCD) (No Power)	8192
Samsung	T335	2	BHandset (Power Up, Bad LCD) (No Power)	8193
Samsung	T350	1	BHandset (Power Up, Bad LCD) (No Power)	8194
Samsung	T365	6	BHandset (Power Up, Bad LCD) (No Power)	8195
Samsung	T377	5	BHandset (Power Up, Bad LCD) (No Power)	8196
Samsung	T378	2	BHandset (Power Up, Bad LCD) (No Power)	8197
Samsung	T380	3	BHandset (Power Up, Bad LCD) (No Power)	8198
Samsung	T385	2	BHandset (Power Up, Bad LCD) (No Power)	8199
Samsung	T387	10	BHandset (Power Up, Bad LCD) (No Power)	8200
Samsung	T390	1	BHandset (Power Up, Bad LCD) (No Power)	8201
Samsung	T500	1	BHandset (Power Up, Bad LCD) (No Power)	8202
Samsung	T520	5	BHandset (Power Up, Bad LCD) (No Power)	8203
Samsung	T530	7	BHandset (Power Up, Bad LCD) (No Power)	8204
Samsung	T533	1	BHandset (Power Up, Bad LCD) (No Power)	8205
Samsung	T535	2	BHandset (Power Up, Bad LCD) (No Power)	8206
Samsung	T537	1	BHandset (Power Up, Bad LCD) (No Power)	8207
Samsung	T550	12	BHandset (Power Up, Bad LCD) (No Power)	8208
Samsung	T555	1	BHandset (Power Up, Bad LCD) (No Power)	8209
Samsung	T560	6	BHandset (Power Up, Bad LCD) (No Power)	8210
Samsung	T561	3	BHandset (Power Up, Bad LCD) (No Power)	8211
Samsung	T580	28	BHandset (Power Up, Bad LCD) (No Power)	8212
Samsung	T585	3	BHandset (Power Up, Bad LCD) (No Power)	8213
Samsung	T590	21	BHandset (Power Up, Bad LCD) (No Power)	8214
Samsung	T595	1	BHandset (Power Up, Bad LCD) (No Power)	8215
Samsung	T700	2	BHandset (Power Up, Bad LCD) (No Power)	8216
Samsung	T705	11	BHandset (Power Up, Bad LCD) (No Power)	8217
Samsung	T710	20	BHandset (Power Up, Bad LCD) (No Power)	8218
Samsung	T713	6	BHandset (Power Up, Bad LCD) (No Power)	8219
Samsung	T715	1	BHandset (Power Up, Bad LCD) (No Power)	8220
Samsung	T719	10	BHandset (Power Up, Bad LCD) (No Power)	8221
Samsung	T800	15	BHandset (Power Up, Bad LCD) (No Power)	8222
Samsung	T805	9	BHandset (Power Up, Bad LCD) (No Power)	8223
Samsung	T810	2	BHandset (Power Up, Bad LCD) (No Power)	8224
Samsung	T813	16	BHandset (Power Up, Bad LCD) (No Power)	8225
Samsung	T815	8	BHandset (Power Up, Bad LCD) (No Power)	8226
Samsung	T819	5	BHandset (Power Up, Bad LCD) (No Power)	8227
Samsung	T889	1	BHandset (Power Up, Bad LCD) (No Power)	8228
Samsung	T905	1	BHandset (Power Up, Bad LCD) (No Power)	8229
Samsung	T999	8	BHandset (Power Up, Bad LCD) (No Power)	8230
Vodafone	SMart V22	1	BHandset (Power Up, Bad LCD) (No Power)	8231
Vodafone	V995	3	BHandset (Power Up, Bad LCD) (No Power)	8232
Vodafone	VFD 200	1	BHandset (Power Up, Bad LCD) (No Power)	8233
Vodafone	VFD 510	1	BHandset (Power Up, Bad LCD) (No Power)	8234
Vodafone	VFD 513	1	BHandset (Power Up, Bad LCD) (No Power)	8235
Vodafone	VFD 600	1	BHandset (Power Up, Bad LCD) (No Power)	8236
Vodafone	VFD 610	15	BHandset (Power Up, Bad LCD) (No Power)	8237
Vodafone	VFD 630	3	BHandset (Power Up, Bad LCD) (No Power)	8238
Vodafone	VFD 700	3	BHandset (Power Up, Bad LCD) (No Power)	8239
Vodafone	VFD 710	6	BHandset (Power Up, Bad LCD) (No Power)	8240
Vodafone	VFD 720	7	BHandset (Power Up, Bad LCD) (No Power)	8241
Vodafone	VFD 730	2	BHandset (Power Up, Bad LCD) (No Power)	8242
Vodafone	VFD 900	3	BHandset (Power Up, Bad LCD) (No Power)	8243
Zte	A2017	2	BHandset (Power Up, Bad LCD) (No Power)	8244
Zte	B2017G	3	BHandset (Power Up, Bad LCD) (No Power)	8245
Zte	Blade 10	1	BHandset (Power Up, Bad LCD) (No Power)	8246
Zte	Blade 10 SMart	1	BHandset (Power Up, Bad LCD) (No Power)	8247
Zte	Blade A212	1	BHandset (Power Up, Bad LCD) (No Power)	8248
Zte	Blade A31	2	BHandset (Power Up, Bad LCD) (No Power)	8249
Zte	Blade A33S	5	BHandset (Power Up, Bad LCD) (No Power)	8250
Zte	Blade A52 Lite	3	BHandset (Power Up, Bad LCD) (No Power)	8251
Zte	Blade A53 Pro	6	BHandset (Power Up, Bad LCD) (No Power)	8252
Zte	Blade A53+	4	BHandset (Power Up, Bad LCD) (No Power)	8253
Zte	Blade A530	1	BHandset (Power Up, Bad LCD) (No Power)	8254

Zte	Blade A610 Plus	1	BHandset (Power Up, Bad LCD) (No Power)	8255
Zte	Blade A7(2020)	4	BHandset (Power Up, Bad LCD) (No Power)	8256
Zte	Blade L2	1	BHandset (Power Up, Bad LCD) (No Power)	8257
Zte	Blade L3	3	BHandset (Power Up, Bad LCD) (No Power)	8258
Zte	Blade L5 Plus	1	BHandset (Power Up, Bad LCD) (No Power)	8259
Zte	Blade S6	2	BHandset (Power Up, Bad LCD) (No Power)	8260
Zte	Blade V10 Vita	7	BHandset (Power Up, Bad LCD) (No Power)	8261
Zte	Blade V1000	1	BHandset (Power Up, Bad LCD) (No Power)	8262
Zte	Blade V20 SMart	2	BHandset (Power Up, Bad LCD) (No Power)	8263
Zte	Blade V6	1	BHandset (Power Up, Bad LCD) (No Power)	8264
Zte	Blade V8 Lite	1	BHandset (Power Up, Bad LCD) (No Power)	8265
Zte	Blade X10	4	BHandset (Power Up, Bad LCD) (No Power)	8266
Zte	T85	1	BHandset (Power Up, Bad LCD) (No Power)	8267
Zte	Z981	1	BHandset (Power Up, Bad LCD) (No Power)	8268
Zte	Z999	1	BHandset (Power Up, Bad LCD) (No Power)	8269
Alcatel	OT4019	1	Mainboard	8270
Alcatel	OT4030	8	Mainboard	8271
Alcatel	OT4033	19	Mainboard	8272
Alcatel	OT4045	9	Mainboard	8273
Alcatel	OT4046	1	Mainboard	8274
Alcatel	OT5001	1	Mainboard	8275
Alcatel	OT5010	1	Mainboard	8276
Alcatel	OT5017	60	Mainboard	8277
Alcatel	OT5033	1	Mainboard	8278
Alcatel	OT5036	3	Mainboard	8279
Alcatel	OT5042	81	Mainboard	8280
Alcatel	OT5044	39	Mainboard	8281
Alcatel	OT5050	36	Mainboard	8282
Alcatel	OT5065	1	Mainboard	8283
Alcatel	OT5080	1	Mainboard	8284
Alcatel	OT6010	10	Mainboard	8285
Alcatel	OT6012	17	Mainboard	8286
Alcatel	OT6016	1	Mainboard	8287
Alcatel	OT6030	13	Mainboard	8288
Alcatel	OT6034	21	Mainboard	8289
Alcatel	OT6036	30	Mainboard	8290
Alcatel	OT6039	36	Mainboard	8291
Alcatel	OT6045	1	Mainboard	8292
Alcatel	OT6050	10	Mainboard	8293
Alcatel	OT6055	4	Mainboard	8294
Alcatel	OT8055	1	Mainboard	8295
Alcatel	OT8062	1	Mainboard	8296
Alcatel	OT808	1	Mainboard	8297
Alcatel	OT9002	3	Mainboard	8298
Alcatel	OT9010	1	Mainboard	8299
Alcatel	OT902	3	Mainboard	8300
Alcatel	OT-1216	1	Mainboard	8301
Alcatel	OT-P310	1	Mainboard	8302
Asus	K012	1	Mainboard	8303
Ericsson	C1504	17	Mainboard	8304
Ericsson	C1904	20	Mainboard	8305
Ericsson	C2104	7	Mainboard	8306
Ericsson	C6502	8	Mainboard	8307
Ericsson	C6833	1	Mainboard	8308
Ericsson	C6906	11	Mainboard	8309
Ericsson	D2004	16	Mainboard	8310
Ericsson	D2206	4	Mainboard	8311
Ericsson	D2303	44	Mainboard	8312
Ericsson	D5503	3	Mainboard	8313
Ericsson	D5803	8	Mainboard	8314
Ericsson	D6503	4	Mainboard	8315
Ericsson	D6603	5	Mainboard	8316
Ericsson	E2006	1	Mainboard	8317
Ericsson	E2303	1	Mainboard	8318
Ericsson	E2306	115	Mainboard	8319
Ericsson	E5653	2	Mainboard	8320
Ericsson	E5823	5	Mainboard	8321
Ericsson	E6533	1	Mainboard	8322
Ericsson	E6553	2	Mainboard	8323
Ericsson	E6653	2	Mainboard	8324
Ericsson	E6853	1	Mainboard	8325
Ericsson	F3111	1	Mainboard	8326
Ericsson	F3113	6	Mainboard	8327
Ericsson	F3313	8	Mainboard	8328
Ericsson	F8331	1	Mainboard	8329
Ericsson	G3313	19	Mainboard	8330
Ericsson	G3412	2	Mainboard	8331
Ericsson	G8141	1	Mainboard	8332
Ericsson	i3312	1	Mainboard	8333
Ericsson	ST21i	2	Mainboard	8334
Ericsson	ST23i	5	Mainboard	8335
Ericsson	W580	3	Mainboard	8336
Htc	U11	1	Mainboard	8337
Huawei	AGS2-W09	1	Mainboard	8338
Huawei	CAM-L21	1	Mainboard	8339
Huawei	CUN-L01	1	Mainboard	8340

Huawei	DIG-L01	1	Mainboard	8341
Huawei	G6620	1	Mainboard	8342
Huawei	G8	1	Mainboard	8343
Huawei	LDN-L21	1	Mainboard	8344
Huawei	NMO-L31	1	Mainboard	8345
Huawei	P8 Lite	1	Mainboard	8346
Huawei	P8 Lite 2017	2	Mainboard	8347
Huawei	P9	2	Mainboard	8348
Huawei	U8220	5	Mainboard	8349
Huawei	Y330	1	Mainboard	8350
Huawei	Y360	2	Mainboard	8351
Huawei	Y560	2	Mainboard	8352
Huawei	Y635	1	Mainboard	8353
Lg	D625	1	Mainboard	8354
Lg	D725	1	Mainboard	8355
Lg	D855	1	Mainboard	8356
Lg	D950	2	Mainboard	8357
Lg	E610	1	Mainboard	8358
Lg	E975	1	Mainboard	8359
Lg	H840	1	Mainboard	8360
Lg	K120	1	Mainboard	8361
Lg	K350	1	Mainboard	8362
Lg	K430	1	Mainboard	8363
Lg	X230	1	Mainboard	8364
Motorola	XT2307	1	Mainboard	8365
Nokia	435	1	Mainboard	8366
Nokia	625	1	Mainboard	8367
Nokia	630	1	Mainboard	8368
Nokia	1020	1	Mainboard	8369
Nokia	1320	1	Mainboard	8370
Nokia	C3	1	Mainboard	8371
Nokia	1.3 Plus	1	Mainboard	8372
Nokia	C1 Plus	1	Mainboard	8373
Other	Google G011A	1	Mainboard	8374
Other	Lenovo S6000	1	Mainboard	8375
Other	Oppo A16K	1	Mainboard	8376
Other	Oppo A17K	1	Mainboard	8377
Other	Wiko GETAWAY	1	Mainboard	8378
Samsung	A105F	1	Mainboard	8379
Samsung	A207	1	Mainboard	8380
Samsung	A207F	1	Mainboard	8381
Samsung	A300F	7	Mainboard	8382
Samsung	A310	1	Mainboard	8383
Samsung	A310F	32	Mainboard	8384
Samsung	A320F	6	Mainboard	8385
Samsung	A500F	3	Mainboard	8386
Samsung	A510F	13	Mainboard	8387
Samsung	A520F	12	Mainboard	8388
Samsung	A720F	4	Mainboard	8389
Samsung	G310	1	Mainboard	8390
Samsung	G318	2	Mainboard	8391
Samsung	G350F	1	Mainboard	8392
Samsung	G355	4	Mainboard	8393
Samsung	G357F	1	Mainboard	8394
Samsung	G360F	1	Mainboard	8395
Samsung	G398F	1	Mainboard	8396
Samsung	G531F	2	Mainboard	8397
Samsung	G570	1	Mainboard	8398
Samsung	G610	3	Mainboard	8399
Samsung	G800F	6	Mainboard	8400
Samsung	G850	1	Mainboard	8401
Samsung	G900	16	Mainboard	8402
Samsung	G900F	9	Mainboard	8403
Samsung	G901F	2	Mainboard	8404
Samsung	G903F	1	Mainboard	8405
Samsung	G920	8	Mainboard	8406
Samsung	G920F	15	Mainboard	8407
Samsung	G928	1	Mainboard	8408
Samsung	G928F	4	Mainboard	8409
Samsung	G930F	1	Mainboard	8410
Samsung	G935F	6	Mainboard	8411
Samsung	i605	11	Mainboard	8412
Samsung	i8160	32	Mainboard	8413
Samsung	i8190	4	Mainboard	8414
Samsung	i8260	1	Mainboard	8415
Samsung	i8262	2	Mainboard	8416
Samsung	i8550	1	Mainboard	8417
Samsung	i9060	2	Mainboard	8418
Samsung	i9070	9	Mainboard	8419
Samsung	i9100	6	Mainboard	8420
Samsung	i9195	8	Mainboard	8421
Samsung	i9250	1	Mainboard	8422
Samsung	i9300	17	Mainboard	8423
Samsung	i9305	2	Mainboard	8424
Samsung	i9505	13	Mainboard	8425
Samsung	J100	24	Mainboard	8426

Samsung	J120	2	Mainboard	8427
Samsung	J250	22	Mainboard	8428
Samsung	J320	5	Mainboard	8429
Samsung	J320F	20	Mainboard	8430
Samsung	J330	1	Mainboard	8431
Samsung	J330F	7	Mainboard	8432
Samsung	J400	4	Mainboard	8433
Samsung	J410	2	Mainboard	8434
Samsung	J500	8	Mainboard	8435
Samsung	J500F	5	Mainboard	8436
Samsung	J510F	6	Mainboard	8437
Samsung	J530	1	Mainboard	8438
Samsung	J530F	1	Mainboard	8439
Samsung	J610	1	Mainboard	8440
Samsung	J700	1	Mainboard	8441
Samsung	J700F	1	Mainboard	8442
Samsung	J701	3	Mainboard	8443
Samsung	J710	1	Mainboard	8444
Samsung	J710F	7	Mainboard	8445
Samsung	J730	1	Mainboard	8446
Samsung	J730F	2	Mainboard	8447
Samsung	J810	1	Mainboard	8448
Samsung	L720	2	Mainboard	8449
Samsung	N5100	1	Mainboard	8450
Samsung	N7000	1	Mainboard	8451
Samsung	N7100	2	Mainboard	8452
Samsung	N8000	1	Mainboard	8453
Samsung	N9005	3	Mainboard	8454
Samsung	N910	7	Mainboard	8455
Samsung	N910F	1	Mainboard	8456
Samsung	N915F	1	Mainboard	8457
Samsung	N920F	1	Mainboard	8458
Samsung	N9600	1	Mainboard	8459
Samsung	P1000	2	Mainboard	8460
Samsung	P5100	1	Mainboard	8461
Samsung	P5220	1	Mainboard	8462
Samsung	P600	1	Mainboard	8463
Samsung	P7300	1	Mainboard	8464
Samsung	S5830	1	Mainboard	8465
Samsung	S6500	1	Mainboard	8466
Samsung	S7500	1	Mainboard	8467
Samsung	S918B	1	Mainboard	8468
Samsung	T110	1	Mainboard	8469
Samsung	T211	1	Mainboard	8470
Samsung	T230	4	Mainboard	8471
Samsung	T310	3	Mainboard	8472
Samsung	T320	1	Mainboard	8473
Samsung	T395	1	Mainboard	8474
Samsung	T500	1	Mainboard	8475
Samsung	T520	2	Mainboard	8476
Samsung	T530	1	Mainboard	8477
Samsung	T531	1	Mainboard	8478
Samsung	T560	2	Mainboard	8479
Samsung	T580	1	Mainboard	8480
Samsung	T595	1	Mainboard	8481
Samsung	T705	2	Mainboard	8482
Samsung	T710	1	Mainboard	8483
Samsung	T713	4	Mainboard	8484
Samsung	T715	1	Mainboard	8485
Samsung	T719	3	Mainboard	8486
Samsung	T800	3	Mainboard	8487
Samsung	T810	3	Mainboard	8488
Samsung	T815	1	Mainboard	8489
Samsung	T825	1	Mainboard	8490
Samsung	T999	3	Mainboard	8491
Samsung	W708	1	Mainboard	8492
Vr	Samsung GEAR Vr	74	Accessories (New)	8493
手機手制	Moto Mods	21	Accessories (New)	8494
Watch	Huawei Band 7	3	Accessories (Nearly New)	8495
Ear-phone	雜usb耳機	1	Accessories (Nearly New)	8496
Telephone	Adoc K4	90	Accessories (Nearly New)	8497
Telephone	Dt180	2	Accessories (Nearly New)	8498
Telephone	Homephone 4G	15	Accessories (Nearly New)	8499
Telephone	Neo 3850	4	Accessories (Nearly New)	8500
Telephone	Neo 3850(連耳機)	1	Accessories (Nearly New)	8501
Telephone	Neo 4800	2	Accessories (Nearly New)	8502
暖爐	Denver Smart Convector Heater Sch-2105	15	Accessories (Nearly New)	8503
遊戲卡	NINTENDO Switch 遊戲卡	1	Accessories (Nearly New)	8504
電子磅	Xiaomi Body Composition SScale 2	14	Accessories (Nearly New)	8505
bluetoothEar-phone	Plantronics Cs540	1	Accessories (Nearly New)	8506
警報器	Vodafone Help Flash	3	Accessories (Nearly New)	8507
Dvd機	Alba Dvd機	1	Accessories	8508
Dvd機	HD95cx	2	Accessories	8509
Dvd機	Philip Dvd機	14	Accessories	8510
Dvd機	Samsung Dvd機	1	Accessories	8511
Dvd機	Spd3400C	1	Accessories	8512

Gps	Allterco Myki Spot	1	Accessories	8513
Gps	Blaupunkt Gs02	12	Accessories	8514
Gps	Kippy EVO	14	Accessories	8515
Gps	Vodafone Vst001	11	Accessories	8516
Gps	雜gps	56	Accessories	8517
Mp3	Sony Nwze585	1	Accessories	8518
Other	雜 Watch	145	Accessories	8519
Other	雜配件	419	Accessories	8520
Usb線	Apple原裝 Lightning To Usb Cable	1	Accessories	8521
Usb線	Collect Type C-Type C Cable	1	Accessories	8522
Usb線	Collect Usb-A-Lightning Cable	2	Accessories	8523
Usb線	Collect Usb-A-Type C Cable	4	Accessories	8524
Usb線	Samsung原裝 Type-C To Type-C Cable	1	Accessories	8525
Usb線	Samsung原裝 Usb-A To Usb-C Cable	1	Accessories	8526
Usb線	Samsung原裝 Usb-C To Usb-C Cable	1	Accessories	8527
Usb線	原裝samsung Usb線	1	Accessories	8528
Vr	Alcatel Vr	1	Accessories	8529
Vr	Samsung GEAR Vr	84	Accessories	8530
Wifi蛋插座	Netgear Dc112A	3	Accessories	8531
Antenna	B2368天線	10	Accessories	8532
Antenna	Cel-Fi Solo Kh41-9B-333	6	Accessories	8533
戶外運動錄影套裝	Gopro Hero 3	1	Accessories	8534
手機固定支架	Bigben SMartphone Bike Holder	1	Accessories	8535
手機Signal booster	Nextivity Cel-Fi Rswu1	409	Accessories	8536
手機屏幕保護貼	Honor X8A	1	Accessories	8537
手機屏幕保護貼	Samsung A14	2	Accessories	8538
手機屏幕保護貼	Samsung A54	1	Accessories	8539
手機屏幕保護貼	Samsung S24 Ultra	1	Accessories	8540
Phone case	Honor 70	19	Accessories	8541
Phone case	Honor 90 Lite	3	Accessories	8542
Phone case	Honor Magic 4 Lite	5	Accessories	8543
Phone case	Honor Magic 5 Lite	1	Accessories	8544
Phone case	Honor X7B	1	Accessories	8545
Phone case	Honor X8	10	Accessories	8546
Phone case	Lg K22	10	Accessories	8547
Phone case	Motorola G60	1	Accessories	8548
Phone case	Samsung A01	10	Accessories	8549
Phone case	Samsung A05s	29	Accessories	8550
Phone case	Samsung A14	2	Accessories	8551
Phone case	Samsung A25	2	Accessories	8552
Phone case	Samsung A34	2	Accessories	8553
Phone case	Samsung A54	1	Accessories	8554
Phone case	Samsung A55	1	Accessories	8555
Phone case	Samsung Galaxy S10	4	Accessories	8556
Phone case	Samsung S23 Fe	1	Accessories	8557
Phone case	Samsung S23 Ultra	1	Accessories	8558
Phone case	Silicon Case	8	Accessories	8559
Phone case	Xiaomi Note 13	1	Accessories	8560
Phone case	Xiaomi Redmi 12	18	Accessories	8561
Phone case	Xiaomi Redmi 9C	10	Accessories	8562
Phone case	Xiaomi Redmi Note 12	4	Accessories	8563
Phone case	原裝 Samsung A146	1	Accessories	8564
Watch	Amazfit Gts 2 Mini	4	Accessories	8565
Watch	Amazfit Stratos 3	1	Accessories	8566
Watch	Amozfit	1	Accessories	8567
Watch	Apple Watch 42mm	1	Accessories	8568
Watch	Apple Watch Series 1 38mm	8	Accessories	8569
Watch	Apple Watch Series 1 42mm	18	Accessories	8570
Watch	Apple Watch Series 2 38mm	3	Accessories	8571
Watch	Apple Watch Series 2 42mm	8	Accessories	8572
Watch	Apple Watch Series 3 38mm	63	Accessories	8573
Watch	Apple Watch Series 3 38mm Nike	1	Accessories	8574
Watch	Apple Watch Series 3 42mm	1	Accessories	8575
Watch	Apple Watch Series 4 40mm	11	Accessories	8576
Watch	Apple Watch Series 4 44mm	13	Accessories	8577
Watch	Apple Watch Series 5 40mm	15	Accessories	8578
Watch	Apple Watch Series 5 44mm	12	Accessories	8579
Watch	Apple Watch Series 6 40mm Nike	1	Accessories	8580
Watch	Apple Watch Series 6 44mm	35	Accessories	8581
Watch	Apple Watch Series 6 44mm Nike	1	Accessories	8582
Watch	Apple Watch Series 7 41mm	15	Accessories	8583
Watch	Apple Watch Series 7 45mm	2	Accessories	8584
Watch	Apple Watch Series SE 40mm	1	Accessories	8585
Watch	Apple Watch Series SE 44mm	10	Accessories	8586
Watch	Apple Watch Ultra 49mm	2	Accessories	8587
Watch	Wi501Q	1	Accessories	8588
Watch	Fitbit Charge 5	1	Accessories	8589
Watch	Fitbit Fb409	2	Accessories	8590
Watch	Fitbit Fb417	3	Accessories	8591
Watch	Fitbit Fb421	14	Accessories	8592
Watch	Fitbit Fb423	1	Accessories	8593
Watch	Fitbit Fb504	7	Accessories	8594
Watch	Fitbit Fb505	3	Accessories	8595
Watch	Fitbit Fb507	11	Accessories	8596
Watch	Fitbit Fb511	6	Accessories	8597
Watch	Fitbit Fb512	1	Accessories	8598

Watch	Fitbit Fb523	4	Accessories	8599
Watch	Fitbit Watch	1	Accessories	8600
Watch	Fossil C1Nf1	1	Accessories	8601
Watch	Fossil Dw10F1	9	Accessories	8602
Watch	Fossil Dw2B	2	Accessories	8603
Watch	Fossil Dw4A	4	Accessories	8604
Watch	Fossil Dw6F1	6	Accessories	8605
Watch	Fossil Dw7F1	2	Accessories	8606
Watch	Fossil Dw9F2	5	Accessories	8607
Watch	Google GBdu9	1	Accessories	8608
Watch	Huawei Ads-B29	2	Accessories	8609
Watch	Huawei Band 6	19	Accessories	8610
Watch	Huawei Band 7	2	Accessories	8611
Watch	Huawei Ers-B29	1	Accessories	8612
Watch	Huawei Ter-B19S	1	Accessories	8613
Watch	Huawei Tia-B09	1	Accessories	8614
Watch	Lg W150	1	Accessories	8615
Watch	Mi Buds 3 Pro	9	Accessories	8616
Watch	Mi Buds Lite 3	71	Accessories	8617
Watch	Mi Watch 2 Lite	1	Accessories	8618
Watch	Mi Watch Lite	11	Accessories	8619
Watch	Moto 360 2Nd Gen	1	Accessories	8620
Watch	Moto 360 3Nd Gen	1	Accessories	8621
Watch	Motorola Moto 360	1	Accessories	8622
Watch	Oppo Band Ob19B1	5	Accessories	8623
Watch	Redmi Band 2	1	Accessories	8624
Watch	Redmi Buds 3	27	Accessories	8625
Watch	Redmi Watch 2 Lite	11	Accessories	8626
Watch	Redmi Watch 3	2	Accessories	8627
Watch	Samsung L705	1	Accessories	8628
Watch	Samsung R220	17	Accessories	8629
Watch	Samsung R350	6	Accessories	8630
Watch	Samsung R360	3	Accessories	8631
Watch	Samsung R365	13	Accessories	8632
Watch	Samsung R370	15	Accessories	8633
Watch	Samsung R375	12	Accessories	8634
Watch	Samsung R380	2	Accessories	8635
Watch	Samsung R381	1	Accessories	8636
Watch	Samsung R390	2	Accessories	8637
Watch	Samsung R500	32	Accessories	8638
Watch	Samsung R700	1	Accessories	8639
Watch	Samsung R720	20	Accessories	8640
Watch	Samsung R730	21	Accessories	8641
Watch	Samsung R732	10	Accessories	8642
Watch	Samsung R800	2	Accessories	8643
Watch	Samsung R820	184	Accessories	8644
Watch	Samsung R830	47	Accessories	8645
Watch	Samsung R835	27	Accessories	8646
Watch	Samsung R840	6	Accessories	8647
Watch	Samsung R855	1	Accessories	8648
Watch	Samsung R880	56	Accessories	8649
Watch	Samsung R885	62	Accessories	8650
Watch	Samsung R890	301	Accessories	8651
Watch	Samsung R895	52	Accessories	8652
Watch	Samsung雜 Watch	1	Accessories	8653
Watch	Sony Mn2	2	Accessories	8654
Watch	Sony Rd-0140	2	Accessories	8655
Watch	Sony Sw2	20	Accessories	8656
Watch	Sony Swr 30	1	Accessories	8657
Watch	Sony Swr10	214	Accessories	8658
Watch	Sony Swr50	5	Accessories	8659
Watch	Spacetalk St2-4G-1	3	Accessories	8660
Watch	Spacetalk W525c	22	Accessories	8661
Watch	Vodafone Vkw001	11	Accessories	8662
Watch	Xiaomi Mi Band 4	1	Accessories	8663
Watch	Xiaomi Mi Band 6	3	Accessories	8664
Watch	Xiaomi SMart Band 7	1	Accessories	8665
Watch	Xiaomi Xmsh07HM	1	Accessories	8666
Watch	Xiaomi 運動 Watchamazfit Bip	13	Accessories	8667
Watch	小米智能手環	8	Accessories	8668
Watch	兒童 Watch	2	Accessories	8669
Watch	雜 Watch	4	Accessories	8670
Watch	雜兒童 Watch	342	Accessories	8671
Watch	雜智能 Watch	2	Accessories	8672
Watch	雜智能手環	9	Accessories	8673
Charger	5V/3A + Type C Cable	3	Accessories	8674
Charger	Apple原裝兩腳火牛 5W(盒)	1	Accessories	8675
Charger	Collect 2.4A	7	Accessories	8676
Charger	Gyrux兩腳5V 3A充電器	36	Accessories	8677
Charger	Home Phone Adapter	2	Accessories	8678
Charger	Iphone原裝火牛usb 5W(盒)	2	Accessories	8679
Charger	Iphone原裝火牛usb 5W(單)	4	Accessories	8680
Charger	Samsung 15W Pd Usb-C	3	Accessories	8681
Charger	Samsung原裝 15W Pd Power Adapter	4	Accessories	8682
Charger	Samsung原裝 15W Pd Power Adapter Usb-C	17	Accessories	8683
Charger	Sturdo 3A 20W Usb/Type-C	2	Accessories	8684

Charger	Sturdo 3A 20W Usb/Type-C + Cable	2	Accessories	8685
Charger	Sturdo Pd Fast Type-C Cable	1	Accessories	8686
Charger	二合一5V/3A Micro Usb/Type C	5	Accessories	8687
Charging-kit	GyruX兩腳5V 2.1A充電器+Micro Usb套裝	43	Accessories	8688
Charing Kit	Lg Cbg-700	1	Accessories	8689
Charging-cable	Altice Cable 3 In 1	1	Accessories	8690
Charging-cable	Altice Hdmi 4K Cable	3	Accessories	8691
Charging-cable	Altice Micro Usb Cable 2A	1	Accessories	8692
Charging-cable	GyruX Iphone充電線	57	Accessories	8693
Charging-cable	GyruX Type C充電線	73	Accessories	8694
Charging-cable	Lighting To Type C	2	Accessories	8695
Charging-cable	Lighting To Usb Cable	12	Accessories	8696
Charging-cable	Micro Usb To Usb Cable	16	Accessories	8697
Charging-cable	Muvit Travel Charger	1	Accessories	8698
Charging-cable	Muvit Usb Cable 3.0M	2	Accessories	8699
Charging-cable	Neoxeo Bluetooth Audio Receiver	1	Accessories	8700
Power Bank	2500Mah	1	Accessories	8701
Power Bank	2600Mah	20	Accessories	8702
Power Bank	Busted Bus-Pd-Pd10Ah 10000Mah	1	Accessories	8703
Power Bank	Dus-Wich-S10W-10	1	Accessories	8704
Power Bank	Ee E1-04 2600Mah	2	Accessories	8705
Power Bank	T2000 2000Mah	1	Accessories	8706
Power Bank	Volt 2600Mah	1	Accessories	8707
Table Keyboard	OT-P360X	1	Accessories	8708
打印機	Photo SMart 325	3	Accessories	8709
有線Ear-phone	Huawei Headphones Lite	6	Accessories	8710
有線Ear-phone	JBL Tune 110	1	Accessories	8711
有線Ear-phone	JBL Tune 205	1	Accessories	8712
有線Ear-phone	Wb101	1	Accessories	8713
有線Ear-phone	Proline Echo Buds Pro	1	Accessories	8714
Ear-phone	Adoc Bt01	2	Accessories	8715
Ear-phone	Beats Ep-On Ear	13	Accessories	8716
Ear-phone	Beats Solo	6	Accessories	8717
Ear-phone	Iphone 5原裝耳機	6	Accessories	8718
Ear-phone	Jabra Hs C015	4	Accessories	8719
Ear-phone	JBL Tune 110	46	Accessories	8720
Ear-phone	JBL Tune 210	20	Accessories	8721
Ear-phone	Marshall Major II	2	Accessories	8722
Ear-phone	Marshall Major III	5	Accessories	8723
Ear-phone	Marshall Monitor	2	Accessories	8724
Ear-phone	Motorola雜Blue芽耳機	7	Accessories	8725
Ear-phone	Philips Shd8700	1	Accessories	8726
Ear-phone	Philips Shd8850	3	Accessories	8727
Ear-phone	Plantronics Hw111N	6	Accessories	8728
Ear-phone	Samsung Hs1303原裝耳機	11	Accessories	8729
Ear-phone	Samsung Type C 原裝耳機	5	Accessories	8730
Ear-phone	Sennheiser Rs118	1	Accessories	8731
Ear-phone	Sennheiser Rs127	5	Accessories	8732
Ear-phone	Sennheiser Rs165	2	Accessories	8733
Ear-phone	Sennheiser Rs2000	1	Accessories	8734
Ear-phone	Sennheiser Rs5000	1	Accessories	8735
Ear-phone	Sennheiser Urbanite XL	2	Accessories	8736
Ear-phone	Sony Mdr Rf855	3	Accessories	8737
Ear-phone	Sony Mdr Rf895	4	Accessories	8738
Ear-phone	Sony Mdr Xb950	7	Accessories	8739
Ear-phone	Usb C To 3.5mm 耳機轉換頭	2	Accessories	8740
Ear-phone	原裝 Samsung 耳機	6	Accessories	8741
Ear-phone	Blue牙耳機aricular Bth10	442	Accessories	8742
Ear-phone	Blue牙耳機aricular Bht10	5	Accessories	8743
Ear-phone	Blue牙耳機gyruX G930B1	64	Accessories	8744
Ear-phone	Blue牙耳機jay S T4W01	2	Accessories	8745
Ear-phone	Blue牙耳機motorola S305	20	Accessories	8746
Ear-phone	Blue牙耳機nokia Bh-200	442	Accessories	8747
Ear-phone	Blue牙耳機nokia Bh-209	1	Accessories	8748
Ear-phone	Blue牙耳機plantronics B235	1	Accessories	8749
Ear-phone	Blue牙耳機plantronics Cs540	11	Accessories	8750
Ear-phone	Blue牙耳機plantronics Cs540/H110	3	Accessories	8751
Ear-phone	Blue牙耳機plantronics Ep310	1	Accessories	8752
Ear-phone	Blue牙耳機plantronics Ep320	4	Accessories	8753
Ear-phone	Blue牙耳機samsung G920	1	Accessories	8754
Ear-phone	Blue牙耳機savi440	9	Accessories	8755
Ear-phone	雜耳機	11	Accessories	8756
伺服器	Huawei Esight Rh2288H V3	1	Accessories	8757
助聽器	Loopset Lps-5	64	Accessories	8758
汽車gps	Blaupunkt Moto Pilot	1	Accessories	8759
汽車gps	Blaupunkt Pilot 53	1	Accessories	8760
汽車gps	Decker Active 6	1	Accessories	8761
汽車gps	Decker Transit 6sl	2	Accessories	8762
汽車gps	Decker Transit 70	1	Accessories	8763
汽車gps	Decker Transit 7SI	3	Accessories	8764
汽車gps	Falk Tiger Geo	1	Accessories	8765
汽車gps	Garmin Camper 770	1	Accessories	8766
汽車gps	Garmin Dezl 770	1	Accessories	8767
汽車gps	Garmin Drive 40	1	Accessories	8768
汽車gps	Garmin Drive 50	9	Accessories	8769
汽車gps	Garmin Drive SMart 61	4	Accessories	8770

汽車gps	Garmin Nuvi 57	3	Accessories	8771
汽車gps	Teasi One 3X	1	Accessories	8772
汽車gps	Tomtom Go 520	1	Accessories	8773
汽車gps	Tomtom Go 5200	2	Accessories	8774
汽車gps	Tomtom Go 6100	1	Accessories	8775
汽車gps	Tomtom Go 6200	2	Accessories	8776
汽車gps	Tomtom Start 20	1	Accessories	8777
汽車gps	Tomtom Start 25M	4	Accessories	8778
汽車gps	Tomtom Start 42	1	Accessories	8779
汽車gps	Tomtom Start 52	2	Accessories	8780
汽車gps	Tomtom Start 62	1	Accessories	8781
汽車gps	Tomtom Via 52	1	Accessories	8782
汽車gps	Tomtom Via 62	1	Accessories	8783
Car Charging kit	Collect 3.4A 18W	1	Accessories	8784
Car Charging kit	Gyrux Car Double Usb	32	Accessories	8785
Car Charging kit	Gyrux Cargador Auto Qc 3.0	9	Accessories	8786
Car Charging kit	車充連apple充電線	10	Accessories	8787
Car Charging kit	車充連type C充電線	5	Accessories	8788
Car Charging kit	原裝 Samsung 車充	1	Accessories	8789
兒童Watch	X5 Play	5	Accessories	8790
Two-Pin Charger	Gyrux Quick Charge 2.0	67	Accessories	8791
Signal transmitter	Cisco Signal Box	276	Accessories	8792
Signal transmitter	Siemens Networks	24	Accessories	8793
Signal booster	4G Lte Signal Booster	22	Accessories	8794
Signal booster	Solid Home Repeater	1323	Accessories	8795
屏幕保護貼	屏幕保護貼 Ipad Pro 12.9	1	Accessories	8796
Original Phone case	Honor 70	4	Accessories	8797
Original Phone case	Honor Magic 4 Lite Series Pc Case	8	Accessories	8798
Original Phone case	Honor X8	10	Accessories	8799
Original Phone case Samsung	A225	3	Accessories	8800
Original Phone case Samsung	A235	3	Accessories	8801
Original Phone case Samsung	A325	1	Accessories	8802
Original Phone case Samsung	A326	1	Accessories	8803
Original Phone case Samsung	A336	1	Accessories	8804
Original Phone case Samsung	A516	1	Accessories	8805
Original Phone case Samsung	A525	2	Accessories	8806
Original Phone case Samsung	A536	2	Accessories	8807
Original Phone case Samsung	A725	4	Accessories	8808
Original Phone case Samsung	A736	3	Accessories	8809
Original Charging-kit Huawei	Huawei兩腳火牛5V/2A+Micro Usb線	20	Accessories	8810
Original Charging-cable Huawei	Usb A To Micro Usb	8	Accessories	8811
Original Charging-cable Huawei	二合一usb A To Micro Usb/Type C	2	Accessories	8812
Telephone	Panasonic Kx-Tg6821E	1	Accessories	8813
Telephone	雜家用電話	15	Accessories	8814
Telephone	雜家電	39	Accessories	8815
Home-wifi	Apple Airport 2	1	Accessories	8816
Home-wifi	Apple Airport 5	1	Accessories	8817
Home-Lens	D-Link Dcs-5222L	2	Accessories	8818
Home-Lens	D-Link Dcs-930L	2	Accessories	8819
Home-Lens	D-Link Dcs-942L	5	Accessories	8820
追蹤器	Localizador Apt-210	3389	Accessories	8821
Accessory	Router R101配件	1245	Accessories	8822
Trumpet	Google H2C	1	Accessories	8823
Trumpet	Motorola車用Blue芽 Speaker	49	Accessories	8824
Trumpet	Sony雜 Speaker	76	Accessories	8825
Trumpet	Vf Visor Kit	83	Accessories	8826
Trumpet	車用Blue芽 Speaker	2	Accessories	8827
Trumpet	Blue芽 Speakerhdx Wireless Speaker Hxp230	1	Accessories	8828
Trumpet	Blue芽 Speakermk6100	10	Accessories	8829
Trumpet	Blue芽 Speakerplantronics P610	18	Accessories	8830
Trumpet	雜車用Blue芽 Speaker	17	Accessories	8831
Trumpet	雜 Speaker	8	Accessories	8832
Trumpet	雜Blue芽 Speaker	21	Accessories	8833
智能Home-助理	Google Nest Hub 2	1	Accessories	8834
WirelessCharing Kit	Dusted 3 In 1 Wireless Charger	6	Accessories	8835
WirelessCharing Kit	Fun+ Wireless Charger	16	Accessories	8836
WirelessCharing Kit	Gigastone Ga-9600B	2	Accessories	8837
WirelessCharing Kit	Gigastone Ga-9660B	6	Accessories	8838
WirelessCharing Kit	Hama 10W Fast Charger	1	Accessories	8839
WirelessCharing Kit	Robot Wireless Charge	1	Accessories	8840
Wireless充電器	Dusted Dus-Cch-10W	1	Accessories	8841
WirelessCar Charging kit	Gyrux Soperte De Auto	15	Accessories	8842
感應器	Multipurpose Sensor	4	Accessories	8843
感應器	Zipato Indoor Siren	2	Accessories	8844
暖手蛋	Lc-C300	1	Accessories	8845
運動Camera	Gopro Hero	1	Accessories	8846
運動Camera	Gopro Hero 5	8	Accessories	8847
運動Camera	Gopro Hero 5 Session	6	Accessories	8848
運動Camera	Gopro Hero 6	6	Accessories	8849
電力線網路轉換器	Power Line	1491	Accessories	8850
電子磅	Huawei Body Fat SCale	1	Accessories	8851
Battery	iPhone 4s電池	151	Accessories	8852
Battery	iPhone 5電池	41	Accessories	8853
Battery	iPhone 6 Plus電池	75	Accessories	8854
Battery	iPhone 6s Plus電池	30	Accessories	8855
Battery	iPhone 6電池	53	Accessories	8856

Battery	iPhone 7 Plus電池	125	Accessories	8857
Battery	iPhone 7電池	70	Accessories	8858
Battery	iPhone 8 Plus電池	34	Accessories	8859
Battery	iPhone 8電池	86	Accessories	8860
Battery	iPhone Xr電池	35	Accessories	8861
Battery	iPhone Xs Max電池	31	Accessories	8862
Battery	iPhone Xs電池	33	Accessories	8863
Battery	iPhone X電池	21	Accessories	8864
電容筆	Apple Pencil	5	Accessories	8865
電容筆	雜電容筆	2	Accessories	8866
網路Signal transmitter	Claro Wireless Q24Cl001	191	Accessories	8867
遙控器	Apple Tv遙控器 A1962	1	Accessories	8868
遙控器	Now Tv	1	Accessories	8869
播放器	S400I	1	Accessories	8870
調製解調器	Adoc V1	135	Accessories	8871
STB	Apple Tv 3	1	Accessories	8872
STB	Bt Dtr-T2100	1	Accessories	8873
STB	Bt Tv Box Pro	2	Accessories	8874
STB	Bt Youview Box Db-T2200	1	Accessories	8875
STB	Db-T2200	1	Accessories	8876
STB	Diw350	1	Accessories	8877
STB	DS183	147	Accessories	8878
STB	DS700	171	Accessories	8879
STB	Ee Tv Box Pro	1	Accessories	8880
STB	Hsv 4033	10	Accessories	8881
STB	Hsv4035	47	Accessories	8882
STB	Lg St-600	477	Accessories	8883
STB	Sec Ipa 1114	22	Accessories	8884
STB	Sky Ip061	1	Accessories	8885
STB	Tv Box Pro	1	Accessories	8886
STB	Zxv10 B866V2	3	Accessories	8887
STB	雜機頂盒	2336	Accessories	8888
Watch-band	Apple原裝錶帶 38mm	1	Accessories	8889
Watch-band	Apple原裝錶帶 40mm	1	Accessories	8890
Watch-band	Apple原裝錶帶 42mm	1	Accessories	8891
Watch-band	Apple原裝錶帶 44mm	1	Accessories	8892
頭戴式Ear-phone	Audrfono Blink 400	1	Accessories	8893
頭戴式Ear-phone	JBL E35	1	Accessories	8894
頭戴式Ear-phone	JBL T450	1	Accessories	8895
頭戴式Ear-phone	Soundmagic P11S	1	Accessories	8896
Head-bluetooth headset	JBL Jr300Bt	1	Accessories	8897
Head-bluetooth headset	Soundmagic P22Bt	1	Accessories	8898
Head-bluetooth headset	Urbanista Seattle	1	Accessories	8899
Keyboard	Apple Ipad Pro 11"	1	Accessories	8900
Keyboard	Lenovo Chromebook Keyboard	2	Accessories	8901
bluetoothEar-phone	Apple AirPods	179	Accessories	8902
bluetoothEar-phone	Apple AirPods Pro	10	Accessories	8903
bluetoothEar-phone	Astrum Et340	6	Accessories	8904
bluetoothEar-phone	Awei N1	5	Accessories	8905
bluetoothEar-phone	B&O Beo Play H2	1	Accessories	8906
bluetoothEar-phone	Beats Powerbeats Pro	1	Accessories	8907
bluetoothEar-phone	Beats Solo 2 Wireless	2	Accessories	8908
bluetoothEar-phone	Beats Solo 3 Wireless	36	Accessories	8909
bluetoothEar-phone	Beats Solo Wireless	8	Accessories	8910
bluetoothEar-phone	Beats Studio 2 Wireless	3	Accessories	8911
bluetoothEar-phone	Beats Studio 3	1	Accessories	8912
bluetoothEar-phone	Beats Studio 3 Wireless	12	Accessories	8913
bluetoothEar-phone	Beats Studio Buds	1	Accessories	8914
bluetoothEar-phone	Beats Studio Wireless	21	Accessories	8915
bluetoothEar-phone	Blik Air600	50	Accessories	8916
bluetoothEar-phone	Boom Buds Go	4	Accessories	8917
bluetoothEar-phone	Bose Quiet Comfort 35 II	1	Accessories	8918
bluetoothEar-phone	Bose Quietcontrol 20	1	Accessories	8919
bluetoothEar-phone	Bose Quietcontrol 25	2	Accessories	8920
bluetoothEar-phone	Bose Quietcontrol 30	1	Accessories	8921
bluetoothEar-phone	Bose Quietcontrol 35	7	Accessories	8922
bluetoothEar-phone	Bose Sound Link Ae2	5	Accessories	8923
bluetoothEar-phone	Bose Sound Link Onear	2	Accessories	8924
bluetoothEar-phone	Bose Sound Sport Free	1	Accessories	8925
bluetoothEar-phone	Bose Sound Spot	12	Accessories	8926
bluetoothEar-phone	Bose Sound True Ae2	1	Accessories	8927
bluetoothEar-phone	Choetech Bht02	1	Accessories	8928
bluetoothEar-phone	Dusted Aura Pro	1	Accessories	8929
bluetoothEar-phone	Dusted Earp Sleep	2	Accessories	8930
bluetoothEar-phone	Hama My Voice 1500	6	Accessories	8931
bluetoothEar-phone	Hama My Voice 700	3	Accessories	8932
bluetoothEar-phone	Hama Spirit Go	2	Accessories	8933
bluetoothEar-phone	Headpods BoomPods	1	Accessories	8934
bluetoothEar-phone	Honor Choice Earbuds X	1	Accessories	8935
bluetoothEar-phone	Honor Choice Earbuds X3	1	Accessories	8936
bluetoothEar-phone	Honor Earbuds Ce79	5	Accessories	8937
bluetoothEar-phone	Honor Earbuds X	4	Accessories	8938
bluetoothEar-phone	Honor Earbuds X5	1	Accessories	8939
bluetoothEar-phone	Huawei Free Buds 3	1	Accessories	8940
bluetoothEar-phone	Huawei Free Buds Se	1	Accessories	8941
bluetoothEar-phone	Huawei Freebuds 3I	5	Accessories	8942

bluetoothEar-phone	Huawei Freebuds Lite	2	Accessories	8943
bluetoothEar-phone	Jabra Elite 7 Active	1	Accessories	8944
bluetoothEar-phone	JBL Audifones Tune 115Tws	8	Accessories	8945
bluetoothEar-phone	JBL C45Bt	5	Accessories	8946
bluetoothEar-phone	JBL E40Bt	1	Accessories	8947
bluetoothEar-phone	JBL E45Bt	8	Accessories	8948
bluetoothEar-phone	JBL E500Bt	2	Accessories	8949
bluetoothEar-phone	JBL E50Bt	10	Accessories	8950
bluetoothEar-phone	JBL E55Bt	17	Accessories	8951
bluetoothEar-phone	JBL E65Bt	7	Accessories	8952
bluetoothEar-phone	JBL Free X	2	Accessories	8953
bluetoothEar-phone	JBL T450Bt	1	Accessories	8954
bluetoothEar-phone	JBL T600Bt	2	Accessories	8955
bluetoothEar-phone	JBL V300Bt	3	Accessories	8956
bluetoothEar-phone	JBL V700Bt	1	Accessories	8957
bluetoothEar-phone	JBL V710Bt	2	Accessories	8958
bluetoothEar-phone	Lg Hbs750	1	Accessories	8959
bluetoothEar-phone	Marley Em-De021	1	Accessories	8960
bluetoothEar-phone	Marshall Major Bluetooth	1	Accessories	8961
bluetoothEar-phone	Marshall Major II Bluetooth	4	Accessories	8962
bluetoothEar-phone	Marshall Major III Bluetooth	1	Accessories	8963
bluetoothEar-phone	Marshall Mid Bluetooth	4	Accessories	8964
bluetoothEar-phone	Marshall Monitor Bluetooth	5	Accessories	8965
bluetoothEar-phone	Master Dynamic Mw07	1	Accessories	8966
bluetoothEar-phone	Mi True Wireless Earphones 2 Basic	1	Accessories	8967
bluetoothEar-phone	Bh205	2	Accessories	8968
bluetoothEar-phone	Philips Shb5800	1	Accessories	8969
bluetoothEar-phone	Philips Shb9250	2	Accessories	8970
bluetoothEar-phone	Philips Tah1205	5	Accessories	8971
bluetoothEar-phone	Philips Tat2206	8	Accessories	8972
bluetoothEar-phone	Philips Tat2236	43	Accessories	8973
bluetoothEar-phone	Plantronics Cs540	15	Accessories	8974
bluetoothEar-phone	Plantronics Voyager	1	Accessories	8975
bluetoothEar-phone	Proline Wave Pods Pro	5	Accessories	8976
bluetoothEar-phone	Redmi Buds 3 Lite	27	Accessories	8977
bluetoothEar-phone	Redmi Buds 4 Active	6	Accessories	8978
bluetoothEar-phone	Redmi Buds Lite	1	Accessories	8979
bluetoothEar-phone	Samsung Eo-Pn920	3	Accessories	8980
bluetoothEar-phone	Samsung HM1000	2	Accessories	8981
bluetoothEar-phone	Samsung R140	12	Accessories	8982
bluetoothEar-phone	Samsung R150	7	Accessories	8983
bluetoothEar-phone	Samsung R170	1	Accessories	8984
bluetoothEar-phone	Samsung R180	28	Accessories	8985
bluetoothEar-phone	Sennheiser HD4.40Bt	4	Accessories	8986
bluetoothEar-phone	Sennheiser HD4.50Bt	5	Accessories	8987
bluetoothEar-phone	Sennherser Cx7.00Bt	2	Accessories	8988
bluetoothEar-phone	Skullcandy S1Jtw	31	Accessories	8989
bluetoothEar-phone	Skullcandy S2Dmw	27	Accessories	8990
bluetoothEar-phone	Skullcandy S2Jtw	1	Accessories	8991
bluetoothEar-phone	Sony Bcwf1000X	1	Accessories	8992
bluetoothEar-phone	Sony Bcwfsp700N	1	Accessories	8993
bluetoothEar-phone	Sony Mdr Wh1000X	3	Accessories	8994
bluetoothEar-phone	Sony Mdr Wh1000Xm2	6	Accessories	8995
bluetoothEar-phone	Sony Mdr Whh880	1	Accessories	8996
bluetoothEar-phone	Sony Mdr Whh900	5	Accessories	8997
bluetoothEar-phone	Sony Mdr Xb650	7	Accessories	8998
bluetoothEar-phone	Sony Mdr Xb950Bi	7	Accessories	8999
bluetoothEar-phone	Sony Mdr Zx770	3	Accessories	9000
bluetoothEar-phone	Sony Pulse 3D	1	Accessories	9001
bluetoothEar-phone	Xiaomi Twsej01Ls	1	Accessories	9002
bluetoothEar-phone	Xiaomi Twsej061Ls	4	Accessories	9003
bluetoothEar-phone	Zero Boom Pods	40	Accessories	9004
bluetoothEar-phone	雜Blue牙耳機	26	Accessories	9005
bluetoothTrumpet	Amazon Echo Dot 2	1	Accessories	9006
bluetoothTrumpet	Blik One	1	Accessories	9007
bluetoothTrumpet	Blik Rockwood	1	Accessories	9008
bluetoothTrumpet	JBL Go 2	2	Accessories	9009
藍芽Ear-phone	Defunc Hybrid	1	Accessories	9010
轉換插頭	原裝 Samsung Usb-C 轉換頭	4	Accessories	9011
轉換線	Apple原裝 Lightning To Headphone Jack Adapter	1	Accessories	9012
轉換線	Huawei Type C Headphone Jack Adapter	2	Accessories	9013
寵物飲水機	Xiaomi SMart PEt Fountain	1	Accessories	9014
Lens	SMart Homy Sh-Cano3W	7	Accessories	9015
Lens	SMart Homy Wi-Fi Indoor Cam Sh-Cam04W	16	Accessories	9016
攝錄機	Panasonic Hc-V160	1	Accessories	9017
Network Card	21M-02	9	New	9018
Network Card	Ac501	195	New	9019
Network Card	Apex880	1	New	9020
Network Card	C889	1	New	9021
Network Card	Cs-12	78	New	9022
Network Card	Cs-18	23	New	9023
Network Card	Cs-19	2	New	9024
Network Card	Dwm-222	8	New	9025
Network Card	E122	2	New	9026
Network Card	E1630	2	New	9027
Network Card	E1820	5	New	9028

Network Card	E220	9	New	9029
Network Card	E230	2	New	9030
Network Card	E270	1	New	9031
Network Card	E3251	4	New	9032
Network Card	E3730	85	New	9033
Network Card	E3735	8	New	9034
Network Card	E5251	1	New	9035
Network Card	E5832	1	New	9036
Network Card	E585	1	New	9037
Network Card	E800	12	New	9038
Network Card	E881E	21	New	9039
Network Card	Ge0301	11	New	9040
Network Card	Ge0441	68	New	9041
Network Card	Gi0335	4	New	9042
Network Card	Gi0431	3	New	9043
Network Card	Icon 225	17	New	9044
Network Card	Icon 505	800	New	9045
Network Card	Icon 7.2S	1	New	9046
Network Card	K3520	2	New	9047
Network Card	K3520Z	11	New	9048
Network Card	K3565Z	7	New	9049
Network Card	K3571Z	18	New	9050
Network Card	K3760	5	New	9051
Network Card	K3771	2	New	9052
Network Card	K3772Z	28	New	9053
Network Card	K3773	13	New	9054
Network Card	K4201	1	New	9055
Network Card	K4203Z	29	New	9056
Network Card	K4305	1	New	9057
Network Card	K4505Z	24	New	9058
Network Card	K4607Z	66	New	9059
Network Card	K5006Z	1	New	9060
Network Card	Mc950D	28	New	9061
Network Card	Mc996D	7	New	9062
Network Card	Md@4GB	99	New	9063
Network Card	Md@Duo	20	New	9064
Network Card	Md@Extreme42	20	New	9065
Network Card	Md@Hsupa	10	New	9066
Network Card	Md@Mini	5	New	9067
Network Card	Md@Revo	198	New	9068
Network Card	Md300	2	New	9069
Network Card	Mf112	14	New	9070
Network Card	Mf192	10	New	9071
Network Card	Mf30	11	New	9072
Network Card	Mf620	1	New	9073
Network Card	Mf626	2	New	9074
Network Card	Mf6261	18	New	9075
Network Card	Mf627	24	New	9076
Network Card	Mf635	25	New	9077
Network Card	Mf637	1	New	9078
Network Card	Mf637U	2	New	9079
Network Card	Mf652	6	New	9080
Network Card	Mf662	1	New	9081
Network Card	Mf668	7	New	9082
Network Card	Mf668A	1	New	9083
Network Card	Mf669	6	New	9084
Network Card	Mf680	5	New	9085
Network Card	Mt191Up	1	New	9086
Network Card	OT-Y580	2	New	9087
Network Card	R201	1	New	9088
Network Card	R203Z	1	New	9089
Network Card	R205	4	New	9090
Network Card	R208	1	New	9091
Network Card	R209Z	20	New	9092
Network Card	Um100	65	New	9093
Network Card	Usb 307	4	New	9094
Network Card	X090S	15	New	9095
Network Card	X220	17	New	9096
Network Card	X221	79	New	9097
Network Card	Xu870	12	New	9098
Network Card	21M-02	3	14A	9099
Network Card	Ac330	1	14A	9100
Network Card	Ac880E	138	14A	9101
Network Card	B3740	2699	14A	9102
Network Card	Bmobile M5L	119	14A	9103
Network Card	Cs-18	1	14A	9104
Network Card	Dwm-157	8	14A	9105
Network Card	Dwm-222	24	14A	9106
Network Card	Dwr-932	1	14A	9107
Network Card	E122	1	14A	9108
Network Card	E173	1	14A	9109
Network Card	E1762	3	14A	9110
Network Card	E2010	1	14A	9111
Network Card	E272	1	14A	9112
Network Card	E352	1	14A	9113
Network Card	E3533	1	14A	9114

Network Card	E3730	505	14A	9115
Network Card	E3735	188	14A	9116
Network Card	E510	2	14A	9117
Network Card	E5330	3	14A	9118
Network Card	E5332	2	14A	9119
Network Card	E5830	8	14A	9120
Network Card	E5836	5	14A	9121
Network Card	E583C	1	14A	9122
Network Card	E585	1	14A	9123
Network Card	E586E	1	14A	9124
Network Card	E589	5	14A	9125
Network Card	Ee40	7	14A	9126
Network Card	Ee71	3	14A	9127
Network Card	Ge0201	44	14A	9128
Network Card	Ge0301	66	14A	9129
Network Card	Icon 7.2	1	14A	9130
Network Card	K4203	10	14A	9131
Network Card	K5008Z	1	14A	9132
Network Card	L100	1	14A	9133
Network Card	L800Z	2	14A	9134
Network Card	Md@	11	14A	9135
Network Card	Md@Duo	22	14A	9136
Network Card	Md@Mini	1	14A	9137
Network Card	Md@Revo	55	14A	9138
Network Card	Mf100	5	14A	9139
Network Card	Mf110	2	14A	9140
Network Card	Mf190	1	14A	9141
Network Card	Mf192	37	14A	9142
Network Card	Mf193	7	14A	9143
Network Card	Mf30	11	14A	9144
Network Card	Mf335	2385	14A	9145
Network Card	Mf50	1	14A	9146
Network Card	Mf51	137	14A	9147
Network Card	Mf60	4	14A	9148
Network Card	Mf622	21	14A	9149
Network Card	Mf635	10	14A	9150
Network Card	Mf636	1	14A	9151
Network Card	Mf659	1	14A	9152
Network Card	Mf668A	3	14A	9153
Network Card	Mf680	2	14A	9154
Network Card	Mf691	1	14A	9155
Network Card	Mf79	442	14A	9156
Network Card	Mf821	2	14A	9157
Network Card	Mf920	671	14A	9158
Network Card	Mifi 2200	22	14A	9159
Network Card	Mifi 2352	2	14A	9160
Network Card	Mifi 3352	1	14A	9161
Network Card	Olive V-Me100	158	14A	9162
Network Card	Onda Dt501Hs	1	14A	9163
Network Card	Onda Mh505Up	2	14A	9164
Network Card	Onda Mh602Hs	6	14A	9165
Network Card	R203Z	1	14A	9166
Network Card	R205	3	14A	9167
Network Card	R206	4	14A	9168
Network Card	R206Z	4	14A	9169
Network Card	R207	9	14A	9170
Network Card	R208	2	14A	9171
Network Card	R209	6	14A	9172
Network Card	R210	1	14A	9173
Network Card	R219Z	7	14A	9174
Network Card	Sapphire S1	114	14A	9175
Network Card	Turbo 7	9	14A	9176
Network Card	Usb-8521	20	14A	9177
Network Card	V101F	4	14A	9178
Network Card	Wm66H	552	14A	9179
Network Card	X500	1	14A	9180
Network Card	X602	13	14A	9181
Network Card	Xs Box Go	6	14A	9182
Network Card	Xs Box Go+	2	14A	9183
Network Card	Xu870	2	14A	9184
Network Card	Y600	1	14A	9185
Network Card	Y800	6	14A	9186
Network Card	Y850	1	14A	9187
Network Card	Y853	6	14A	9188
Network Card	Y854	3	14A	9189
Network Card	Y855	2	14A	9190
Network Card	Z810	1	14A	9191
Network Card	21M-02	272	AHandset	9192
Network Card	Ac2746	410	AHandset	9193
Network Card	Ac310U	1	AHandset	9194
Network Card	Ac318U	36	AHandset	9195
Network Card	Ac326U	5	AHandset	9196
Network Card	Ac330	2	AHandset	9197
Network Card	Ac501	2	AHandset	9198
Network Card	Ac503	126	AHandset	9199
Network Card	Ac753S	629	AHandset	9200

Network Card	Ac754s	1	AHandset	9201
Network Card	Ac875	3	AHandset	9202
Network Card	Ac880E	534	AHandset	9203
Network Card	A1621	3	AHandset	9204
Network Card	A1720	1	AHandset	9205
Network Card	Alm-N245	2	AHandset	9206
Network Card	Apex880	52	AHandset	9207
Network Card	ARCHOS G9	6	AHandset	9208
Network Card	B3740	275	AHandset	9209
Network Card	Bmobile M5L	2	AHandset	9210
Network Card	Bp3-Usb	36	AHandset	9211
Network Card	Bt71	1	AHandset	9212
Network Card	C170	48	AHandset	9213
Network Card	C278	47	AHandset	9214
Network Card	C597	59	AHandset	9215
Network Card	C885	2	AHandset	9216
Network Card	C888	26	AHandset	9217
Network Card	C889	23	AHandset	9218
Network Card	Cardman 6121	7	AHandset	9219
Network Card	Cs-10	608	AHandset	9220
Network Card	Cs-15	571	AHandset	9221
Network Card	Cs-17	1359	AHandset	9222
Network Card	Cs-18	766	AHandset	9223
Network Card	Cs-19	246	AHandset	9224
Network Card	Dc87-0	38	AHandset	9225
Network Card	Dwm-156	2	AHandset	9226
Network Card	Dwm-157	3	AHandset	9227
Network Card	Dwm-222	27	AHandset	9228
Network Card	Dwr-932	1	AHandset	9229
Network Card	E122	116	AHandset	9230
Network Card	E153	41	AHandset	9231
Network Card	E1556	1	AHandset	9232
Network Card	E156B	4	AHandset	9233
Network Card	E160	92	AHandset	9234
Network Card	E160E	1	AHandset	9235
Network Card	E161	6	AHandset	9236